

VSN Operation Manual

016-2020-001 Rev. C

2/2021

E36702



DISCLAIMER

While every effort has been made to ensure the accuracy of this document, Raven Industries assumes no responsibility for omissions and errors. Nor is any liability assumed for damages resulting from the use of information contained herein.

Raven Industries shall not be responsible or liable for incidental or consequential damages or a loss of anticipated benefits or profits, work stoppage or loss, or impairment of data arising out of the use, or inability to use, this system or any of its components. Raven Industries shall not be held responsible for any modifications or repairs made outside our facilities, nor damages resulting from inadequate maintenance of this system.

As with all wireless and satellite signals, several factors may affect the availability and accuracy of wireless and satellite navigation and correction services (e.g. GPS, GNSS, SBAS, etc.). Therefore, Raven Industries cannot guarantee the accuracy, integrity, continuity, or availability of these services and cannot guarantee the ability to use Raven systems, or products used as components of systems, which rely upon the reception of these signals or availability of these services. Raven Industries accepts no responsibility for the use of any of these signals or services for other than the stated purpose.

Chapter 1	Important Safety Information.....	1
	Electrical Safety	1
Chapter 2	Introduction.....	3
	System Specifications	4
	Installation	4
	Recommendations	4
	Care and Maintenance	4
	Glass Care and Cleaning	4
	Radar Sensors	4
	Updates	5
	Software and Firmware Updates	5
Chapter 3	Calibration Wizard	7
	Camera and Equipment Calibration	7
	Rear Boom Sprayers	7
	Front Boom Machines	9
	Implement	11
	Image Exclusion	13
	Radar Sensors	14
	Calibration Summary	15
	Row Spacing Preset Calibration	16
Chapter 4	Operation	19
	Home Page	19
	VSN Status Icon	20
	Quality	20
	Row Sensor Source	20
	Machine Roll	20
	Machine Speed	21
	Camera Furrow Offset	21
	Row Detection Solution Quality	21
	Row Spacing Preset	21
	VSN Operation Widgets	22
	Operation Mode Widgets	22
	Status and Engage Widget	23
	Analog Video Display Widget	24
	VSN Status Widget	25
Chapter 5	VSN System Settings and Tuning	27
	Machine Settings Tab	27
	Navigation Partner	28
	Reset Defaults	28
	Camera Mounting	28
	System Settings Tab	29
	Camera Calibration	30
	Camera Settings	31

Table of Contents

Advanced Settings	32
Radar Settings	33
Front Boom Settings	34
Network Settings Tab	35
Slingshot Name Display	35
Ethernet Settings	35
WIFI Settings	36
T1 Ethernet Settings	38
Chapter 6 Diagnostics	39
System Information	40
Slingshot Status Icon	40
Software Update	41
Diagnostic Trouble Codes (DTCs)	44
VSN Diagnostic LED States	44
System Summary	45

CHAPTER

1

IMPORTANT SAFETY INFORMATION

NOTICE

Read this manual and the operation and safety instructions included with your implement and/or controller carefully before installing the VSN™ system.

- Follow all safety information presented within this manual.
- If you require assistance with any portion of the installation or service of your Raven equipment, contact your local Raven dealer for support.
- Follow all safety labels affixed to the system components. Be sure to keep safety labels in good condition and replace any missing or damaged labels. To obtain replacements for missing or damaged safety labels, contact your local Raven dealer.

When operating the machine after installing the system, observe the following safety measures:

- Be alert and aware of surroundings.
- Do not operate the system or any agricultural equipment while under the influence of alcohol or an illegal substance.
- Remain in the operator's position in the machine at all times when the system is engaged.
- Disable the system when exiting the operator's seat and machine.
- Do not drive the machine with the system enabled on any public road.
- Determine and remain a safe working distance from other individuals. The operator is responsible for disabling the system when the safe working distance has diminished.
- Ensure the system is disabled prior to starting any maintenance work on the system or the machine.

CAUTION

ELECTRICAL SAFETY


- Always verify that the power leads are connected to the correct polarity as marked. Reversing the power leads could cause severe damage to the equipment.
- Ensure that the power cable is the last cable to be connected.

When coupled with a Raven field computer and RS1/SC1, VSN™ is designed to offer hands-free steering of agricultural sprayers and cultivator implements.

NOTE: Implement steering is only supported with a CR12 and an SC1 steering system.

The chapters in this manual are intended to assist with the proper calibration and operation of the VSN system.

FIGURE 1. VSN Home Page



SYSTEM SPECIFICATIONS

TABLE 1. VSN™ Technical Specifications

		U.S.	Metric
Dimensions	Height	7.74 in.	19.66 cm
	Width	9.94 in.	25.25 cm
	Depth	3.36 in.	8.53 cm
	Weight	approx. 8.75 lbs.	approx. 3.9 kg
Power	Operating Voltage	9 to 16 V DC nominal (reverse polarity protected)	
Environmental	Operating Conditions	-40° to 185° F	-40° to 85° C
	Storage Conditions	-40° to 185° F	-40° to 85° C

INSTALLATION



⚠ WARNING

Carefully read and follow all safety requirements and precautions contained in this manual and the machine-specific or implement Installation Manual. Failure to follow safety instructions may lead to equipment damage, personal injury, or death.

RECOMMENDATIONS

Raven Industries recommends the following best practices when installing or operating the VSN system for the first time, at the start of the season, or when moving the VSN system to another machine:

- Verify that the hydraulic system is using fresh oil and that the filters have been recently changed.
- Ensure there are no issues with the hydraulic system (e.g. pump issues, faulty hydraulic motors, fine metal deposits in the hydraulic hoses, etc.).
- Ensure there are no issues with the steering system (worn bushings, faulty tie rod ends, improperly adjusted steer components, etc.).

CARE AND MAINTENANCE

GLASS CARE AND CLEANING

- Avoid pressure washing the camera lens.
- Use any glass cleaning products with a soft cloth. Avoid any abrasive products that could scratch or damage the glass.

RADAR SENSORS

- If the system does not allow the operator to engage while using radar sensors, use a rag or cloth to clean the radar sensors and allow for better solution quality.

UPDATES

Software and manual updates are available on the Raven Applied Technology website.

<https://portal.ravenprecision.com/>

Sign up for email alerts, and you will be automatically notified when updates for your Raven products are available on the website.

At Raven Industries, we strive to make your experience with our products as rewarding as possible. One way to improve this experience is to provide us with feedback on this manual.

Your feedback will help shape the future of our product documentation and the overall service we provide. We appreciate the opportunity to see ourselves as our customers see us and are eager to gather ideas on how we have been helping or how we can do better.

To serve you best, please send an email with the following information to

techwriting@ravenind.com

- VSN Operation Manual
- 016-2020-001 Rev. B
- Any comments or feedback (include chapter or page numbers if applicable).
- Let us know how long have you been using this or other Raven products.

We will not share your email or any information you provide with anyone else. Your feedback is valued and extremely important to us.

Thank you for your time.

SOFTWARE AND FIRMWARE UPDATES

Please review the *Software Update* section on page 41 for assistance with updating the VSN system or radar sensors.

The following sections offer assistance with the VSN system calibration wizard.

NOTE: For best results, take all measurements in operating conditions and measure to the nearest 1/4 inch [nearest cm].

To reset or adjust the Machine Calibration, the VSN system must be reset to factory defaults.

CAMERA AND EQUIPMENT CALIBRATION

Refer to the following sections to get started with the VSN calibration for the specific application:

- *Rear Boom Sprayers* section on page 7
- *Front Boom Machines* section on page 9
- *Implement* section on page 11
- *Radar Sensors* section on page 14


REAR BOOM SPRAYERS

1. Use the Machine Type drop down list to select the Rear Boom Sprayer option.
2. Use the Machine Make and Model drop down lists to select your machine.

NOTE: If your machine make or model is not listed, select the Generic option.

3. Measure the height of the camera lens to the bottom of the furrow.
4. Use the on-screen keypad to enter the camera height.

FIGURE 1. VSN Camera Height



5. Select the Next button.
6. Next, measure and enter the distance from the rear axle of the vehicle to the camera lens.


NOTE: A positive value means the camera is located in front of the rear axle.

FIGURE 2. VSN Camera Fore/Aft Position



7. Select the Next button.
8. Enter the pitch (tilt) of the camera from horizontal.

FIGURE 3. VSN Camera Tilt



9. Select the Next button.
 10. Measure the distance between the front and rear axles of the machine and enter the measurement as the Wheel Base
 11. Select the Next button.
- Proceed to the *Image Exclusion* section on page 13 to proceed with calibration wizard.

FRONT BOOM MACHINES

1. Use the Machine Type drop down list to select the Front Boom Sprayer option.
2. Use the Machine Make and Model drop down lists to select your machine.


NOTE: If your machine make or model is not listed, select the Generic option.

3. Lower the center rack to the down position.
4. Measure the height of the camera lens to the bottom of the furrow.
5. Use the on-screen keypad to enter the camera height. VSN will calculate the camera to sensor offset and display the value on the page.

NOTE: If an AutoBoom XRT system is detected, VSN will utilize the center rack height sensor for dynamic VSN camera height monitoring. If not, a stand-alone height sensor may be installed for dynamic VSN height detection.

If no height sensor is installed, the operator must manually enter the camera height during guidance operations.


FIGURE 4. VSN Camera Height



6. Select the Next button.
7. Next, measure and enter the distance from the rear axle of the vehicle to the camera lens.


NOTE: A positive value means the camera is located in front of the rear axle.

FIGURE 5. VSN Camera Fore/Aft Position



8. Select the Next button.
9. Enter the pitch (tilt) of the camera from horizontal.

FIGURE 6. VSN Camera Tilt



10. Select the Next button.
11. Measure the distance between the front and rear axles of the machine and enter the measurement as the Wheel Base.
12. Select the Next button.
Proceed to the *Image Exclusion* section on page 13 to proceed with calibration wizard.


IMPLEMENT

1. Use the Machine Type drop down list to select the Implement option.
2. Use the Machine Make and Model drop down lists to select your machine.

NOTE: If your machine make or model is not listed, select the Generic option.

3. Lower the implement to the working height.
4. Measure the height of the camera lens to the bottom of the furrow.
5. Use the on-screen keypad to enter the camera height. VSN will calculate the camera to sensor offset and display the value on the page.


FIGURE 7. VSN Camera Height



6. Select the Next button.
7. Next, measure and enter the distance from the working point of the implement to the camera lens.

NOTE: A positive value means the camera is located in front of the working point.

FIGURE 8. VSN Camera Fore/Aft Position



8. Select the Next button.
9. Enter the pitch (tilt) of the camera from horizontal.

FIGURE 9. VSN Camera Tilt




10. Select the Next button.

Proceed to the *Image Exclusion* section on page 13 to proceed with calibration wizard.

IMAGE EXCLUSION

1. Select areas to exclude from the camera image. For example, if part of the machine is in sight of the camera, exclude this area to avoid issues with row guidance.

FIGURE 10. Image Exclusion Page




2. Select the Next button and proceed to the *Radar Sensors* section on page 14 to proceed with calibration wizard.

RADAR SENSORS

1. Use the Left and Right Side drop down lists to select the serial number of the radar sensor mounted on the left and right wheel.


FIGURE 11. Left/Right Radar Sensor Setup Page



NOTE: Touch the Flip Left/Right button to flip the entered values for the left and right radar sensors. Touch the Refresh button to redetect the radar sensors connected to the system.

2. Select the Next button.
3. Measure the angle of the radar sensors. This angle is measured using the direction of forward vehicle travel as 0°.


FIGURE 12. Radar Sensor Angle Page



NOTE: The factory radar brackets are designed to mount the radar sensors at a 45° angle with the forward course over ground. Enter the radar sensor angle as a positive value.

4. Enter the offset from the center of the tire to the radar sensor lens.

FIGURE 13. Radar Sensor Offset Page




5. Select the Next button.

CALIBRATION SUMMARY

1. The Calibration Summary page will be displayed after all camera and machine settings have been entered.

FIGURE 14. VSN Machine Calibration Summary



2. To complete the Machine Calibration and save the displayed settings, select the check mark button.
3. Proceed to the *Row Spacing Preset Calibration* section on page 16 to continue with the calibration wizard.

ROW SPACING PRESET CALIBRATION


Complete the following steps to calibrate a row spacing preset on the VSN system.

NOTE: Up to 5 row spacing presets may be saved with the VSN system.

1. Select the Row Spacing button to proceed with the calibration process.

NOTE: If radar sensors are available, VSN may be run in a radar only mode. If no radar sensors are installed, a row spacing calibration will need to be completed before the VSN camera may be used for row guidance.

FIGURE 15. VSN Row Spacing Preset Selection




2. Enter the row spacing of the crop (in inches [cm]) in which the VSN steering system will be used.
3. Enable the Radar Only option to bypass the Row Spacing Calibration.

NOTE: If the Radar Only option is enabled, the system will skip the following calibration steps and the row sensor source will be locked to radar sensors. This option may be useful when completing the calibration in full canopy or late season crops where the VSN system may encounter lower visual solution qualities.

Proceed to Chapter 4, *Operation*, for assistance with VSN operation in the Radar Only mode.

FIGURE 16. VSN Row Spacing



4. Select the Next button.
5. Review the calibration instructions on-screen before selecting the Start button to begin the calibration.

FIGURE 17. Begin VSN Camera Calibration



6. Drive slowly down the row while steering the machine manually. Drive at a speed of 5 to 10 mph [8.5 to 16 km/h]. After approximately 100 yards [91 m], the calibration process will be complete.

NOTE: The VSN camera needs to be calibrated in a flat field with straight rows. A good calibration is extremely important to good steering performance.

FIGURE 18. Calibration In Progress




NOTE: Values displayed in red during the calibration process indicate an issue with the calibration parameters and may cause the calibration to stop or require the calibration to be restarted.

To successfully complete calibration, the following values will be required:

- Yaw rate must remain below 2.5° per second
- Roll must be less than 2°
- Quality must be above 50

7. Bring the machine to a complete stop.
8. Review the Camera Calibration Results page. To complete the calibration and save the displayed values, select the check mark button.

FIGURE 19. VSN Camera Calibration Summary





NOTICE

Do not use abrasive cleaning materials or sharp objects on the VSN camera lens. Check the lens periodically during field operations. Wipe lens with a soft cloth using glass cleaner if needed.

Refer to the ROS (Raven Operating System) Basic Operation Manual (P/N 016-0171-539) or CRX Operation Guide (P/N 016-0171-664) for instructions on starting a job and setting guidance lines.

HOME PAGE

The following sections provide information about the system status and settings shown on the VSN System Home page.

FIGURE 1. VSN Main Page - Calibrated Row Spacing





FIGURE 2. VSN Main Page - Radar Only



VSN STATUS ICON

TABLE 1. VSN System Status Icon Displays

Status Icon	Description
Green	System is ready for row steering operation. No active Diagnostic Trouble Codes (DTC).
Yellow	Solution quality is low. No active DTCs. System may be operated with caution.
Red	Active DTCs are preventing the system from operating.

QUALITY

The percentage displayed indicates the current steering solution quality.

ROW SENSOR SOURCE

NOTE: The row sensor source option is not available when operating in radar only mode.

Select one of the following as the source of VSN row detection for field guidance:

Camera. Use the VSN camera for visual row guidance in the Vision or Vision+ operation modes.

Radar. Use the radar sensors to detect the crop stalks below the canopy.

MACHINE ROLL

The left/right tilt angle of the vehicle.

MACHINE SPEED

Current GPS speed of the machine.

CAMERA FURROW OFFSET

NOTE: The camera furrow offset is not available when operating in radar only mode.

Distance from the camera to the center of the nearest furrow bottom.

- A positive value means the camera is to the right of the furrow.
- A negative value means the camera is to the left of the furrow.

The offset value may be edited after the VSN camera has been calibrated to fine tune the tire-to-furrow position and help to center the tire in the furrow. Select the left button to nudge the tire to the left, and the right button to nudge the tire to the right. Using these buttons will nudge the tire in ± 1 inch increments.

ROW DETECTION SOLUTION QUALITY

Set the minimum quality value that must be met to engage VSN. This value is the cameras ability to detect the crop rows versus the furrows. This value is editable.

A value of 50% is recommended. In Vision Only mode, VSN will disengage if the solution quality goes below the set percentage. In Vision Plus mode, VSN will revert back to GPS guidance.

ROW SPACING PRESET

Displays the current row spacing entered for the current row spacing preset. Select the button to select a currently calibrated row spacing preset or calibrate a new row spacing preset.

NOTE: Up to 5 row spacing presets may be saved.

VSN OPERATION WIDGETS

The following widgets are available for use with the VSN system to quickly change modes, monitor system operations, and engage the system from the Raven field computer running the Raven Operating System (ROS) or CRX operating system during field operations.

OPERATION MODE WIDGETS

The Operation Mode widget must be added to the field computer guidance screen to allow the operator to change modes during a field operation.

TABLE 2. VSN Operation Modes

ROS Widget	Description
	GPS Mode. Guidance is performed via GPS guidance points only.
	Vision. Guidance is performed via the VSN camera or radar sensors only. GPS corrections are neither utilized for guidance nor available as a fall-back solution. Line acquire must be performed manually. When the solution quality falls below the minimum threshold the steering system will disengage.
	<p>Vision+. Guidance is performed via a combination of GPS and the VSN camera or radar sensors. This mode can be utilized for line acquire via GPS with the system switching to the VSN camera when the machine is aligned and near the guidance line.</p> <p>This mode will also fall back to GPS guidance if the solution quality falls below the minimum threshold. The system will then return to VSN guidance automatically when the solution quality is above the minimum threshold.</p> <p>NOTE: It is recommended to use Last Pass when using Vision+ mode.</p>

STATUS AND ENGAGE WIDGET

The following widget may be used with Raven steering systems to engage steering from the field computer screen and view the current status of the steering system.


NOTE: The VSN steering system may be engaged using the machine engage switch. Refer to the RS1 or SC1/TC1 manual for additional information on using the machine engage switch.

ROS Widget	CRX Widget	Description
		System disabled and cannot be engaged. Check for active DTCs and VSN solution quality.
		VSN solution quality is nearing minimum thresholds. System may be engaged, but system performance may be impacted.
		System ready for steering.
		System engaged in GPS mode or using GPS fall back corrections in Vision+ mode.
		System engaged and using Vision or radar sensors for steering solution.

ANALOG VIDEO DISPLAY WIDGET

The Analog Video Display widget can be helpful when troubleshooting the visual guidance system.

FIGURE 3. Analog Video Widgets



NOTE: Refer to the Viper/Viper 4+ Installation and Operation manual (P/N 016-0171-539) or CRX Operation Guide (P/N 016-0171-664) for information on adding widgets.

Solution Quality Display. The solution quality is displayed on the analog video display from the VSN camera.

Vehicle Heading. The current vehicle heading is displayed on the VSN analog video as a white line.

Rows. The green lines shown on the analog video display should correspond with crop rows shown in the video image.

Furrows. The brown lines displayed in the analog video should correspond to the furrow bottoms.

VSN STATUS WIDGET

The VSN Status widget allows the operator to quickly check the current status of the VSN system during operation.

ROS Widget		Description
Vision	Radar	
		VSN requires calibration.
		No A-B path or guidance line has been set, solution quality is below minimum threshold, or an active DTC is preventing the VSN system from engaging.
		VSN is detected and ready.
		VSN solution quality is nearing minimums. While in a caution state, the system may be engaged, but system performance may be impacted.

NOTE: Machine roll is displayed on the VSN Status widget.

Refer to *Diagnostic Trouble Codes Tab* section on page 44 for additional status conditions which may be displayed in the VSN on-screen widget.

CHAPTER

5

VSN SYSTEM SETTINGS AND TUNING


The following buttons will be used to navigate the settings and option pages in the following sections and will be referenced while offering assistance with the settings menus and options available for tuning the VSN system.

TABLE 1. UT Navigation Buttons

	Accept - Saves the changes made to the VSN system at the end of the setup process and returns the to the Tools Menu.
	Next - Saves the changes made to the VSN system and proceeds to the next step in the setup process.
	Previous - Returns the UT display to the previous screen in the setup process.

MACHINE SETTINGS TAB

FIGURE 1. Machine Settings Tab




NAVIGATION PARTNER

Displays the Navigation Controller to which the VSN system is communicating.

RESET DEFAULTS

To restore system default settings:



Touch the Reset Defaults button to clear stored row spacing presets and recalibrate the system. Accepting the confirmation will restore the VSN back to factory default settings.

NOTE: Review Chapter 3, *Calibration Wizard*, for additional assistance with calibrating the VSN system and completing the calibration wizard after resetting the system defaults.

CAMERA MOUNTING

The Camera Mounting window is accessible via the Machine Settings page.

To adjust camera mounting settings and measurements





FIGURE 2. Camera Mounting Settings Page



NOTE: A factory reset will be required to change or adjust the Camera Mounting Settings.

Camera Fore/Aft. Distance from the VSN camera lens to the rear axle. A positive value indicates the camera is positioned in front of the rear axle.


Camera Height. Distance from the VSN camera lens to the bottom of the furrow.

Camera Angle. Pitch of the camera from horizontal.

Wheel Base. Measurement between the front and rear axle.

SYSTEM SETTINGS TAB

FIGURE 3. System Settings Tab




CAMERA CALIBRATION

The Camera Calibration window is accessible via the System Settings page.

To tune the camera calibration settings:



FIGURE 4. Camera Calibration Page



Row Spacing Name. Displays the currently selected Row Spacing Preset.

Camera to Furrow Offset. Displays the distance from the right camera lens to the center of the nearest furrow bottom. This distance value is calculated during the row spacing preset calibration procedure. Use the + and - buttons to fine tune the tire-to-furrow position to center the tire in the furrow.

Camera Yaw Offset. Displays the calibrated camera Yaw offset value. This value can be tuned to help account for any camera left or right heading alignment errors.

Row Spacing Calibration. Touch the Calibrate Row Spacing button to recalibrate the row spacing preset outside of the preset calibration wizard.

CAMERA SETTINGS

The Camera Settings window is accessible via the System Settings page.

To tune the camera exposure settings or capture a still image through the VSN camera:



FIGURE 5. Camera Settings Page



Enable Auto Exposure. Automatically determines the correct exposure for video without any user input. Disable this option to manually adjust camera exposure.

NOTE: Auto Exposure is enabled by default and it is recommended to allow the VSN system to automatically adjust exposure during operation.

Exposure Control. Determines how much light is allowed to reach the VSN sensor and adjusts how light or dark the image appears. The correct exposure allows optimal contrast for system performance.

NOTE: It is not recommended to manually adjust the Exposure Control value.

Capture Image. Touch the Capture Image button to save a still image of the current VSN camera view. The image will be saved on the VSN system and may be used by the Raven Service Team to help troubleshoot potential field issues.


ADVANCED SETTINGS

The Advanced Settings window is accessible via the System Settings page.

To access advanced VSN system settings:



FIGURE 6. Advanced Settings Page



Filter Level. This setting controls the noise level in the guidance errors sent onto the CANbus from VSN. A lower setting has less filtering and lower latency. A higher setting has more filtering and more latency.

NOTE: The default value for the Filter Level is 2. It is only recommended to adjust this setting with the support of a technician.

Quality Warning Offset. The threshold above the Row Detection Quality (shown on Home page) at which the operator will be notified that the solution quality from the VSN system has dropped to into a caution state. This value is editable.

For example, if the Row Detection Quality is set to 50 and the Quality Warning Offset is set to 10, the VSN icon will be in a caution (yellow) state when the Row Detection Quality is between 50 and 60.

Side Hill Compensation. Provides additional compensation to adjust for guidance errors due to machine roll.

NOTE: Side Hill Compensation is enabled by default and it is recommended to leave this option selected.


RADAR SETTINGS

The Radar Settings window is accessible via the System Settings page.

To tune the radar row sensor settings:



FIGURE 7. Radar Sensor Settings



Right/Left Side Serial Number. Use the drop down options to set the orientation of the radar sensors on the machine.

Radar Angle. Set the horizontal angle of the radar sensors. This angle is measured using the direction of forward vehicle travel as 0°.

NOTE: The factory radar brackets are designed to mount the radar sensors at a 45° angle with the forward course over ground. Enter the radar sensor angle as a positive value.

Radar Offset Distance. The offset distance from the centerline of the tire to the radar sensor lens.


FRONT BOOM SETTINGS

The Front Boom Settings window is accessible via the System Settings page.

To adjust the VSN camera mounting settings for front boom configurations:



FIGURE 8. Height Sensor Page




Height Source. The height sensor source used with the front boom mounted VSN. This option may be set to utilize the XRT center rack height sensor or a standalone height sensor.

Camera to Sensor Offset. The offset is the difference between the VSN camera lens and the height radar sensor. Enter a positive offset value if the VSN camera is above the radar height sensor.

Height of VSN. The calculated height of the VSN camera. The value displayed in this field utilizes the height sensor source and camera to sensor offset to calculate the current height of the VSN camera.

NETWORK SETTINGS TAB

FIGURE 9. Network Settings Tab




SLINGSHOT NAME DISPLAY

Displays the registered name of the VSN on the Raven Slingshot Portal.

ETHERNET SETTINGS

Touch the Ethernet Settings button to review the IP address assigned to the VSN system and the current link speed.

FIGURE 10. Ethernet Settings Page



WiFi SETTINGS

The WiFi Settings window is accessible via the Network Settings page.

To change WiFi or wireless communication settings:



Touch the WiFi Settings button to review all WiFi Networks available to the VSN system. The network to which VSN is currently connected will be displayed with a green check mark next to the name.

RAVEN AUTO

Select Raven Auto to allow VSN to automatically connect with a compatible Raven device.

FIGURE 11. Raven Auto Mode



MANUAL


If a compatible Raven device is not available, select Manual from the Mode drop down list to display a list of available WiFi networks. The network to which VSN is currently connected will be displayed with a green check mark next to the name.

FIGURE 12. Manual Mode




T1 ETHERNET SETTINGS

To review or change the T1 Ethernet settings:



The T1 Ethernet Settings window is accessible via the Network Settings page.

FIGURE 13. T1 Server and Client Mode Pages



Raven Field Computer (Server Mode). Allows other devices to connect to the VSN.

Field Hub (Client Mode). Allows the VSN to connect to another device via wireless Internet.

Device IP Address. Displays the IP address the VSN has received (via Field Hub) or the IP address of the VSN broadcast (via Server Mode).

Link Speed. Displays the fastest data rate for all devices connected via Ethernet cable. The value is measured in megabits per second (MB/s).


The following buttons will be used to navigate the diagnostics menus and pages described in the following sections.

TABLE 1. UT Navigation Buttons

	Accept - Saves the changes made to the VSN system at the end of the setup process and returns the to the Tools Menu.
	Next - Saves the changes made to the VSN system and proceeds to the next step in the setup process.
	Previous - Returns the UT display to the previous page in the setup process.

SYSTEM INFORMATION

FIGURE 1. System Information Tab



The System Information tab displays the following information associated with the VSN system:

- Hardware Version
- Software Version
- Inertial Data
- System Hours
- System Voltages


SLINGSHOT STATUS ICON

- Green - Denotes a VSN connection to Slingshot.
- Red - Denotes that the VSN is NOT connected to Slingshot.

SOFTWARE UPDATE

Select the Update Software button at the bottom of the page to update the software version on the VSN system.

FIGURE 2. Software Download Page



The current software version installed on the VSN system is displayed along with any available OTA (Over the Air) updates.

NOTE: VSN may be updated with a USB drive via the field computer or UT. An OTA update may be completed with an Internet connection either via WiFi or Ethernet.

Refer to the CAN Node Update process in the field computer manual and ensure WiFi is enabled on the field computer.

TO UPDATE SOFTWARE

FIGURE 3. Software Download Page



1. Select the Check for Server Updates button to search for available updates.
2. Select the desired software update from the list.

3. Select the Accept button.

NOTE: The software will download, but will not be installed until later in the procedure. Before proceeding, accept the Data Usage Warning to allow the system to use cellular data to download the updates.

FIGURE 4. Data Usage Warning Page




NOTE: Select Cancel to exit without downloading the software update.

FIGURE 5. Software Download Page



4. Select Accept to begin the software download.
5. Wait for the software download to be completed.


FIGURE 6. Software Update Notice



6. Select Accept to install the software.

NOTE: Do not shutdown the system or field computer during the software update.


FIGURE 7. Software Installation in Progress



DIAGNOSTIC TROUBLE CODES (DTCS)

The Diagnostic Trouble Code tab displays lists of both active and previous (inactive) diagnostic trouble codes (DTCs) that occur during VSN system operation. Active DTCs must be fixed before the VSN system can be enabled for guidance and steering operation. Once a DTC has been corrected, the code moves to the inactive DTC code list. Refer to Figure 8 on page 44 for an example of DTCs and DTC summaries.

FIGURE 8. Diagnostic Trouble Codes Tab



Selecting Clear deletes the inactive DTCs from the Inactive DTC error log. For a complete list of VSN DTCs, please visit:

http://ravenprecision.force.com/knowledgebase/articles/Tech_Tip/RS1-Lights-and-Diagnostic-Codes/

Select the Log Error button to record diagnostic CAN data.

VSN DIAGNOSTIC LED STATES


TABLE 2. VSN Diagnostic LED Displays

Status	Description
Green	•Flashing (1 Hz) - VSN system is calibrated and detecting rows.
Yellow	•Flashing (10 Hz) - No CAN communication. •Flashing (1 Hz) - CAN Communication Present.
Red	•Flashing - VSN has power and is starting up.
Red / Purple	•Flashing - VSN needs reprogramming.

SYSTEM SUMMARY

The System Summary tab provides an overview of the current VSN settings and may be useful to verify that the system is configured properly for the machine or implement with which the system is operating.

FIGURE 9. System Summary Tab



I

Important Safety Information	1
Electrical Safety	1
Hydraulic Safety	1
Introduction	
Installation	4
Recommendations	4
Updates	5

U

Updating the Node	5
-------------------	---

LIMITED WARRANTY

WHAT DOES THIS WARRANTY COVER?

This warranty covers all defects in workmanship or materials in your Raven Applied Technology Division product under normal use, maintenance, and service when used for intended purpose.

HOW LONG IS THE COVERAGE PERIOD?

Raven Applied Technology products are covered by this warranty for 12 months from the date of retail sale. In no case will the Limited Warranty period exceed 24 months from the date the product was issued by Raven Industries Applied Technology Division. This warranty coverage applies only to the original owner and is non-transferable.

HOW CAN I GET SERVICE?

Bring the defective part and proof of purchase to your Raven dealer. If the dealer approves the warranty claim, the dealer will process the claim and send it to Raven Industries for final approval. The freight cost to Raven Industries will be the customer's responsibility. The Return Materials Authorization (RMA) number must appear on the box and all documentation (including proof of purchase) must be included inside the box to be sent to Raven Industries.

WHAT WILL RAVEN INDUSTRIES DO?

Upon confirmation of the warranty claim, Raven Industries will (at our discretion) repair or replace the defective product and pay for the standard return freight, regardless of the inbound shipping method. Expedited freight is available at the customer's expense.

WHAT IS NOT COVERED BY THIS WARRANTY?

Raven Industries will not assume any expense or liability for repairs made outside our facilities without written consent. Raven Industries is not responsible for damage to any associated equipment or products and will not be liable for loss of profit, labor, or other damages. The obligation of this warranty is in lieu of all other warranties, expressed or implied, and no person or organization is authorized to assume any liability for Raven Industries.

Damages caused by normal wear and tear, misuse, abuse, neglect, accident, or improper installation and maintenance are not covered by this warranty.

EXTENDED WARRANTY

WHAT DOES THIS WARRANTY COVER?

This warranty covers all defects in workmanship or materials in your Raven Applied Technology Division product under normal use, maintenance, and service when used for intended purpose.

DO I NEED TO REGISTER MY PRODUCT TO QUALIFY FOR THE EXTENDED WARRANTY?

Yes. Products/systems must be registered within 30 days of retail sale to receive coverage under the Extended Warranty. If the component does not have a serial tag, the kit it came in must be registered instead.

WHERE CAN I REGISTER MY PRODUCT FOR THE EXTENDED WARRANTY?

To register, go online to www.ravenhelp.com and select Product Registration.

HOW LONG IS THE EXTENDED WARRANTY COVERAGE PERIOD?

Raven Applied Technology products that have been registered online are covered for an additional 12 months beyond the Limited Warranty for a total coverage period of 24 months from the date of retail sale. In no case will the Extended Warranty period exceed 36 months from the date the product was issued by Raven Industries Applied Technology division. This Extended Warranty coverage applies only to the original owner and is non-transferable.

HOW CAN I GET SERVICE?

Bring the defective part and proof of purchase to your Raven dealer. If the dealer approves the warranty claim, the dealer will process the claim and send it to Raven Industries for final approval. The freight cost to Raven Industries will be the customer's responsibility. The Return Materials Authorization (RMA) number must appear on the box and all documentation (including proof of purchase) must be included inside the box to be sent to Raven Industries. In addition, the words "Extended Warranty" must appear on the box and all documentation if the failure is between 12 and 24 months from the retail sale.

WHAT WILL RAVEN INDUSTRIES DO?

Upon confirmation of the product's registration for the Extended Warranty and the claim itself, Raven Industries will (at our discretion) repair or replace the defective product and pay for the standard return freight, regardless of the inbound shipping method. Expedited freight is available at the customer's expense.

WHAT IS NOT COVERED BY THE EXTENDED WARRANTY?

Raven Industries will not assume any expense or liability for repairs made outside our facilities without written consent. Raven Industries is not responsible for damage to any associated equipment or products and will not be liable for loss of profit, labor, or other damages. Cables, hoses, software enhancements, and remanufactured items are not covered by this Extended Warranty. The obligation of this warranty is in lieu of all other warranties, expressed or implied, and no person or organization is authorized to assume any liability for Raven Industries.

Damages caused by normal wear and tear, misuse, abuse, neglect, accident, or improper installation and maintenance are not covered by this warranty.