

**Installation and
Operation Manual:
UHarvest™ Data
Management System**

P/N 016-0171-570 Rev. C 07/15 E24724

Copyright 2015

Disclaimer

While every effort has been made to ensure the accuracy of this document, Raven Industries assumes no responsibility for omissions and errors. Nor is any liability assumed for damages resulting from the use of information contained herein.

Raven Industries shall not be responsible or liable for incidental or consequential damages or a loss of anticipated benefits or profits, work stoppage or loss, or impairment of data arising out of the use, or inability to use, this system or any of its components. Raven Industries shall not be held responsible for any modifications or repairs made outside our facilities, nor damages resulting from inadequate maintenance of this system.

As with all wireless and satellite signals, several factors may affect the availability and accuracy of wireless and satellite navigation and correction services (e.g. GPS, GNSS, SBAS, etc.). Therefore, Raven Industries cannot guarantee the accuracy, integrity, continuity, or availability of these services and cannot guarantee the ability to use Raven systems, or products used as components of systems, which rely upon the reception of these signals or availability of these services. Raven Industries accepts no responsibility for the use of any of these signals or services for other than the stated purpose.

Important Installation and Safety Information	1
Electrical Safety	1
Hydraulic Safety	1
Introduction	3
Overview	3
Product Registration and Software Updates	3
System Components	4
Cab Component Installation	7
Components	7
Mounting the UHarvest Processor	7
Installing the CAN Cable	9
System Diagrams	13
Operation with a Tablet	17
Startup and Wi-Fi Connection	17
Header Information	19
Scale Setup	19
Grower Information	21
Importing/Exporting Grower Information	23
Trucks, Destinations and Varieties	24
Starting a Job	25
Scale Screen	26
Unload Screen	27
Manual Logging	29
Report Screen	30
Scale Calibration	31
Moisture Calibration	32
Editing Load Information	33
Operating AccuLoad	34
Spout Centering	36
Steerable Duals	37
Diagnostics Screen	38
Changing the Wi-Fi Password	38
File Management	39
Software Updates	43
Operation with a Virtual Terminal	45
Locating UHarvest on the Virtual Terminal	45
Header and Navigation Icon Information	46
Scale Setup	47
Grower Information	48
Starting a Job	50
Trucks, Destinations and Varieties	52

Scale Screen	53
Unload Screen	54
Manual Load Logging	56
Report Screen	56
Scale Calibration	57
Moisture Calibration	59
Editing Load Information	59
Operating AccuLoad	59
Spout Centering	61
Steerable Duals	63
Diagnostics Screen	64
File Management	64
Operation with a Virtual Terminal: UHarvest Lite	67
Loading UHarvest Lite on the Virtual Terminal	67
Navigation Icon Information	67
Scale Setup	67
Scale Screen	68
Combine Verify Screen	69
Unload Screen	70
Report Screen	70
Scale Calibration	71
File Management	72
Upgrade to Full UHarvest	74
Operation with a Smart Phone	75
Phone Connections	75
Phone Screen Navigation	78
File Transfer	79
Scale Screen	79
Report Screen	80
Setup/Diagnostics Screen	81
Viewing the Job File in Excel	83
Job File	83
Viewing Jobs in Slingshot	85
Viewing the License Agreement	87
Troubleshooting	89
Tablet Wi-Fi Connection	89
UHarvest Display on Virtual Terminal	89
Processor and ECU Communication	90
Tablet Charging	91

Table of Contents

Scale	91
Recording	93
AccuLoad	94
Moisture Sensor	98
Spout Centering	98
Joystick	99
Steerable Duals	100
Slingshot	100
Appendix	101

Important Installation and Safety Information



Electrical Safety

While installing the UHarvest system and other electrical system components:

- Disconnect the UHarvest devices and all electrical components of the system before jump-starting the vehicle or welding on any component of the equipment.
- Always verify that the power leads are connected to the correct polarity as marked. Reversing the power leads could cause severe damage to the equipment.
- To ensure that any system components are not activated automatically while installing system components, install power cables, leads or connectors last.

Hydraulic Safety

While installing any hydraulic system components for the UHarvest system:

- Raven Industries recommends that appropriate protective equipment be worn at all times when working on any hydraulic system.
- Ensure the UHarvest devices are disabled prior to starting any maintenance work on the machine or components of the control system.
- Never attempt to open or work on a hydraulic system with the equipment running. Use caution when opening a system that has been previously pressurized.
- When disconnecting the hydraulic hoses or purging is required, be aware that the hydraulic fluid may be extremely hot and under high pressure. Caution must be exercised.
- Any work performed on a hydraulic system must be done in accordance with the machine manufacturer's approved maintenance instructions.
- When installing hydraulics or performing diagnostics, maintenance or routine service, ensure that precautions are taken to prevent any foreign material or contaminants from being introduced into the machine's hydraulic system. Objects or materials that are able to bypass the machine's hydraulic filtration system will reduce performance and possibly damage the hydraulic valves.

NOTICE

Read this manual and the operation and safety instructions included with the equipment and/or controller carefully before installing the UHarvest system.

- Follow all safety information presented within this manual.
- If you require assistance with any portion of the installation or service of UHarvest equipment, contact a local Unverferth dealer for support.
- Follow all safety labels affixed to the system components. Be sure to keep safety labels in good condition and replace any missing or damaged labels. To obtain replacements for missing or damaged safety labels, contact a local Unverferth dealer. When operating the machine after installing the UHarvest system, observe the following safety measures:

When operating the machine after installing the UHarvest system, observe the following safety measures:

- Be alert and aware of surroundings.
- Do not operate the UHarvest system while under the influence of alcohol or an illegal substance.
- Remain in the operator's position in the machine at all times when UHarvest is engaged in product control functions or while any additional automated features are operating. Disable these functions or features when exiting the operator's position.
- Determine and remain a safe working distance from other individuals. The operator is responsible for disabling the UHarvest system or any system features when the safe working distance has been diminished.

Introduction

Overview

Thank you for purchasing the Unverferth UHarvest™ or UHarvest™ Lite data management system for your grain cart. The UHarvest system interfaces with your grain cart to monitor and record harvest data. The full UHarvest system can track grower, farm, and field data in addition to crop variety, truck identification, and destination. UHarvest can run through a tablet or the tractor's existing ISOBUS virtual terminal. UHarvest Lite is run strictly through a virtual terminal. This manual explains how to install the components in your tractor cab and how to operate UHarvest. For installation of components on the grain cart, refer to Unverferth manual P/N 271911.

FIGURE 1. UHarvest on a Tablet



Product Registration and Software Updates

Register this product at www.uharvest.net to receive alerts about software, hardware, and other updates.

System Components

The UHarvest system includes a processor in the tractor cab and an electronic control unit (ECU) on the grain cart. Communication between the two devices is achieved via the tractor's ISOBUS. The primary user interface is either a tablet device or a virtual terminal (VT). The VT also communicates through the ISOBUS while the tablet uses the processor's Wi-Fi or Bluetooth connection. Limited functionality is available with a smart phone. UHarvest data can be sent to a Raven Slingshot account over the air or with a USB flash drive.

The UHarvest Lite system includes the ECU on the grain cart, the tractor's ISOBUS, and a VT. No processor is required. Operation with a tablet or a smart phone is not available. UHarvest Lite can be upgraded to full UHarvest with the addition of a processor and supporting cables.



In addition to sending a wireless signal, the UHarvest processor is the primary data storage device for the system. The processor is not weatherproof, so it should be mounted inside the tractor cab.

The processor's USB ports can be used to charge a tablet, but the charging capabilities are limited. Different tablets have different rates of power consumption. If the tablet's screen is at full brightness, the charger will not be able to keep up. For USB charging from the processor, the recommended screen brightness is 50% or less. If the charge from the processor is not satisfactory, a cigarette lighter type of charger may be needed.

FIGURE 2. Processor Features





Table 1: Processor Status LED


LED Color	Meaning
Off	Not Powered
Yellow	Booting up or updating Processor software
Blue	Operational
Light Blue	ECU software update available
Green and Blue (Alternating)	ECU software update in progress
Red	Error state

FIGURE 3. UHarvest ECU



The ECU is mounted on the grain cart. Its primary task is to read the cart's load cell measurements. The ECU also monitors and controls various UHarvest features.

FIGURE 4. ECU LEDs and Meanings



Cab Component Installation

Components

This section contains a list of components that are included in the UHarvest processor kit. These components will be installed in the tractor.

Note: *These items are not used in the UHarvest Lite.*

Table 1: UHarvest Processor (P/N 063-9000-006; 9006854) and Tractor Kit (P/N 117-9000-019; 9007359)

Description	Raven P/N	Unverferth P/N	Qty.
UHarvest Processor	063-9000-004	9006854	1
RAM Mount Diamond Base	103-0001-034	9006868	1
RAM Mount Arm	103-0001-035	9006870	1
RAM Mount Round Base	103-0001-036	9006869	1
Screw - #8-32 x 2-1/4"	311-0001-352	903172-354	2
Nut - # 8-32 Locking	312-4000-160	9397-001	2
USB Flash Drive	524-0002-069	9007095	1
Power Cable	115-0172-257	9007288	1
CAN Cable	115-0172-293	9007289	1


Mounting the UHarvest Processor

FIGURE 1. RAM Diamond Base attached to Processor



1. Attach the RAM diamond base (P/N 103-0001-034) to the processor (P/N 063-9000-004) using the supplied #8-32 screws and nuts.
2. Attach the RAM mount arm (P/N 103-0001-035) onto the RAM diamond base.


FIGURE 2. Processor Mounting



3. Identify a location in the tractor cab to mount the processor. Mount the RAM round base (P/N 103-0001-036) to that location.

Note: Hardware is not provided.

FIGURE 3. RAM Tablet Holder mounted with Processor




4. Place the remaining end of the RAM mount arm onto the RAM round base. Tighten the RAM mount arm to secure the processor.

Note: If a RAM tablet holder is being used, it can utilize the same #8-32 screws and nuts. Visit www.rammount.com to learn more about RAM tablet holders.

Installing the CAN Cable

ISO-ready Tractors

FIGURE 4. ISO Connector




1. Locate the processor CAN cable (P/N 115-0172-293).
2. Identify the tractor's ISO connector at the back of the tractor.

FIGURE 5. Deutsch 4-Pin Connector Removed




3. On the front side of the ISO connector, disconnect the 4-pin Deutsch connector.

FIGURE 6. CAN Cable / ISO Connector




4. Connect the CAN cable between the tractor's 4-pin Deutsch connector and the ISO connector.
5. Route the remainder of the CAN cable into the cab.

FIGURE 7. UHarvest Processor Connections



6. Connect the 4-pin Deutsch connector to the CAN A port on the UHarvest processor.
7. Locate the processor power cable (P/N 115-0172-257).

FIGURE 8. Accessory Power Connections



Accessory
Power
Connector

8. Connect the round 3-pin connector to the tractor's accessory power connector.
Note: Some smaller tractors have the constant and switched power wires reversed compared to larger tractors. It may be necessary to swap the red and orange wires on the UHarvest power cable in order to provide constant power to the processor.

Note: As an alternative, the power cable can be connected to a John Deere power strip. Connect the red wire to the constant power source and the black wire to the ground.


9. Connect the 2-pin Deutsch connector to the 12 VDC port of the processor. Use the rocker switch on the cable to turn processor power on and off.

10. Secure cables away from moving parts with zip ties.

Non-ISO Tractors

1. Locate the optional tractor ISO cable (P/N 115-7300-021).

FIGURE 9. ISO Connector Installed




ISO Connector

2. Mount the large ISO connector at the back of the tractor.

Note: Hardware and brackets are not provided.

3. Route the wires with ring terminals toward the tractor's battery.
4. Connect the red wire to the battery's positive terminal.
5. Connect the white wire to the battery's negative terminal.
6. Route the remainder of the cable into the cab.

FIGURE 10. Accessory Power Connector



Accessory
Power
Connector

7. Connect the round 3-pin connector to the tractor's accessory power connector.

Note: The remaining round 3-pin connector can be used as a spare power port for other devices.

FIGURE 11. Power/CAN Cable (115-7300-023)



8. Route the round 19-pin connector toward the UHarvest processor.
9. Connect the power/CAN cable (P/N 115-7300-023) to the 19-pin connector.
10. Connect the 4-pin Deutsch connector to the CAN A port on the UHarvest processor.
11. Connect the 2-pin Deutsch connector to the 12VDC port on the processor.

Note: This will supply switched power to use the processor. For constant power, use the standard power cable (P/N 115-0172-257). Refer to the previous section for additional information.

12. Coil any excess cable length and store it in a location that will not be in the way.
13. Use zip ties to secure the ISO cable away from any moving parts or heat sources.

Note: If the optional 115-7300-023 cable is being used, the standard 115-0172-293 cable will not be used.

System Diagrams

FIGURE 12. Wiring for ISO Ready Tractors




FIGURE 13. Wiring for Non-ISO Ready Tractors




FIGURE 14. Wiring for Avalanche Grain Carts





FIGURE 15. Wiring for non-Avalanche Grain Carts

WIRING DIAGRAM FOR CORNER AUGER GRAIN CARTS



Operation with a Tablet

Startup and Wi-Fi Connection

Note: *The pictures and steps below are based on an Apple iPad tablet. Your tablet may differ based on brand, model or operating system. Consult your device's manual if necessary.*

1. Start the tractor or turn the key to run to apply power to the UHarvest system.
2. Verify that the processor is powered on.

Note: *Upon startup, the processor's LED will be yellow while booting up. The LED will turn blue when it finishes booting.*


3. Go to your tablet's network connection page.
4. Select "uharvest-xxxx" from the list of available networks. The last four characters in the network name are unique to each UHarvest processor.

Note: *The uharvest-xxxx information can be found on one of the processor's stickers.*

5. Enter the password to join the network. This is only required for first time connections. The default password is "uharvest" - one word, all lowercase.


Note: *The Wi-Fi password can be changed. See the "Changing the Wi-Fi Password" section for details.*

FIGURE 1. Password Entry



6. Open your tablet's Internet browser and type the number 192.168.100.254 into the address bar then press Go. The UHarvest processor will direct you to the UHarvest application page.
7. Popup messages similar to the messages below may appear:
 - a. "UHarvest Would Like to Use Your Current Location": The UHarvest processor can access your tablet's current GPS coordinates (if it has a data plan) and use that information in your field reports. Select "Allow" if you want that feature.
 - b. "Trust This Computer?": UHarvest does not require any additional files from the tablet, so select "Don't Trust" for the UHarvest system to function properly.

FIGURE 2. Add UHarvest to Home Screen



8. In your browser settings, select the “Add to Home Screen” option.
9. Close the Internet browser and return to the tablet home screen. A new UHarvest icon will be on your home screen.


FIGURE 3. UHarvest on Home Screen



10. Select the UHarvest icon to open the program.
11. The end user license agreement must be accepted in order to use UHarvest.


Header Information

The header is visible on most screens. It displays current job and connectivity information.




Scale Setup

FIGURE 4. Setup Screen



1. From the UHarvest Home screen, select the Setup icon in the bottom left corner.
2. Select the local time zone from the drop-down menu.
3. Select "Cart Setup".

FIGURE 5. Make/Model/Undercarriage Selections



Grower: Test Farm: Test Field: 1 Year: 2015 Crop: Corn

Cart Setup

Make: Brent Model: 1186

Undercarriage: Single Float Tires

Capacity lbs: 63000.0

Scale Weight Intervals: 1

Units: lbs

Manual Load Logging


Calibrate Spout Load Cell Setup

AccuLoad Tune

Open Time (sec): 8 Close Time (sec): 7.5 Open Percentage: 90 Min Auger RPM: 500


4. For Unverferth family carts (Unverferth, Brent, Parker, Killbros), use the drop downs to select your cart's make, model, and undercarriage. Example: Brent/2096/In-line Steering Tandem.

FIGURE 6. Load Cell Adapter Cable (115-9000-022)



5. If your cart is another brand, select the "Custom" options and manually enter your cart's capacity. You also need to select "Custom" if you are using the optional 115-9000-022 load cell adapter cable.

FIGURE 7. Load Cell Setup Screen



Grower: Test Farm: Test Field: 1 Year: 2015 Crop: Corn

Load Cell Setup

Gain (K,XX mV/V): 0.75

Capacity: 56000

Cal Number: 70121


Total # of Load Cells: 5

6. Select the Load Cell Setup button.
7. For Unverferth carts, verify that all of the fields were populated.
8. For Custom carts, enter the appropriate values into all four fields. If the optional 115-9000-022 load cell cable is being used, enter 1 for the total number of load cells.

Note: Use 1.50 mV/V for the gain. Refer to the Appendix for additional calibration number information.

9. Select the green check mark to confirm your entries.

FIGURE 8. Scale Weight Intervals



Scale Weight Intervals

10. Select your desired scale weight interval from the drop down.
11. Select your desired scale unit (pounds or kilograms). This selection is unique to each display, so it must be repeated if multiple tablets are in use.
12. Select the green check mark to confirm your entries.

Grower Information

Harvest information is saved in a Grower/Farm/Field format. A Field name is entered under a specific Farm name. That Farm is entered under a specific Grower. New information can be entered at any time.

Note: Avoid using special characters (/ \: & ; { } * \$ % |, etc.) in Grower/Farm/Field entries.


Note: Names should be approximately 20 characters or less for the name to fully display on tablet screens.

FIGURE 9. New Job Icon on Home Screen



1. From the Home screen, select the New Job icon.

FIGURE 10. Grower, Farm, Field Screen



2. Select the Add icon to create a new Grower. Enter the Grower name and press OK.
3. To enter Farms underneath a particular Grower, make sure the Grower name is selected from the dropdown menu.
4. Select the Add icon to create a new Farm. Enter the Farm name and press OK.

FIGURE 11. Field Entry



5. To enter Fields underneath a particular Farm, make sure the correct Grower and Farm names are selected from the dropdown menus.
6. Select the Add icon to create a new Field. Enter the Field name and press OK.
7. Growers, Farms, and Fields and can also be deleted by selecting the Delete icon.

Important: *Deleting an entry will also delete any entries underneath it. For example, deleting Grower X will delete all of the Farms and Fields that were entered for Grower X.*


Note: *Grower/Farm/Field entries cannot be deleted if there is a saved job file that utilizes those entries. See the File Management section of this manual for more information on deleting job files.*

Importing/Exporting Grower Information

After creating a Grower/Farm/Field database, the database can be transferred to additional processors. This procedure will only add new grower information to the receiving processor. It does not edit or delete existing grower information.

1. Go to the setup screen.
2. Insert a USB flash drive into the processor that contains the grower information. An "Export GFF to USB" button should appear in the window.
3. Press the button to transfer the existing Grower/Farm/Field database to the flash drive.

FIGURE 12. Export GFF to USB



4. A “Raven/UHarvest” file path will automatically appear on the flash drive. This folder will contain the Grower database file.
5. Insert the same flash drive into the UHarvest processor you want to contain the Grower/Farm/Field information. In the tablet setup screen, an “Import GFF from USB” button should appear.
6. Press the “Import GFF from USB” button to import the Grower information.


Trucks, Destinations and Varieties

Add more detail to your harvest records by tracking trucks, destinations, and varieties.

Note: Names should be approximately 20 characters or less for the name to fully display on tablet screens.

1. Navigate to the Setup screen and select Database Manager.
2. Select the Add icon to add a new Truck, Destination, or Variety. Enter the new name and press OK.

FIGURE 13. Database Manager Screen



- For trucks, you can also enter the capacity. Make sure the appropriate truck is selected from the dropdown menu and then add the weight to the capacity field.
- Names can be edited. Select the name you want to change from the dropdown menu and then hit the Edit icon.

Note: *The edited name will not apply to old job files that utilize the entry. The change is only applied moving forward.*

- Names can be deleted by selecting the Delete icon.


Note: *An entry cannot be deleted if there is a saved job file that utilizes the entry. See the File Management section of this manual for more information on deleting job files.*

Starting a Job

Scale information is not available until you start a job. You can either start a brand new job or resume a previous job.

Starting a New Job:

FIGURE 14. Starting a New Job




- From the Home screen, select the New Job icon.
- Select the appropriate Grower, Farm, and Field.
- Select the appropriate crop.
- Hit the green arrow to start the job or the red X to cancel.

Resuming an Old Job:

- A list of old job icons is available on the bottom half of the Home screen. The most recent job is located at the top center of the screen.

FIGURE 15. List of Jobs on Home Screen



2. Select the appropriate Year/Grower/Farm/Field information to search for a particular job within the list.
3. Select the icon for the previous job you wish to resume. The icon shows the crop, field name, start date, and number of loads.


FIGURE 16. Old Job Icon



Scale Screen

The Scale screen will appear when you first start or resume a job. This screen is the primary interface to the cart's scale. You can monitor total weight, partial weight, hitch weight, load information, and field totals.

FIGURE 17. Scale Screen



- The total weight on the cart is shown as the Load Weight. It is also shown on the bottom progress bar.
- To zero the Load Weight, press the Zero Button to the left of the display and then confirm. The weight will zero after about 2 seconds.
- Press the Load Weight number to toggle to the Combine Verify weight. Combine Verify can be used for combine yield monitor calibration without having to zero the full Load Weight.
- To set the tare for Combine Verify, press the zero button to the left of the display and then confirm.
- Press the lbs/bu icon to toggle between pounds and bushels. The bushel calculation uses a standard test weight for the crop.
- The weight on the hitch is shown in the top progress bar. 6000 lbs of hitch weight corresponds to 100% on the progress bar. If the hitch is being overloaded, reposition the cart to transfer some weight away from the hitch.


Note: If the optional 115-9000-022 load cell cable is used, the hitch weight will always be at 0%.

- Running field totals are shown in the bottom right corner.
- Previous loads are shown in the bottom left corner. Scroll up and down to see additional loads.

Unload Screen

The Unload screen monitors how much weight is unloaded from the cart. You can also select Truck, Destination, and Variety. Some optional UHarvest features can be controlled from the Unload screen.

FIGURE 18. Unload Screen



- The Unload Weight is displayed at the top of the screen. This represents the weight that was unloaded from the cart during the previous unload event. It is a positive number.
- The Unload Weight will continue to display until the next load is started. When the load starts, the Unload Weight will reset to zero and then count upward as weight is unloaded from the cart.

FIGURE 19. Animations




- Press the lbs/bu icon to toggle between pounds and bushels. The bushel calculation uses a standard test weight for the crop.
- Total load weight and hitch weight can be seen on the progress bars.
- The auger and trailer icons will display flowing grain when PTO motion is detected.
- Use the dropdown menus to select the desired Truck, Destination, and Variety.
- The Unload Weight Target is linked to each truck or can be entered manually. See the AccuLoad section of this manual for more information.

- The processor remembers the weight dumped on to the truck. This value is subtracted from the truck's capacity to determine the Unload Weight Target.
- This value will be used for AccuLoad but can also be used as a reference for operators without the AccuLoad feature.
- The Weight on Truck value automatically resets to zero once the value is within 3% of the truck's capacity. The truck weight before reset will display for 10 seconds after the load.
- The weight on truck value can be manually set to zero by pressing the Reset button.

FIGURE 20. Target Weight Calculation



FIGURE 21. Destination and Weight Sent




- The Weight Sent field is linked to Destination. It will display how much weight has been sent to each Destination during the job.
- The Spout Center and Dual Unlock icons are used for carts with optional spout centering and steerable duals. See the Spout Centering and Steerable Duals sections for more information.

Manual Logging

In the event that the PTO sensor is damaged or missing, a manual logging feature is available.

FIGURE 22. Enable Manual Load Logging



1. Go to the Cart Setup screen and check Manual Load Logging.

Note: AccuLoad will be disabled while UHarvest is in manual load logging mode.

FIGURE 23. Manual Unload Logging Button



2. A start/stop recording button will be available on the Unload screen.
3. To start recording, press the icon when it has a triangle shown. The grain flow animations will begin after the button is pressed.
4. To stop recording, press the icon when it has a square shown.

Report Screen

The Report screen shows an extensive list of information for every load in the job. Scroll up and down to view more loads. Running field totals are shown at the bottom of the screen.

FIGURE 24. Report Screen

The screenshot shows the UHARVEST Report Screen. At the top, it displays 'RAVEN slingshot' and 'UHARVEST from Harvest'. The main data is presented in a table with columns for Load ID, Weight (lbs), Truck ID, Destination, Moisture, Test Weight (lbs), Wet Bu., Dry Bu., Variety, and Time-CDT. Below the table, there are three summary boxes for Field Weight (lbs), Average Moisture %, and Field Dry Bushels. At the bottom, there is a navigation bar with icons for Setup, File Management, Scale, Unload, Report, and Diagnostics.

Load ID	Weight (lbs)	Truck ID	Destination	Moisture	Test Weight (lbs)	Wet Bu.	Dry Bu.	Variety	Time-CDT
13	5,805.5	Truck 1	Dest 1	16.7%	57.0	101.9	100.4	Var 1	17:21:16
12	4,367.2	Truck 1	Dest 1	16.7%	57.0	76.6	75.5	Var 1	14:05:38
11	3,935.7	Truck 1	Dest 1	16.7%	56.0	70.3	69.3	Var 1	14:05:32
10	3,440.5	Truck 1	Dest 1	16.7%	56.0	61.4	60.6	Var 1	14:05:26
9	4,470.6	Truck 1	Dest 1	16.7%	56.0	79.8	78.7	Var 1	14:05:21
8	86.9	Truck 1	Dest 1	0%	56.0	1.6	1.6	Var 1	14:05:13
7	86.6	Truck 1	Dest 1	0%	56.0	1.6	1.6	Var 1	14:04:51


Field Weight (lbs)	Average Moisture %	Field Dry Bushels
51,129	16	897

- **Load ID:** The load ID starts at 1 and will increment upward with each new load. Pressing on the load number will bring up the load editor window. See the “Editing Load Information” section for more details.
- **Weight:** The weight unloaded from the cart.
- **Truck ID:** The name of the truck used during the load.
- **Destination:** Where the truck is taking the grain.
- **Moisture:** Average moisture for the load. If the cart does not have a moisture sensor, the moisture column will display low moisture content.
- **Test Weight:** Test weight for the load. A standard test weight is used for each crop, but test weight can be edited on the Report screen and the Scale screen if necessary. If English units are selected, the value is in lbs/bu. If metric units are selected, the value is in kg/hL.
- **Wet Bu.:** Conversion from weight in pounds to bushels using the test weight. If metric units are selected, the Wet Bushel column is removed from the report.
- **Dry Bu. (or Dry kg):** Conversion from wet bushels (or wet kg) accounting for the measured load moisture. If the cart does not have a moisture sensor, the dry value will equal the wet value.
- **Variety:** The crop variety in that load.
- **Time:** The time when the load occurred. The time is listed using Coordinated Universal Time (UTC) unless the local time has been selected in the setup screen.
- **Running field totals:** Shows field weight, average moisture, and field dry bushels (or dry kg).

Scale Calibration

1. Navigate to the Setup screen.

FIGURE 25. Calibration Section of Setup Screen



2. Verify that Weight Calibration is selected instead of Moisture Calibration.

FIGURE 26. Scale Calibration



3. Press the Certified Weight field and enter your known weight (Example: Elevator scale ticket).

4. Press the Grain Cart Weight field and enter the weight measured by the grain cart scale.

5. After entering the two weights, a new cal number will be calculated. Press the “Calibrate” button to apply the new value.

Important: The new calibration value will not apply unless the “Calibrate” button is pressed. After the new value is applied, it will appear in the Current Cal location.

6. The load cell calibration number can also be manually entered in the Load Cell Setup screen.

Moisture Calibration

1. Go to the Setup screen.

2. Verify that Moisture Calibration is selected instead of Weight Calibration.

FIGURE 27. Moisture Calibration



3. Press the Certified Moisture field and enter the known moisture value.

4. Press the Load Moisture field and enter the moisture measured by UHarvest.

5. After entering the two moistures, a new offset number will be calculated. Hit the “Calibrate” button to apply the new value.


Important: *The new calibration value will not apply unless the “Calibrate” button is pressed. After the new value is applied, it will appear in the Old Offset location.*

Editing Load Information

The UHarvest system gives the user the ability to designate a Truck, Destination, and Variety for each load. If the information was entered incorrectly or forgotten, the user can edit the load information at any point. The user can also add a short note for each load description.

1. On the Scale and Report screens, the load ID number is highlighted in blue. Press the load number for the load you wish to edit.

FIGURE 28. Load Editor Screen



2. The Load Editor window will appear. Use the dropdown menus to select the appropriate Truck, Destination, or Variety.
3. Press inside the Notes area to activate the tablet's keyboard.
4. Add a descriptive note to the load (up to 140 characters).


Note: Some characters such as commas and backslashes will be ignored.

Operating AccuLoad

The optional AccuLoad feature can be used to automatically open and close the grain flow gate to achieve a target unload weight.

1. Time how long it takes to open and close the flow gate using the tractor's hydraulic lever.

FIGURE 29. AccuLoad Tune Section of Cart Setup Screen



2. In the Cart Setup screen, enter the open and close times into the AccuLoad Tune section.
3. Enter the desired open percentage. This setting controls how far AccuLoad will open the gate. For faster unloading times, use a higher open percentage.
4. Enter the minimum auger RPM value. AccuLoad will not open the gate until the PTO is spinning at or above this setting.

Note: Select an RPM value that will protect the tractor's engine from stalling when the grain gate is fully opened. 750 RPM is a good starting point.

FIGURE 30. Unload Weight Target




5. On the Unload Screen, enter a target unload weight. The target is linked to the truck's capacity or you can manually enter a weight by selecting the Unload Weight Target field.

Note: Unless manually entered, the target weight will be automatically calculated as the difference between the truck capacity and the current weight on the truck.

6. Use the Auto/Manual button to toggle AccuLoad to Auto mode.

Note: You cannot enter Auto mode if the gate close hose is pressurized or if the cart is configured for manual load logging.

FIGURE 31. AccuLoad Mode Button



7. When you are in Auto mode and ready to unload grain, detent the tractor's hydraulic lever to the gate open position. The AccuLoad valve will hold the gate closed.

8. Engage the tractor's PTO and increase the engine speed.

9. Once the minimum RPM setting is reached, the AccuLoad valve will drive the gate open.

10. As the unload weight approaches the target weight, the AccuLoad valve will begin to close the gate.


11. When the target is reached, the AccuLoad valve will hold the gate closed.
12. Decrease the engine speed and disengage the PTO.
13. Return the tractor's hydraulic lever to neutral.
14. AccuLoad can be overridden at any time by moving the tractor's hydraulic lever to the close position. This triggers a pressure switch and causes AccuLoad to return to manual mode.

Note: *AccuLoad will remain in Auto mode unless the button is toggled to Manual or if the hydraulic lever is moved to the close position.*

Spout Centering


Optional spout centering control is available for some grain carts. This feature can be used to return the spout to a designated “center” position prior to unloading or folding.

FIGURE 32. Calibrate Spout Icon



1. Go to the Cart Setup screen and select the Calibrate Spout icon.
2. Identify the tractor's hydraulic lever that supplies the joystick's electric over hydraulic (EOH) valve.
3. Pressurize the EOH valve.
4. With the auger unfolded, use the joystick to maneuver the spout to each end point (In, Out, Front, Rear) and press the corresponding arrow to save that value.
5. Use the joystick to maneuver the spout to the desired center position.

FIGURE 33. Spout Calibration



6. Press the target icon to set the center point.

FIGURE 34. Spout Center Icon on Unload Screen




7. On the Unload screen, the spout center icon can be used to return the spout to the set center position.

Note: The spout will not move unless the EOH valve is pressurized.

Steerable Duals

For grain carts with in-line steerable duals, the UHarvest screen can be used instead of a switch box. Connect the steerable duals cable to the “STEERABLE DUALS” connector on the ECU cable. The steerable duals icon can be found on the Home and Unload screens.


FIGURE 35. Steerable Duals Icon Location



- Verify that “In-Line Steering Tandem” has been selected as the cart’s undercarriage (see the “Scale Setup” section). The steerable duals icon will not appear unless the cart has been configured correctly.
- Toggle to the “unlock” position to allow the grain cart to trail the tractor.
- To lock the current steering position, toggle to the “lock” position and detent the tractor’s hydraulic remote lever.
- To manually steer the tandem, toggle to the “lock” position and use the hydraulic lever to turn the wheels.

Diagnostics Screen

FIGURE 36. Diagnostics Screen




The Diagnostics page can be used for troubleshooting and checking software versions. See the Troubleshooting chapter of this manual for more information.

Changing the Wi-Fi Password

1. Go to the Diagnostics screen and press the “Change Wi-Fi Password” button.
2. Enter the new password.
3. Press Confirm.
4. Cycle power to the processor to apply the change.

Note: For password reset help, contact Unverferth product support.

FIGURE 37. Password Reset Screen



File Management

The File Management screen can be used to transfer files between the UHarvest processor and a USB flash drive or Slingshot. You can also use this screen to remove old or unwanted files from the processor.

Exporting Files from the Processor via USB

1. Insert a USB flash drive into either of the processor's USB ports.

FIGURE 38. File Management Screen




2. On the right side of the File Management screen, select USB from the drop down menu.
3. On the left side of the screen, press the empty space inside the Local Machine Files window to activate the window.

FIGURE 39. Export Files from Processor

Files on the Processor

Job File



Export File

Export All

4. In the center column, select Export All to transfer all job files to the flash drive.
5. If you do not want to export all files, open the folders under the Local Machine Files until you find the job you wish to export. Select Export File from the center column.


Exporting Files from the Processor via Slingshot

1. Verify that the processor is connected to an Internet source such as:
 - Modem in the tractor (connect to Ethernet Port A on the processor).
 - UHarvest/Slingshot Mobile app (see “Phone Operation” section for connection details).

Note: *If the processor has an Internet source, the Slingshot icon in the header will have a green underline and the processor ID icon will have a blue cloud outline.*

2. Select the Slingshot icon from the header.

FIGURE 40. Slingshot Access Key



3. Enter your unique access key. The access key can be generated from your Slingshot account.

- In your Slingshot account, select Data Access Control from the Share tab.
- In the API Keys section, select Create Key.
- Fill in the required information and check the “Enabled” box.
- Press CREATE to finish.


Note: The access key will only need to be entered once.

FIGURE 41. File Management Screen



4. Go to the File Management screen. On the right side of the screen, select Slingshot from the dropdown menu.
5. On the left side of the screen, press the empty space inside the Local Machine Files window to activate the window.


FIGURE 42. Export Files from Processor



6. In the center column, select Export All to transfer all job files to your Slingshot account.

- If you do not want to export all files, open the folders under Local Machine Files until you find the job(s) you wish to export. Check the corresponding box and select Export Selected from the center column.

FIGURE 43. Successful Slingshot Upload



- A message will confirm the file transfer.

Note: A failed upload may be due to an incorrect access key, lost Internet signal, or as a result of sending a job without load information.

Importing Files to the Processor:

- Insert a USB flash drive into either of the processor's USB ports.

FIGURE 44. Import Files to the Processor




- On the right side of the File Management screen, select USB from the dropdown menu.
- On the right side of the screen, press the empty space inside the USB window to activate the window.
- In the center column, select Import All to transfer all job files to the processor.

5. If you do not want to import all files, open the folders in the USB section until you find the job you wish to import. Press Import Selected from the center column.

Deleting Files from the Processor:

1. Open the folders under Local Machine Files until you find the job you wish to delete. Select the Delete Selection icon from the bottom left corner of the screen.

FIGURE 45. Deleting a Job File



2. Confirm that you want to delete the job file.


Software Updates

If a UHarvest software update is available, the update can be performed with a USB flash drive or over the air if the processor is connected to an Internet source. Always refer to any update instructions provided with the new software files.

Updating Software with a USB Flash Drive:

1. Create the following folders on your flash drive: Raven - GrainCart - Updates. "GrainCart" is one word with no spaces. The file structure is case sensitive, so use the same capitalization.

FIGURE 46. USB Folder Structure



2. Copy and paste the software update file into the Updates folder.
3. Insert the flash drive into one of the UHarvest processor's USB ports.
4. The processor will automatically search the flash drive and will begin updating.


- The update will take several minutes. At the end of the update, the processor will reboot.
 - During the processor update, the LED will turn yellow. Once complete, the processor will reboot and the LED will turn blue.
 - When the processor is preparing to update the ECU, the LED will turn light blue.
 - While the processor is updating the ECU, the processor LED will alternate between blue and green. When complete, the LED will remain blue.

Important: Remove the update file from the flash drive after the update is completed.

Updating Software Over the Air:

- If the processor is connected to an Internet source, go to the File Management screen and select Software Updates.

FIGURE 47. Update from Web Icon



- Select the Update from Web icon to look for available updates.
- If a newer software version is found, the processor will begin to update. The update will take several minutes, and the processor will reboot at the end of the update.


Operation with a Virtual Terminal

Locating UHarvest on the Virtual Terminal

1. Start the tractor or turn the key to run to apply power to the UHarvest system and the virtual terminal (VT).

Note: Upon startup, the processor's LED will be yellow while booting up. The LED will turn blue when it finishes booting.

FIGURE 1. UHarvest VT Icon




2. Go to your VT's menu and select the UHarvest icon depicting a grain cart.

3. Two different UHarvest screens are available.

- Full UHarvest: Available when the ECU and processor are communicating.
- UHarvest Lite: Available when the ECU and Processor are not communicating (refer to "Operation with a Virtual Terminal: UHarvest Lite" on page 67 for more information.)

Note: Upon startup, the VT and ECU are typically booted up before the processor. UHarvest Lite screens may appear briefly on the display but the Full UHarvest will resume once the processor is booted.

FIGURE 2. Full UHarvest vs. UHarvest Lite



Header and Navigation Icon Information

The header and navigation icons are visible on most screens. The header displays current job and connectivity information. The icons can be used to navigate between various UHarvest screens.

FIGURE 3. Header and Navigation Icons




FIGURE 4. UHarvest Header






FIGURE 5. Navigation Icons



Scale Setup


1. Navigate to the Setup screen by selecting the Setup icon.

FIGURE 6. Setup Screen



2. Select “Cart Setup”.

FIGURE 7. Cart Setup Screen



3. In the Load Cell Setup window, enter the appropriate values for your grain cart into all four fields.

- Gain (X.XXX mV/V): The gain value sets the load cell amplifier gain inside the ECU. Use a value of 1.500 mV/V.
- Capacity: The capacity value refers to the overall storage capacity (pounds or kg) of the grain cart.

- Cal Number: The cal number is used to convert the output of the load cells to a known weight. Refer to the table in the appendix for suggested cal numbers.
- Total # of Load Cells: This value reflects how many load cells are on the cart. If the optional 115-9000-022 load cell adapter cable is being used, enter 1 for the total # of load cells.

FIGURE 8. Load Cell Adapter Cable (115-9000-022)





FIGURE 9. Scale Weight Intervals



4. Select your desired scale weight interval from the drop down. Choose 1, 5, 10, 20, or 50 pound increments
5. Select the green check mark to confirm your entries.
6. Go to your ISO VT's settings page and select the weight unit (pounds or kilograms) you wish to use. The UHarvest system will display the weight according to that selection.


Grower Information

Harvest information is saved in a Grower/Farm/Field format. A Field name is entered under a specific Farm name. That Farm is entered under a specific Grower. New information can be entered at any time.

Note: Avoid using special characters (/ \: & ; { } * \$ % |, etc.) in Grower/Farm/Field entries.


Note: Names should be approximately 12 characters or less for the name to fully display on the VT screens.

FIGURE 10. Home Screen




1. From the Home screen, select the Start New Job icon.

FIGURE 11. Grower, Farm, Field Screen



2. Select the Add icon to create a new Grower and then enter the Grower name and hit OK. With a virtual terminal, UHarvest is limited to 30 Growers.

FIGURE 12. Field Entry



3. To enter a Farm underneath a particular Grower, make sure the Grower name is selected from the dropdown menu.
4. Select the Add icon to create a new Farm and then enter the Farm name. Up to 30 Farms can be entered for each Grower.
5. To enter a Field underneath a particular Farm, make sure the correct Grower and Farm names are selected from the dropdown menus.
6. Select the Add icon to create a new Field and then enter the Field name. Up to 30 Fields can be entered for each Farm.
7. Growers, Farms, and Fields and can be deleted by selecting the Delete icon.

Important: *Deleting an entry will also delete any entries underneath it. For example, deleting Grower X will delete all of the Farms and Fields that were entered for Grower X.*


Note: *Grower/Farm/Field entries cannot be deleted if there is a saved job file that utilizes those entries. See the File Management section of this manual for more information on deleting job files.*

Note: *Grower information can be transferred between grain carts by using a flash drive. However, a tablet display is required to use that feature. Refer to the “Operation with a Tablet” section for additional details.*

Starting a Job

Scale information is not available until you start a job. You can either start a brand new job or resume a previous job.


Starting a New Job: FIGURE 13. Starting a New Job



1. From the Home screen, select the Start New Job icon.
2. Select the appropriate Grower, Farm, and Field.
3. Select the appropriate crop.
4. Hit the green check mark to start the job or the red X to cancel.

Resuming an Old Job:

FIGURE 14. Resume an Old Job



1. To quickly resume the job that was active before UHarvest was powered down, press the "Resume Latest Job" button on the home screen.
2. To search for any existing job, press the "Resume Old Job" button on the home screen.
3. Use the dropdown menus on the screen to select the appropriate Grower/Farm/Field for the job you wish to resume.

- Underneath Field, select the file for the specific job. The file name shows the crop, start date, start time, and processor identification number.
- Press the green check mark icon to resume the old job.


Trucks, Destinations and Varieties

You can add more detail to your harvest records by identifying trucks, destinations, and varieties. Once entered, these items are available for every Grower/Farm/Field combination. Each Grower can store up to 30 trucks, 30 destinations, and 30 varieties. Additional entries past 30 will not be stored.

Note: A tablet must be used to delete entries.


Note: Names should be approximately 12 characters or less for the name to fully display on the VT screens.

FIGURE 15. Setup Screen



- Go to the Setup screen and select Database Manager.
- To add a new truck, select the name box under Truck Setup and then enter the new name.

FIGURE 16. Database Manager Screen




3. For trucks, you can also enter the capacity. Select the capacity field and enter the truck's capacity in pounds.
4. After the new name and capacity have been entered, press the add icon to add the new truck to the database.
5. To add a new destination or variety, select the name field under the appropriate section and then enter the new name.
6. Press the Add icon to add the new entry to the database.

Scale Screen

The Scale screen will appear when you first start or resume a job. This screen is the primary interface to the cart's scale. You can monitor total weight, combine verify, hitch weight, load information, and field totals.

FIGURE 17. Scale Screen



- The total weight on the cart is shown as the Load Weight. It is also shown on the bottom progress bar.
- To zero the Load Weight, press the Zero button to the left of the displayed weight and confirm the selection in the pop-up message.
- Press the Load Weight number to toggle to the Combine Verify weight. Combine Verify can be used for combine yield monitor calibration without having to zero the full Load Weight.
- To set the tare for Combine Verify press the Zero button to the left of the displayed weight and confirm the selection in the pop-up message.
- Press the “lbs” or “bu” icon to toggle between pounds and bushels. The bushel calculation uses a standard test weight for the crop.
- The weight on the hitch is shown in the top progress bar. 6000 lbs of hitch weight corresponds to 100% on the progress bar. If the hitch is being overloaded, reposition the cart to transfer some weight away from the hitch.


Note: If the optional 115-9000-022 load cell cable is used, the hitch weight will always be at 0%.

- Running field totals are shown at the bottom of the page.
- Previous loads are shown on the bottom portion of the page. Only the four most recent loads are displayed.

Unload Screen


The Unload screen monitors how much weight is unloaded from the cart. You can also select Truck, Destination, and Variety. Some optional UHarvest features can be controlled from the Unload screen.

FIGURE 18. Unload Screen




- The Unload Weight is displayed at the top of the screen. This represents the weight that was unloaded from the cart during the previous unload event. It is a positive number.
- The Unload Weight will continue to display until the next load is started. When the load starts, the Unload Weight will reset to zero and then count upward as weight is unloaded from the cart.
- Press the lbs or bu icon to toggle between pounds and bushels. The bushel calculation uses a standard test weight for the crop.
- Total load weight and hitch weight can be seen on the progress bars.

FIGURE 19. Grain Flow Animation




- The auger icon in the bottom left corner will display “ENGAGED” and flash when PTO motion is detected.
- Use the dropdown menus to select the desired Truck, Destination, and Variety.
- The Unload Weight Target is linked to each truck or can be entered manually. See the AccuLoad section of this manual for more information.
 - Weight on Truck: Press the Truck Information button (below Truck ID) to view additional information about the truck.
 - The processor remembers how much weight has been dumped onto a truck. This value is subtracted from the truck’s capacity to determine the Target unload weight.
 - This value will be used for AccuLoad, but it can also be used as a reference for operators who do not have the AccuLoad feature.
 - The Weight on Truck value automatically resets to zero once the value is within 3% of the truck’s capacity.
 - The weight on truck value can be manually set to zero by pressing the Reset button.

FIGURE 20. Target Weight Calibration



- The Weight Sent field is linked to Destination. It will display how much weight has been sent to each Destination during the job.

FIGURE 21. Spout Center Icon




- The Spout Center icon is used for carts with optional spout centering. See the Spout Centering section for more information.

Manual Load Logging

In the event that the PTO sensor is damaged or missing, a manual logging feature is available.


FIGURE 22. Manual Load Logging Screen



1. On the Setup screen, check Manual Load Logging.

Note: Accuload will be disabled while UHarvest is in manual logging mode.

FIGURE 23. Manual Logging Icon



2. A start/stop recording button will be available on the Unload screen.


3. Press the record (triangle) icon to start recording.

4. Press the stop recording (square) icon to stop recording.

Report Screen

The Report screen shows an extensive list of information for every load in the job. Scroll up and down to view more loads. Scroll left or right to see more information for each load. Running field totals are shown at the bottom of the screen.

FIGURE 24. Report Screen




- Load ID: The load ID starts at 1 and will increment upward with each new load.
- Weight: The weight unloaded from the cart. Depending on the selected units, this value will be in pounds or kilograms.
- Truck ID: The name of the truck used during the load.
- Moisture: Average moisture for the load. If the cart does not have a moisture sensor, the moisture column will display low moisture content.
- Test Weight: Test weight for the load. A standard test weight is used for each crop, but test weight can be edited on the Report screen if necessary. Depending on the selected units, the value will be in lbs/bu or kg/hL.
- Destination: Where the truck is taking the grain.
- Variety: The crop variety in that load.
- Wet Bu.: Conversion from pounds to bushels using the test weight. If metric units are selected, the Wet Bushel column is labeled “kg” and the value will match the first Weight column.
- Dry Bu.: Conversion from wet bushels accounting for the measured load moisture. If the cart does not have a moisture sensor, the dry bushel value will equal the wet bushel value. If metric units are selected, this column will display “Dry kg.”
- Time: The time when the load occurred. The time is listed using Coordinated Universal Time (UTC).
- Running field totals: Shows field weight, average moisture, and field dry bushels (or dry kg).

Scale Calibration


1. Go to the Setup screen.

FIGURE 25. Calibration Section of Setup screen



2. Verify that Weight Calibration is selected instead of Moisture Calibration.

FIGURE 26. Scale Calibration



3. Press the Certified Weight field and enter your known weight. (Example: elevator scale ticket)
4. Press the Load Weight field and enter the weight measured by the grain cart scale.
5. After entering the two weights, a new cal number will be calculated. Hit the "CAL" button to apply the new value.


Important: The new calibration value will not apply until the "CAL" button is pressed. After the new value is applied, it will appear in the Current Cal location.

6. The load cell calibration number can also be manually entered in the Load Cell Setup screen.

Moisture Calibration

1. Go to the Setup screen.
2. Verify that Moisture Calibration is selected instead of Weight Calibration.

FIGURE 27. Moisture Calibration



3. Verify that Moisture Calibration is selected instead of Weight Calibration.
4. Press Certified Moisture field and enter the known moisture.
5. Press Load Moisture field and enter the moisture measured by UHarvest.
6. After entering the two moistures, a new offset number will be calculated. Hit the "Cal" button to apply the new value.

Important: The new calibration value will not apply until the "CAL" button is pressed. After the new value is applied, it will appear in the Current Offset location.

Editing Load Information


The load editing feature is not available with an ISO VT. It is only available with a tablet.

Operating AccuLoad

The optional AccuLoad feature can be used to automatically open and close the grain flow gate to achieve a target unload weight.

1. Time how long it takes to open and close the flow gate using the tractor's hydraulic lever.


FIGURE 28. AccuLoad Settings



2. In the Cart Setup screen, enter the open and close times into the AccuLoad Tune section.
3. Enter the desired open percentage. This setting controls how far AccuLoad will open the gate. For faster unloading times, use a higher open percentage.
4. Enter the minimum RPM value. AccuLoad will not open the gate until the PTO is spinning at or above this setting.

Note: Select an RPM value that will protect the tractor's engine from stalling when the grain gate is fully opened. 750 RPM is a good starting point.

FIGURE 29. Unload Weight Target



5. On the Unload Screen, enter a target unload weight. The target is linked to the truck's capacity or you can manually enter a weight by selecting the AccuLoad Target field.

Note: Unless manually entered, the target weight will be automatically calculated as the difference between the Truck Capacity and the current Weight on Truck.

6. Use the Auto/Manual button to toggle AccuLoad to Auto mode.


Note: You cannot enter Auto mode if the gate close hose is pressurized or if the cart is configured for manual load logging.

FIGURE 30. AccuLoad Mode Button

Auto Mode



Manual Mode



7. When you are in Auto mode and ready to unload grain, detent the tractor's hydraulic lever to the gate open position. The AccuLoad valve will hold the gate closed.
8. Engage the tractor's PTO and increase the engine speed.
9. Once the minimum RPM setting is reached, the AccuLoad valve will drive the gate open.
10. As the unload weight approaches the target weight, the AccuLoad valve will begin to close the gate.
11. When the target is reached, the AccuLoad valve will hold the gate closed.
12. Decrease the engine speed and disengage the PTO.
13. Return the tractor's hydraulic lever to neutral.
14. AccuLoad can be overridden at any time by moving the tractor's hydraulic lever to the close position. This triggers a pressure switch and causes AccuLoad to return to manual mode.


Note: AccuLoad will remain in Auto mode unless the button is toggled to Manual or if the hydraulic lever is moved to the close position.

Spout Centering

Optional spout centering control is available for some grain carts. This feature can be used to return the spout to a designated "center" position prior to unloading or folding.


1. Go to the Cart Setup screen and select the Spout Cal icon.

FIGURE 31. Spout Cal Icon




2. Identify the tractor's hydraulic lever that supplies the joystick's electric over hydraulic (EOH) valve and detent the lever to pressurize the EOH valve.
3. With the auger unfolded, use the joystick to maneuver the spout to each end point (In, Out, Front, Rear) and press the corresponding arrow to save that value.

FIGURE 32. Spout Calibration



4. Maneuver the spout to the desired "center" position and press the target icon to set the center point.

FIGURE 33. Spout Center Icon



5. On the Unload screen, the spout center icon can be used to return the spout to the set center position.

Note: The spout will not move unless the EOH valve is pressurized.

Steerable Duals

For grain carts with in-line steerable duals, the UHarvest screen can be used instead of a switch box. Connect the steerable duals cable to the “STEERABLE DUALS” connector on the ECU cable. The steerable duals icon can be found with the navigation icons on the right side of the screen.

1. Navigate to Setup > Cart Setup.
2. Check the “Steerable Duals Installed” box to enable this feature.

FIGURE 34. Steerable Duals Setup





FIGURE 35. Steerable Duals Icon



- Toggle to the “unlock” position to allow the grain cart to trail the tractor.
- To lock the current steering position, toggle to the “lock” position and detent the tractor’s hydraulic remote lever.
- To manually steer the tandem, toggle to the “lock” position and use the hydraulic lever to turn the wheels.

Diagnostics Screen

FIGURE 36. Diagnostics Screen




The Diagnostics pages can be used for troubleshooting and checking software versions. See the Troubleshooting chapter of this manual for more information.

File Management

Exporting Files from the Processor via USB:


1. Insert a USB flash drive into either of the processor’s USB ports.

FIGURE 37. File Transfer



2. On the Home screen, select the File Management button.

FIGURE 38. Successful file Transfer



3. Press the “Transfer All Files” button. All job files will copy to the flash drive.
4. A popup window will appear after a successful transfer.


Exporting Files from the Processor via Slingshot:

Files cannot be exported to Slingshot using a virtual terminal. Slingshot access is only available through a tablet or phone. See the Tablet Operation and Phone Operation chapters for more information.

Importing Files to the Processor:

Files cannot be imported using an ISO VT as the sole display. A tablet must be used to import files. See the Tablet Operation chapter for more information.

Deleting Files From the Processor: FIGURE 39. Deleting an Old Job



1. Use the dropdown menus on the File Management screen to select the appropriate Grower/Farm/Field for the job you wish to delete.
2. Underneath the Field, select the file for the specific job. The file name shows the crop, start date, start time, and processor identification number.
3. Press the Delete File icon to delete the selected file.

FIGURE 40. Delete Confirmation




4. A confirmation window will pop up. Select the green check mark to confirm the deletion.

Operation with a Virtual Terminal: UHarvest Life

Loading UHarvest Lite on the Virtual Terminal

1. Start the tractor or turn the key to run to apply power to the UHarvest system and the Virtual Terminal (VT).

FIGURE 1. UHarvest Lite Icon




2. Go to the VT menu and select the UHarvest icon depicting a grain cart.

Navigation Icon Information

The navigation icons are visible on most screens and can be found along the right side of the screen.


FIGURE 2. Navigation Icons



Scale Setup

1. Navigate to the Setup screen by selecting the Setup icon.

FIGURE 3. Cart Setup Screen




2. In the Load Cell Setup window, enter the appropriate values for your grain cart in the four fields.
 - Grain (X.XXX mV/V): The gain value is the rated output of the cart's load cells. This information can typically be found on a sticker on the load cell. If the gain is not known, enter a value of 1.500 mV/V.
 - Capacity: The capacity value refers to the overall storage capacity (pounds or KG) of the grain cart.
 - Cal Number: The Cal number is used to convert the output of the load cells to a known weight. Refer to the table in the appendix for suggested cal numbers.
 - Total # of Load Cells: This value reflects how many load cells are on the cart. If the optional 115-9000-022 load cell adapter cable is being used, enter 1 for the total number of load cells.
3. Select the desired scale weight interval from the drop down. Choose 1, 5, 10, 20, or 50 pound increments.

Scale Screen

The scale screen is the first screen that will appear upon startup. This screen is the primary interface to the cart's scale. You can monitor total weight, percentage of capacity, and hitch weight.

FIGURE 4. Scale Screen




- The total weight on the cart is shown as the Load Weight in large font near the center of the screen. It is also shown on the bottom progress bar.
 - To zero the load Load Weight, press the Zero softkey and confirm the selection in the pop-up message.
 - The weight on the hitch is shown in the top progress bar. 6,000 lbs of hitch weight corresponds to 100% on the progress bar. If the hitch is overloaded, reposition the cart to transfer some weight away from the hitch.
- Note:** If the optional 115-9000-022 load cell cable is used, the hitch weight will always be 0%.
- The most recent load's weight is shown at the bottom of the screen. This value will be updated with every new load.

Combine Verify Screen

The Combine Verify screen can be used for combine yield monitor calibration without having to zero the full load weight.

FIGURE 5. Combine Verify Screen




- To set the tare for the Combine Verify, press the Zero softkey and confirm the selection in the pop-up message.
- The total weight on the cart is shown in the bottom progress bar.
- The hitch weight is shown in the top progress bar.
- The most recent load weight is shown at the bottom of the screen.

Unload Screen

The Unload screen monitors how much weight is unloaded from the cart. The screen cannot be directly accessed and is only available if UHarvest Lite detects PTO motion.

FIGURE 6. Unload Screen




- Once PTO motion is detected (>300 RPM), UHarvest Lite automatically displays the Unload screen.
- While the PTO is engaged, most screens are unavailable. The Unload and Diagnostics screens are the only screens that can be viewed during a load.
- The Unload Weight is displayed near the center of the screen. This represents the weight unloaded from the cart during the load.
- With each new load, the Unload Weight value resets to zero and counts up as weight is unloaded from the cart.
- An auger icon is shown to the left of the Unload Weight. This icon will flash during the course of the load.
- Total load weight and hitch weight can be seen on the progress bars.
- The previous load weight is shown at the bottom of the screen.

Report Screen

The Report screen shows a list of past loads that are currently stored in the ECU's memory.

FIGURE 7. Report Screen




- **Weight:** The weight unloaded from the cart. Depending on the selected units, this value will display in pounds or kilograms.
- **Date:** The month/date/year when the load occurred. This value is determined by the VT's calendar setting. If the date is inaccurate, check the VT's settings. If a date is not displayed, the VT is not properly communicating the date to the ISOBUS.
- **Time:** The time when the load occurred. This value is determined by the VT's clock. If the time is inaccurate, check the VT's settings. If a time is not displayed, the VT is not properly communicating the time to the ISOBUS.
- **Scroll up or down** to view more loads. The most recent loads are at the top of the list.
- UHarvest Lite can remember and display up to 400 loads. Refer to the File Management section for more information about system memory capabilities.

Scale Calibration

1. Go to the Setup screen.

FIGURE 8. Load Cell Calibration



2. In the Weight Calibration area, press the Certified Weight field and enter the known weight. (i.e. Elevator scale ticket).
 3. Press the Load Weight field and enter the weight measured by the grain cart scale.
 4. After entering the two weights, a new cal number will be calculated. Press the CAL softkey to apply the new value.
- Important:** *The new calibration value will not apply until the CAL softkey is pressed. After the new value is applied, it will appear in the Current Cal location.*
5. The load cell calibration number can also be manually entered in the Load Cell Setup section at the top of the screen.

File Management

The UHarvest Lite system will record the load when it detects PTO motion. The ECU can save up to 400 loads. Go to the File Management screen to monitor the storage status, delete old loads, and export files. The file export feature is only available on some ISO virtual terminals. Visit uharvest.net for more information on compatible VTs.

FIGURE 9. File Management Screen




Monitor Storage

The UHarvest Lite system will provide alerts when memory approaches capacity. The background of the File Management navigation icon will be blue, yellow, or red depending on the number of loads in memory. The File Management screen will also show the exact number of loads in memory.

- When the icon is blue (0-349 loads), the next new load will be recorded and all old loads will be retained.
- When the icon is yellow (350-399 loads), the next new load will be recorded and all loads will be retained. However, the ECU is nearing maximum saved load capacity.
- When the icon is red (400 loads), the new load will be recorded but the oldest load will be permanently deleted to create storage space for the new load.

FIGURE 10. Navigation Icon Backgrounds



Deleting Loads

1. Navigate to the File Management screen.
2. Press Delete All Loads. A confirmation pop-up will open.
3. Press the check mark softkey to delete the loads.

Important: *This will erase all loads from memory. They cannot be recovered.*

Exporting Files (Compatible VTs Only)

1. Insert a removable memory device. (i.e. Data card or USB flash drive) into the ISO VT's access port.
 2. Go to the file management screen.
 - If an Export softkey is visible, the ISO VT supports file transfer functionality.
 - In an Export softkey is not visible, the ISO VT does not support file transfer functionality. Load information can be viewed on the Report screen.
 3. Press the Export softkey to transfer load information to the memory device.
- Note:** *The export process may take up to 20 seconds.*
4. After pressing Export, a pop-up screen will show the results.

- Successful: A file was written to the memory device and the loads still exist in the ECU memory.
- Failure: The file was not written to the memory device. Potential causes include a full memory device or corrupted memory on the device. Try again using a different memory device.

Exported File Contents (Compatible VTs Only)

The exported file will be a Comma Separated Value (.CSV) file, and the name is based on details of the most recent load within the file (i.e. 06-06-15UHARVEST12-25-PM000437.CSV). In this example, the most recent load in the file occurred on June 6, 2015 at 12:25 p.m. The load is the 437th load that occurred during the ECU's lifetime. If the VT does not properly report a date or time for the load, there may be NoDate or NoTime in the file name.

FIGURE 11. Exported File Example

	A	B	C	D	E
1	UHarvest Light Version	1.0			
2	Weight(lbs)	Date	Time	Load ID	
3	61548	6/6/2015	9:08 AM	433	
4	58236	6/6/2015	10:03 AM	434	
5	59231	6/6/2015	10:48 AM	435	
6	60843	6/6/2015	11:59 AM	436	
7	37610	6/6/2015	12:25 AM	437	
8					
9					
10					

The load number increments upward and is unique to each load. This number cannot be reset even if you delete all of your loads from the ECU. For example, if you delete your first 100 loads, the next load will be load number 101 rather than load number 1.

Double-click the file name or use the browser in Excel to open the file. The table will show the weight in pounds, the date, the time, and the load ID number for every load that was stored in the ECU at the time of the file transfer. The oldest load will be shown at the top of the table.

Upgrade to Full UHarvest

UHarvest Lite can be easily upgraded to full UHarvest. If you have already purchased an upgrade kit, refer to the Cab Component Installation section for installation instructions. To learn more about upgrade options, contact your local Unverferth dealer. Full UHarvest features include:

- View grain cart information on a virtual terminal, tablet, and smartphone.
- Create specific jobs in a grower/farm/field structure.
- Record truck, destination, and variety information for each load.
- Send job files to your Raven Slingshot account and create harvest reports.
- Optional moisture sensor for logging moisture content and dry bushels.
- Optional AccuLoad feature for automatic gate control.

Operation with a Smart Phone

UHarvest can be viewed on a smart phone. Due to smaller screen sizes, the phone view has fewer functions than the tablet view. The phone view can be used to transfer job files and to view scale and report information. Adding grower information, starting jobs, calibrating the scale, and manipulating other data must be done on a tablet or ISO VT.

Phone Connections

The phone can connect to the processor via Wi-Fi or Bluetooth. The Bluetooth connection requires the UHarvest/Slingshot mobile app (available at the Apple store). With the UHarvest/Slingshot mobile app, the processor uses the phone's data plan to send UHarvest jobs to Slingshot. This app is also available for iPads with data plans. Since the Bluetooth connection is typically slower than the Wi-Fi connection, choose the appropriate connection type for the task at hand:

- Bluetooth connection (with App): primarily for transferring files to Slingshot.
- Wi-Fi connection: primarily for viewing the scale and looking at past load information.

Connecting via Bluetooth

The following steps apply to smart phones and tablets that are utilizing the UHarvest/Slingshot mobile app.

1. Download the UHarvest/Slingshot mobile app from the app store.

FIGURE 1. Mobile App Icon




2. Power on the UHarvest system.
3. Go to the device's network settings screen.
4. Turn Bluetooth and Personal Hotspot on.
5. On the Bluetooth page, select "uharvest-xxxx" from the available networks list. The last four characters in the network name are unique to each UHarvest processor.

Note: *This process is only required for the initial connection between the mobile device and the processor.*

Note: *The uharvest-xxxx information can be found on one of the processor's stickers.*

6. The status will change to "Not Connected".

FIGURE 2. Bluetooth Settings




7. Open the UHarvest app. A list of UHarvest processors in range will display.

8. Press the green “Connect” button to complete the connection.


Note: *If a yellow “setup” button is shown behind a network, the connection on the Bluetooth page has not been completed successfully.*

FIGURE 3. Network Selection



9. Once the app has connected to the processor, a blue bar should appear at the top of the screen to indicate that a personal hotspot is active. A red “Disconnect” softkey should appear behind the network name. The network name should be a gray softkey.

FIGURE 4. Connected




10. Press the network name (gray button) to launch the processor screens and view the grain cart information.
11. After viewing the cart information, press the “Done” softkey to return to the network selection screen.
12. Press the “Disconnect” softkey to break the connection between the device and the processor.

Connecting via Wi-Fi


1. Power the UHarvest system.
2. Go to the phone’s Wi-Fi network page.
3. Select “uharvest-xxxx” from the list of available networks. The first four characters in the network name are unique to each UHarvest processor.
Note: *The uharvest-xxxx information can be found on one of the processor’s stickers.*
4. Enter the password. This is only required for first time connections. The default password is “uharvest”.
5. Open the phone Internet browser and enter 192.168.100.254/newphone into the address bar.
6. Press go. The UHarvest processor will direct you to the UHarvest application page.
7. Select “Add to Home Screen” in the browser settings.

FIGURE 5. Browser and Add to Home



- 8. Close the Internet browser and return to the phone's home screen.
- 9. Select the UHarvest icon.

FIGURE 6. Wi-Fi Shortcut



Phone Screen Navigation

The phone has four screens: File Transfer, Scale, Report, and Setup/Diagnostics. The navigation icons are found at the bottom of the screen.

FIGURE 7. Navigation Icons




File Transfer

To transfer files:

1. Select the desired destination from the drop down menu at the top-right corner of the screen.

Note: *The Slingshot transfer requires an Internet connection via the UHarvest/ Slingshot mobile app or an Internet modem connected to the processor.*

FIGURE 8. File Transfer Screen



2. To send files to Slingshot:

- a. In your Slingshot account, select Data Access control from the Share tab.
- b. In the API keys section, select Create Key.
- c. Fill in the required information.
- d. Check “Enabled”.
- e. Press Create.
- f. In the UHarvest phone view, press the Slingshot button then enter the alpha-numeric access key as it appears on your Slingshot account.

Note: *The access key will only need to be entered once.*

3. Press “jobs” to view the folders on the processor.

4. To transfer specific files, check the box next to the name of the job and press “Export”.


5. To transfer all files to a destination, press “Export All”.

6. To delete files, check the box by the desired file and press “Delete”. A popup window will open asking you to confirm the action.

Scale Screen

Use the scale screen to monitor the load weight on the cart. It also shows the current job description and field totals.

FIGURE 9. Scale Screen and Combine Verify



- The active job description (Grower, Farm, Field, Crop) is shown at the top of the screen.
 - The load weight shows the total weight on the cart. This value is repeated in the bottom progress bar.
 - The weight on the hitch is shown in the top progress bar. 6000 lbs. of hitch weight corresponds to 100% on the progress bar. If the hitch is being overloaded, reposition the cart to transfer some weight away from the hitch.
- Note:** If the optional 115-9000-022 load cell cable is being used, the hitch weight will always be at 0%.
- Press the Load Weight number to toggle to Combine Verify Weight. Combine verify can be used for combine yield monitor calibration without having to zero the full load weight.
- Note:** To set the Combine Verify tare, press the zero button next to the weight value and then Confirm.
- Running field totals are shown at the bottom of the screen.

Report Screen

Use the report screen to view information about individual loads within a job.

FIGURE 10. Report Screen

The screenshot shows the UHARVEST Report Screen. At the top, it displays the Verizon logo, signal strength, time (4:26 PM), and battery level (52%). Below the header, there are three summary columns: Field Wt (lbs), Avg Mois %, and Field Dry Bu. The values are 265,374, 17, and 5,341 respectively. Below this is a table of individual loads with columns: L, Wt (lbs), Truck, Moisture, and Test. The table contains 11 rows of data, with load IDs 16 down to 6. At the bottom, there are icons for home, back, list, and settings.

Field Wt (lbs)	Avg Mois %	Field Dry Bu
265,374	17	5,341

L	Wt (lbs)	Truck	Moisture	Test
16	8,159.0	Truck 2	17.4%	48.0
15	12,981.9	Truck 1	17.4%	48.0
14	11,756.9	Truck 1	17.4%	48.0
13	19,625.6	Truck 1	17.4%	48.0
12	12,664.3	Truck 1	17.4%	48.0
11	11,906.4	Truck 1	17.4%	48.0
10	23,099.8	Truck 2	17.4%	48.0
9	13,164.3	Truck 2	17.4%	48.0
8	15,194.0	Truck 1	17.4%	48.0
7	14,371.6	Truck 1	17.4%	48.0
6	20,997.5	Truck 3	17.4%	48.0

- Running field totals are shown at the top of the screen.
- Individual loads are listed in a table. Scroll up and down to view more loads.
- “L”: Corresponds to the load ID number. This starts at 1 and will increment upward.
- “Wt (lbs)” or “Wt (kg)”: The weight unloaded from the cart.
- “Truck”: The name of the truck used during the load.
- “Moisture”: Average moisture for the load.
- “Test”: Test weight for the load. If imperial units are selected, the value is in lbs/ bu. If metric units are selected, the value is in kg/hL.

Setup/Diagnostics Screen

Use the Setup/Diagnostics screen for basic setup and troubleshooting.

FIGURE 11. Setup/Diagnostics Screen

The screenshot shows the UHARVEST Setup/Diagnostics Screen. At the top, it displays the Verizon logo, signal strength, time (4:26 PM), and battery level (51%). Below the header, there are several sections. Section 1 (Hitch Voltage) shows 0.531 mV. Section 2 (Axle Voltage) shows 0.151 mV. Section 3 (Moisture Voltage) shows 2.500 V. Temperature Voltage shows 2.800 V. Auger Rotation shows 0 RPM. Below this is a table of software components and revisions. At the bottom, there are configuration options for Units (LBS) and Scale Interval (5). At the very bottom, there are icons for home, back, list, and settings.

Hitch Voltage	0.531 mV
Axle Voltage	0.151 mV
Moisture Voltage	2.500 V
Temperature Voltage	2.800 V
Auger Rotation	0 RPM

Component	Revision
ECU Software	1.03.06
Processor Software	1.2.0-b725

Config

Units: LBS ▾

Scale Interval: 5 ▾


- Table 1 shows diagnostic values for: hitch load cell voltage, axle load cell voltage, moisture sensor's moisture voltage, moisture sensor temperature voltage, PTO speed.
- Table 2 shows the ECU and processor software versions.
- Table 3 has drop-downs for unit selection and scale weight intervals.

Viewing the Job File in Excel

Job File


1. Open Excel on your computer.
2. Select File and then Open.
3. Navigate to the folder where the job file is stored.

FIGURE 1. Change File Type




4. In the bottom right corner of the popup window, change from “All Excel Files...” to “All Files...”.
5. Select the job file (.grc) you wish to view.
6. Since the job file is not in Excel format, a configuration wizard will appear.

FIGURE 2. Page 1 of Text Import Wizard



7. On the first page of the wizard, ensure that “Delimited” is selected.

FIGURE 3. Page 2 of Text Import Wizard



8. On the second page of the wizard, check the boxes for “Tab” and “Comma”.
9. Select “Finish”.

FIGURE 4. Job File in Excel

LoadNumber	Weight	TruckID	Destination	MeasuredMoisture	MoistureCorrection	Moisture	TestWeight	WetBushels	DryBushels	Variety	UTC Date	UTC Time	Latitude	Longitude	LoadCellCAL	LocalDate	LocalTime
1	1155.76	underlined	underlined	7.4	0	7.4	30	38.52	38.52	underlined	11/1/2013	17:02:29	43.55092	-96.72033004	252812	11/1/2013	12:01:29
2	2152.38	Truck 2	Dest 2	7.4	0	7.4	29	70.4	70.4	Var 2	11/1/2013	17:03:49	43.55092	-96.72033004	252812	11/1/2013	12:01:30
3	3404.87	Truck 3	Dest 3	7.4	0	7.4	30	113.5	113.5	Var 3	11/1/2013	17:03:44	43.55092	-96.72033004	252812	11/1/2013	12:01:44
4	1219.71	Truck 3	Dest 3	0	0	0	30	41.22	41.22	Var 3	11/1/2013	17:04:14	43.55092	-96.72033004	252812	11/1/2013	12:04:14
5	2118.17	Truck 3	Dest 3	7.4	0	7.4	30	70.95	70.95	Var 3	11/1/2013	17:04:19	43.55092	-96.72033004	252812	11/1/2013	12:04:19
6	1545.11	Truck 3	Dest 3	7.4	0	7.4	30	51.5	51.5	Var 3	11/1/2013	17:04:24	43.55092	-96.72033004	252812	11/1/2013	12:04:24
7	1320.33	Truck 3	Dest 3	7.4	0	7.4	30	45.18	45.18	Var 3	11/1/2013	17:04:28	43.55092	-96.72033004	252812	11/1/2013	12:04:28
8	2475.87	Truck 3	Dest 3	7.4	0	7.4	30	82.38	82.38	Var 3	11/1/2013	17:04:34	43.55092	-96.72033004	252812	11/1/2013	12:04:34
9	2561.26	Truck 3	Dest 3	7.4	0	7.4	30	83.38	83.38	Var 3	11/1/2013	17:04:39	43.55092	-96.72033004	252812	11/1/2013	12:04:39
10	1785.65	Truck 3	Dest 3	7.4	0	7.4	30	392.19	392.19	Var 3	11/1/2013	17:04:47	43.55092	-96.72033004	252812	11/1/2013	12:04:47
11	850.8	Truck 3	Dest 3	7.4	0	7.4	30	295.29	295.29	Var 3	11/1/2013	17:04:59	43.55092	-96.72033004	252812	11/1/2013	12:04:59
12	11422.6	Truck 1	Dest 1	7.4	0	7.4	30	380.75	380.75	Var 3	11/1/2013	17:05:13	43.55092	-96.72033004	252812	11/1/2013	12:05:13


10. The job file for the field is ready to be viewed.

Viewing Jobs in Slingshot

Slingshot provides online data storage and analysis. You can use Slingshot to create PDF reports, merge data from multiple grain carts and/or fields, and more. Visit www.uharvest.net for more information.

Note: UHarvest Lite files cannot be viewed in Slingshot.

FIGURE 1. Slingshot Report



Viewing the License Agreement

The end user license agreement can be viewed at any time through a tablet or a virtual terminal. Select File and then Open.

- Tablet: Go to the Diagnostics screen and select “End User License Agreement”.
- VT: Go to the Setup screen and select “End User Agreement”.

The UHarvest software utilizes open source code. The licenses for the open source code can be retrieved from the processor. In the license agreement, the UHarvest processor is referred to as the “Grain Cart bridge”. From section 2.4 of the license agreement:

“2.4 The license agreements for the open source code listed in the Appendix have been shipped with the software binaries on the Grain Cart bridge. To retrieve the license texts please use the following procedure:

1. Identify a USB thumb drive that you intend to use to retrieve a copy of the licenses from the Grain Cart bridge.
2. Please insure that this USB thumb drive has been formatted to use the file system type fat32.
3. Please insure that this USB thumb drive has at least 100 MB of space available.
4. Please create a folder in the top level directory of the USB thumb drive with the name upload_license. This folder must be named exactly upload_license using all lower case characters and an underscore.
5. Please insert the USB thumb drive into the USB port on the Grain Cart bridge. The Grain Cart LED will turn amber while the license text file is being copied.
6. Please wait until the Grain Cart LED turns back to blue before removing the USB thumb drive.

The open source license agreements and any additional, necessary documentation may then be viewed on any computer that accepts “thumb drives”.

Troubleshooting

Tablet Wi-Fi Connection

The UHarvest processor provides a Wi-Fi signal for a tablet. If the tablet cannot connect to Wi-Fi:


- Verify that the tablet's Wi-Fi setting is enabled.
- Verify that the UHarvest network is selected in the tablet's Wi-Fi settings.
- Verify that the processor is powered.
- Verify that the processor's antenna is connected.
- In the tablet's settings, forget the UHarvest network and retry. You will need to provide the network password again.
- If the Wi-Fi password was changed and then forgotten, contact Unverferth technical support.
- Consult your tablet's manual for more information about its Wi-Fi settings and capabilities.

UHarvest Display on Virtual Terminal

The UHarvest screens for the VT are generated by the ECU. If UHarvest is not available through the VT:

- Verify that the ECU has HC power and Logic power.
 - Check the fuses on the ECU harness.
- Check the ECU harness on the grain cart and verify that a CAN terminator is installed near the ECU.

FIGURE 1. CAN Terminator




- For non-ISO tractors, verify that a CAN terminator is installed on the supplied ISO cable.
- Check the tractor's fuse panel for any blown power fuses.
- Verify that the VT is set up as instance #1. The UHarvest ECU will not appear on a VT if it is set for another instance number.

Processor and ECU Communication

Tablet Communication

For important information, the tablet will display a yellow alert icon in the bottom right corner of the screen. Press the icon for more details. If communication is lost between the processor and ECU, “ISO Node not responding” will be displayed.

FIGURE 2. Tablet Alert Message



If the tablet shows an error:

- Press the Home icon to refresh the system.
- Cycle power on the system.
- Verify that the ECU has HC power and Logic power.
 - Check the LEDs on the ECU.
 - Check the fuses on the ECU harness.
- Verify that the ECU harness is properly connected to the tractor's ISO connector.
- Verify that the CAN connector is plugged into port A of the processor and not port B.
 - CAN connector should have a green wire on pin 4 and a yellow wire on pin 2.
- Check the ECU harness on the grain cart and verify that a CAN terminator is installed near the ECU.
- For non-ISO tractors, verify that a CAN terminator is installed on the supplied ISO cable.
- Check the tractor's fuse panel for any blown power fuses.

ISO VT Communication

A green check mark icon in the header indicates that the UHarvest processor and ECU are communicating properly. If there is a loss of communication between the two, the icon will display a red X. If communication loss persists for more than 45 seconds, the VT screen will change to UHarvest Lite mode.

FIGURE 3. ISO VT Icons



If the red X or UHarvest Lite screens are displayed on the VT:

- Cycle power on the system.
- Verify that the processor is powered.
 - +12V on pin 1 and Ground on pin 2
- Verify that the CAN connector is plugged into port A of the processor and not port B.
 - CAN connector should have a green wire on pin 4 and a yellow wire on pin 2.
- Check the tractor's fuse panel for any blown power fuses.

Tablet Charging

If your tablet is not charging at all while connected to the UHarvest processor:

- Ensure a good connection between the tablet and the processor's USB port.
- Try connecting to the processor's second USB port.

Scale

FIGURE 4. Load Cell Junction Box





FIGURE 5. Load Cell Connector Pinout



If the scale is unresponsive to weight changes on the grain cart:

- Verify that non-zero values have been entered for load cell gain, number of load cells, and calibration number.
- Check for weigh bar voltages in the Diagnostics page.
- Verify all connections at the load cell junction box.
- Verify the homerun cable connection between the junction box and the ECU cable.
- Verify that the ECU has HC power and Logic power.
 - Check the LEDs on the ECU.
 - Check the fuses on the ECU cable.
- Verify that the ECU cable is properly connected to the tractor's ISO connector.
- Check for 5V power across pins 1 and 12 of the green "JUNCTION BOX" connector on the ECU cable.

If the scale is inaccurate or unstable:

- Recalibrate the scale system.
 - Use the average values from multiple loads to determine the calibration number.
- Verify that the correct values were entered for load cell gain and number of load cells.
 - If you edit those values, recalibration will be required.
- Verify that all of the load cells are connected to the junction box.
- Check the load cell cables for loose or broken wires.

- Disconnect all but one load cell.
 - Stand or hang your weight above that load cell and observe the weight change on the scale.
 - The weight change should be positive and stable.
 - Even with a good load cell, the weight will probably be inaccurate due to the other load cells being disconnected from the system.
 - Repeat this procedure with each individual load cell to see if there is a faulty load cell in the system.
- Connect a suspected faulty load cell to a different port of the junction box.
 - If the load cell signal is improved on the different port, the junction box may need to be replaced.

If the hitch weight is not displayed:

Check for hitch weight voltage in the Diagnostics page.

- Verify that the hitch load cell is connected to the “HITCH” port of the junction block.
- Check the hitch load cell cable for loose or broken wires.
 - Verify that the hitch load cell is powered.
 - Check for 5V power across pins 1 and 4 of the HITCH port of the junction box.
 - Check for 5V power across pins 1 and 12 of the green “JUNCTION BOX” connector on the ECU cable.
- The optional 115-9000-022 load cell merges the hitch load cell signal with the axle load cell signals. The hitch weight on the UHarvest display will always show 0.

Recording

FIGURE 6. PTO Sensor and Target



If UHarvest does not record your loads:

- In the Diagnostics screen, watch the auger rotation measurement.
 - The speed should be 0 rpm when the PTO is off.


- The speed should increase when the PTO is engaged.
- The speed should increase or decrease accordingly when the PTO speed changes.
- If the PTO speed is detected, check if UHarvest is in manual load logging mode.
 - In manual load logging mode, the start/stop button is the primary recording device.
- If PTO speed is not detected in the Diagnostics screen, check the LED on the PTO sensor.
 - The light should turn on when the target is detected and turn off when the target is not detected.
- Check the clearance between the PTO sensor and the target.
 - The clearance should be 1/16" to 1/4".
- Verify that the PTO sensor is powered.
 - There should be 12V across pins B and C of the PTO sensor connector.
- Check the PTO sensor cable for loose or broken wires.

If UHarvest records multiple small loads in place on one large load:

- Check the clearance between the PTO sensor and target. The sensor may be at the edge of its functional detection range.
- The clearance should be 1/16" to 1/4".

AccuLoad

FIGURE 7. AccuLoad Hydraulic Schematic



AccuLoad Demo Mode

An AccuLoad Demo mode is available to allow troubleshooting without running grain through the auger. The Demo mode will simulate a weight change and open or close the gate accordingly. The Demo mode should be used to troubleshoot electrical and hydraulic connections. Troubleshooting the accuracy of AccuLoad should be done outside of Demo mode.

1. Go to the Load Cell Setup section of the tablet or ISO VT.
2. Enter 400,000 as the Capacity. This is the code to enter the AccuLoad Demo mode. It will not overwrite your existing capacity entry.

Note: *“DEMO MODE” will be displayed in the header.*

3. Go to the Unload screen and enter a target unload weight.
4. Enable Auto mode and move the tractor’s hydraulic lever to the “gate open” position. The AccuLoad valve will hold the gate closed.
5. To start the simulated unload event, press the Spout Center button.

Note: *Do not start the tractor’s PTO. The PTO sensor is ignored during Demo mode.*

6. The simulation will begin to show that grain is being unloaded from the cart. The gate should open and remain open for the majority of the load. As the target weight approaches, the AccuLoad valve will begin to close the gate.
7. Once the target weight is reached, the gate will be fully closed. Press the Spout Center button again to end the simulation.
8. Observe the troubleshooting steps in the following sections if AccuLoad behaves abnormally. Repeat the simulation as needed.
9. When you are finished with Demo mode, go to the Load Cell Setup screen and re-enter 400,000 as the Capacity. This will cause UHarvest to exit the AccuLoad Demo mode.

If AccuLoad is stuck in Manual mode and cannot be set to Auto mode:

- Make sure UHarvest is not in manual load logging mode.
 - AccuLoad is disabled during manual load logging.
- Verify that the T port of the AccuLoad valve is not pressurized.
 - If the T port is pressurized, the pressure switch will be triggered and AccuLoad will not engage.
 - Detent the tractor’s hydraulic lever in the opposite direction.
- Verify that the PSI connector of the AccuLoad cable is connected to the pressure switch on the AccuLoad valve.
- Verify that the pressure switch is set at 2200 psi.
 - If the pressure switch is set lower than the hydraulic circuit’s standby pressure, AccuLoad will not engage.
 - Adjust the pressure switch setting if necessary.
- Check the AccuLoad cable for loose or broken wires.

If the door chatters when opening or closing:

- Reduce the tractor’s hydraulic flow until the chatter is removed.
 - If the flow rate is adjusted, the AccuLoad open and close times should also be adjusted in the UHarvest AccuLoad settings.
- Flush the hydraulic lines to eliminate contaminants that may cause the AccuLoad cartridges to stick.
- Check the AccuLoad connectors and cables for intermittent power supply.

If AccuLoad does not open the door during a load:

- Make sure AccuLoad is in Auto mode.
- Verify that the hydraulic lever is set in the same direction that is used to open the door in Manual mode.
- Make sure the actual PTO operating speed reaches the minimum AccuLoad rpm setting.
- Set the tractor hydraulic lever so it provides continuous flow instead of timing out.
- Make sure S1, S2, and S3 connectors are attached to the correct cartridges in the AccuLoad valve.
- Verify operation of the door in Manual mode.
 - Check hose coupler connections.
- Verify that the PTO sensor is functioning properly.
 - Watch the rpm value in the Diagnostics screen.
 - Check the LED on the PTO sensor. It should turn on when the target is detected.
 - Make sure the target is within 1/16" and 1/4" of the sensor.
 - Verify that the sensor is powered. There should be 12V across pins B and C of the PTO sensor connector.
 - Check the sensor cable for loose or broken wires.

If the door does not open all the way:

- Increase the AccuLoad open percentage.
- Confirm the accuracy of the AccuLoad Open Time that it takes to open the door. Adjust if necessary.
- Set the tractor hydraulic lever so it provides continuous flow instead of timing out.
- The target weight might be too low. For a small target weight, the AccuLoad controller will only open partially to avoid overshooting the target.

If the door opens immediately after engaging the hydraulic lever but before the PTO is turning at the minimum speed for AccuLoad:

- Verify that the S2 connector is connected to the S2 cartridge.
- Verify that the S2 cartridge is powered.
- Verify that AccuLoad has not returned to Manual mode.
 - Adjust the pressure switch if necessary.

If the door does not close at any time during a load:

- Set the tractor hydraulic lever so it provides continuous flow instead of timing out.
- Confirm the accuracy of the AccuLoad Close Time that it takes to close the door. Adjust if necessary.
- Verify that the S1 and S2 connectors are connected to the correct AccuLoad cartridges.
- Check the AccuLoad cable for loose or broken wires.
- Check the AccuLoad relief valve setting.

- The relief setting should be 2200 psi.
- Verify that the tractor's relief setting is higher than 2200 psi.
- Flush the S1 and S2 cartridges to remove contaminants.

If the door does not close completely:

- The target weight was not reached because the grain cart ran out of grain.

If the door closes well before reaching the target weight:

- Minimize cart motion while unloading. Large movements can result in false weight measurements that cause the AccuLoad controller to close the door too early.
- Verify that the PTO speed is above the minimum AccuLoad setting.

If the door closes part way and then opens completely:

- Set the tractor hydraulic lever so it provides continuous flow instead of timing out.
- Power to S2 may have been lost.
 - Check the connection at the S2 cartridge.
 - Check the AccuLoad cable for loose or broken wires.

If the door does not close when operator panic mode is engaged by moving the tractor's hydraulic lever in the opposite direction:

- Verify that the S3 connector is connected to the S3 cartridge.
- Verify that S3 is powered when in Auto mode.
- Verify that the pressure switch is powered.
- Check the pressure switch setting.
 - The switch should be set at 2200 psi.
- Verify that the tractor relief setting is above 2200 psi.
- Check the AccuLoad cable for loose or broken wires.
- Move the hydraulic lever to the AccuLoad position and enter Auto mode. Do not engage the PTO.
 - If both hoses to P and T have flow but are not highly pressurized, the hoses are correct.
 - If the T hose is pressurized, the flow direction is reversed. Move the hydraulic lever the opposite direction.

Moisture Sensor

FIGURE 8. Moisture Sensor on Cleanout Door



If the measured moisture does not change at all for different loads:

- In the Diagnostics screen, check the Moisture Voltage and Temperature Voltage.
 - The Temperature should have a stable, non-zero voltage.
 - The Moisture Voltage should respond instantaneously to a moisture change. Placing your hand over the sensing element should result in a voltage spike.
- Verify that the moisture sensor is getting powered.
 - There should be 12V across pins A and B.
- Check for loose or broken wires on the moisture sensor.

If the measured moisture seems erratic or inaccurate:

- Verify that the correct crop was chosen for the job. The output of the moisture sensor is crop dependent.
- Recalibrate the moisture sensor offset.
 - Use the average values from multiple loads to determine the offset number.
- Check for loose or broken wires on the moisture sensor.

Spout Centering

If the spout does not move when the Spout Center icon is pressed:

- Verify that the spout center feature was configured through the UHarvest display.
- Make sure the EOH valve is pressurized correctly.
- Make sure the sensors at the spout are connected to the cable.
- Make sure the spout sensor cable is connected to the ECU cable.
- Verify that the joystick is powered.
 - Check for blown fuses on the tractor.

- Check the joystick connections at the ECU harness and verify that the connectors are fully seated.
- Check the joystick cables and EOH valve cable for any loose connections or broken wires.
- Check the spout sensor cable for any loose or broken wires.
- Verify that the ECU harness is properly connected to the tractor's ISO connector at the back of the tractor.
- Verify that the contact switch at the vertical auger hinge is being compressed when the auger is unfolded.

If the spout moves erratically after pressing the Spout Center icon:

- Watch the spout voltages in the Diagnostics screen.
 - The voltages should be stable when the spout is stationary.
 - The voltages should change smoothly as the spout moves.
- Check the sensors mounted on the cart and verify that all components and linkages are mounted securely.
- Inspect the rotating shaft of each sensor and make sure it is correctly phased.
 - The shaft of the position sensor can turn freely, but the sensor only has a sensing range of 180°.
 - When the shaft is centered in its sensing range, the flat face of the shaft is turned away from the sensor's electrical connector.
- Verify that the position sensor operates within its sensing range across the full range of spout motion.
 - Reposition the sensor and/or mounting components if necessary.
- Check the spout sensor cable for any loose or broken wires.
- Check the joystick cables and EOH valve cable for any loose connections or broken wires.

Joystick

If the grain cart joystick is not functioning while connected to the UHarvest system:

- Verify that the EOH valve is correctly pressurized.
- Verify that the joystick is powered.
 - Check for blown fuses on the tractor.
- Verify that the ECU harness is properly connected to the tractor's ISO connector at the back of the tractor.
- Check the joystick connections at the ECU harness and verify that the connectors are fully seated.
- Bypass the ECU harness and connect the joystick directly to the EOH valve cable. Attempt to use the joystick.
 - If the joystick functions properly, there may be a problem with the ECU harness wiring.
 - If the joystick still does not function, check the joystick cables and EOH valve cable for any loose connections or broken wires.

Steerable Duals

If the in-line tandem duals do not trail the tractor:

- Verify that the steerable duals icon on the UHarvest display is set to the Unlock position.
- Check the electrical connection at the steerable duals valve.
 - In the Unlock position, there should be 0V.
 - In the Lock position, there should be 12V.
- If the Unlock position is supplying 12V, check the cable for any pinched or broken wires.
- Check the relief setting in the steerable duals valve. Refer to the grain cart's manual for more information.

If the in-line tandem duals do not lock or steer manually:

- Verify that steerable duals icon on the UHarvest display is set to the Lock position.
- Verify that the steerable duals hydraulic circuit is pressurized.
- Check the electrical connection at the steerable duals valve.
 - In the Unlock position, there should be 0V.
 - In the Lock position, there should be 12V.
- If the Lock position is supplying 0V, check the cable for any pinched or broken wires.

Slingshot

If you are unable to export files to your Slingshot account:

- Verify that the correct Slingshot access key was entered into UHarvest.
- On the tablet, observe the Slingshot and Processor ID icons in the header. If the processor has an Internet connection, the Slingshot icon will have a green underline and the Processor ID icon will be highlighted with a blue cloud.
- If an Internet modem is being used, verify that the Ethernet cable is connected to the processor's Ethernet port A instead of port B.
- Verify that the other end of the Ethernet cable is connected to the modem.
- Verify that the modem is powered.
- Slingshot will not accept blank jobs. Only jobs that contain load information will be transferred.

Appendix

Table 1: Expected Load Cell Calibration Values

Brand	Model	Steerable Tandem	Tracks	Walking Tandem	Single Tires (5pt)	Single Tires (3pt)	Straddle Duals
Brent	2096	78000	40000	-	-	-	-
	1596	40000	40000	-	-	-	-
	1396	-	40000	40000	40000	-	-
	1196	-	40000	40000	40000	-	-
	1386	-	40000	-	40000	-	-
	1186	-	40000	-	40000	-	-
	1282	-	40000	40000	40000	-	-
	1082	-	40000	-	-	24000	-
	882	-	-	-	-	24000	-
	782	-	-	-	-	24000	-
	678	-	-	-	-	24000	-
	576	-	-	-	-	24000	-
Unverferth	1610	-	40000	-	-	-	-
	1310	-	40000	40000	40000	-	-
	1110	-	40000	40000	40000	-	-
	1317	-	40000	40000	40000	-	-
	1117	-	40000	40000	40000	-	-
	1017	-	40000	-	40000	46500	-
	1315	-	40000	40000	40000	-	-
	1115	-	40000	40000	40000	-	-
	1015	-	40000	-	40000	46500	-
	9250	-	-	-	-	(900) 24000	-
		-	-	-	-	(1050) 46500	-
	8250	-	-	-	-	24000	46500
	7250	-	-	-	-	24000	46500
	6225	-	-	-	-	24000	-
5225	-	-	-	-	24000	-	
Parker	1648	-	46000	-	-	-	-
	1348	-	46000	46000	46000	-	-
	1048	-	46000	-	-	27500	-
	1039	-	-	-	-	27500	-
	839	-	-	-	-	27500	27500
	739	-	-	-	-	27500	27500
	624	-	-	-	-	27500	-
	524	-	-	-	-	27500	-
Killbros	1611	-	46000	-	-	-	-
	1311	-	46000	46000	46000	-	-
	1111	-	46000	46000	46000	-	-
	1950	-	46000	-	-	27500	-
	1195	-	-	-	-	27500	-
	1185	-	-	-	-	27500	27500
	1175	-	-	-	-	27500	27500
	1160	-	-	-	-	27500	-
	1150	-	-	-	-	27500	-

For all other brand grain carts use the following formula

$$\text{Cal Number} = \text{Axle Weigh Bar Capacity} / (5 \times \text{mV Output}) \times \# \text{ load cells } \times 2$$

A

AccuLoad Operation, Tablet 34
 Accuload Operation, VT 59

C

Cab Component Installation
 ISO Connector 11
 Power / CAN Cable 9
 Processor Mounting 7
 RAM Tablet Holder 8

Calibration

Moisture, Tablet 32
 Moisture, VT 59
 Scale, Tablet 31
 Scale, VT 57
 Spout, Tablet 37
 Spout, VT 62

Cart 47

E

ECU 6
 ECU LEDs and Meanings 6
 Electrical safety 1

H

Hydraulic Safety 1

I

Important Installation and Safety
 Information 1

Installation

Power / CAN Cable 9
 Processor 8
 Ram Tablet Holder 8

Introduction 3

M

Moisture Calibration, Tablet 32
 Moisture Calibration, VT 59
 Mounting the UHarvest Processor 7

O

Operation with a Tablet

Diagnostic Screen 38
 File Management 38
 Grower Information 21
 Header Information 19
 Moisture Calibration 32
 Operating AccuLoad 34
 Password Entry 17
 Report Screen 30
 Scale Calibration 31
 Scale Screen 26
 Scale Setup 19
 Software Updates 43
 Spout Centering 36
 Starting a Job 25
 Startup 17
 Steerable Duals 37

Trucks, Destinations and
 Varieties 24

Unload Screen 27
 WI-FI Connection 17

Operation with a Virtual Terminal

Diagnostic Screen 64
 File Management 64
 Grower Information 48
 Header Information 46
 Moisture Calibration 59
 Operating AccuLoad 59
 Report Screen 56
 Scale Calibration 57
 Scale Screen 53
 Scale Setup 47
 Spout Calibration 62
 Spout Centering 61
 Starting a Job 50
 Steerable Duals 63

Trucks, Destinations and
 Varieties 52

Unload Screen 54

Overview 3

P

Password Entry 17
 Power / Can Cable 9
 Processor Features 5
 Processor Kit 7

Processor Mounting 7
Product Registration and Software Updates 3

S

Safety

Electrical 1
Hydraulic 1

Scale Screen, Tablet 26
Scale Screen, VT 53
Scale Setup, Tablet 19
Scale Setup, VT 47
Starting a Job, Tablet 25
Starting a Job, VT 50
System Components 4
System Diagrams 13

T

Troubleshooting

AccuLoad 94
Display on Virtual Terminal 89
ECU Communication 90
Joystick 99
Moisture sensor 98
Processor 90
Recording 93
Scale 91
Slingshot 100
Spout Centering 98
Steerable Duals 100
Tablet charging 91
Tablet Wi-Fi Connection 89

U

UHarvest ECU 6
UHarvest Processor Kit 7

V

Viewing a Job File In Excel 83
Viewing the License Agreement 87

RAVEN

RAVEN INDUSTRIES

Limited Warranty

What Does this Warranty Cover?

This warranty covers all defects in workmanship or materials in your Raven Applied Technology Division product under normal use, maintenance, and service when used for intended purpose.

How Long is the Coverage Period?

Raven Applied Technology Division products are covered by this warranty for 12 months from the date of retail sale. In no case will the Limited Warranty period exceed 24 months from the date the product was issued by Raven Industries Applied Technology Division. This warranty coverage applies only to the original owner and is non-transferable.

How Can I Get Service?

Bring the defective part and proof of purchase to your Raven dealer. If the dealer approves with the warranty claim, the dealer will process the claim and send it to Raven Industries for final approval. The freight cost to Raven Industries will be the customer's responsibility. The Return Materials Authorization (RMA) number must appear on the box and all documentation (including proof of purchase) must be included inside the box to be sent to Raven Industries.

What Will Raven Industries Do?

Upon confirmation of the warranty claim, Raven Industries will (at our discretion) repair or replace the defective product and pay for the standard return freight, regardless of the inbound shipping method. Expedited freight is available at the customer's expense

What is not Covered by this Warranty?

Raven Industries will not assume any expense or liability for repairs made outside our facilities without written consent. Raven Industries is not responsible for damage to any associated equipment or products and will not be liable for loss of profit, labor, or other special damages. The obligation of this warranty is in lieu of all other warranties, expressed or implied, and no person or organization is authorized to assume any liability for Raven Industries.

Damages caused by normal wear and tear, misuse, abuse, neglect, accident, or improper installation and maintenance are not covered by this warranty.

R A V E N

RAVEN INDUSTRIES

Extended Warranty

What Does this Warranty Cover?

This warranty covers all defects in workmanship or materials in your Raven Applied Technology Division product under normal use, maintenance, and service when used for intended purpose.

Do I Need to Register My Product to Qualify for the Extended Warranty?

Yes. Products/systems must be registered within 30 days of retail sale to receive coverage under the Extended Warranty. If the component does not have a serial tag, the kit it came in must be registered instead.

Where Can I Register My Product for the Extended Warranty?

To register, go online to www.ravenhelp.com and select Product Registration.

How Long is the Extended Warranty Coverage Period?

Raven Applied Technology products that have been registered online are covered for an additional 12 months beyond the Limited Warranty for a total coverage period of 24 months from the date of retail sale. In no case will the Extended Warranty period exceed 36 months from the date the product was issued by Raven Industries Applied Technology Division. This Extended Warranty coverage applies only to the original owner and is non-transferable.

How Can I Get Service?

Bring the defective part and proof of purchase to your Raven dealer. If the dealer approves with the warranty claim, the dealer will process the claim and send it to Raven Industries for final approval. The freight cost to Raven Industries will be the customer's responsibility. The Return Materials Authorization (RMA) number must appear on the box and all documentation (including proof of purchase) must be included inside the box to be sent to Raven Industries. In addition, the words "Extended Warranty" must appear on the box and all documentation if the failure is between 12 and 24 months from the retail sale.

What Will Raven Industries Do?

Upon confirmation of the product's registration for the Extended Warranty and the claim itself, Raven Industries will (at our discretion) repair or replace the defective product and pay for the standard return freight, regardless of the inbound shipping method. Expedited freight is available at the customer's expense.

What is Not Covered by the Extended Warranty?

Raven Industries will not assume any expense or liability for repairs made outside our facilities without written consent. Raven Industries is not responsible for damage to any associated equipment or products and will not be liable for loss of profit, labor, or other damages. Cables, hoses, software enhancements, and remanufactured items are not covered by this Extended Warranty. The obligation of this warranty is in lieu of all other warranties, expressed or implied, and no person or organization is authorized to assume any liability for Raven Industries.

Damages caused by normal wear and tear, misuse, abuse, neglect, accident, or improper installation and maintenance are not covered by this warranty.