

Simply improving your position.[™]

Installation & Service Manual





<u>WARNING</u>

Disconnect console before jump starting, charging battery, or welding on equipment.

FOR FUTURE REFERENCE. THE CALIBRATION NUMBERS CARD IS PROVIDED FOR OPERATOR'S CONVENIENCE. PENCIL IN ON DOTTED LINE, FOLD, AND INSERT INTO PLASTIC ENVELOPE. CUT



TABLE OF CONTENTS

SYMBOLDEFINITION	3
INTRODUCTION	4
PRODUCT INSTALLATIONS	5
1. MOUNTING THE RAVEN RADAR SPEED SENSOR	5
2. MOUNTING THE FLOWMETER	6
3. MOUNTING THE CONTROL VALVE	6
4. MOUNTING THE CONSOLE AND CABLING	/
BATTERYCONNECTIONS	0
	8
	9
CONSOLE CALIBRATIONS	10
1. CALCULATING "BOOM CAL"	10
2. CALCULATING "SPEED GAL"	10
4 CALCULATING CARRIER METER CAL	
5. CALCULATING "PROD 1 AND PROD 2 CAL"	12
INITIAL CONSOLE PROGRAMMING	14
1. REQUIRED CONSOLE PROGRAMMING	15
2. OTHER DISPLAY FEATURES	18
3. SELF TEST FEATURE	18
5. SEQUENCE TO CHANGE DATA-LOCK	19
6. ENTER MODE SEQUENCE WITH ACTIVATED DATA-LOCK	19
7. CONTROL VALVE DELAY	19
8. AUTOMATIC RATE +/	20
9. VOLUME/AREA RATE ALARM	20
10. LOW LEVEL TANK FAULT	20
12 DECIMAL SHIFT	20
	01
PRODUCT INJECTION INSTALLATION AND SET-UP	32
1. PLUMBING THE INJECTION MODULE	32
2. RECOMMENDED INJECTION PUMP FLUSH SYSTEM	33
3. DETERMINING INJEGTION MODULE "METER GAL"	34
5 ADJUSTING PUMP SETTING	33
SYSTEM OPERATION	37
1. INITIAL CARRIER SET-UP	37
2. INITIAL CARRIER FIELD TEST	38
3. INITIAL INJECTION SET-UP	38
PREVENTIVE MAINTENANCE	30

1. WHEEL DRIVE SPEED SENSOR INSTALLATION AND CALIBRATION PROCEDURE	. 41
2. SPEEDOMENTER DRIVE SPEED SENSOR INSTALLATION AND CALIBRATION	. 44
3. ALTERNATE BY-PASS PLUMBING DIAGRAM	. 46
4. PROCEDURE TO TEST SPEED SENSOR EXTENSION CABLE	. 48
5. PROCEDURE TO TEST PRODUCT FLOW CABLES	. 49
6. PROCEDURE TO RE-CALIBRATE FLOW METER	. 50
7. IMPREGNATION MODULE INSTALLATION	. 51
8. INJECTION MODULE INSTALLATION	. 53
9. INJECTION MODULE MOUNTING INSTALLATION	. 55
10. FLOW METER MAINTENANCE AND ADJUSTMENT PROCEDURE	. 57
11. PROCEDURE TO RE-CALIBRATE PUMP	. 58
12. REMOTE SWITCH OPTION	. 59
13. BOOM CAL DATA ENTRY FOR SCS 710 6 BOOM CONSOLE	. 60
14. SCS 710 6 BOOM CONSOLE WIRING DIAGRAM	. 61
15. SERIAL INTERFACE	. 62
16. SCS 700/710 COMMUNICATION STRINGS	. 63
17. SCS 700/710 DATA MENU KEY FEATURES	. 64

REPLACEMENT PARTS SHEETS

SYMBOL DEFINITION

GPM	- Gallons per minute	cm	- Centimeters
lit/min	- Liters per minute	dm	- Decimeters
dl/min	- Deciliter per minute	m	- Meter
PSI	- Pounds per square inch	MPH	- Miles per hour
kPa	- Kilopascal	km	- Kilometers
GPA	- Gallon per acre	km/h	 Kilometers per hour
lit/ha	- Liter per hectare	US	- Volume per ACRE
ml/ha	- Milliliter per hectare	SI	- Volume per HECTARE
GPK	- Gallons per 1,000 sq. ft.	TU	- Volume per 1,000 sq. ft.
mm	- Millimeters	[]	- Metric numbers
		{}	- 1,000 sq. ft. numbers

METER CAL CONVERSIONS

To convert the METER CAL number simply divide the original number (number printed on Flow Meter label) by the desired conversion factor.

FOR EXAMPLE:

Original METER CAL No. = METER CAL No. for displays in Fluid Ounces

Original METER CAL No. = METER CAL No. for displays in Liters 3.785

Original METER CAL No. = METER CAL No. for displays in Pounds Weight of one gallon

LIQUID CONVERSIONS

U.S. Gallons x 128 = Fluid Ounces U.S. Gallons x 3.785 = Liters U.S. Gallons x 0.83267 = Imperial Gallons U.S. Gallons x 8.34 = Pounds (Water)

LENGTH

1 millimeter (mm) = 0.039 inch 1 centimeter (cm) = 0.393 inch 1 meter (m) = 3.281 feet 1 kilometer (km) = 0.621 mile 1 inch = 25.4 millimeters; 2.54 centimeters 1 mile = 1.609 kilometers

PRESSURE

1 psi = 6.89 kPa

AREA

1 square meter = 10.764 square feet

1 hectare (ha) = 2.471 acres; 10,000 square meters

1 acre = 0.405 hectare; 43,560 square feet

1 square mile = 640 acres; 258.9 hectares

INTRODUCTION

The Raven SCS 700 (PRODUCT INJECTION SYSTEM) is designed to improve the accuracy and uniformity of spray applications. Its performance relies on the installation and preventive maintenance of the complete sprayer. It is important that this Installation and Service Manual be reviewed thoroughly before operating the system. This Manual provides a simple step-by-step procedure for installing and operating the system.

The SCS 700 consists of a computer based Control Console, a Speed Sensor, one or two Injection Modules (each includes a Motor Control and Metering Pump with sensors), an In-Line mixer, and cables. The Console mounts directly in the cab of the vehicle for easy operator use. The Radar Speed Sensor is mounted to the frame of the vehicle or implement (Wheel Drive and Speedometer Drive Speed Sensors are also available). The Injection Module mounts to the framework of the sprayer. The In-Line Mixer mounts just before the Boom On/Off Valves. Appropriate cabling is furnished for field installation.

The operator sets the target application rate for each product to be sprayed and the SCS 700 automatically maintains the flow regardless of vehicle speed or gear selection. A manual override switch allows the operator to manually control flow for each product for spot spraying. Actual volume per area being applied is displayed at all times for both products. The SCS 700 additionally functions as an area monitor, speed monitor, and volume totalizer.

TYPICAL SYSTEM (WITH CARRIER) DIAGRAM:

The diagram shown below is a typical SCS 700 system. It is suggested that the SCS 700 console be installed to use Product 1 as the carrier, and Product 2 for injection or auxiliary. Although this is not required, it is the recommended system.



PRODUCT INSTALLATIONS

1. MOUNTING THE RAVEN RADAR SPEED SENSOR

See Appendix 1 for Wheel Drive Speed Sensor installation instructions. See Appendix 2 Speedometer Drive Speed Sensor installation instructions.

For mounting the radar, the following guidelines will assure proper installation: It is suggested that a large heavy mounting bracket, (P/N 107-0159-693) be attached to the vehicle frame for mounting the radar.

- 1) Park vehicle on level surface.
- 2) Select mounting site by considering the following:
 - The line of sight from the lens to the ground must not be obstructed by structures or tires. Obstructions must not come closer than 20 inches to the bottom of the radar. See Figures 1 and 2.
 - **b)** The radar lens must be parallel to the ground from front to back. Radar can be tilted out 0-15 degrees to provide more clearance and miss obstructions. See Figure 2.
 - c) The radar should be mounted so that the **length** of the radar is **parallel** with direction of vehicle travel.
- 3) Use carpenters level to verify that mounting bracket is parallel to the ground.
- 4) Bolt mounting bracket to implement.
- 5) Bolt radar to mounting bracket using mounting hardware. See Figure 3.
- 6) Connect radar with Radar Interface Cable (P/N 115-0159-539) to the Console. The Red wire should be connected to the Orange cable wire. The White wire should be connected to the negative terminal of the battery. See "BATTERY CONNECTIONS".



FIGURE 1

2. MOUNTING THE FLOW METER

- 1) Mount Flow Meter in the area of the boom valves per Figure 4. All flow through Flow Meter must go to booms only, i.e., no return line to tank or pump after Flow Meter.
- 2) Mount Flow Meter horizontal to the ground. Use the bracket to secure the Flow Meter.
- **3)** For best results, allow a minimum of 7 1/2 inches [20 cm] of straight hose on inlet of Flow Meter. Bend radius of hose on outlet of Flow Meter should be gradual.
- 4) Flow must be in direction of arrow on Flow Meter.



FIGURE 4

NOTE: It is critical, when using suspensions, that the system be thoroughly rinsed out each day after use.

NOTE: If system does not use carrier control for PROD 1, the injection option shown for PROD 2 is available for use in place of carrier control.

3. MOUNTING THE CONTROL VALVE

- 1) Mount the motorized Control Valve in the main hose line between the Flow Meter and the booms, with motor in the upright position. (For flow less than 3 GPM [11 lit/min] the motorized Control Valve is mounted in a bypass line, refer to Appendix 3 for alternate plumbing diagram).
- 2) Connect Product Cable connectors to Flow Meter, Control Valve, and Injection Module. Install Adapter Cable P/N 115-0159-456 on Control Valve.
- 3) Connect Boom Cable to the Boom Valves (Black wire to Valve #1, Brown wire to Valve #2, and Blue wire to Valve #3.

4. MOUNTING THE CONSOLE AND CABLING

- I) Mount the Console to a secure support inside the cab of the vehicle.
- 2) Install Product Cable to the connectors on the Injection Modules (Prod 1-White, Prod 2-Black) and Boom On/Off Valves (Boom 1-Black, Boom 2-Brown, Boom 3-Blue). Secure with plastic cable ties. (See Figures 4 & 5).
- **3)** Connect the Console Control Cable to the plug in the back of the Console. (See Figure 5). Run the Console Control Cable out of the vehicle cab and connect with Product Control Cable on the sprayer. (Extension cables are available from a Raven Dealer). Secure with plastic cable ties.



FIGURE 5

4) Turn POWER ON/OFF switch OFF and route the Red and White battery wires to a 12 volt battery. Attach the White wire to the NEGATIVE (-) terminal and the Red 16 gauge wire to the POSITIVE (+) terminal. (DO NOT CONNECT WIRES TO THE STARTER). Secure the battery wires with plastic cable ties. DO NOT tie the battery wires close to the existing battery leads or other electrical wiring.

NOTE: Power relay P/N 063-0159-929 must be installed. Reference Battery Connection Figure 6A.

- 5) Connect the Speed Sensor Cable to the plug in the back of the Console.
- 6) Installation of the system is now complete.

BATTERY CONNECTIONS

BATTERY HOOK-UP FOR CONSOLE HARNESS

- 1) Connect the 10 gauge white wire to the negative post of the battery. Install fuseholder and 20 amp fuse on 16 gauge red wire.
- 2) A relay must be installed between the red 10 gauge wires and the battery. The relay is normally controlled from the accessory side of the ignition switch. See Figure 6A.



NOTE: Disconnect console battery wires if the system is not used for an extended period, (i.e. two weeks). With the POWER switch to OFF, the system draws 9 milliamps of current to maintain information stored in the Console.

CONSOLE FEATURES

SELFTEST

--

Simulates Vehicle Speed

IMPORTANT: This Console requires selection of US (acres), SI [hectares], or TU {1,000 sq. ft.} area; and SP1 (wheel drive, etc.) or SP2 (radar) speed sensor; C-Sd (Standard Valve), C-F (Fast Valve), or C-FC (Fast Close valve).



--

DATAMENU

9

Injection Module Tank

Various data options

CONSOLE CALIBRATIONS

A calibration procedure must be completed before operating the console. Calibration of the Console can be achieved by performing the following calculations. Once these calculations are complete, the information can be added to the console by following the INITIAL CONSOLE PROGRAMMING procedure.

CALCULATING "BOOM CAL" 1

Calculate the width of each boom in inches [cm] by multiplying the number of tips times the spacing. Write these boom widths down for future reference when programming the Console. The Console is capable of controlling up to three (3) booms.



FIGURE 6

CALCULATING "SPEED CAL" 2.

See Appendix 1 for Wheel Drive Speed Sensor installation instructions. See Appendix 2 for Speedometer Drive Speed Sensor installation instructions.

Initial SPEED CAL is 598 [152]. Complete Steps 1 thru 6 to refine this number after "INITIAL CONSOLE PROGRAMMING" has been completed.

1) Set POWER switches to ON, all other switches to OFF.



2)

Drive 1 mile [1 kilometer]. To achieve the most accurate calibration, accelerate and decelerate 3) slowly.

CAUTION: Do not use vehicle odometer to determine distance. Use section lines or highway markers.

Read DISTANCE by depressing DISTANCE. DISTANCE should read a value of approximately 5280 4)

[1000]. If it reads between 5260-5300 [990-1010], the SPEED CAL for the vehicle is 598 [152]. If the DISTANCE display reads any other value, perform the following calculation:

EXAMPLE: Assume DISTANCE reads 5000 [980]. Corrected SPEED CAL = Old SPEED CAL x 5280 DISTANCE

ENGLISH UNITS:	METRIC UNITS:
= <u>598 x 5280</u> = 631.48	= <u>[152] x [1000]</u> = [155]
5000	[980]

5) The number to enter for SPEED CAL is 631 [155]. 6) Recheck the new SPEED CAL derived in Step 5 by repeating Steps 2 thru 5.

3. CALCULATING CARRIER "METER CAL"

When calculating METER CAL for a carrier (typically METER 1 CAL is used as a carrier), refer to the Flow Meter calibration number which is stamped on the label attached to the Flow Meter. This number is to be used for gallon per area applications. To convert original METER CAL from gallons to desired units of measure (oz, lbs, or liters per area) see "METER CAL CONVER-SIONS". Write down this calibration number for future reference when programming the Console.

NOTE:Reference "PRODUCT INJECTION INSTALLATION AND SET-UP" For information regarding setting the METER CAL for injection or auxiliary.

4. CALCULATING "VALVE 1 AND VALVE 2 CAL"

The initial Control Valve calibration number for VALVE 1 CAL and VALVE 2 CAL is 2123 for C-Sd (injection module/standard valve), or 743 for C-F (fast valve) and C-FC (fast close valve). The VALVE CAL number is used to control response time of the Motor Control to the change in vehicle speed. After operating the system, this number may be refined. See definitions below:



Dead-Band Digit

Allowable difference between target and actual application rate, where rate correction is not performed.

Range: 1 to 9 1 = 1%9 = 9%

5. CALCULATING "PROD 1 AND PROD 2 CAL"

1) Determine the target application rate at which the product should be sprayed for the PROD 1 and PROD 2 CAL. Write down these calibration numbers for future reference when programming the Console. Consult with a Raven Dealer to ensure your spray nozzles are capable of applying at this target rate.

Selecting Spray Nozzles:

To determine correct spray nozzles provide the following information:

1) Nominal Application Pressure	PSI [kPa] {PSI}
2) Target Application Rate	GPA [lit/ha] {GPK)
3) Target Speed	MPH [km/ha] {MPH}
4) Nozzle Spacing	inches [centimeters] {inches}

From this information calculate the volume per minute per nozzle as follows:

GPM	=	<u>GPA {GPK} X MPH {MPH} X inches {inches}</u> 5,940 {137}
lit/min	=	<u>lit/ha x km/h x cm</u> 60,000

Use GPM [lit/min] and pressure to select appropriate tip from tip chart.

EXAMPLE:	 Applicati Target A Target S Nozzle S 	on Pressure pplication Rate peed Spacing	30 PSI [200 kPa] {30 PSI} 20 GPA [200 lit/ha] {.46 GPK} 5.2 MPH [8.4 KM/H] {5.2 MPH} 20 inches [50 cm] {20 inches}
US (ENGLISI	H UNITS)	GPM	= <u>20 GPA X 5.2 MPH X 20 inches</u> = 0.35 5,940
SI (METRIC	UNITS)	[lit/min]	= <u>200 lit/ha X 8.4 km/h X 50 cm</u> = 1.40 6,000
TU (TURF U	NITS)	GPM	= <u>.46 GPK X 5.2 MPH X 20 inches</u> = 0.35 137

Using GPM <u>.35</u> and pressure <u>30</u> select tip number XR8004 from the chart shown as Figure 8, since it comes closest to providing the desired output.

TIP	TIP NO.				LIQUID	CAPACITY	GALLONS	PER ACR	E 20"	SPACING
COLOR	80 DEG.	110 DEG.	IN PSI	IN GPM	IN OZ./MIN.	5 MPH	6 MPH	7 MPH	8 MPH	
YELLOW	XR8002	XR11002	15 20 30 40 60	.12 .14 .17 .20 .25	15 18 22 26 32	7.3 8.4 10.3 11.9 14.6	6.1 7.0 8.6 9.9 12.1	5.2 6.0 7.4 8.5 10.4	4.5 5.3 6.4 7.4 9.1	
BLUE	XR8003	XR11003	15 20 30 40 60	.18 .21 .26 .30 .37	23 27 33 38 47	10.9 12.6 15.4 17.8 22.0	9.1 10.5 12.9 14.9 18.2	7.8 9.0 11.0 12.7 15.6	6.8 7.9 9.7 11.1 13.6	
RED	XR8004	XR11004	15 20 30 40 60	.24 .28 .35 .40 .49	31 36 45 51 63	14.5 16.8 21.0 24.0 29.0	12.1 14.0 17.2 19.8 24.0	10.4 12.0 14.7 17.0 21.0	9.1 10.5 12.9 14.9 18.2	
BROWN	XR8005	XR11005	15 20 30 40 60	.31 .35 .43 .50 .61	40 45 55 64 78	18.2 21.0 26.0 30.0 36.0	15.2 17.5 21.0 25.0 30.0	13.0 15.0 18.4 21.0 26.0	11.4 13.1 16.1 18.6 23.0	

FIGURE 8

VERIFYING FLOW RATE LIMITS:

The gallons per minute (GPM) (liter per minute [lit/min]) flow rate of the sprayer must be within the range of that specified for the Flow Meter included with the Console.

FLOW METER MODEL RFM 5 RFM 15 RFM 60P/60S RFM 100 RFM 200/200 Poly RFM 400 FLOW RANGE

0.05-5 GPM [0.2-18.9 lit/min] 0.3-15 GPM [1.1-56.8 lit/min] 1-60 GPM [3.8-227 lit/min] 3-100 GPM [11.4-379 lit/min] 15-200 GPM [56.8-757 lit/min] 25-400 GPM [94.6-1514 lit/min]

2) Determine the target application rate for PROD 2 CAL that you are spraying (Refer to the instructions on the product container) using section DETERMINING INJECTION MODULE METER CAL.

INITIAL CONSOLE PROGRAMMING

STANDARD DATA ENTRY PROCEDURE:

When entering data into any of the keys on the Console, the data entry sequence is always the same.





Depress the key in which you wish to enter data.

Depress the "ENTER" key. An "E" will illuminate in the DATA display.



PRODUCT 2 Ō MAN O 0 DATA 1824 3 CAL 6 ALVE CAL $\widehat{}$ œ. FIELD VOLUNE YDLUME TANK 1 VOLUME TANK 2 DATA WENU RAVEN Sprayer Control Ē

Complete the entry by again depressing the "ENTER" key.

Depress the keys corresponding to the number you wish to enter (i.e., "1", "0", "2", "4",). The numbers will be displayed in the DATA display as they are entered.

1. REQUIRED CONSOLE PROGRAMMING

When power is first applied to the console, after all installation procedures have been completed, the Console will flash "CAL" in the PROD 1 and PROD 2 displays. This means it must be "calibrated" or programmed before it can be operated. This is a one-time operation which does not have to be repeated. Turning OFF the POWER ON/OFF Switch does not affect the Console memory. All data is retained.

IMPORTANT: If an entry selection error is made during Steps 1-6, place the		
POWER ON/OFF switch to OFF. Depress and hold while placing the		
POWER ON/OFF switch to ON. This will "reset" the Console.		

The PROD 1 and PROD 2 display will show "CAL", the DATA display will show "US". The following steps must be followed:

1) Displaying units of measure selections: US (acres), SI [hectares], or TU {1000 sq. ft.).

	a)	Depressing momentarily	steps the DATA display from US to SI.
	b)	Depressing momentarily	steps the DATA display from SI to TU.
	c)	Depressing momentarily	steps the DATA display from TU to US.
2)	Selecti	ing a unit of measure (US, SI, or TU).	
	a)	To select US, SI, or TU, step	until the desired code is displayed in DATA display.
	b)	Momentarily depress . The D	ATA display will now display SP1.
3)	Display	ying Speed Sensor selections: SP1 (v	wheel drives, etc.) or SP2 (radar sensor).
	a)	Depressing momentarily	steps the DATA display from SP1 to SP2.
	b)	Depressing momentarily	os the DATA display from SP2 to SP1.
4)	Selecti	ing a Speed Sensor (SP1 or SP2).	
	a)	To select SP1 or SP2, step with	until desired code is displayed in DATA display.
	b)	Momentarily depress the DA	TA display will now display 1-Sd.

- 5) Displaying Valve selections for PROD 1: 1-Sd (Injection Module/Standard Valve), 1-F (Fast Valve), or 1-FC (Fast Close Valve).
 - CE a) Depressing momentarily steps the DATA display from 1-Sd to 1-F. CE Depressing momentarily b) steps the DATA display from 1-F to 1-FC. CE c) Depressing momentarily steps the DATA display from 1-FC to 1-Sd. Selecting a Valve for PROD 1 (1-Sd, 1-F, or 1-FC). CE a) To select 1-Sd, 1-F, or 1-FC, step until desired code is displayed. ENTER b) Momentarily depress The DATA display will now display "2-Sd". Displaying Valve selections for PROD 2: 2-Sd (Injection Module/Standard Valve), 2-F (Fast Valve), or 2-FC (Fast Close Valve). CE Depressing momentarily a) steps the DATA display from 2-Sd to 2-F. CE Depressing momentarily steps the DATA display from 2-F to 2-FC. b) CE Depressing momentarily c) steps the DATA display from 2-FC to 2-Sd. Selecting a Valve for PROD 2 (2-Sd, 2-F, or 2-FC). CE until desired code is displayed. a) To select 2-Sd, 2-F, or 2-FC, step ENTER The DATA display will now display "0". b) Momentarily depress The Console is now ready for the required Console Calibration programming to be entered.

NOTE: When entering data under the following keys, refer to the STANDARD DATA ENTRY PROCEDURE detailed at the beginning of the INITIAL CONSOLE PROGRAMMING section.

9) Procedure to enter BOOM CAL: Definition of keys:



6)

7)

8)

Depressing this key displays selected boom number in PROD 2 display window. **EXAMPLE:** Boom 1 will be displayed as b-01.



Depressing this key after selecting BOOM CAL selects the next boom number. **EXAMPLE:** b-01 will increase to b-02.



Depressing this key after selecting BOOM CAL selects the last boom number. **EXAMPLE:** b-02 will decrease to b-01.

Entering the calculated Boom Cal data:

- a) Select desired boom number.
- b) Enter boom length as determined in section "CALCULATING BOOM CAL".
- c) If a boom is not needed or used, enter a "0" for the length.
- SPEED CAL 10) Enter SPEED CAL in 4 METER CAL 11) Enter METER 1 CAL calibration number in 5 METER 2 If only one product is being used, enter "0". 12) Enter METER 2 CAL calibration number in the CAL 6 VALVE 1 CAL 13) Enter VALVE 1 CAL calibration number in 7 VALVE 2 CAL 14) Enter VALVE 2 CAL calibration number in If only one product is being used, enter "0". 8 PROD CAL 15) Enter PROD 1 CAL Target Application Rate 9

NOTE: A decimal point is automatically shown in the display window. Therefore, 20 ounces per acre is entered as "2""0""0", but shown as "20.0".

ROD

0

16) Enter PROD 2 CAL Target Application Rate, in

If only one product is being used, you must

perform the following two steps to complete the INITIAL CONSOLE PROGRAMMING:

- a) Enter "1.0" for PROD 2 CAL.
- b) Re-enter "0" for PROD 2 CAL.

YOU HAVE NOW COMPLETED REQUIRED PROGRAMMING FOR THE CONSOLE

17) The flashing "CAL" should now extinguish. If not, repeat the programming procedures starting at Step 9.

2. OTHER DISPLAY FEATURES

1) To display TOTAL AREA covered, momentarily depress

To "zero out" this total at any time,

enter a "0" in this key.

FIELD AREA 2) To display FIELD AREA covered, momentarily depress To "zero out" this total at any time, enter a "0" in this key. VOLUME Enter the estimated total volume of PRODUCT 1 tank in 3) Enter the estimated total volume of PRODUCT 2 tank in VOLUME **Each time the tank is refilled, this number must be re-entered.** PROD 1 VOLUME To "zero out" a) To display accumulated VOLUME of PRODUCT 1 sprayed, depress this total at any time, enter a "0" in this key. PROD 2 VOLUME b) To display accumulated VOLUME of PRODUCT 2 sprayed, depress To "zero out" this total at any time enter a "0" in this key. DISTANCE 4) To display DISTANCE (feet) [meters] traveled, depress To "zero out" this total at any time, enter a "0" in this key. SPEED 5) To display MPH [km/h], momentarily depress VOLUME 6) To display current VOLUME in PRODUCT 1 TANK, depress VOLUME TANK 2 7) To display current VOLUME in PRODUCT 2 TANK, depress To display current UNITS OF MEASURE selection (US, SI, or TU); SPEED SENSOR selection (SP1 8) SELF TEST or SP2); or VALVE selections (1-Sd, 1-F, or 1-FC; and 2-Sd, 2-F, or 2-FC), depress 3. SELF TEST FEATURE SELF TEST allows speed simulation for testing the system while the vehicle is not moving. Enter SELF TEST the simulated operating speed in the If 6 MPH [9.6 km/h] is desired, enter 6.0 [9.6] (See

CONSOLE PROGRAMMING). Verify speed by depressing

The DATA display will show a

speed of 6.0 [9.6]. The SELF TEST speed will clear itself when motion of vehicle is detected by the Speed Sensor. A SPEED CAL Value of 900 [230] or greater is recommended when operating in this mode.

SPEED

	NOTE:	To prevent nuisance clearing of self-test speed, disconnect speed connector on back of the Console when Radar Speed Sensors are used.
4.	SEQUEN	NCE TO ACTIVATE DATA-LOCK
1)	Depress	for 5 seconds, "NEU.1" and "CodE" will flash in DATA display.
2)	Enter a 4 digit	code within 15 seconds.
	EXAMPLE: F	or 1058, depress: $\begin{bmatrix} A \\ 1 \end{bmatrix} \begin{bmatrix} PROD & 2 \\ CAL \\ 0 \end{bmatrix} \begin{bmatrix} METER & 1 \\ CAL \\ 5 \end{bmatrix} \begin{bmatrix} VALVE & 2 \\ CAL \\ 8 \end{bmatrix}$ and $\begin{bmatrix} ENTER \\ CAL \\ 8 \end{bmatrix}$.
5.	SEQUEN	NCE TO CHANGE DATA-LOCK
1)	Depress	for 5 seconds, "oLd" and "CodE" will flash in DATA display.
2)	Enter old 4 dig	git code within 15 seconds: $\begin{bmatrix} PROD & 2 \\ 1 & 0 \end{bmatrix} \begin{bmatrix} METER & 1 \\ CAL \\ 5 & CAL \\ 5 & CAL \\ 8 \end{bmatrix}$ and $\begin{bmatrix} ENTER \\ ENTER \\ NEU.1" \end{bmatrix}$
	EXAMPLE: F	or 1258, depress: $\begin{bmatrix} \mathbf{A} \\ 1 \end{bmatrix} \begin{bmatrix} \mathbf{V} \\ 2 \end{bmatrix} \begin{bmatrix} METER & 1 \\ CAL \\ S \end{bmatrix} \begin{bmatrix} VALVE & 2 \\ CAL \\ S \end{bmatrix} \text{ and } \begin{bmatrix} ENTER \\ CAL \\ S \end{bmatrix}$.
6.	ENTER	MODE SEQUENCE WITH ACTIVATED DATA-LOCK
1)	Depress the k	ey into which you wish to enter data.
2)	Depress	, "CodE" will appear in DATA display. Enter your DATA-LOCK CODE.
	If code is corre	ect, "E" will replace "CodE" in DATA display. Now enter data normally.
	NOTE:	The DATA-LOCK feature prohibits the entry of data without first entering the DATA-LOCK CODE. If DATA-LOCK is not desired, omit Steps 4, 5, and 6. The DATA-LOCK CODE may be cleared by entering a code of "0" or by resetting the Console as described in REQUIRED CONSOLE PROGRAMMING.
7.	CONTRO	OL VALVE DELAY Control Valve Delay Digit X 0 0 0
	Hold key	until DATA display flashes. The Control Valve Delay number is a 4 digit number.
	The first digit in Booms are tun 1-9 means a d are always zen or ON in inter	In the Control Valve Delay number represents the time (in seconds) between when the red ON and when the Console actually begins to control the flow rate. A value of elay of 1-9 seconds respectively, a value of 0 means no delay. The remaining 3 digits ro. The Control Valve Delay feature only operates when the booms are toggled OFF vals of 30 seconds or less.

8. AUTOMATIC RATE +/-

This feature sets the increment at which flow is increased or decreased in AUTO operation. Select



EXAMPLE: If rate is to changed by "1.0":

Enter a value of 1.0 for RATE +/-. When in AUTO, each time the INC/DEC switch is positioned to INC the PROD CAL for that product will increase by "1.0". Likewise, when positioned to DEC the PROD CAL will decrease by "1.0".

9. VOLUME/AREA RATE ALARM

Console alarm sounds if the application rate is 30% or more away from the target application rate for more than 5 seconds.

NOTE:	Go to DATA MENU to silence alarm.

10. LOW TANK FAULT

This feature will sound the alarm when the volume in the tank drops below an entered value. The alarm will intermittently beep every 15 seconds and the DATA display will flash "LEVL". The alarm will stop when a value equal to or greater than the LOW TANK ALARM is entered into VOL/TANK or the booms are turned OFF. Entering "0" into LOW TANK ALARM disables it. To select LOW

TANK ALARM depress $\left(\begin{array}{c} VOLUME \\ TANK & 1 \end{array} \right)$ for PRODUCT 1 or $\left(\begin{array}{c} VOLUME \\ TANK & 2 \end{array} \right)$ for PRODUCT 2 until the DATA displa
ashes. To enter a value,
lepress ENTER, then LOW TANK ALARM value, and ENTER.
IOTE: Go to DATA MENU to silence alarm.

11. DATAMENU

The following are brief descriptions of features available under the DATA MENU key:

	DISPLAY SCH					
SERIAL PORT SCREENS						
	SPr	Prn	bEGn	CONSOLE DATA PRINTOUT Sends data through serial port to attached optional printer to print field begin and field end pages.		
	SPr	FrEF	0	FIELD REFERENCE Allows user to enter up to a four-digit number to represent a field. Field reference is included in field begin and field end pages and the data logger time/ date string.		
	SPr	bAUd	1200	BAUD RATE Used in GPS mode and data logging mode. Select- able between 1200 or 9600 baud.		
	SPr	rAtE	on	RATE CHANGE ALARM ON/OFF Turns rate change alarm ON or OFF. When rate change alarm is selected ON; alarm sounds 4 long beeps when a rate calibration number is changed via the serial port using a valid change request data string.		
	SPr	triG	0	DATA LOGGER TRIGGER VALUE Used in data logging mode. The trigger determines how often actual rate data string (See Appendix 16 for data communication string formats) is sent to the serial port. The trigger may be either feet [meters] or seconds.		
	SPr	Unit	Ft	DATA LOGGER TRIGGER UNITS Used in data logging mode. The trigger unit is select- able between feet [meters] or seconds.		
	SPr	dLoG	oFF	DATA LOGGER ON/OFF Turns data logger ON or OFF.		
GLOBAL POSITIONING SYSTEM SCREENS						
	GPS	FiLE	1	GPS FILE REFERENCE Used only with Raven Grid Application System. See Grid Application System manual for more details.		
	GPS	SYSt	InAC	GPS SYSTEM OPTIONS Used only with Raven Grid Application System. See Grid Application System manual for more details.		

	DISPLAY SCREEN				
	PROD 1	<u>PROD 2</u>	<u>DATA</u>	FEATURE and DESCRIPTION	
DATE	SUREENS	() A	0.00		
	dAtE	tiME	0:00	Time of day.	
	dAtE	onth	0	MONTH Current month of year.	
	dAtE	daY	0	DATE Current date of month.	
	dAtE	YEAr	0	YEAR Current year.	
	dAtE	P dn	10	POWER DOWN Puts Console into low power mode.	
FLOW	/ RATE SCREENS				
	Fr	FL01	0	VOLUME/MINUTE PRODUCT 1 Displays volume per minute of Product 1.	
	Fr	FLo2	0	VOLUME/MINUTE PRODUCT 2 Displays volume per minute of Product 2.	
	Fr	LL 1	0	VOLUME/MINUTE RATE FAULT PRODUCT 1 Turns alarm ON if Product 1 actual volume per minute falls below this limit.	
	Fr	LL 2	0	VOLUME/MINUTE RATE FAULT PRODUCT 2 Turns alarm ON if Product 2 actual volume per minute falls below this limit.	
ΔΙΔΡΙ					
ALARI	Al r	AL rN/	00		
	ALI	ALIM	UI	AUDIBLE ALARMS ON/OFFTurns audible alarms ON or OFF for the following:1)Volume/Area Rate Alarm2)Volume/Minute Rate Fault3)Low Tank Fault4)Vacuum Alarm5)Flow Alarm6)Flow Error Alarm	
	ALr	vL 1	on	VACUUM AND FLOW FAULT PRODUCT 1 Turns alarms ON or OFF for a vacuum or flow fault in Product 1 injection pump.	
	ALr	vL 2	on	VACUUM AND FLOW FAULT PRODUCT 2 Turns alarms ON or OFF for a vacuum or flow fault in Product 2 injection pump.	

	DISPLAY SCREEN <u>PROD 1</u> <u>PROD 2</u>		DATA	FEATURE and DESCRIPTION		
	ALr	FE 1	on	FLOW ERROR PRODUCT 1 Turns alarms ON or OFF for flow error in Product 1.		
	ALr	FE 2	on	FLOW ERROR PRODUCT 2 Turns alarms ON or OFF for flow error in Product 2.		
MISCELLANEOUS SCREENS						
	MiSC	diSP	on	DISPLAY SMOOTHING ON/OFF Turns display smoothing ON or OFF. Selecting dis- play smoothing ON means the RATE window dis- plays target rate when actual rate is within a percent- age of target rate. The third digit of VALVE CAL determines this percentage.		
	MiSC	AG 1	oFF	AGITATOR PRODUCT 1 Turns agitator ON or OFF for Product 1.		
	MiSC	AG 2	oFF	AGITATOR PRODUCT 2 Turns agitator ON or OFF for Product 2.		
	MiSC	APh	0	AREA/HOUR Displays area per hour.		

1) Definition of Data Menu Key:



Depressing this key displays the selected Data Menu category in the PROD 1 display.



Depressing this key again increments through the Data Menu categories ("SPr", "GPS", "dAtE", etc...) in the PROD 1 display.



Depressing this key (after desired category is shown in PROD 1 display) toggles up through desired features within a category. Selected feature is shown in the PROD 2 display.



Depressing this key (after desired category is shown in PROD 1 display) toggles down through desired features within a category. Selected feature is shown in the PROD 2 display.

SERIAL PORT SCREENS

- 2) CONSOLE DATA PRINTOUT
 - a) PROD 1 display will show "SPr". PROD 2 display will show "Prn". DATA display will show "bEGn" (Print Field Begin).
 - 1) To Print Field Begin, depress

- b) PROD 2 display will now show "Prn" and DATA display will show "End" (Print Field End).
 - To Print Field End, depress
 While "End" is displayed, if Field Begin is required, depress
 to toggle DATA display to "BEGn".
- c) Momentarily depress $\begin{bmatrix} \Delta \\ 1 \end{bmatrix}$ to advance to FIELD REFERENCE.
- 3) FIELD REFERENCE
 - a) PROD 1 display will show "SPr". PROD 2 display will show "FrEF". DATA display will show "0".
 - **b)** Enter the field number.
 - c) Momentarily depress 4 to advance to BAUD RATE.
- 4) BAUD RATE
 - a) PROD 1 display will show "SPr". PROD 2 display will show "bAUd". DATA display will show "1200".
 - **b)** Depressing CE momentarily changes the DATA display between "1200" and "9600".
 - c) Momentarily depress 4 to advance to RATE CHANGE ALARM ON/OFF.
- 5) RATE CHANGE ALARM ON/OFF
 - a) PROD 1 display will show "SPr". PROD 2 display will show "rAtE". DATA display will show "on".
 - **b)** Depressing ce momentarily changes the DATA display between "on" and

"oFF". A value of "on" means alarm is enabled; a value of "oFF" means alarm is disabled.

c) Momentarily depress

to advance to DATA LOGGER TRIGGER VALUE.

- 6) DATA LOGGER TRIGGER VALUE
 - a) PROD 1 display will show "SPr". PROD 2 display will show "TriG". DATA display will show "0".
 - **b)** Enter the TRIGGER VALUE.
 - c) Momentarily depress 4 to advance to DATA LOGGER TRIGGER UNITS.

NOTE: The TRIGGER VALUE default value is "zero". This value must be changed to a desired number ranging from 1-9999. The DATA LOGGER features will not work if this number is not changed.

7) DATA LOGGER TRIGGER UNITS

CE

- a) PROD 1 display will show "SPr". PROD 2 display will show "Unit". DATA display will show "Ft"["MEtr"].
- b) Depressing

momentarily changes the DATA display between "Ft"

[MEtr"] and "SEC". A value of "Ft"["MEtr"] means feet [meters], or a value of "SEC" means seconds have been chosen as the unit of measurement for the TRIGGER VALUE programmed previously.

c) Momentarily depress

to advance to DATA LOGGER.

8) DATA LOGGER ON/OFF

- a) The DATA LOGGER uses the communications strings listed in Appendix 16 to pass data out through the serial port. The data is sent at a set time interval or a set distance traveled, as determined by the values entered in the DATA LOGGER TRIGGER VALUE and DATA LOGGER TRIGGER UNITS. Upon each trigger, the Actual Rate string, Data Strings 1, 2, and 3, and the Time/date string are sent, in that order. When a Console calibration value is changed, the Console will automatically send out the Cal 1, 2, and 3 strings. When a Console switch is changed, the Data 1, 2, 3, Time/Date, and Cal 1, 2, 3 strings will be sent by the Console. The Data, (with Time/Date string included) and Cal strings can also be requested by the data logger using the request strings shown in Appendix 16.
- b) PROD 1 display will show "SPr". PROD 2 display will show "dLOG". DATA display will show "oFF".
- c) Depressing $\left(\begin{array}{c} c \\ c \end{array}\right)$ momentarily changes the DATA display between "oFF" and "on".

A value of "oFF" means DATA LOGGER is disabled; a value of "on" means DATA LOGGER is enabled.

d) Momentarily depress 4 to advance to CONSOLE DATA PRINTOUT.

DATA MENU

e) Momentarily depress

to advance to the GLOBAL POSITIONING SYSTEM category.

GLOBAL POSITIONING SYSTEM SCREENS

9) GPS FILE REFERENCE

- a) PROD 1 display will show "GPS". PROD 2 display will show "FILE". DATA display will show a "1".
- **b)** Enter the GPS file number.
- c) Momentarily depress 4 to advance to GPS SYSTEM OPTIONS.

10) GPS SYSTEM OPTIONS

a) GPS is inactive when the PROD 1 display shows "GPS", the PROD 2 display shows "SYSt", and the DATA display shows "InAC". The GPS features are explained further in the GRID APPLICATION SYSTEM MANUAL.



DATE SCREENS

- 11) TIME
 - a) PROD 1 display will show "dAtE". PROD 2 display will show "tiME". The DATA display will show "0:00".
 - **b)** Enter the current time of day.
 - c) Momentarily depress $\begin{bmatrix} A \\ 1 \end{bmatrix}$ to advance to MONTH.

NOTE: This is a 24 hour clock. Therefore, all time after 12:59 p.m., add 12 hours. Thus, 8:30 a.m. is entered as 8:30, but 1:30 p.m. is entered as 13:30 in the keyboard.

12) MONTH

- a) PROD 1 display will show "dAtE". PROD 2 display will show "onth". The DATA display will show "0".
- **b)** Enter the current month by number (i.e. 1 = January, 2 = February, etc.).
- c) Momentarily depress 4 to advance to DAY.

13) DAY

- a) PROD 1 display will show "dAtE". PROD 2 display will show "daY". The DATA display will show "0".
- **b)** Enter the current day of the month.
- c) Momentarily depress

to advance to YEAR.

14) YEAR

- a) PROD 1 display will show "dAtE". PROD 2 display will show "YEAr". The DATA display will show "00".
- b) Enter the current year.
- c) Momentarily depress $\begin{bmatrix} A \\ 1 \end{bmatrix}$ to advance to POWER DOWN.
- **15)** POWER DOWN
 - a) If the Console is not used for 10 days, it will go into a power down (low power) mode of operation. In this mode, all data is retained, but the time

of day clock will reset to 0:00. The delay time is initially set at 10 days; but can be changed by the user.

- b) PROD 1 display will show "dAtE". PROD 2 display will show "P dn". The DATA display will show "10".
- c) To change the delay time enter a new number from 0 to 200 days.

DATA MENU

- d) Momentarily depress
- e) Momentarily depress

to advance to TIME.

to advance to the FLOW RATE category.

FLOW RATE SCREENS

- **16)** VOLUME/MINUTE PRODUCT 1
 - **a)** PROD 1 display will show "Fr". PROD 2 display will show "FLo1". The DATA display will show the volume per minute of Product 1.
 - **b)** Momentarily depress to advance to VOLUME/MINUTE PRODUCT 2.
- **17)** VOLUME/MINUTE PRODUCT 2
 - a) PROD 1 display will show "Fr". PROD 2 display will show "FLo2". The DATA display will show the volume per minute of Product 2.
 - b) Momentarily depress to advance to VOLUME/MINUTE RATE FAULT PRODUCT 1.
- 18) VOLUME/MINUTE RATE FAULT PRODUCT 1
 - a) If the actual volume per minute falls below the set limit, the injection pump stops slowing down, or the control valve stops closing, an alarm sounds and the PROD 1 display flashes "-LL-".

The low limit value should be determined with all booms ON. This value is automatically proportioned to the percentage of booms that are ON.

EXAMPLE:The entered low limit is 4. If half the total boom length is turned OFF, the Console will automatically reduce the entered low limit to 2.

- **b)** PROD 1 display will show "Fr". PROD 2 display will show "LL 1". The DATA display will show "0".
- c) Enter the set limit.
- d) Momentarily depress to advance to VOLUME/MINUTE RATE FAULT PRODUCT 2.

19) VOLUME/MINUTE RATE FAULT PRODUCT 2

a) If the actual volume per minute falls below the set limit, the injection pump stops slowing down, or the control valve stops closing, an alarm sounds and the PROD 2 display flashes "-LL-".

The low limit value should be determined with all booms ON. This value is automatically proportioned to the percentage of booms that are ON.

- **EXAMPLE:** The entered low limit is 4. If half the total boom length is turned OFF, the Console will automatically reduce the entered low limit to 2.
- **b)** PROD 1 display will show "Fr". PROD 2 display will show "LL 2". The DATA display will show "0".
- c) Enter the set limit.
- d) Momentarily depress to advance to VOLUME/MINUTE PRODUCT 1.
 e) Momentarily depress data MENU to advance to the ALARM category.

ALARM SCREENS

20) AUDIBLE ALARM ON/OFF

- a) PROD 1 display will show "ALr". PROD 2 display will show "ALrM". DATA display will show "on".
- b) Momentarily depressing changes the DATA display between "on"

(alarms enabled) and "oFF" (alarms disabled).

- c) Momentarily depress to advance to VACUUM AND FLOW FAULT PRODUCT 1.
- 21) VACUUM AND FLOW FAULT PRODUCT 1
 - a) Too much vacuum on the inlet side of the injection pump will cause inaccurate operation. If pulling 10 inches of Hg for 5 seconds an audible alarm will sound and the PROD 1 display will flash "VAC".

If there is a vacuum alarm:

- 1) Strainer screen is plugged.
- 2) Investigate other possible obstructions.
- **b)** If an injection pump is running and no flow is detected for 5 seconds an audible alarm will sound and the PROD 1 display will flash "FLo".

If there is a flow alarm:

- 1) Injection module tank is empty.
- 2) Product is not being injected.
- c) PROD 1 display will show "ALr". PROD 2 display will show "vF 1". The DATA display will show "on".
- d) Momentarily depressing

changes the DATA display between "on"

(alarms enabled) and "oFF" (alarms disabled).

CE

e) Momentarily depress



- **22)** VACUUM AND FLOW FAULT PRODUCT 2
 - a) Too much vacuum on the inlet side of the injection pump will cause inaccurate operation. If pulling 10 inches of Hg for 5 seconds an audible alarm will sound and the PROD 2 display will flash "VAC".

If there is a vacuum alarm:

- 1) Strainer screen is plugged.
- 2) Investigate other possible obstructions.
- **b)** If an injection pump is running and no flow is detected for 5 seconds an audible alarm will sound and the PROD 2 display will flash "FLo".

If there is a flow alarm:

- 1) Injection module tank is empty.
- 2) Product is not being injected.
- c) PROD 1 display will show "ALr". PROD 2 display will show "vF 2". The DATA display will show "on".
- d) Momentarily depressing $\begin{bmatrix} c \\ c \end{bmatrix}$ changes the DATA display between "on"

(alarms enabled) and "oFF" (alarms disabled).

- e) Momentarily depress 4 to advance to FLOW ERROR PRODUCT 1.
- 23) FLOW ERROR PRODUCT 1
 - a) If the booms are off or there is no speed, but flow is detected for 5 seconds, an audible alarm will sound and the PROD 1 display will flash "FLo Err".
 - b) PROD 1 display will show "ALr". PROD 2 display will show "FE 1". DATA display will show "on".
 - c) Momentarily depressing
- changes the DATA display between "on"

(alarms enabled) and "oFF" (alarms disabled).

CE

d) Momentarily depress

to advance to FLOW ERROR PRODUCT 2.

- 24) FLOW ERROR PRODUCT 2
 - a) If the booms are off or there is no speed, but flow is detected for 5 seconds, an audible alarm will sound and the PROD 2 display will flash "FLo Err".
 - **b)** PROD 1 display will show "ALr". PROD 2 display will show "FE 2". DATA display will show "on".
 - c) Momentarily depressing

changes the DATA display between "on"

(alarms enabled) and "oFF" (alarms disabled).

CE



CE

MISCELLANEOUS SCREENS

25) DISPLAY SMOOTHING ON/OFF

b) Momentarily depressing

changes the DATA display between "on" and "oFF". A value

of "on" means smoothing is enabled; a value of "oFF" means smoothing is disabled. The percent smoothing is determined by the third digit of VALVE CAL value as shown:

Brake Point Digit (3rd digit) of VALVE CAL 2 123

0 = 1% + Deadband	5 = 25% + Deadband
1 = 3% + Deadband	6 = 30% + Deadband
2 = 7% + Deadband	7 = 35% + Deadband
3 = 10% + Deadband	8 = 40% + Deadband
4 = 20% + Deadband	9 = 45% + Deadband

Actual rate is displayed if unit does not reach deadband within 10 seconds. "oFF" means RATE displays the actual rate at all times.

c) Momentarily depress $\begin{bmatrix} 4 \\ 1 \end{bmatrix}$ to advance to AGITATOR PRODUCT 1.

26) AGITATOR PRODUCT 1

- a) PROD 1 display will show "MiSC". PROD 2 display will show "AG 1". DATA display will show "oFF".
- **b)** Momentarily depressing

changes the DATA display between "on"

(agitator 1 enabled) and "oFF" (agitator 1 disabled).

c) Momentarily depress 4 to advance to AGITATOR PRODUCT 2.

27) AGITATOR PRODUCT 2

- a) PROD 1 display will show "MiSC". PROD 2 display will show "AG 2". DATA display will show "oFF".
- **b)** Momentarily depressing ^{CE} changes the DATA display between "on"

(agitator 2 enabled) and "oFF" (agitator 2 disabled).

c) Momentarily depress 4 to advance to AREA/HOUR.

NOTE:Some options within the DATA MENU LISTINGS may be unavailable if certain
features are on or active. The options affected are:CONSOLE DATA PRINTOUT:Console Data Printout will not be available when DATA
LOGGER is ON or when GPS functions are ACTIVE.GPS OPTIONS:GPS Options will not be available when DATA LOGGER is
ON.DATA LOGGER:DATA LOGGER will not be available when GPS functions
are active.

12. DECIMALSHIFT

The DECIMAL SHIFT feature is used to increase system accuracy at low application rates. Shifting of the decimal point is done during the entry of METER CAL.

After entering METER CAL mode, depress the decimal shift

constant number and depress

The sequence to unshift the decimals while in METER CAL

SELF TEST

is to enter the meter calibration constant number and depress

ENTER

The following table illustrates

Enter the meter calibration

how shifting the decimal point can increase system accuracy.

DECIMAL PLACE LOCATIONS

	US		METRIC		TURF	
	UNSHIFT	SHIFT	UNSHIFT	SHIFT	UNSHIFT	SHIFT
prod 1 display	000.0	00.00	0000	000.0	00.00	00.00
PROD 2 DISPLAY	000.0	00.00	0000	000.0	00.00	00.00
prod 1 Cal	000.0	00.00	0000	000.0	00.00	00.00
PROD 2 CAL	000.0	00.00	0000	000.0	00.00	00.00
PROD 1 VOLUME	0000	000.0	0000	000.0	000.0	000.0
PROD 2 VOLUME	0000	000.0	0000	000.0	000.0	000.0
VOLUME/TANK 1	0000	000.0	0000	000.0	000.0	000.0
VOLUME/TANK 2	0000	000.0	0000	000.0	000.0	000.0
DATA MENU FLo1	0000	000.0	0000	000.0	000.0	000.0
DATA MENU FLo2	0000	000.0	0000	000.0	000.0	000.0
DATA MENU LL1	0000	000.0	0000	000.0	000.0	000.0
DATA MENU LL2	0000	000.0	0000	000.0	000.0	000.0
PROD 1 RATE +/-	000.0	00.00	0000	000.0	00.00	00.00
PROD 2 RATE +/-	000.0	00.00	0000	000.0	00.00	00.00
PROD 1 LOW TANK	0000	000.0	0000	000.0	000.0	000.0
PROD 2 LOW TANK	0000	000.0	0000	000.0	000.0	000.0

When entering PROD 1 CAL and PROD 2 CAL, remember that 2 GPA [20 lit/ha] is entered as 2.0 [20.0] when unshifted and 2.00 [20.00] when shifted.

PRODUCT INJECTION INSTALLATION AND SET-UP 1. PLUMBING THE INJECTION MODULE



FIGURE 9A

- 1) Plumb the Pressure Relief Valve (PRV), Flow Meter, Control Valve, Carrier Check Valve, Product Check Valves, and In-line Mixer just ahead of the Boom On/Off Valves as shown in Figure 4.
- 2) Mount Injection Modules close to the Boom On/Off Valves to minimize amount of product in tubing. See Appendixes 7, 8, and 9 for mounting instructions on various styles of injection modules.
- 3) Inlet line from product tank to Injection Module shall be 3/4" suction hose.
- 4) Plumb output lines of Injection Modules to Product Check Valves with 3/8 inch [10 mm] tubing on low volume modules; or 1/2 inch [13 mm] tubing on high volume modules (Product Check Valves and tubing not furnished).
- 5) Figure 9B defines the handle positions for the three way valve.


6) Figure 9C illustrates typical injection module plumbing, showing the three way valve handle positions for injecting product.



FIGURE 9C

2. RECOMMENDED INJECTION PUMP FLUSH SYSTEM

The recommended system is shown in Figure 10. Strainers are recommended for the product and flush system water. Strainers suitable for concentrated product are typically 20 mesh stainless steel. However, certain products may not flow through strainer without causing excessive vacuum or may clog strainer entirely. It is recommended that a flush system be incorporated with the injection system. This will enhance the performance of the injection pump. The basic components are shown below and are available through local spraying equipment supplier. This system shall be installed as shown and operated per the following instructions. The required frequency of flushing may vary per the product being injected.

- 1) Drain or empty Product Injection Tank.
- 2) Place VALVE 3 in Recirculation position.
- Place VALVE 2 in position to let clean water circulate thru Injection Pump from flush pump.
 VENT PRODUCT TANK. Start the Flush System, pump approximately 1/2 gallon into Injection Tank.
- 4) Reposition VALVE 2 and VALVE 3 to allow rinse mixture to be injected. Spray rinse mixture at normal recommended rate.
- 5) Repeat this procedure until Pump and Tank are clean. (i.e. Triple rinse).



3. DETERMINING INJECTION MODULE "METER CAL"

1) Use the calibration tag attached to the Injection Pump (reproduced below) to determine the METER CAL for each product used.

NOTE: Product METER CALS are oz (dl) per unit.



FIGURE 11

- Using the Pump Setting Number determined in "CALCULATING PUMP SETTING". Locate the METER CAL number that corresponds to this setting.
 EXAMPLE: For Pump Setting 5 the METER CAL number is 220 [744].
- **3)** Write down this METER CAL calibration number for future reference when programming the Console.
- 4) If two injection pumps are used, determine the METER CAL for remaining Injection Pump.

4. CALCULATING PUMP SETTING

The following procedure calculates the correct Pump Setting for Injection Pump. The High Volume Injection Module has an output range of 2.5 to 200 oz/min, use Figure 12A. The Low Volume Injection Module has an output range of 1.0 to 100 oz/min, use Figure 12B. The Ultra Low Volume Injection Module has an output range of .5 to 40 oz/min, use Figure 12C.

1) Calculate **MAXIMUM** and **MINIMUM** volume per minute (oz/min)[dl/min] of product required by using the following formulas:

MAXIMUM vol/min	= <u>Speed x Boom Width x Rate</u> 5,940 [60,000] {137}
Speed Boom Width	 Maximum Spray Speed in MPH [km/h] Maximum Number of Spray Nozzles x Nozzle Spacing in inches [cm] (i.e. total boom width)
Rate	= Recommended Product Application Rate in Ounces per Acre [dl/ha] {oz/1,000 sq. ft.}
MINIMUM vol/min	= <u>Speed x Boom Width x Rate</u> 5,940 [60,000] {137}
MINIMUM vol/min Speed Boom Width	 = Speed x Boom Width x Rate 5,940 [60,000] {137} = Minimum Spray Speed in MPH [km/h] = Minimum Number of Spray Nozzles x Nozzle Spacing in inches [cm] (i.e. one boom width)

EXAMPLE: Maximum vol/min (High Volume Pump)

US (ENGLISH UNITS)

Speed	= 15 MPH
Boom Width	= 36 nozzles x 20 inches/nozzle = 720 inches
Rate	= 2 pints/acre x 16 oz/pint = 32 oz/acre
Maximum oz/min	= <u>15 MPH x 720 inches x 32 oz/acre</u> = 58.1
	5,940

SI (METRIC UNITS)

Speed	= 24.1 km/h
Boom Width	= 36 nozzles x 51 cm/nozzles = 1836 cm
Rate	= 2.3 lit/ha x 10 dl/liter = 23 dl/ha
Maximum dl/min	= <u>24.1 km/h x 1836 cm x 23 dl/ha</u> = 17.0
	60,000

TU (TURF UNITS)		
Speed	=	15
Boom Width	=	36 nozzles x 20 inches = 720 inches
Rate	=	.73 oz/1,000 sq. ft.
Maximum oz/min	=	15 MPH x 720 inches x .73 oz/1,000 sq. ft. = 58.1
		137

EXAMPLE: <u>Minimum vol/min (High Volume Pump)</u>

US (ENGLISH	UNITS)	
Speed	=	8 MPH
Boom Width	=	12 nozzles x 20 inches/nozzle = 240 inches
Rate	=	2 pints/acre x 16 oz/pint = 32 oz/acre
oz/min	=	<u>8 MPH x 240 inches x 32 oz/acre</u> = 10.3
		5,940

SI (METRIC UNITS)

Speed	=	12.9 km/h
Boom Width	=	12 nozzles x 51 cm/nozzles = 612 cm
Rate	=	2.3 lit/ha x 10 dl/liter = 23 dl/ha
dl/min	=	<u>12.9 km/h x 612 cm x 23 dl/ha</u> = 3.0
		60.000

TU (TURF UNITS)

Speed	=	8
Boom Width	=	12 nozzles x 20 inches = 240 inches
Rate	=	.73 oz/1,000 sq. ft.
oz/min	=	8 MPH x 240 inches x .73 oz/1,000 sq. ft. = 10.3
		137

- 2) Locate the calculated MAXIMUM and MINIMUM oz/min [dl/min] on the horizontal line of Pump Chart. (See Figures 12A, 12B & 12C).
- 3) Draw a vertical line from these points to the highest pump setting.
- 4) Use highest pump setting which intersects both vertical lines on the graphs.

EXAMPLE: MAXIMUM setting of 58.1 oz/min [17.0 dl/min]; MINIMUM setting of 10.3 oz/min [3.0 dl/min] = pump setting 6 (See Figure 13).

NOTE: Use the "10" setting for all product application rates that are within the range of the "10" setting (i.e. 2.5 to 200 oz/min for the high volume module, 1.0 to 100 oz/min for the low volume module and .5 to 40 oz/min for the ultra low volume module.)

NOTE: The pump must be set to the "10" setting for priming.

5. ADJUSTING PUMP SETTING

- 1) Loosen the pump-setting locking nut, pull out on locking pin and rotate the 2-10 setting pointer to the proper number. (See Figure 13).
- 2) Tighten the pump setting locking nut taking care to keep setting pointer on the number.



<u>CAUTION</u>: An error in positioning the setting pointer will result in an error in product application.

SYSTEM OPERATION

1. INITIAL CARRIER SET-UP

- 1) Fill tank with water only. (If positive displacement type pump is used, fully open pressure relief valve, PRV).
- 2) Place MASTER ON/OFF to ON and all BOOM ON/OFF switches to OFF.
- 3) Place carrier PRODUCT OFF/MAN/AUTO switch to MAN.
- 4) Place POWER ON/OFF switch to ON.
- 5) Verify correct Boom Widths, SPEED CALS, METER CALS, VALVE CALS, and RATE CALS have been entered in the Console.
- 6) Run pump at normal operating RPM.
- 7) If centrifugal pump is used, proceed to Step 8. If positive displacement type pump is used, set pressure relief valve (PRV) to 65 PSI [448 kPa].

- 8) Verify that each Boom ON/OFF Valve operates and that no nozzles are plugged by operating BOOM ON/OFF switches.
- 9) Enter a SELF TEST speed equal to that of normal operating speed, verify entry by depressing SPEED (6 MPH [9.6 km/h] is recommended). (See "SELF TEST FEATURE").
- 10) Place all BOOM ON/OFF switches to ON, the carrier PRODUCT display should show a reading.
- **11)** Hold the carrier PRODUCT INC/DEC switch in INC position for approximately 12 seconds. This assures that the motorized Control Valve is fully open. Verify maximum pressure and carrier PRODUCT rate. (Pressure gauge is not supplied)

NOTE: A pressure gauge MUST be installed to properly monitor the system.

- 12) Adjust agitator line hand valve for desired agitation. Verify maximum pressure is still present.
- **13)** Hold the carrier PRODUCT INC/DEC switch in DEC position for approximately 12 seconds. This assures motorized Control Valve is fully closed. Verify minimum pressure and carrier PRODUCT rate can be achieved. If not, consider increasing application rate of carrier or changing type of Control Valve. Consult a Raven Dealer.

NOTE: It is recommended that PRODUCT 1 be used for a Carrier.

2. INITIAL CARRIER FIELD TEST

- 1) Drive down field or road at target speed with sprayer booms OFF to verify speed readout on Console.
- 2) Turn on Sprayer pump and booms, place the carrier PRODUCT OFF/MAN/AUTO switch to AUTO. Increase or decrease speed by one MPH [2 km/h], the system should automatically correct to the target application rate.
- **3)** If, for any reason, the system is unable to correct to the desired GPA [lit/ha], check for an empty tank, a plugged line, a malfunctioning pump, improper vehicle speed, or a defect in the system.
- 4) If the system does not appear to be correcting properly, review "INITIAL CARRIER SET-UP".
- 5) At the end of each row, switch the MASTER ON/OFF switch to OFF to shut off flow. This also shuts off the area totalizer.
- 6) Verify area covered and volume used.

3. INITIAL INJECTION SET-UP

- 1) Fill Injection Module Tank with <u>water</u>.
- 2) Place the 3-way valve handle on Injection Pump to the "injection" position (See Figure 9C).

- 3) Place MASTER ON/OFF switch to ON and BOOM ON/OFF switches to OFF.
- 4) Place all PRODUCT OFF/MAN/AUTO switches to OFF.
- 5) Place POWER ON/OFF switch to ON.
- 6) Verify correct Boom Widths, SPEED CALS, METER CALS, VALVE CALS, and RATE CALS have been entered in the Console.
- 7) Run main carrier pump at normal operating RPM.
- 8) Verify that each BOOM ON/OFF Valve operates and that no nozzles are plugged by operating Boom ON/OFF switches. (MASTER switch must be ON).
- 9) Enter a SELF TEST speed equal to that of normal operating speed, verify entry by depressing SPEED (6 MPH [9.6 km/h] is recommended). (See Self Test mode under "SPEED" in "OTHER DISPLAY FEATURES").
- **10)** Place all BOOM ON/OFF switches to ON.
- **11)** Place PRODUCT 2-OFF/MAN/AUTO switch to MAN, the PRODUCT 2 display should display a reading.
- **12)** Verify that by operating the injection PRODUCT 2 INC/DEC switch, that injection PRODUCT 2 can be varied over a wide range above and below the desired application rate in oz/acre [dl/ha]. Then set injection PRODUCT 2 for normal oz/acre [dl/ha] of application.
- **13)** Repeat Steps 11 and 12 for each Product in use.
- **14)** Place OFF/MAN/AUTO switch for each Product in use to AUTO. The system will seek the programmed injection PRODUCT RATE CAL.
- **15)** Enter a SELF TEST speed 2 MPH [3.2 km/h] greater than that initially programmed (8.0 MPH) [12.9 km/h]. The system will automatically correct for this speed variation.
- **16)** Turn one BOOM ON/OFF switch to OFF position. The system will automatically correct for this change in boom lengths.
- 17) Repeat Steps 11 thru 16 for all remaining injection products.
- **17)** Drain water from Injection Module Tank and add product.
- **18)** To verify at any time that the Injection Pump is properly calibrated, refer to Appendix 11.

PREVENTIVE MAINTENANCE

Preventive maintenance is most important to assure long life of the system. The following maintenance procedures should be followed on a regular basis:

- 1) Flush carrier system with water after use of suspension type products. Failure to clean systems can result in crystallization of products which may plug the Flow Meter, lines, and/or tips.
- 2) Flush and drain system before storing.

IMPORTANT: Freezing temperatures may damage system if water is not drained.

- 3) Periodically clean strainer on Injection Module.
- 4) Check oil level in Injection Pump daily. If addition of oil is required, add Mobil #1 (5W30) ONLY. Drain and refill the pump after every 150 hours of operation. (See Figure 14).
- 5) Flush Injection system by using flush system (See "RECOMMENDED INJECTION PUMP FLUSH SYSTEM") or by recirculating water through Injection Module until pump is clear of product. When storing at the end of season, recirculate antifreeze during the last flush.



FIGURE 14

APPENDIX 1 WHEEL DRIVE SPEED SENSOR INSTALLATION AND CALIBRATION PROCEDURE

1. MOUNTING WHEEL DRIVE SPEED SENSOR

The Wheel Drive Speed Sensor consists of four magnets, a switch assembly with cable, and mounting hardware.

Sequence of mounting Speed Sensor:

- I) Select a non-driven wheel (left front tractor wheel or implement wheel).
- 2) Check for predrilled holes in rim. If not predrilled, see "RIM DRILLING INSTRUCTIONS FOR WHEEL DRIVE SPEED SENSOR".
- **3)** Mount the four magnets to inside of rim and tighten. (See Figures 15A, 15B, & 15C). Magnets must be mounted in alternating red-black order.
- 4) Mount switch assembly to stationary column with the hardware provided. (See Figure 15A). The switch assembly need not pivot with the wheel.





- 5) Position switch assembly so that as the wheel rotates the magnets pass across the center of the black, molded switch assembly. (See Figures 15A & 15C).
- 6) Clearance gap between magnets and switch assembly must be between 1/4 inch [6 mm] and 1 inch [25 mm]. With wheels pointed straight ahead, rotate wheel to ensure gap is correct. Make sure vehicle wheels can be turned to their extremes in each direction without the magnets hitting the switch assembly.
- 7) Tighten switch assembly bracketry.
- 8) Secure cable to column with plastic cable ties.

2. RIM DRILLING INSTRUCTIONS FOR WHEEL DRIVE SPEED SENSOR MAGNETS

On wheels which do not have pre-punched mounting holes, proceed as follows:

RIMS WITH FOUR OR EIGHT HOLE STUD PATTERN:

Choose stud holes that are opposite each other as shown in Figure 16A. Using the center of opposite holes, scribe two lines on the rim web to divide the circumference into four equal parts. Measure in one inch from the outer edge of the web on each of the lines drawn. Mark this point as the center. Drill four 1/2" holes for mounting the magnets.

NOTE:Distance (D) between each set of drilled holes must be equal within 1/8" [3 mm] to ensure accuracy of system.

RIMS WITH SIX HOLE STUD PATTERN:

Locate the center of the holes to be drilled by using the rim webbing as a guide. (See Figure 16B). Obtain a small piece of wood and cut to fit exactly over the web as shown in Figure 16B. Measure the length of the piece of wood and mark the center on one edge. Using the center mark on the piece of wood, mark each of the four webs. Measure in one inch from the outer edge of the web on each of the lines drawn. Mark this point as center and drill four 1/2" holes for mounting the magnets.

NOTE:Distance (D) between each set of drilled holes must be equal within I/8" [3 mm] to ensure accuracy of system.



3. CALCULATING "SPEED CAL"

- 1) Place a chalk mark or tape onto the vehicle tire that the Speed Sensor mounted to it as shown below.
- 2) Mark the initial spot on the ground.
- **3)** Drive vehicle straight ahead counting 10 full revolutions of the wheel. The mark must stop at the same position it was in when the vehicle started.
- **4)** Measure the distance from the ground starting mark to stopping mark in inches [dm] (Round off fractions).
- 5) Write down this distance as the SPEED CAL number; keep it for future reference when programming the Console.



NOTE: This measurement is critical to the performance of the Console. MEASURE CAREFULLY. Be sure tire is properly inflated before measuring. Measure tire in type of soil in which you will be spraying. Circumference of tire will vary when measured in soft soil versus hard packed soil. For best results, measure several times and average the results.

Large tires and very low speed applications may require additional magnets to insure accurate speed readings. Any even number of magnets may be used as long as they are of alternating color and equally spaced. After calculating "SPEED CAL", this number must be adjusted according to the number of magnets used.

Normal Number of Magnets x Speed Cal = Adjusted Speed Cal

Example: $\frac{4}{6} \times 1200 = 800$

SCS 330, SCS 500 and SCS 550 normally use two magnets. All other consoles normally use four magnets.

APPENDIX 2 SPEEDOMETER DRIVE SPEED SENSOR INSTALLATION AND CALIBRATION PROCEDURE

1. MOUNTING THE SPEEDOMETER DRIVE SPEED SENSOR

- 1) Remove the existing speedometer cable from the back of the vehicle speedometer. Pull cable through fire wall into engine compartment.
- 2) Install adapter and key on speedometer cable and connect to Transducer Assembly. (Some units do not use adapter and key).



- 3) Connect Extension Cable to Transducer Assembly.
- 4) Push Extension Cable through fire wall and re-install on speedometer.
- 5) Connect the cable on the Transducer Assembly to the Console.
- 6) Secure all cables with plastic cable ties.

You are now ready to calibrate the Speedometer Drive Speed Sensor.

2. CALCULATING "SPEED CAL"

- 1) Complete "INITIAL CONSOLE PROGRAMMING" before doing this procedure.
- 2) Enter "0" in key labelled

3) Enter a SPEED CAL of 612 [155] in key labelled

4

4) Drive 1 mile [1 km].

<u>CAUTION:</u> Do not use vehicle odometer to determine distance. Use section lines or Highway markers.

5) Read DISTANCE by depressing key labelled DISTANCE

- a) DISTANCE should read a value of approximately 5280 [1000]. If it reads between 5200-5350 [990-1010], the SPEED CAL for your vehicle is 612 [155].
- **b)** If the DISTANCE display reads any other value, perform the following calculation:

Multiply the SPEED CAL by the target distance reading, then divide the sum by the actual value in DISTANCE display. This will give you the corrected value to enter for SPEED CAL. *You must round off to the nearest 3 digit whole number.*

EXAMPLE: SPEED CAL = 612 [155] Target distance reading = 5280 [1000] Assume the actual DISTANCE display reads 5000 [980]

	ENGLISH UNITS:		METRIC UNITS:
=	<u>612 x 5280</u> = 646.3	=	[<u>155] x [1000]</u> = [158.1]
	5000		[980]

- 6) The corrected number to enter for SPEED CAL is 646 [158].
- 7) Verify the corrected SPEED CAL number calculated above:
 - a) Zero out the DISTANCE display as in Step 2.
 - **b)** Enter the corrected SPEED CAL number as in Step 3.
 - c) Repeat Steps 4 and 5a. If DISTANCE value does not read correctly repeat Steps 5b, 6, and
 7.

APPENDIX 3 ALTERNATE BY-PASS PLUMBING DIAGRAM



FIGURE 18

INITIAL SYSTEM SET-UP

Plumb the system as shown in Figure 18.

Adjust as follows:

Install Polarity Reversal Jumper in motorized Control Valve Cable (P/N 115-0159-415).

- 1) Fill tank with water only.
- 2) Place MASTER ON/OFF switch to ON and BOOM ON/OFF switches to OFF.
- 3) Place AUTO/MAN/OFF switch to MAN, and POWER ON/OFF switch to ON.
- 4) Verify that Boom Widths, SPEED CAL, METER CAL, and RATE CALS have been entered correctly into the Console. In SELF TEST mode enter the normal sprayer operating speed.
- 5) With pump not running, fully open main line hand valve, fully open by-pass #1 hand valve, and completely close agitator line hand valve. If positive displacement pump is used, fully open the pressure relief valve (PRV).
- 6) Run pump at normal operating RPM.
- 7) If centrifugal pump is used, proceed with Step 8. If positive displacement pump is used, proceed as follows:
 - a) Place MASTER ON/OFF switch to OFF.
 - b) Close by-pass #1 hand valve.
 - c) Set PRV to 65 psi [450 kPa].
 - d) Open by-pass #1 hand valve.
 - e) Place MASTER ON/OFF switch to ON.

- 8) Verify that each boom valve operates and that no nozzles are plugged by operating the BOOM ON/ OFF switches.
- 9) Place all BOOM ON/OFF switches to ON.
- **10)** Hold the FLOW CONTROL switch to INC position for approximately 12 seconds. This assures motorized Control Valve is fully closed. (Pressure gauge is not supplied).

NOTE: A pressure gauge MUST be installed to properly adjust the system.

- 11) Adjust agitator line hand valve for desired agitation.
- 12) Close the main line hand valve, if necessary, to set the desired maximum operating pressure. Maximum pressure should be approximately 10 psi [70 kPa] above normal spraying pressure.
 EXAMPLE: If normal spraying pressure is 30 psi [210kPa], set maximum pressure at approximately 40 psi [280 kPa].
- **13)** Hold the MAN ADJ switch to DEC position for approximately 12 seconds. This assures motorized Control Valve is fully open.

14) Close by-pass #1 hand valve to set the desired minimum operating pressure. Minimum pressure should be approximately one half the normal spraying pressure.
 EXAMPLE: If normal spraying pressure is 30 psi [210 kPa], set minimum pressure at approximately 15 psi [105 kPa].

15) Verify maximum and minimum pressures and RATE by repeating Steps 11 and 14.

INITIAL SYSTEM FIELD TEST

- 1) Drive down field or road at target speed with sprayer booms OFF, to verify SPEED readout on Console.
- 2) Turn on sprayer and booms and place the MAN/AUTO switch to AUTO. Increase or decrease speed by one (1) MPH [2 km/h]. The system should automatically correct to the target application rate.
- 3) If for any reason, the system is unable to correct to the desired RATE, check for an empty tank, a plugged line, a malfunctioning pump, improper vehicle speed or a defect in the system.
- 4) If the system does not appear to be correcting properly, first review INITIAL SYSTEM SET-UP, then refer to TROUBLESHOOTING GUIDE.
- 5) At the end of each row, switch the MASTER ON/OFF to OFF to shut off flow. This also shuts off the area totalizer.
- 6) Verify area covered and volume used.

APPENDIX 4

PROCEDURE TO TEST SPEED SENSOR EXTENSION CABLES

Verify that the Console is in the SP1 Speed Sensor mode while testing the cable. Disconnect extension cable from Speed Sensor Assembly cable. Hold extension cable connector so that keyway is pointing in the 12 o'clock position.



PIN DESIGNATIONS

2 o'clock socket location is power.10 o'clock socket location is ground.6 o'clock socket location is signal.

VOLTAGE READINGS

- 1) 10 o'clock socket to 6 o'clock socket = +5 VDC.
- 2) 10 o'clock socket to 2 o'clock socket = +5 VDC.

If a +5 VDC voltage reading is not present, disconnect the Flow Sensor cable. If the Speed reading is restored, Test the Flow Sensor cable per Appendix "PROCEDURE TO TEST FLOW METER CABLES".

PROCEDURE TO CHECK CABLE:

I) Enter SPEED CAL number of 1000 in key labelled



2) Depress key labelled DISTAN



- **3)** With small jumper wire (or paper clip), short between the 10 o'clock and 6 o'clock sockets with a "short-no short" motion. Each time a contact is made, the DISTANCE total should increase by increments of 1 or more counts.
- 4) If DISTANCE does not increase, remove the section of cable and repeat test at connector next closest to Console. Replace defective cable as required.
- 5) Perform above voltage checks.
- 6) If all cables test good, replace Speed Sensor.

NOTE: After testing is complete, re-enter correct SPEED CAL number before application.

APPENDIX 5 PROCEDURE TO TEST FLOW METER CABLES

Disconnect cable from Flow Sensor. Hold Flow Sensor cable so that the keyway is pointing in the 12 o'clock position:



PIN DESIGNATIONS

2 o'clock socket location is ground.

10 o'clock socket location is power.

6 o'clock socket location is signal.

VOLTAGE READINGS

- 1) 2 o'clock socket to 6 o'clock socket = +5 VDC.
- 2) 2 o'clock socket to 10 o'clock socket = +5 VDC.

If a +5 VDC voltage reading is not present, disconnect the Speed Sensor cable. If the Flow reading is restored, Test the Speed Sensor cable per Appendix "PROCEDURE TO TEST SPEED SENSOR EXTENSION CABLES".

PROCEDURE TO CHECK CABLE:

1) Enter a METER CAL number of one (1) in key labelled:



2) Depress key labelled:



- 3) Place BOOM switches to ON.
- 4) With small jumper wire (or paper clip), short between the 2 o'clock and 6 o'clock sockets with a "short-no short" motion. Each time a contact is made, the TOTAL VOLUME should increase by increments of 1 or more counts.
- 5) If TOTAL VOLUME does not increase, remove the section of cable and repeat test at connector next closest to Console. Replace defective cable as required.
- 6) Perform above voltage checks.
- 7) If all cables test good, replace Flow Sensor.

NOTE: After testing is complete, re-enter correct METER CAL numbers before application.

APPENDIX 6 PROCEDURE TO RE-CALIBRATE FLOW METER

METER 1 CAL

5

PROD 1 VOLUME

- 1) Enter a METER 1 CAL number of 10 [38] in the key labelled:
- 2) Enter a PROD 1 VOLUME of 0 in the key labelled:
- 3) Switch OFF all booms.



- 5) Switch ON appropriate boom switch and MASTER switch. Pump exactly 10 gallons [38 liters].
- 6) Readout in DATA display is the new METER CAL number. This number should be within +/-3% of the number stamped on the tag on Flow Meter.
- 7) Repeat this procedure several times to confirm accuracy. (Always "zero out" the PROD 1 VOLUME display before retesting).

NOTE:	For greatest precision, set METER CAL to 100 and pump 100 gallons (378 liters)
	of water.

8) To verify Flow Meter calibration, fill applicator tank with a predetermined amount of measured liquid (i.e. 250 gallons). DO NOT RELY ON GRADUATION NUMBERS MOLDED INTO APPLICATOR TANK. Empty the applicator tank under normal operating conditions. If the number displayed under PROD 1 VOLUME is different from the predetermined amount of measured liquid by more than +/-3%, complete the following calculation.

EXAMPLE:	METER 1 CAL	= 720 [190]
	PROD 1 VOLUME	= 260 [984]
	Predetermined amount of measured liquid	= 250 [946]

Corrected METER CAL	= <u>METER CAL x TOTAL VOLUME</u>
	Predetermined amount of measured liquid

ENGLISHUNITS:	METRIC UNITS:
= <u>720 x 260</u> = 749	= <u>[190] x [984]</u> = [198]
250	[946]

Corrected METER 1 CAL = 749 [198]

9) Enter corrected METER 1 CAL before resuming application.



APPENDIX 7 IMPREGNATION MODULE INSTALLATION

1. PLUMBING IMPREGNATION MODULE



FIGURE 20

- 1) Plumb the Pressure Relief Valve (PRV), Flow Meter, Control Valve, Carrier Check Valve, Product Check Valve, and In-Line Mixer just ahead of the Boom On/Off Valves as shown in Figure 4.
- 2) Mount Injection Module close to the Boom On/Off Valves to minimize amount of product in tubing.
- 3) Plumb three way valve on output line of Injection Module (See Figure 20). Plumb recirculation line from three way valve to Product supply tank using 3/8 inch [10mm] tubing. Plumb injection line from three way valve to product check valve using 3/8 inch [10 mm] tubing (For low volume modules) or 1/2 inch [13 mm] tubing (for high volume modules). Product Check Valve and tubing not furnished.
- 4) Plumb inlet hose from product tank as shown in Figure 21.



IMPORTANT: Inlet hose must have gradual upward slope to pump inlet fitting with no dips or sags.

FIGURE 21

- 5) See "ADJUSTING PUMP SETTING".
- 6) See "MOUNTING THE CONSOLE AND CABLING" for installation of Control Console.

APPENDIX 8 TANK INJECTION MODULE INSTALLATION

1. PLUMBING THE INJECTION MODULE





- 1) Plumb Pressure Relief Valve (PRV), Flow Meter, Control Valve, Carrier Check Valve, Product Check Valves, and In-line Mixer just ahead of the Boom On/Off Valves as shown in Figure 4.
- 2) Mount Injection Modules close to the Boom On/Off Valves to minimize amount of product in tubing.
- **3)** Plumb output lines of Injection Modules to Product Check Valves (See Figure 23). Use 3/8 inch [10 mm] tubing on low volume modules and 1/2 inch [13 mm] tubing on high volume modules. Product Check Valves and tubing not furnished.

2. MOUNTING THE INJECTION MODULE



INJ. MODULE	UNITS	DIM A	DIM B	DIM C	DIM D	DIM E	DIM F	DIM G
	IN	29.68	33	12.15	27.78	10.25	32	17
16 GALLON	СМ	75.4	83.8	30.8	70.6	26	81.3	43.2
	IN	29.68	41.5	12.15	27.78	10.25	32	17
24 GALLON	СМ	75.4	105.4	30.8	70.6	26	81.3	43.2

FIGURE 24

- 1) Mount injection module using bolts in four corners. Reinforce vertical supports with external braces (steel angle iron or tubing) that are secured to structure of mobile sprayer. OPERATION OF SYSTEM WITHOUT EXTERNAL BRACES MAY CAUSE FAILURE OF TANK SUPPORTS.
- 2) See "INITIAL INJECTION SET-UP" before operating system.

APPENDIX 9 INJECTION MODULE MOUNTING INSTRUCTIONS

1. TYPICAL MODULE DIAGRAM



2. MODULE ASSEMBLY INSTRUCTIONS

- 1) Install the straps onto tank saddle per instructions enclosed in saddle kit, and secure saddle to frame (See "TYPICAL MODULE DIAGRAM").
- 2) Connect hose to elbow on bottom of tank, and secure with two hose clamps. Position clamps opposite to each other for best seal. Place tank in saddle and secure with straps.
- 3) Install over center buckle on the large strap by inserting webbing thru the metal loop, back thru upper slot. thru the lower slot, and back thru the metal loop as shown in Detail A.
- 4) Secure with buckle and safety pin on small strap (See Detail B).
- 5) Mount pump module to frame using the 3/8" x 1" bolts, lockwashers, and flat washers.
- 6) Connect hose from tank to hose barb on pump and secure with two hose clamps. Position hose clamps opposite each other for best seal.

If Strap Assembly parts are desired:

- 7) Attach the large strap onto right side of the frame using 7/16" x 1 3/4" bolt, lockwasher, and nut.
- 8) Attach the small strap on the left side of the frame using a 7/16" x 1 3/4" bolt, lockwasher, and nut as shown in Detail C.



DETAIL C

APPENDIX 10 FLOW METER MAINTENANCE AND ADJUSTMENT PROCEDURE

1) Remove Flow Meter from sprayer and flush with clean water to remove any chemicals.

NH₃ **WARNING:** Thoroughly bleed nurse tank hose and all other system lines prior to disassembling the Flow Meter, fittings, and hoses.

- 2) Remove flange bolts or clamp from the Flow Meter.
- 3) Remove the turbine hub and turbine from inside Flow Meter.
- 4) Clean turbine and turbine hub of metal filings or any other foreign material, such as wettable powders. Confirm that the turbine blades are not worn. Hold turbine and turbine hub in your hand and spin turbine. The turbine should spin freely with very little drag inside the turbine hub.
- 5) If transducer assembly is replaced or if turbine stud is adjusted or replaced, verify the turbine fit before reassembling. Hold turbine hub with turbine on transducer. Spin turbine by blowing on it. Tighten turbine stub until turbine stalls. Loosen turbine stud 1/3 turn. The turbine should spin freely.
- 6) Re-assemble Flow Meter.
- 7) Using a low pressure (5 psi) [34.5 kPa] jet of air, verify the turbine spins freely. If there is drag, loosen hex stud on the bottom of turbine hub 1/16 turn until the turbine spins freely.
- 8) If the turbine spins freely and cables have been checked per Appendix "PROCEDURE TO TEST FLOW CABLES", but Flow Meter still is not totalizing properly, replace Flow Meter transducer.

APPENDIX 11 PROCEDURE TO RE-CALIBRATE PUMP

- 1) Enter 50 into the METER 2 CAL key on the Console.
- 2) Place 3-way valve handle on Injection Pump for PROD 2 to recirculate position. (See Figure 9C).
- 3) Place BOOM and MASTER switches ON. Place the OFF/MAN/AUTO switch for PROD 2 to MAN.
- 4) Run pump until liquid appears from tank return hose. Place OFF/MAN/AUTO switch to OFF.
- 5) Enter "0" into PROD 2 VOLUME key (or for product under test).
- 6) Place tank return hose into measuring container.
- 7) Place OFF/MAN/AUTO switch to MAN until 50 ounces of measured product is pumped. The number displayed in PROD 2 VOLUME is the new METER 2 CAL.
- 8) Enter this new METER CAL number in METER 2 CAL key.
- 9) Enter "0" in PROD 2 VOLUME key.
- **10)** Place OFF/MAN/AUTO switch to MAN until 50 ounces of measured product is pumped.
- 11) The number in PROD 2 VOLUME should be 49, 50, or 51. If not, repeat calibration procedures.
- **12)** Empty tank return hose into measuring container.
- **13)** Pour product caught in measuring container back into Injection Module Tank.

CALIBRATION FLASK 106-0159-454



APPENDIX 12 REMOTE SWITCH OPTION



The REMOTE switch when installed is in parallel with the MASTER switch; therefore switching on the REMOTE switch or the MASTER switch will energize the Boom Valves.

APPENDIX 13 BOOM CAL DATA ENTRY FOR SCS 710 6 BOOM CONSOLE



DEFINITION OF KEYS



Depressing this key displays selected boom number in PROD 2 display. **EX-AMPLE:** Boom 1 will display as b-01.



Depressing this key after selecting BOOM CAL increments the boom number. **EXAMPLE:** b-01 will increment to b-02.



Depressing this key after selecting BOOM CAL decrements the boom number. **EXAMPLE:** b-02 will decrement to b-01.

ENTERING DATA

- 1) Select desired boom number.
- 2) Enter boom length as detailed in "CALCULATING BOOM CAL".



APPENDIX 15 SERIAL INTERFACE

1) Cable pinout (P/N 115-0159-624), supplied with Thermal Printer Kit (P/N 117-0159-529).



2) Changing PROD 1 CAL and PROD 2 CAL by remote computer.a) Configuration of RS-232C serial port:

1200 or 9600 Baud Rate NO Parity 8 Data Bits 2 Stop Bits

b) Data stream to Raven Console.

EXAMPLE: Change PROD 1 to 123.4 and PROD 2 to 6.5



Decimal point is not sent from Remote Computer to Raven Console.

3) Optional 9 pin to 9 pin cable pinout (P/N 115-0159-822).



APPENDIX 16 SCS 700/710 COMMUNICATION STRINGS

REMOTE COMPUTER TO SCS 700/710 CONSOLE

All request strings begin with \$R, to indicate a Raven communication string.

Rate Change Request: To set Prod Cal values for both products: \$R,RC,<prod_1_cal>,<prod_2_cal><CR><LF> To set Prod Cal value for product 2 only: \$R,RC,,<prod_2_cal><CR><LF>

Calibration String Values Request:

\$R,CR<CR><LF>

Data String Request:

\$R,DR<CR><LF>

SCS 700/710 CONSOLE TO REMOTE COMPUTER

All console output strings begin with \$R047F, the \$R indicates a Raven communication string, the 047 is the last three digits of the current SCS 700/710 programmed chip part number and F is the software revision number.

Calibration Strings:

<u>Bit</u>	Switch Byte 1 Switch	<u>h Byte 2</u>			
0	boom 1	0			
1	boom 2	0			
2	boom 3	0			
3	boom 4*	prod 1 auto			
4	boom 5*	prod 1 manual			
5	boom 6*	prod 2 auto			
6	0	prod 2 manual			
7	1	1			
Design 4 F and 0 and a she is the 000 740 Occur					

Booms 4, 5, and 6 are only in the SCS 710 Console strings.

NOTE: If prod auto and manual are both zero, the product is in Off. For switch Byte Bits; 0 = off and 1 = on.

Data Strings:

\$R047F,D1,<total_area>,<field_area><CR><LF>

\$R047F,D2,<prod_1_volume>,<prod_ 2_volume><CR><LF>

```
$R047F,D3,<tank_1_volume>,<tank_2_volume>,<feet/meters><CR><LF>
```

Actual Rate:

```
$R047F,AR,<actual_rate_1>,<actual_rate_2><CR><LF>
```

Time/Date:

\$R047F,TD,<hr:min>,<month/day/year>,<field_reference><CR><LF>

APPENDIX 17 SCS 700/710 DATA MENU KEY FEATURES

The SCS 700/710 has multiple features that are located under the DATA MENU key. These features are accessed by using the DATA MENU key to toggle between main menu titles, and the UP and DOWN arrow keys to toggle between the sub menu titles. The current settings for these features are shown in the DATA display window. For further explanation on these features see the DATA MENU section of the manual.

MAIN MENU TITLE	SUB MENU TITLE	SETTINGS
PROD 1 display	PROD 2 display	<u>DATA display</u>
SERIAL PORT MENUS	_	
SPr	Prn	BEGn / End
	FrEF	0
	bAUd	1200/9600
	rAtE	on / off
	triG	0
	Unit	Ft / SEC
	dLoG	on / off
GLOBAL POSITIONING SYSTE	EMMENUS	
GPS	FiLE	0
	SySE	inAC
	Grid	0
	LAt	0
	Lon	0
	NodE	C / A / n / nc
TIME AND DATE MENUS		
dAtE	tiNE	0:00
	onth	0
	dAY	0
	YEAr	0
	P dn	10
Fr Er	FL o1	0
11	FL o2	0
		0
	LL 2	0
		-
ALARMMENUS	AL -N.	
ALF		on / off
	UF 1	on / off
		on / off
	FE 1	on / off
	FE 2	on / off
MISCELLANEOUS MENUS		
NiSC	diSP	on / off
	AG 1	on / off
	AG 2	on / off
	APh	0

SCS 700 REPLACEMENT PARTS

	ITEM	DESCRIPTION	RAVEN PART#
	1	MASTER Switch	412-2011-046
	2	BOOM Switch	412-2011-047
	3	MAN ADJ Switch	412-2011-049
	4	AUTO/ MAN/ OFF Switch	412-2011-050
	5	Power Switch	412-2011-048
	б	Mounting Bracket	106-0159-437
	7	Mounting Knob	106-0159-438
	8	Fuse Holder	510-2001-018
	9	Fuse, 15 Amp	510-1003-003
	10	Console Control Cable (18 ft.)	115-0159-861
		Console Control Cable (3 ft.)	115-0159-864
	11	Product Cable (21 ft.)	115-0159-562
	12	Assorted Terminal Kit	117-0159-402
	13	Switch Cover	063-0159-606
	14	1-Set Filler Spacers	117-0159-421
	15	Face Plate Assembly	063-0159-611
	16	Display Board Spacer	107-0159-478
	17	LCD Display Board	064-0159-454
	18	Processor Board (Ser. Interface)	064-0159-604
	19	Connector Plate Assembly (Ser. Interface)	063-0171-346
	20	Back Assembly	063-0159-530
	21	Boom Cable (21 ft.)	115-0159-862
	22	Product Ext. Cable (12 ft.)	115-0159-612
		Product Ext. Cable (24 ft.)	115-0159-613
	23	Boom Ext. Cable (12 ft.)	115-0159-614
		Boom Ext. Cable (24 ft.)	115-0159-615
	24	Thermal Printer Kit (Ser. Interface)[not shown]	117-0159-529
	25	RS232 Computer Cable (Ser. Interface)[not shown]	115-0159-822
	26	SCS 700 Console	063-0171-344
(5)	$\sqrt{3}$ $\sqrt{3}$ $\sqrt{3}$	$1 \qquad 13 \qquad 13 \qquad 15$	20
999			7
#A #A #A #A			(19)
			γ
	PROD DATA		
	و قصه (فقه (والمناه (والمناه (والمناه (والمناه ه		9779

{



R A V E N **RAVEN INDUSTRIES**

Limited Warranty

What Does this Warranty Cover?

This warranty covers all defects in workmanship or materials in your Raven Applied Technology Product under normal use, maintenance, and service.

How Long is the Coverage Period?

Raven Applied Technology Products are covered by this warranty for 12 months after the date of purchase. This warranty coverage applies only to the original owner and is nontransferable.

How Can I Get Service?

Bring the defective part and proof of purchase to your Raven Dealer. If your Dealer agrees with the warranty claim, the Dealer will send the part and proof of purchase to their distributor or to Raven Industries for final approval.

What Will Raven Industries Do?

Upon confirmation of the warranty claim, Raven Industries will, at our discretion, repair or replace the defective part and pay for return freight.

What is not Covered by this Warranty?

Raven Industries will not assume any expense or liability for repairs made outside our facilities without written consent. Raven Industries is not responsible for damage to any associated equipment or products and will not be liable for loss of profit or other special damages. The obligation of this warranty is in lieu of all other warranties, expressed or implied, and no person or organization is authorized to assume any liability for Raven Industries.

Damages caused by normal wear and tear, misuse, abuse, neglect, accident, or improper installation and maintenance are not covered by this warranty.



SCS 700 Installation & Service Manual (P/N 016-0159-419 Rev S 2/09)

Simply improving your position.[™]



Raven Industries Applied Technology Division P.O. Box 5107 Sioux Falls, SD 57117-5107

Toll Free (U.S. and Canada): (800)-243-5435 or Outside the U.S. :1 605-575-0722 Fax: 605-331-0426 www.ravenprecision.com atdinfo@ravenind.com

Notice: This document and the information provided are the property of Raven Industries, Inc. and may only be used as authorized by Raven Industries, Inc. All rights reserved under copyright laws.