

**Case IH Viper Pro™ for Case IH
Liquid Sprayers and Applicators
(Software Version 3.10)**

P/N 016-0171-152 Rev G

06/15

E222653

Disclaimer

While every effort has been made to ensure the accuracy of this document, Raven Industries assumes no responsibility for omissions and errors. Nor is any liability assumed for damages resulting from the use of information contained herein.

Raven Industries shall not be responsible or liable for incidental or consequential damages or a loss of anticipated benefits or profits, work stoppage or loss, or impairment of data arising out of the use, or inability to use, this system or any of its components. Raven Industries shall not be held responsible for any modifications or repairs made outside our facilities, nor damages resulting from inadequate maintenance of this system.

As with all wireless and satellite signals, several factors may affect the availability and accuracy of wireless and satellite navigation and correction services (e.g. GPS, GNSS, SBAS, etc.). Therefore, Raven Industries cannot guarantee the accuracy, integrity, continuity, or availability of these services and cannot guarantee the ability to use Raven systems, or products used as components of systems, which rely upon the reception of these signals or availability of these services. Raven Industries accepts no responsibility for the use of any of these signals or services for other than the stated purpose.

Calibration Reference Sheet	vii
Unit Definitions and Conversions	viii
Unit of Measure Definitions	viii
Unit of Measure Conversions	viii
Chapter 1 <i>Important Safety Information</i>.....	1
Safety Information	1
Hydraulic Safety	2
Electrical Safety	2
Chapter 2 <i>Introduction</i>.....	3
Viper Pro Features	4
Speed Compensated Product Control and Datalogging	4
Variable Rate Application (VRA)	4
On-Screen Guidance	4
AgX™ Compatibility	5
Optional Features	5
The Viper Pro Interface	6
Active Matrix Transflective Touch Screen	6
Front Panel	7
File Transfer	8
Rear Panel	9
Viper Pro Care and Use	10
Technical Specifications	10
Chapter 3 <i>Installation, Start Up and Registration</i>	13
Overview of the Installation Process	13
Kit Contents	14
Mounting the Field Computer	14
Cable Platforms and Connections	16
Generation 1 Cable Connections	17
Generation 2 Cable Connections	19
DGPS Receiver Connection	21
CANbus Network Connection	22
Start Up	23
Touch Screen Calibration Wizard	26
Registering the Viper Pro	27
Viper Pro Features	27
Activation Key Request	28
Chapter 4 <i>Initial Set Up and Navigation</i>	33
Detecting CANbus Nodes	33

Table of Contents

CAN Initialization Results	34
Re-Addressing Product Nodes	34
Initial Set Up	37
Language	37
Time Zone	37
Display Units	37
Product Control Type	38
Speed Sensor Type and Cal	39
Application and Control Valve Type(s)	40
Rate Cal(s)	42
Meter Cal(s)	42
Valve Cal(s)	43
Dual Loop Control Cals	44
Boom or Section Cal	45
Profiles	49
Powering Down the Viper Pro	50
Navigating the Viper Pro Interface	52
Main and Job Screen Displays	52
Controller Status Screen	61

Chapter 5 *Using the Viper Pro System*..... 65

Overview of Job Files and Features	65
Overview of Job Types	66
Overview of Job Features	66
Starting a New AgX Job	68
Selecting Control Channels	70
Booms	71
Default Rate	71
Conversion Factor	72
Machine Control Settings	72
Starting a Standard Job	73
Product Setup	76
Prescription Rate Conversions and Default Rates	77
Existing Jobs	78
Viewing an Existing Job	78
Adding to an Existing Job	78
Using an Existing Field Boundary	79
Pausing and Resuming Jobs	80
Pause a Job	80
Resume a Paused Job	80
Application Rates Area	81
Tabs	83
Main Tab	83
Guide Tab	83

Rx+Cov+Scout Tab	84
Rx Tab	84
Cov Tab	86
Scout Tab	87
AccuBoom™ Tab	88
Marking a Field Feature	88
How to Mark a Field Boundary	89
Importing a Field Boundary	91
Tally Registers	93
Resetting the Tally Registers	94
Setting or Resetting Distance and Individual Nodes	95
Alarms	96
Addressing Alarm Conditions	97
Creating Application Reports	98
To Enter Report Information	99
 Chapter 6 <i>Viper Pro Guidance</i>	105
Guidance Views	105
Swath Guidance Patterns	106
Setting the Straight (A-B) Line Pattern	106
Set A-B Line by Heading	108
Setting the Fixed Contour Pattern	109
Setting the Last Pass Pattern	109
Setting the Pivot Pattern	110
Using the Guide Tab	111
Screen Icons	113
A-B Lines	114
Saving an A-B Line	114
Loading an A-B Line	115
Nudge Feature	116
Configuring Nudge Settings	116
Using the Nudge Feature	117
 Chapter 7 <i>Advanced Settings and Features</i>	119
Overview	119
Advanced Product Control Settings and Features	119
Section Assignments	120
Miscellaneous Settings Area	121
Feature Settings Area	124
Product Control Settings Area	128
Dual Pressure Area	133
Application Area	134
GPS Status Screens	135

Table of Contents

SmarTrax Settings Screens	136
AutoBoom™ Status Indicator	137
Wireless Communication Status	137
Menu	138
Exit Button	138
About Button	138
Web Button	140
Setup Button	141
File Maintenance	141
Start Job	142
Setup Menus	142
Registration Keys	142
Maps	143
Street Maps	143
Scout Maps	145
Coverage Maps	146
Prescription (Rx) Maps	148
Local Settings	153
Power Option	153
Serial Communication Port Setup	154
GPS Comm Port Setup	154
Console Comm Port Setup	157
Auxiliary Comm Port Setup	158
Weather Module Setup	158
Light Bar Guidance	159
Configuring the Light Bar Display	160
Boom and Implement Setup	160
 Chapter 8 <i>Using AccuBoom™</i>	161
AccuBoom™ Control Setup	163
Configuring AccuBoom™ Control	165
AccuBoom™ Boom Disable	166
AccuBoom™ Aggressiveness Factor	167
Enabling AccuBoom™ Override	168
AccuBoom™ Spray/No-Spray Mapping	169
Standard AccuBoom™ Method	169
Create AccuBoom™ No-Spray Map Method	170
Load AccuBoom™ No-Spray Map Method	170
Create Map From Field Boundary Method	171
Changing Spray/No-Spray Default Colors	171
AccuBoom™ Spray/No-Spray Maps	171
How to Create a Spray/No-Spray Map	172

Chapter 9	<i>Using AutoBoom™</i>	175
AutoBoom™ Status Display		176
Chapter 10	<i>File Maintenance and Editing Reports</i>	177
Overview		177
File Maintenance		177
Preparing a USB Flash Drive for File Maintenance		178
Flash Drive File Structure		180
RDE Folder		180
Viper Folder		180
Performing File Maintenance		182
Wireless File Transfer		183
Uploading Prescription Maps from a USB Flash Drive		184
USB File Transfer and Advanced File Maintenance		185
Initialize External USB Flash Drive		187
Automatic File Maintenance		188
Clone or Restore Settings		189
AgX File Maintenance		190
Select External Drive		190
Uploading Reports to the Slingshot Web Site		191
File Transfer Methods		191
User Account Sign-up		192
Uploading Job Reports from a USB to the Slingshot Web Site		192
Chapter 11	<i>Troubleshooting the Viper Pro System</i>	195
Viper Pro Troubleshooting Information		195
General Issues		195
Setup Issues		196
Job Issues		197
Rx Map Issues		198
Coverage Map Issues		198
Error Messages		199
General Error Messages		199
Setup Error Messages		199
Job Error Messages		200
Variable Rate Control (VRC) Error Messages		200
GPS Error Messages		201
CAN Troubleshooting		202

APPENDICES

Appendix A	<i>System Diagrams</i>	203
Appendix B	<i>Calculating the Calibration Values.....</i>	215
Appendix C	<i>Testing Extension Cables</i>	237
Appendix D	<i>Updating CAN Nodes via the Viper Pro</i>	241
Appendix E	<i>Using the Front Panel Program with the Viper Pro System</i>	245
Appendix F	<i>External Serial Rate Control</i>	247
Appendix G	<i>Weather Station</i>	249
Appendix H	<i>Wireless Communications and Remote Service</i>	253

Calibration Reference Sheet

Record the settings and calibration values used when programming the field computer and keep this sheet for future reference or when contacting a service technician.

Circle the setting selected on the field computer for the following options:

Units	US (Acres)	SI (Hectares)	Turf (1000 Square Feet)	
Speed Sensor	SP1 (Wheel Speed)	SP2 (Radar)	Speed Cal	

Write down the selected settings for each configured control channel in the spaces provided:

	Control Channel 1	Control Channel 2	Control Channel 3	Control Channel 4	Control Channel 5
Control Type					
Valve Type					

	Control Channel 6	Control Channel 7	Control Channel 8	Control Channel 9	Control Channel 10
Control Type					
Valve Type					

Write down the calculated calibration values in the spaces provided:

Boom Widths (Boom Cal)	Meter Cal	Rate Cal	Valve Cal	Volume in Tank/Bin
1.	1.	1.	1.	1.
2.	2.	2.	2.	2.
3.	3.	3.	3.	3.
4.	4.	4.	4.	4.
5.	5.	5.	5.	5.
6.	6.	6.	6.	6.
7.	7.	7.	7.	7.
8.	8.	8.	8.	8.
9.	9.	9.	9.	9.
10.	10.	10.	10.	10.

Unit Definitions and Conversions

Unit of Measure Definitions

Abbreviation	Definition	Abbreviation	Definition
GPM	Gallons per Minute	PPK	Pounds per 1,000 square feet
L/min	Liters per Minute	mm	Millimeters
dL/min	Deciliters per Minute	cm	Centimeters
PSI	Pounds per Square Inch	dm	Decimeters
kPa	Kilopascal	m	Meter
GPA	Gallons per Acre	MPH	Miles per Hour
L/ha	Liters per Hectare	km	Kilometers
mL/ha	Milliliters per Hectare	km/h	Kilometers per Hour
GPK	Gallons per 1,000 Square Feet	US	Volume per Acre
PPM	Pounds per Minute	SI	Volume per Hectare
kg/min	Kilograms per Minute	TU	Turf Units (Volume per 1,000 Square Feet)
PPA	Pounds per Acre	[]	Metric Values
kg/ha	Kilograms per Hectare	{ }	Turf Unit Values

Unit of Measure Conversions

To convert the METER CAL value into the selected unit of measure, divide the original number printed on the Flow Meter label by the desired conversion value.

Fluid Ounces Conversion Formula	Liters Conversion Formula	Pounds Conversion Formula
$\frac{\text{Original METER CAL Number}}{128}$	$\frac{\text{Original METER CAL Number}}{3.785}$	$\frac{\text{Original METER CAL Number}}{\text{Weight of One Gallon of Product}}$

Liquid

- 1 U.S. gallon = 128 fluid ounces
- 1 U.S. gallon = 3.785 liters
- 1 U.S. gallon = 0.83267 imperial gallons
- 1 U.S. gallon = 8.34 pounds (water)

Length

- 1 millimeter (mm) = 0.039 inches
- 1 centimeter (cm) = 0.393 inches
- 1 meter (m) = 3.281 feet
- 1 kilometer (km) = 0.621 miles
- 1 inch = 25.4 mm or 2.54 cm
- 1 mile = 1.609 km

Area

- 1 square meter = 10.764 square feet
- 1 hectare = 2.471 acres or 10,000 square meters
- 1 acre = 0.405 hectares or 43,560 square feet
- 1 square mile = 640 acres or 258.9 hectares

Pressure

- 1 psi = 6.89 kPa
- 1 kPa = 0.145 psi

CHAPTER

1

Important Safety Information

Safety Information

NOTICE

Read this manual and the operation and safety instructions included with the implement and/or controller carefully before installing the Viper Pro field computer.

- Follow all safety information presented within this manual.
- If you require assistance with any portion of the installation or service of Raven equipment, contact a local Raven dealer for support.
- Follow all safety labels affixed to the system components. Be sure to keep safety labels in good condition and replace any missing or damaged labels. To obtain replacements for missing or damaged safety labels, contact a local Raven dealer.

When operating the machine after installing the Viper Pro field computer, observe the following safety measures:

- Be alert and aware of surroundings.
- Do not operate the field computer while under the influence of alcohol or an illegal substance.
- Remain in the operator's position in the machine at all times when the field computer is engaged in product control or feature operation. The machine operator is responsible for disabling or turning off automatic control features before leaving the operator's position.
- Determine and remain a safe working distance from other individuals. The operator is responsible for disabling or turning off automatic control features when the safe working distance has been diminished.
- Ensure the field computer is disabled prior to starting any maintenance work on the machine or parts of the field computer.
- Follow all label instructions for proper chemical mixing, handling and container disposal methods.



DANGER

Thoroughly bleed the nurse tank hose and all other system lines prior to disassembling the flow meter, fittings and hoses, especially in the case of anhydrous ammonia.



Hydraulic Safety

- Raven Industries recommends that appropriate protective equipment be worn at all times when working on any hydraulic system.
- Never attempt to open or work on a hydraulic system with the equipment running. Care should always be taken when opening a system that has been previously pressurized.
- When disconnecting the hydraulic hoses or purging is required, be aware that the hydraulic fluid may be extremely hot and under high pressure. Caution must be exercised.
- Any work performed on a hydraulic system must be done in accordance with the machine manufacturer's approved maintenance instructions.
- When installing hydraulics or performing diagnostics, maintenance or routine service, ensure that precautions are taken to prevent any foreign material or contaminants from being introduced into the machine's hydraulic system. Objects or materials that are able to bypass the machine's hydraulic filtration system will reduce performance and possibly damage the hydraulic valves.

Electrical Safety

- Always verify that the power leads are connected to the correct polarity as marked. Reversing the power leads could cause severe damage to the equipment.
- Ensure that the power cable is the last cable to be connected.
- Disconnect the Viper Pro field computer before jump-starting the vehicle.
- Disconnect the Viper Pro field computer and any other Raven systems before welding any component of the machine.

CHAPTER

2

Introduction

Congratulations on the purchase of the Viper Pro precision application management system!

Viper Pro is a multi-purpose precision tool offering the latest technology in precision agriculture with features including product application control, field mapping and application reports, as well as in-field guidance via a connected DGPS (Differential Global Positioning System) receiver.

FIGURE 1. Case IH Viper Pro Field Computer



Viper Pro Features

The following sections offer a brief introduction to the capabilities of the Viper Pro field computer and some of the optional features available for use with the Viper Pro precision application management system.

Speed Compensated Product Control and Datalogging

The Viper Pro is capable of controlling up to five products through product control nodes connected to a CANbus system. Viper Pro automatically adjusts the application rate of each product according to the speed of the vehicle, width and status of programmed sections, and a programmed target rate.

The Viper Pro is also capable of monitoring and mapping applications controlled by another Raven serial console, such as the Raven SCS 440 or 460 consoles, via a serial connection. Variable rate capabilities of the Viper Pro may also be used with a Raven serial console.

A real-time, as-applied map is displayed on-screen while application and scouting information is logged and saved by the Viper Pro. This “job” information can then be transferred to a home or office PC or the Slingshot web site and used to create printed reports and coverage maps.

Variable Rate Application (VRA)

Viper Pro can provide automatic variable-rate control for liquid, granular, spinner control, anhydrous ammonia, or injection products. Viper Pro will also datalog and store as-applied data or scouting information. This as-applied information can be used to compare the field prescription to the actual application and provide valuable documentation of the application. The Viper Pro system will store the application report and datalogged information on the field computer until transferred to a USB flash drive or uploaded to the Slingshot web site for creating or printing application reports or archiving application information on a home or office PC. See Chapter 10, *File Maintenance and Editing Reports*, or Appendix B, *Understanding Viper Pro Files*, for detailed information. The Viper Pro field computer creates application reports in both the common shapefile format which can be used with many application management software packages and a bitmap (.bmp) file which can be viewed on any computer without specialized software tools. The Viper Pro is also capable of outputting a .jdp (job data package) for the Slingshot web service.

With the single product VRA upgrade (P/N 077-0180-004), the Viper Pro will be capable of variable rate control for a single product. With the Multi-Product VRA upgrade (P/N 077-0171-152), the Viper Pro system can variable rate up to five products simultaneously.

On-Screen Guidance

The Viper Pro system provides on-screen 3-D guidance in the form of a course direction indicator (CDI) as well as an on-screen light bar. The guidance feature offers straight (A-B) line, last pass, fixed contour and pivot swath patterns to match the field and application. In addition, GPS information may be sent to an optional Raven external light bar. See Chapter 6, *Viper Pro Guidance*, for more detailed operation.

AgX™ Compatibility

The SST® AgX platform provides a standardized data structure and agricultural chemical database that enables efficient record keeping and seamless communication between AgX compliant devices and software.

AgX recommendations can be transferred onto the Viper Pro field computer for pre-populated job and product information. The Viper Pro also creates AgX compliant reports for transfer back onto a home or office PC for detailed application reporting.

Note: *Currently, the SST Summit software package is required to provide AgX recommendations for the Raven Viper Pro field computer. Viper Pro software version 3.4 or higher is required to utilize the AgX features with the field computer.*

An AgX activation key is required to use AgX recommendations on the Viper Pro field computer. Application of multiple products using the AgX feature will require a multiple product VRA key.

Optional Features

In addition to the product application control capabilities of the field computer, several optional Raven components and systems are available for use with the Viper Pro system. The Viper Pro is also capable of integrating into many Raven CANbus control systems or with Raven standard serial interface control consoles and virtually any new or existing DGPS receiver.


Contact a local Case IH dealer for more information about these and other optional features and components available for use with the Viper Pro.

The Viper Pro Interface

The following sections offer an overview of the user interface features of the Viper Pro field computer.

Active Matrix Transflective Touch Screen

Active Matrix Transflective touch screen technology offers clear visibility across a range of lighting conditions and even in direct sunlight while the touch screen functionality places menus and options literally at the operator's finger tips.



CAUTION

Do not use sharp objects, such as ball point pens, pocket knives, screwdrivers, etc. on the Viper Pro display.


Front Panel

The front panel of the Viper Pro provides easy access to the power button and the USB connection. The following is a description of the front panel features of the Viper Pro:

FIGURE 2. Viper Pro Front Panel





Press the power button to start up the Viper Pro field computer. The field computer takes approximately two minutes to power up.

	<div>NOTICE</div> <p>Failure to close a job before turning the field computer power off may result in a loss of information for that job. Make sure to properly close any open jobs before shutting down the computer.</p>
--	---

A USB port is conveniently located on the front of the Viper Pro field computer. Insert a USB flash drive into this port to transfer compatible Viper Pro files.

Note: The USB flash drive must be set up with the Viper Pro file structure. See Chapter 10, *File Maintenance and Editing Reports*, for setting up the required file structure on the USB flash drive.

	<div> CAUTION</div> <p>Damage to the field computer may occur if the USB ports are used to charge mobile devices such as cellular phones, tablets, or mp3 devices. The USB ports should only be used for performing file transfer and maintenance.</p>
---	--

File Transfer

The Viper Pro features internal memory to store files for current job and field information. The internal memory should not be used for long term storage and files should be periodically transferred to a home or office PC for archiving and printing job reports. The Viper Pro is compatible with USB flash drives with between 256 MB and 4 GB of storage and should be used to manually transfer files to and from the field computer. USB flash drives may be purchased directly from Raven Industries (4 GB USB Flash Drive P/N 524-0002-065) as well as many retail locations.

FIGURE 3. USB Flash Drive



Note: *Install the USB flash drive only when transferring files. Do not start the Viper Pro or leave the USB flash drive in the Viper Pro during normal operations.*

A Slingshot Field Hub™ may be connected to transfer files wirelessly from the home or office PC to the Viper Pro. Contact a local Slingshot dealer for purchasing and more information.

Rear Panel

The following is a brief introduction to the ports and connectors available on the back of the Viper Pro field computer.

The rear panel offers additional USB ports as well as an ethernet port for wireless capabilities using an optional Slingshot Field Hub.





FIGURE 4. Viper Pro Rear Panel



The main and auxiliary interface connectors are also located on the back of the Viper Pro.

The field computer part and serial numbers, and revision letter, are printed on the tag located on the back of the field computer. Please have this information available when contacting customer support.

Viper Pro Care and Use

Refer to the following guidelines for proper care and use of the Viper Pro field computer.

CAUTION

- Do not apply any type of liquid or glass cleaner directly to the surface of the touch screen. Harsh chemicals may damage the touch screen. Clean the touch screen and field computer exterior as needed with a soft cloth dampened with glass cleaner. Apply the cleaner to the cloth and then wipe the screen gently.
- Do not use any type of pointed or sharp instrument on the touch screen. Only a fingertip or approved stylus should be used when interfacing with the field computer.
- Do not expose the Viper Pro field computer to precipitation, condensation, or other liquids. Store the computer in a dry environment when not in use.
- Mount the field computer securely and route cables to avoid tripping hazards and to keep the wires from pinching or breaking.
- When temperatures are expected to be 32° F [-0° C] or lower, remove the field computer from the vehicle and store it in a climate controlled environment.
- Damage to the field computer may occur if the USB ports are used to charge mobile devices such as cellular phones, tablets, or mp3 devices. The USB ports should only be used for performing file transfer and maintenance.


Technical Specifications

		U.S.	Metric
Dimensions	Height	12.04 in.	[30.58 cm]
	Width	8.95 in.	[22.73 cm]
	Depth	2.98 in.	[7.57 cm]
	Diagonal	10.4 in.	[26.42 cm]
Weight		4.7 lbs.	2.13 kg
Environmental	Operating Temperature	32° F to 158° F	0° C to 70° C
	Storage Temperature	-4° F to 185° F	-20° C to 85° C
Power	Operating Voltage	9 VDC to 28 VDC Reverse Polarity Protected	
Ports	USB	3 (1 on front, 2 on back)	
	Ethernet	1 (Back)	
	Amp	2 (Back)	
Mounting	Clamp ^a (Provided)	1.020 in. dia.	2.59 cm dia.
	Thumb Screws (Provided)	1/4"-20 x 1" Long	

a. Designed to secure the field computer to a 1" dia. [2.54 cm] monitor bar or post.


Amp Connector Pin Definitions

**Main Amp
Connection**



Main Amp Connector	
1.	Battery Negative
2.	Ext. Switch
3.	CAN Hi
4.	CAN Lo
5.	DGPS Receive
6.	DGPS Transmit
7.	DGPS CTS
8.	DGPS RTS
9.	Console Transmit
10.	Console Receive
11.	RS232 Ground
12.	Console CTS
13.	Console RTS
14.	+ 12 V Ignition
15.	+ 12 V Switched
16.	Battery Positive

**Auxiliary Amp
Connection**



Auxiliary Amp Connector	
1.	Auxiliary DSR
2.	Ext. Switch
3.	CAN Hi
4.	CAN Lo
5.	Auxiliary DCD
6.	Not Used
7.	Auxiliary Receive
8.	Auxiliary Transmit
9.	Auxiliary CTS
10.	DTR
11.	Auxiliary RTS
12.	RS232 Ground
13.	Not Used
14.	Radar Out

CHAPTER

3

Installation, Start Up and Registration

Overview of the Installation Process

The following sections are intended as an overview of the Viper Pro installation process. These instructions cover basic installation of the Viper Pro field computer and supplied components and cabling.

Note: *For instructions on installing additional hardware with the Viper Pro, refer to instructions provided with the additional or optional component(s). Refer to the Raven CANbus Network Installation Manual for additional information on building a CAN (Controller Area Network) system.*

Basic installation of the Viper Pro system is as follows:

1. Review kit contents
2. Mounting the Viper Pro field computer
3. Mounting the DGPS receiver and antenna
4. Route and connect interface cable(s) or chassis cables
5. Connect any optional CAN or GPS components

Kit Contents

Before proceeding with the installation of the Viper Pro system, review the following components of the Viper Pro kit:

TABLE 1. Case IH Viper Pro

Part/Description	Case IH Part Number	Raven Part Number
Console, Viper Pro	84586928	063-0173-431
Kit, Mounting Bracket	87272481	117-0154-993
Knob, Mounting Clamp	N/A	309-1000-021
Cable, A-Post Main Interface	N/A	115-0171-768
Manual, Case IH Viper Pro	87730376	016-0171-152
Quick Reference Guide, Viper Pro	N/A	016-0171-154
Other Available Components	Case IH Part Number	Raven Part Number
Cable, Adapter, Viper to Viper Pro	87714028	115-0171-742
CAN Node, Boom/Speed	87268815	063-0172-378
CAN Node, Single Product	87271219	063-0172-460

Mounting the Field Computer

Refer to the following requirements when selecting a mounting location for the Viper Pro field computer:

- The Viper Pro is not weatherproof. Mount the field computer inside of the machine cabin or drivers compartment within easy reach of the driver or operator.
- Secure the field computer to an existing post or display bar using the built in mounting posts and provided clamps.
- If necessary, securely fasten the mounting bracket (P/N 107-0171-415) to a suitable, flat surface. Once mounted, the bracket must provide a stable base for the field computer and should not impede normal machine operation.
- The Viper Pro should be mounted in a location where it will not be jarred during normal equipment operation. Keep the field computer clear of moving elements within the machine's cab.
- Keep cable routing in mind when selecting a mounting location to avoid tripping hazards or damage to the cable during normal operation.

To mount the field computer:


Note: If the CAN Switch Box will be installed with the Viper Pro field computer, use the mounting hardware provided with the CAN Switch Box. Refer to the CAN Switch Box Installation and Operation Guide for mounting instructions.

1. If necessary, fasten the mounting bracket (P/N 107-0171-415) securely within the cab of the vehicle.

Note: The mounting bracket is not necessary if a suitable post or monitor bar is available.

2. Using the provided clamp and thumb screws, secure the field computer to the mounting bracket, post or monitor bar.

FIGURE 1. Field Computer Rear Panel



Cable Platforms and Connections


Two cable platform options are available for use with the Viper Pro field computer. Each platform offers a range of optional features which can be added to the control system at any time.

The Viper Pro field computer may be installed with either the generation 1 or generation 2 cable platform.



NOTICE

Please review the *Raven CANbus Network Installation Manual* for installation instructions for the specific cable platform being installed with the field computer prior to beginning installation. Contact a local Raven dealer for assistance or to purchase additional components necessary to set up the CANbus system.




CAUTION

Viper Pro field computers with hardware revision A or higher should be connected directly to the vehicle battery. Field computers with no revision ("Rev -" or empty rev box on Viper Pro serial number tag) should be connected to a clean, controlled power source.


Generation 1 Cable Connections

Ensure that the field computer has been properly mounted and all component cabling is connected properly before connecting the Viper Pro to power.

FIGURE 2. Interface Cable Connection Diagram



1. Route the conduit with red and white leads to a clean, controlled power source such as a clean power bus bar or junction box.
2. Connect the red lead wire to a clean +12V DC power source.



CAUTION


Even when the field computer is powered off, the computer will draw a small current from the battery. Connect the red wire to a controlled power source or, if the machine will not be in use for an extended period of time, remove power from the field computer.

To prevent accidental data loss, the red wire should be connected to a clean power source.

3. Connect the white wire to ground.

Note: Do not connect the orange wire to external power. The orange wire is switched power out of the field computer. When the field computer is powered, +12V DC is applied to the orange wire to power an external device. If more than 1 amp is required to power a device connected to the orange wire, install a relay to switch the higher currents.

FIGURE 3. Relay (P/N 415-1001-009) Terminals




Generation 2 Cable Connections

The chassis cable platform requires the following components:

- Machine specific chassis cable
- Viper Pro chassis interface cable (P/N 115-0172-001)
- CAN Switch Box kit (P/N 117-5020-002)

FIGURE 4. Generation 2 Cable Connection Diagram



Chassis Interface Cable and CAN Switch Box Connection

Note: *The CAN Switch Box and switch box mounting bracket should be mounted to the Viper Pro field computer prior to beginning the following procedure. Refer to the CAN Switch Box Installation and Operation Guide for detailed instructions.*

1. Locate the single round connector labeled 'To Chassis or SmarTrax Tee Cable' on the Envizio Pro/Viper Pro chassis interface cable (P/N 115-0172-001).
2. Insert this connector into the 'To Cab Cable' on the chassis cable previously installed on the vehicle. Thread the connectors together to secure the connection.
3. Route the end of the cable with two round connectors to the back of the Viper Pro and connect to the main and auxiliary ports.
4. Connect the 2-pin Deutsch connector labeled 'Switched Power Output' to the back of the CAN Switch Box.
5. Connect the 4-pin Deutsch connector labeled 'CANbus' to the back of the CAN Switch Box.
6. Connect the 3-pin round connector labeled 'GPS Speed Out' to the back of the CAN Switch Box.

DGPS Receiver Connection



NOTICE


Carefully read and follow all installation instructions included with the DGPS receiver and antenna and any optional DGPS components before connecting the Viper Pro field computer or related cabling.

Signal from a DGPS receiver must be routed into the Viper Pro via the serial connector labeled 'GPS Receiver/DGPS' on the main interface or chassis interface cable. For information on configuring the Viper Pro to receive signal from the connected DGPS Receiver, refer to the *Serial Communication Port Setup* section on page 154.

Note: The 'Internal GPS Receiver Output' connector on the chassis interface cable is not used with the Viper Pro field computer.


FIGURE 5. DGPS Receiver Connection Example Viper Pro with Phoenix 200 (Integrated Receiver/Antenna)

***All listed Part Numbers are Raven Part Numbers.**



Review the Raven CANbus Installation Manual for details on building a CANbus network or adding a control channel to an existing product control system.

FIGURE 6. Sample CANbus System Diagram



Start Up

Note: Before connecting or using any additional or optional components with the Viper Pro precision application management system, be sure to follow any installation instructions and verify proper installation.


Before powering up the Viper Pro, check that the field computer is properly mounted and all power and cable connections have been installed properly as instructed in the previous sections.

Once installation of the Viper Pro precision application management system has been completed and verified, the field computer may be powered up.

To start up the Viper Pro:


1. Press the power button on the Viper Pro. The field computer will take approximately 2 minutes to power up.

Note: Pressing the power button when the following prompt is displayed on-screen will launch the touch screen calibration wizard without displaying the Program Selection Menu.



This prompt is displayed for approximately five seconds and may be ignored to display the Program Selection Menu as normal.

2. The Program Selection Menu will display if the Viper Pro was powered off at this screen the last time the field computer was on.




Note: To skip the Program Selection Menu next time the Viper Pro is powered up, shutdown the field computer from the Viper Pro application. Within the Viper Pro application, touch the Menu button in the lower, right corner of the screen and select Exit, Shutdown Viper.

Pressing and holding the Power button to shutdown the Viper Pro is not recommended. This procedure should only be used in situations when normal shutdown is not possible.

Select the:

- **Sprayer/Spreader** to launch the Viper Pro precision application management system in a liquid or granular applicator mode.
 - **OmniSeed** to launch the Viper Pro precision application management system in an air seeder mode. Refer to the Raven *OmniSeed Installation and Operation Manual* for more information on operation of the field computer in this mode.
 - **Brightness Control** option to adjust the screen brightness.
 - **Front Panel** option to configure Raven DGPS Receivers directly with the Viper Pro using the Front Panel Program. See Appendix E, *Using the Front Panel Program with the Viper Pro System*, for detailed instructions on setting up and using the Front Panel Program.
 - **XP Desktop** option to view the Windows® desktop on the Viper Pro field computer.
 - **Install Viper Pro** option to install the Viper Pro application. This option is only displayed if a flash drive containing the Viper Pro startup directory is inserted into the Viper Pro.
 - **Update CAN Nodes** option to begin the CAN update program. Refer to Appendix D, *Updating CAN Nodes via the Viper Pro*, for more information.
 - **Calibrate Screen** button at the bottom of the screen to begin the touch screen calibration wizard.
3. Select the **Sprayer/Spreader** option to launch the Viper Pro precision application management system.

4. If the Viper Pro is set as the CAN Controller, the Viper Pro will attempt to establish communication with the CANbus system. The CAN Initialization Results screen displays the results of CANbus detection.



5. If the status of the CAN nodes is displayed properly, touch the **Start Viper** button to finish the start up sequence.

Note: Refer to *Detecting CANbus Nodes* section on page 33, for more information on the *CAN Initialization Results* screen, or information on setting up or troubleshooting the CANbus or CAN nodes.

If the field computer is enabled to receive web notifications via the Slingshot server, a prompt or dialogue may be displayed after the Start Viper button is selected and the Main screen is displayed. Refer to the Wireless File Transfer section on page 183 for more information.

6. The Viper Pro main screen will display. For a description of the features and information displayed on the main screen, see *Start Up* section on page 23.

Touch Screen Calibration Wizard


When the operator touches an area of the screen, the Viper Pro displays an arrow in the area where the selection has been made. If this arrow does not appear in the correct location, the touch screen may require recalibration.

There are two ways to access the Touch Screen Calibration Wizard:


- Press the power button while the start up prompt is displayed.
- Select the **Calibrate Screen** option at the bottom of the Program Selection Menu screen.

To complete the Touch Screen Calibration Wizard:

1. Touch and hold in the center of the first of four calibration points.



2. When prompted, release the point. The next calibration point will be displayed.
3. Touch and hold the center of each remaining calibration point as they are displayed.
4. Once all points have been calibrated, touch in various areas of the screen to verify that the arrow appears in the correct location.



Note: This screen will only be displayed for 1 minute. A count down of time remaining is displayed on the **Cancel** button. If the calibration is not accepted before 1 minute lapses, the calibration will be discarded and Viper Pro will continue to start up with the previous touch screen calibration.

5. Touch the **Accept** button to apply the recalibration and continue the Viper Pro start up sequence. Touching the **Cancel** button discards the recalibration and the Viper Pro will start up with the previous touch screen calibration.

Registering the Viper Pro

The Viper Pro must be registered if an optional feature activation key such as the multi-product VRA, AgX prepopulated jobs or a weather station will be activated. Activation keys are specific to each Viper Pro. Once activated, a purchased key may not be transferred to another field computer.

Viper Pro Features

The following feature activation keys are available for the Viper Pro system:

- Single Product VRA (P/N 077-0180-004)
- Multi-Product VRA (P/N 077-0171-152)
- Weather Module (P/N 077-0180-030)
- AgX Prepopulated Jobs (P/N 077-0180-059)

Single Product VRA

This feature is not required for logging data from a Raven multi-product SCS 4000/5000 series console or for “straight rating” multiple products on a CANbus system.

The Single Product VRA feature is only required for automatic variable rate control of one product on the Viper Pro field computer. This feature allows the Viper Pro to automatically control product rate in reference to a prescription map.

Multi-Product VRA

This feature is not required for logging data from a Raven multi-product SCS 4000/5000 series console or for “straight rating” multiple products on a CANbus system.

The Multi-Product VRA feature is only required for automatic variable rate control of more than one product on the Viper Pro field computer. This feature allows the Viper Pro to automatically control product rates in reference to a prescription map or maps.

Weather Module

The Viper Pro is capable of reading information from an external weather station and recording this information into the application report. Refer to *Creating Application Reports* section on page 98 or Appendix G, *Weather Station*, or contact a local Raven dealer, for more information.

AgX Prepopulated Jobs

AgX recommendations can be transferred onto the Viper Pro field computer for pre-populated job and product information for product control and application. The Viper Pro also creates AgX compliant reports for transfer back onto a home or office PC for detailed application reporting.

Note: *Currently, the SST Summit software package is required to provide AgX recommendations for the Raven Viper Pro field computer. Viper Pro software version 3.4 or higher is required to utilize the AgX features with the field computer.*


An AgX activation key is required to use AgX recommendations on the Viper Pro field computer. Application of multiple products using the AgX feature will require a multiple product VRA key.



Activation Key Request

To register and activate a special feature on the Viper Pro:


1. On the main screen, touch the **Menu** button.



Select **Setup** then **Reg. Keys** to display the Validation Data screen.

2. Write down the **Machine ID** and **Validation Code** from the Viper Pro field computer on the Registration Code sheet; an example is shown below.

FIGURE 7. Machine ID and Validation Code



Please note that the registration code appears on this sheet as well. This number will be necessary for future use.


Note: The above values are for example purposes only. If additional features (such as single or multi-product VRA or weather module) have not been purchased, the registration code sheet will not be supplied. Write down the machine ID and validation code from the Viper Pro system on a blank piece of paper for future use.

3. Touch the **Next** button. The Key 1 screen displays. This is the screen on which the activation key code will be entered. Do not navigate away from this screen.

4. On a home or office computer, go to the Raven Applied Technology Division web site at:

www.ravenhelp.com

and click on the “Activation Key Request” link.



5. The Registration Code screen displays.

The screenshot shows the 'Product Registration' screen. At the top is the 'RAVEN HELP .com' logo. Below it, the title 'Product Registration' is displayed. A message states: 'The product you are registering requires an Activation Key. Please fill in the required fields and press the Next button.' A red note below says: 'Please verify that the data is correct. Incorrect data will prevent the Activation Key from working properly.' There are three input fields: 'Machine ID:', 'Validation Code:', and 'Registration Code:'. A red oval highlights these three fields and the 'Next' button located at the bottom right of the form.

6. Fill in the machine ID, validation code, and registration code from the registration code sheet. Click the Next button.
7. Fill in the requested information and then click Next.

The screenshot shows the 'Product Registration' screen. At the top is the 'RAVEN HELP .com' logo. Below it, the title 'Product Registration' is displayed. A message states: 'Thank you for purchasing products from Raven Industries! Please take a few moments to complete the form below to register your purchase. Some products require a special key to operate. This form will allow you to receive these keys online.' The form contains the following fields: 'First Name:', 'Last Name:', 'Company:', 'Address 1:', 'Address 2:', 'City:', 'State/Prov/Terr:', 'Zip/Postal Code:', 'Country:' (with a dropdown menu labeled '(Click here to choose)'), 'Telephone:', 'E-mail Address:', and 'Select Product:' (with a dropdown menu labeled '(Click here to choose)'). A red oval highlights the entire form area. A 'Next' button is located at the bottom right of the form.

8. If the registration was processed successfully, prompt similar to the following will be displayed.

The screenshot shows the 'Product Registration' screen. At the top is the 'RAVEN HELP .com' logo. Below it, the title 'Product Registration' is displayed. A message states: 'Your information has been successfully recorded. Thank you for registering. This is your product Activation Key which will be needed to enable your unit. Be sure to write it down or print this page.' The 'Activation Key: 07484-0008-019F822B93FG' is highlighted with a red oval. Below it are the 'MachineID: 124301', 'Validation Code: 0000004B2FAC', and 'Registration Code: 42036D-020000-09500-0000-2F59'. A 'Register More' button is located at the bottom right.

9. Locate the product Activation Key.

Note: *Print and save this page for future use.*

10. Back on the 'Key 1' screen on the Viper Pro, use the on-screen keyboard to enter the activation key received from the Raven web site (see step 8).

Note: *If the Viper Pro has been registered previously, touch the Menu button on the main screen and select **Setup**, then **Reg. Keys** and **Next** to display the 'Key 1' screen to enter an activation key.*


11. Press **OK**. The activation key is saved to the Viper Pro field computer and the appropriate activation keys are validated.

CHAPTER 4

Initial Set Up and Navigation

Detecting CANbus Nodes

The Viper Pro must be able to communicate with the CANbus system to make sure product is being applied correctly. Viper Pro should automatically establish communication with the boom/speed node and all product nodes connected to the CANbus.



Note: If the Viper Pro establishes communication with a node, it displays as 'Found' on the CAN Initialization Results screen. Nodes not detected during startup will not be displayed on this screen.

If a product node is not found by the Viper Pro field computer, troubleshoot the system to determine why Viper cannot communicate with the node. See Chapter 11, Troubleshooting the Viper Pro System, for more information about communication failures.

CAN Initialization Results

1. Power up the Viper Pro field computer.
2. The CAN Initialization Results screen displays. If the CAN system found all of the connected nodes, touch **Start Viper**. If not, touch **Retry CAN Init**.

Note: *If the product nodes are not found and this is a new installation, skip to the Re-Addressing Product Nodes section on page 34 and follow the instructions for addressing the product nodes.*

3. If product nodes which had been 'Found' during previous Viper Pro applications, but are still not displayed after step 2, troubleshoot the CANbus system to determine why the node is not communicating with the CAN system (i.e. No logic power, ground issues, faulty CAN connection, etc.).

CAN Node Off-line Errors

The most likely causes for losing CAN communication between the field computer and any one of the nodes are:


1. Corroded and/or open connections in the circuit.
2. Field computer and/or CAN node logic power and grounds connected to a "dirty" power source (dirty power is defined as any circuit with a variable load that exceeds 1 ampere). This is especially true of circuits loaded by electrical coils.
3. Field computer and nodes connected to different power and/or ground sources (e.g. battery, alternator or power bus). This can result in components operating at different voltage planes. Connect the field computer and nodes to the same power source via separate leads to eliminate potential issues.
4. Supply voltage below required minimums due to weak alternator or battery outputs. Check the machine battery and alternator and repair or replace as necessary.

Re-Addressing Product Nodes

If the Viper Pro cannot detect a CAN product control node (i.e. single product node, dual product node, motor control node, etc.) during the start up sequence, troubleshoot the CANbus and the node, and then re-address the CANbus:

Note: *It is recommended to retry the CANbus initialization prior to readdressing the system if no new nodes have been connected to the CANbus.*

1. Touch **Re-Addr Nodes** from the CAN Initialization Results screen.



The Readdress screen will be displayed.

2. Touch **Yes**. The Re-Address CAN Nodes screen displays.
3. Cycle the power to the node which will be used to control product channel 1.

Note: To power cycle a node, temporarily disconnect the logic power connector from the node, wait a few seconds and reconnect.

4. Touch the **Next** button on the Viper Pro to cycle the next product node in the system.
5. Repeat steps step 3 and step 4 until all product control nodes in the system have been re-addressed.
6. Touch **Finish**.
7. Touch **Start Viper** when all the product nodes in the system display as 'Found.'


Note: If the field computer is enabled to receive web notifications via the Slingshot server, a prompt or dialogue may be displayed after the Start Viper button is selected and the Main screen is displayed. Refer to the Wireless File Transfer section on page 183 for more information.

Configuring a Product Controller Node

Each Raven product controller node may be configured for up to five control channels to provide controls for individual product control features on the CANbus. It may be necessary to disable control channels on the product controller node if specific channels will not be used or if additional control nodes will be connected to the CANbus network to provide control for specific hardware.

Refer to the following procedures to set up the product controller node on the CANbus network.

1. Power up the Viper Pro field computer select the **Start Viper** option on the CAN Initialization Results screen.



2. From the Viper Pro main screen, touch the **Product Control** button.

3. Select one of control channels currently assigned to the product controller node and touch within the **Product Control Settings** area.

CAN Controller Status			
Boom Cals		Miscellaneous	
L	5	5	180
1	180	*	0
2	300	*	0
3	120	R	5
4	300		
Speed Sensor		Wheel	
Speed Cal		1000	
Self Test		0.00	
Pump RPM		0	
Speed		10.2	
Units		US	
Product 1 ▼			
Dual Flow %		50	
Off Rate %		30	
Low Tank		0.0	
Low Limit		0.0	
Tank Vol		832.0	
Area/Hour		0.0	
Vol/Min		0.0	
Rate Cal		15.0	
Rate +/-		2.0	
Meter Cal		700.0	
Pressure 1		71	
Pressure 2		61	
Flow/Shaft Alarm		Off	
Vac/Bin Alarm		Off	
Decimal Shift		Off	
Zero Shutoff		On	
Smoothing		On	
Agitator		Off	
Ratio Rate		Off	
Spreader		0	
Valve Cal		2123	
Valve Cal 2		0	
Valve Adv		3	
Pump Cal		0	
Min Pw		0	
Max Pw		253	
Pre Set Pw		0	
Pw Freq		122	
Ratio Rate		0.00	
Valve Delay		0.0	
PWM		0	
Application		Liquid	
		Standard Valve	
Tally Registers		OK	

4. The first node settings screen for the selected control channel will be displayed. Touch the **Next** button along the right side of the screen to display the second node settings screen.

Node 2 Settings	
Valve Cal	43
Valve Cal 2	0
Valve Adv	5
Fan Cal	0
Min Pw	1
Max Pw	253
PWM Manual Cal	PWM Auto Cal
Prev	Next
Cancel	OK

5. Touch the displayed valve cal value. Using the on-screen keyboard, enter a valve cal value of '900#' where # is the desired number of control channels assigned to the product controller node. For example, enter a value of '9005' in the valve cal to enable all five control channels on the air cart node.
6. Touch the **OK** button until the Viper Pro main screen is displayed.
7. Select the **Menu** button in the lower, right corner of the display and select the **Exit, Exit to Menu** options.
8. When the Program Selection Menu screen displays, select the **Sprayer/Spreader** option to restart the Viper Pro application. The CAN Initialization Results screen will display again.
9. Verify that the appropriate control channels are displayed before touching the **Start Viper** button. Review the *Configuring a Product Controller Node* section on page 35 to disable control channels on the product controller node.

Initial Set Up

The first time the Viper Pro is powered up, the field computer will require the operator to input information about the machine and the type of applications, products and setup any additional features connected to the system. The following sections are provided to assist the operator in setting the required calibration information prior to starting an actual application with the Viper Pro system.

During initial set up of the field computer, the following settings will be configured:

• <i>Language</i>	• <i>Time Zone</i>	• <i>Display Units</i>	• <i>Product Control Type</i>
• <i>Speed Sensor Type and Cal</i>	• <i>Application and Control Valve Type(s)</i>	• <i>Rate Cal(s)</i>	• <i>Meter Cal(s)</i>
• <i>Valve Cal(s)</i>	• <i>Boom or Section Cal</i>	• <i>Profiles</i>	

The above settings are the standard settings which the Viper Pro requires to monitor and control product application. Depending upon additional features installed with the field computer or application types which the Viper Pro may be used to control, additional settings may be required. Refer to Chapter 7, *Advanced Settings and Features* for additional information on product control settings and features. Refer to Chapter 8, *Using AccuBoom™*, for additional information on the AccuBoom system or Chapter 9, *Using AutoBoom™* for more information on the Glide Series AutoBoom system.

Language

To select the language displayed on the Viper Pro field computer:

1. Touch **Menu**, **Setup**, **Local** and **Lang**. The Language Setup screen will be displayed.
2. Touch the desired language for display on the field computer and select **OK** to return to the main screen.

Time Zone

1. Touch **Menu**, **Setup**, **Local**, and **Time Zone**. The Time Zone Setup screen displays.
2. Touch the desired time zone from the list. Use the **Up** or **Down** arrows if necessary to display additional time zones.
3. Select the **Auto Adjust for Daylight Savings** option to allow Viper to automatically adjust for daylight savings.
4. Touch **OK** to save the displayed selections and return to the main screen.

Display Units

Select the desired unit system for use with the Viper Pro:

1. Touch **Menu**, **Setup**, **Local** and **Units**. The Display Units screen will be displayed.
2. Select **English** (units displayed in feet, miles, ounces, etc.), **Metric** (units displayed in meters, kilometers, liters, etc.), or **Turf** (English measurement system in units per 1000 square feet) for unit displays on the Viper Pro.
3. Touch **OK** to save the displayed settings.
4. Proceed to the *Product Control Type* section on page 38 to continue setting up the Viper Pro.

Product Control Type

To properly configure the field computer for field operations, select the type of system which the Viper Pro will be used to monitor or control:

1. Touch **Menu, Setup, Prod. Control**. The Select Controller screen will be displayed.
2. Select the appropriate controller setting from the list of available options.
 - a. If the Viper Pro field computer will be used to control a CANbus control system, verify that the CAN option is selected.

Note: *If the Viper Pro is set up as the CAN controller, the boom sense/speed node, and at least one product control node must be programmed to allow the Viper Pro to control application of a product during a field application.*

- b. If the Viper Pro will be connected to a separate Raven rate control console via a serial cable, select the specific rate controller from the list of controller model options.

Note: *In this mode, the calibration information presented in following sections will need to be entered on the serial control console. To complete the initial set up of the Viper Pro field computer, refer to the Boom or Section Cal section on page 45 to set up the boom or section configuration on the Viper Pro field computer to match the rate control console. Refer to the rate controller or console manual for details on programming the console for rate control operations.*

- c. If the Viper Pro will be used to provide guidance for a towed implement without rate control capabilities, select the 'Manual' option.
3. Touch **OK** to accept the displayed selection and return to the Main screen.
4. The field computer must be restarted before the control type changes will take affect.

Speed Sensor Type and Cal

To automatically adjust the rate of applied products for vehicle speed, the field computer must be properly calibrated for the sensor type providing speed information.

1. Touch within the **Product Control** area at the bottom of the main screen.
2. Touch within the **Miscellaneous** area on the CAN Controller Status screen.
3. Select **Radar** or **Wheel** for the type of speed sensor connected to the Viper Pro.

Use the **Wheel** option if a magnetic type, such as a wheel or drive shaft magnet, system is used with the Viper Pro. Set the speed sensor setting to the **Radar** option if a radar or GPS unit is sending speed information to the Viper Pro.


4. Touch the **Speed Cal** value and use the on-screen keypad to enter the new value.

Raven recommends the following speed calibration values for initial system setup.

Sensor Type	Used with	US	Metric
Radar/GPS	External Raven GPS Receiver	785	199
	GPS Speed over CANbus	1000	254
	Raven Radar	598	152
Wheel	Wheel Magnets	1000	254
	Speedometer Drive Speed Sensor	612	155

These values are good starting points and generally yield adequate results, however, the speed cal should be refined for each specific vehicle and speed sense system. See Appendix B, *Calculating the Calibration Values*, for instructions on refining the speed cal value.

Note: *The GPS speed over CANbus feature is only available with specific Raven speed sense nodes. This feature utilizes NMEA speed over ground data transmitted over the CAN network which eliminates the need for a separate, external speed sensor.*



NOTICE

When using the GPS speed over CANbus feature, no refining or adjustment is necessary or recommended to the speed cal value. Losing GPS signal for more than a second will also result in loss of the CAN speed signal which may affect product application in progress.

*If another source will be used to detect vehicle speed, touch the **Calibration Assistance** button and follow the on-screen instructions. Refer to Appendix B, *Calculating the Calibration Values* for additional information about the calibration assistance procedure. The procedure outlined in Using the Calibration Assistance section on page 216, should also be performed to refine or verify the initial value used with a speed sensor not listed in the above table.*

5. Touch **OK** to save the currently displayed settings and return to the CAN Controller Status screen.

Application and Control Valve Type(s)

The application and control valve type settings configure the Viper Pro for the type of product applied with the control system and how the products will be applied.

1. Touch within the **Product Control** area at the bottom of the main screen.
2. Make sure that **Node 1** is selected on the CAN Controller Status screen

CAN Controller Status			
Boom Cals		Miscellaneous	
L	5	5	180
1	180	*	0
2	300	*	0
3	120	R	5
4	300		
Speed Sensor		Wheel	
Speed Cal		1000	
Self Test		0.00	
Pump RPM		0	
Speed		10.2	
Units		US	
Product 1			
Dual Flow %	50	Flow/Shaft Alarm	Off
Off Rate %	30	Vac/Bin Alarm	Off
Low Tank	0.0	Decimal Shift	Off
Low Limit	0.0	Zero Shutoff	On
Tank Vol	832.0	Spreader	0
Area/Hour	0.0	Valve Cal	2123
Vol/Min	0.0	Valve Cal 20	
Rate Cal	15.0	Valve Adv	3
Rate +/-	2.0	Pump Cal	0
Meter Cal	700.0	Min Pw	0
		Max Pw	253
Pressure 1	71	Application	Liquid
Pressure 2	61		AIM
Tally Registers		OK	

3. Touch within the **Application** area at the bottom of the CAN Controller status screen.
4. Select the type of control valve installed on the machine and which is controlled with the product assigned to channel or node 1.

The following valves are commonly used:

Valve Type	Description
AIM Command	Select this type when using an AIM Command system.
Fast	Same as the Standard valve, but can change setting at a higher rate.
Fast Close	Same as the Standard valve, but can change setting at a higher rate and closes completely when the master switch is in the 'off' position.
PWM	This valve uses pulse width modulation to control the speed of a hydraulic motor. Typically used to drive a liquid pump.
PWM Close	PWM valve that closes completely when the master boom switch is in the 'off' position. Typically used to control a hydraulic motor to a spreader apron.
Motor Type	The valve type options above will be replaced with the motor type options if CAN motor control node is detected for control of direct injection systems. Refer to the injection pump operation manual for more information on calibrating or operating the injection pump.

5. Select one of the following application types for the selected product channel or control node:

Note: *Depending upon the type of node, or capabilities of each node, connected to the CANbus network, additional options may be available or the following options will be restricted. Contact a local Raven dealer for additional assistance or information on controlling specific applications not listed below.*

Liquid. Application of liquid products.

Note: *Sidekick Pro injection systems will display application type options for a high volume or low volume pump when the integrated motor control node is detected on the CANbus for the selected control channel. Sidekick motor control nodes for legacy injection systems will be controlled using either the Liquid or Granular application type.*

Gran (Granular) 1. Dry or granular product application using a single encoder to meter application equipment with a single bed.

Gran (Granular) 2. Dry or granular product application using a single encoder to meter application from equipment with a dual bed.

Gran (Granular) 3. Dry or granular product application using a dual encoder configuration to meter application from equipment with a dual bed.

Gran (Granular) 4. An air seeder system on which a seed gate or segmented meter roller is used to control seed for active sections before the seed has entered the air system. Most air seeder control systems will be controlled using this application type selection.

Gran (Granular) 5. An air seeder system on which a manifold or distribution bin is used to control air flow to active sections after the seed has entered the air system. This application type will control the RPM of the meter roller based upon active drill sections.

Note: *An optional OmniSeed authorization key is required for Gran 4 and Gran 5 application types to enable the field computer to control air seeder control systems. Contact a local Raven dealer for purchasing information and refer to the Registering the Viper Pro section on page 27 to enter the activation code to unlock the Gran 4 and Gran 5 application type selections.*

Spinner. Select this option for RPM control of spinner speed during field operations.

Note: *A product control node capable of spinner control is required to control the spinner RPM or speed. If the spinner option is not displayed in the application type options, refer to Appendix D, Updating CAN Nodes via the Viper Pro, for assistance with updating the control node. Refer to Appendix B, Calculating the Calibration Values, for additional assistance with the spinner RPM set up.*

NH3. An option for anhydrous ammonia rate control operations will be available if the product node is capable of specific rate control features. It is recommended to ensure this option is available and selected when controlling the application rate of anhydrous ammonia, master control valve functions, and section valves during field operations.


NH3 Boost. The anhydrous pump control selection will be available if the product node is capable of specific control features for the AccuFlow HP boost pump. Select this option to allow the operator configure specific boost pump control features for field operations.

6. Repeat the above process for remaining product nodes or control channels as necessary.

7. Touch **OK** to save the currently displayed settings and return to the CAN Controller Status screen.

Rate Cal(s)

1. Touch within the **Product Control** area at the bottom of the main screen.
2. Make sure that **Node 1** is selected on the CAN Controller Status screen and touch within the second data display, or Product Control Settings area, on the CAN Controller Status screen.

CAN Controller Status			
Boom Cals		Miscellaneous	
L	5	5	180
1	180	*	0
2	300	*	0
3	120	R	5
4	300		
Speed Sensor		Wheel	
Speed Cal		1000	
Self Test		0.00	
Pump RPM		0	
Speed		10.2	
Units		US	
Product 1 			
Dual Flow %	50	Flow/Shaft Alarm	Off
Off Rate %	30	Vac/Bin Alarm	Off
Low Tank	0.0	Decimal Shift	Off
Low Limit	0.0	Zero Shutoff	On
Tank Vol	832.0	Spreader	0
Area/Hour	0.0	Valve Cal	2123
Vol/Min	0.0	Valve Cal 20	Ratio Rate
Rate Cal	15.0	Valve Adv	3
Rate +/-	2.0	Pump Cal	0
Meter Cal	700.0	Min Pw	0
		Max Pw	253
Pressure 1	71	Pre Set Pw	0
Pressure 2	61	Pw Freq	122
		Ratio Rate	0.00
		Valve Delay	0.0
		PWM	0
Application		Liquid	
		AIM	
Tally Registers		OK	

3. Touch the Rate Cal value displayed on the screen and use the on-screen keypad to enter the desired target rate for a product application.

Note: During the initial set up of the field computer, enter a typical rate for product application. The rate cal will need to be adjusted for different products on each product control channel prior to starting actual application of any product. Contact a local sprayer or chemical supply dealer for assistance.

4. Repeat the above process for any remaining product nodes or control channels as necessary.
5. Touch **OK** to save the entered value or proceed to the *Meter Cal(s)* section to continue with the initial set up process.

Meter Cal(s)

Note: The meter cal is required when the corresponding product node or control channel will be controlling application of a liquid product. The meter cal value is typically found on the flow meter.

1. Touch within the **Product Control** area at the bottom of the main screen.
2. Make sure that **Node 1** is selected on the CAN Controller Status screen and touch within the second data display area, or the Product Control Settings area, on the CAN Controller Status screen.
3. Touch the meter cal value displayed on the screen and use the on-screen keypad to enter the meter cal number found on the flow meter connected to the selected product node or control channel.
4. Repeat the above process for any remaining nodes or product control channels as necessary.
5. Touch **OK** to save the entered value or proceed to the *Valve Cal(s)* section on page 43 to continue with the initial set up process.

Valve Cal(s)

Note: The Viper Pro automatically enters the recommended valve cal value for the valve type selected during the procedure in the Application and Control Valve Type(s) section on page 40.

If the dual loop control feature is enabled, the valve cal and valve cal 2 values will be replaced by the flow cal and pr Sgain (pressure system gain) values. See the Node Feature Settings Screen (Page 2) section on page 126 for information on enabling the dual loop control feature. Refer to the Dual Loop Control Cals section on page 44 for more information on setting the flow cal and pr Sgain values.

1. Touch within the **Product Control** area at the bottom of the main screen.
2. Make sure that **Node 1** is selected on the CAN Controller Status screen and touch within the second data display area, or the Product Control Settings area, on the CAN Controller Status screen.
3. Touch the **Next** button to view additional settings for the selected product node or control channel.
4. Touch the displayed valve cal value and use the keypad to enter the calibration value for the installed control valve.

Note: Raven recommends the following initial valve cal values:

Valve Type	Calibration Value
AIM Command	63
Fast or Fast Close Valve (C-F or C-FC)	743
PWM or PWM Close Valve (C-P or C-PC)	43
(Injection Pump) Motor Control Node (select Standard Valve type)	123

These values are good starting points and will generally yield adequate results, however, the valve cal should be refined for the individual control valves installed on the specific machine. Refer to Appendix B, Calculating the Calibration Values, for more information on calculating the valve cal.

5. Repeat the above process for any remaining nodes or product control channels as necessary.
6. Touch **OK** to save the entered value or proceed to the optional Valve Cal 2 (Optional) section if applicable to continue with the initial set up process.

Valve Cal 2 (Optional)

The valve cal 2 value may be used to fine tune control valve response and reduce application rate oscillations when using a Fast Close, PWM or PWM Close control valve.

Fast Close Valves. When using a fast close valve to control product application, valve cal 2 is utilized to enable a high resolution rate control for lower application rates. Enter a non-zero value for the time, in milliseconds, which the valve will be fully opened before switching into high resolution control. For example, a value of 200 will give the valve a 200 millisecond “burst” at a full 12V to open the control valve from the closed position before resuming product rate control. A zero value will disable this feature.

Note: When used with a Fast Close valve, the valve cal 2 feature requires product node software version 1.40 or higher for operation.

PWM or PWM Close Valves. Refer to the Case IH machine manual for valve cal settings and values.

Dual Loop Control Cals

The following calibration values will replace the valve cal and valve cal 2 values if the dual loop control feature is enabled. See the *Dual Loop Control* section on page 127 for details on the dual loop control mode. Refer to the *Node Feature Settings Screen (Page 2)* section on page 126 for information on enabling the dual loop control feature.

Flow Cal

Note: *It is recommended to set the Sgain value prior to making any adjustments to the flow cal value.*

The flow cal value has two components which may be used to adjust the response of the application system.



Flow System Gain. The first digit(s) of the flow cal correspond to a flow system gain between 1 and 99. The higher the flow system gain, the more aggressive the system will respond to changes in flow rate.

Note: *When entering a flow gain value from 1 to 9, it is not necessary to enter a zero in front of the value.*

If the system adjusts to rate control changes too slowly, increase the flow gain digit(s) to increase the system response rate. If the system overshoots or oscillates around the desired flow rate, decrease the flow gain digit(s) to help stabilize the system.

Dead Band Digit. The last, or right most, digit in the flow cal value is the dead band digit. The dead band digit is the allowable difference between the target rate and the actual application rate. The values range from 1 to 9, where 1 equals 1% difference and 9 equals 9% of the difference.

Pr SGain (Pressure System Gain)

The default setting for the Sgain value is 100. To adjust the system aggressiveness, enter a value between 1 and 999 as necessary.

Note: *It is recommended to increase or decrease the current value in increments of 10 or less when making adjustments to the Sgain setting. If the new value does not produce significant or notable changes in the system response, increments of 20 may be used.*

Increase the Sgain value if the observed product pressure increases too slowly or if the system takes a long time to reach a set standby pressure or rate input change. If the system is consistently over shooting a set standby pressure or oscillating around a target rate, decrease the Sgain value until the system stabilizes.

Boom or Section Cal

The boom setup process detailed in this section is required to configure the field computer to the application equipment or implement. This procedure sets the overall width used for guidance of the machine as well as boom or implement section widths used for control of product application.

1. From the main screen, touch **Menu**, then **Setup** and **Boom** to display the Boom Setup screen.

2. Touch the **Overall Width** field and use the on-screen keypad to enter the machine or implement swath width. The overall width is the machine width used for Guidance control without fence row nozzles or foam markers. This value must be entered using the units displayed at the bottom of the Boom Setup screen.
3. Touch the **Number of Boom Sections** value and enter the corresponding number of the highest boom sense connector used by the application system.

Note: The total number of booms may include “skipped” sections or boom sense wires not connected in some cases. Raven boom sense wires are color coded as follows:

Section Number	Lead Wire Color	Section Number	Lead Wire Color
1.	Black	9.	White/Blue
2.	Brown	10.	Pink
3.	Blue	11.	Yellow/White
4.	Black/White	12.	Green/White
5.	Brown/White	13.	Red/White
6.	Blue/White	14.	White/Yellow
7.	White/Black	15.	White/Green
8.	White/Brown	16.	White/Red

Fore or Aft Offset


The fore/aft offset is the distance of the boom or implement in front or behind the GPS antenna.

Note: The fore/aft offset must be measured perpendicular to the boom or implement width. See Figure 1 below. Touch the **More Info** button to see the Boom System Setup Information (including the relationship of the boom to the GPS antenna).

To set the fore/aft value:

1. Touch the current fore/aft value displayed on the Boom Setup screen.
2. Use the keypad to enter the measured fore/aft value in inches (U.S.) or centimeters (Metric).
3. If the boom or implement is behind the GPS antenna, enter a negative value for the fore/aft offset.

FIGURE 1. Example of the Fore/Aft Measurement



Left or Right Offset


The left/right offset is the distance from the GPS antenna to the center line of the boom or implement.

Note: *The left/right offset must be measured parallel to the boom or implement width. See Figure 2 below.*

To set the left/right value:

1. Touch the current left/right value displayed on the Boom Setup screen.
2. Use the keypad to enter the measured left/right value in inches (U.S.) or centimeters (Metric).
3. If the center line of the boom or implement is to the left of the GPS antenna, enter a negative value for the left/right offset.

FIGURE 2. Example of Left/Right Measurement



4. Touch the **Next** button to continue to the Boom Section Setup screen.

Section	Width	Section	Width
1	100.000	6	100.000
2	100.000	7	100.000
3	100.000	8	100.000
4	100.000	9	100.000
5	100.000	10	100.000

☒ Enable On Screen Boom Switches
Measurements Are Inches

Prev
Next
Cancel

5. Use the on-screen keypad, enter the width of each boom or implement section in the corresponding field.

Note: Enter a section width value of zero for skipped boom sections.

6. Check the “Enable On Screen Boom Switches” option to display the Boom Switch Activation icon in the upper, left corner of the Main screen.

Profile: Viper Demo 1

000°
0.0 CAN mph
100 P1
100 P2


1 2 3 4 5 6 7 8 9 0

Main
Guide
Rx+Cov
+Scout
Rx
Cov
Scout

Touch the Boom Switch Activation icon to show or hide the Boom Section Switches display.

Touching a Boom Section Switch will toggle the corresponding boom section. When a boom section number is illuminated green, the corresponding section is on. A grey number indicates that the boom section is off.

7. Press **Next** when all of the section width information has been entered. The boom summary screen displays.



Note: If the section widths do not match the overall guidance width, the Viper Pro will display a 'Boom Setup Warning' to alert the operator to a potential issue. Review the section configuration and select:

- **Yes** to allow the field computer to automatically align sections end-to-end on the swath midpoint and adjust the overall width to the sum of the section widths, or
- **No** to manually set the section locations and keep the overall width entered previously.

Refer to the *Advanced Section Setup* section on page 222 for assistance with manual section location settings.

This screen displays an overview of the section configuration at the top of the screen, the current values for the overall boom system width and offsets, and the width and offset from the GPS antenna for each section.

8. For simple boom configurations, check that the system overview reflects the actual physical application equipment or implement and touch **OK** to save the displayed settings.

For non-standard or specialized boom or implement configurations (e.g. boom sections not aligned end-to-end, boom sense wires not connected in left to right order, etc.), the field computer will require additional boom configuration information. Refer to the *Boom Cal or Section Width Calibration* section on page 220 for more information on adjusting section offsets for non-standard configurations, adjusting the boom sense "Wired As" settings or customize the display characters for the Viper Pro main screen.

Profiles

Once the initial set up is complete for the machine settings, it is recommended to save a machine profile. The profile stores many of the settings previously set during the initial set up procedure as well as any communication port settings, customized section configurations and guidance feature settings.

If the Viper Pro will be used with different machines or application equipment, profiles allow the operator to quickly re-configure the field computer for the specific application and equipment type.

Note: Profiles do not store any information contained in the CAN nodes.

Saving Profile Information

1. Select **Menu**, then **Setup, Local, Profile**, and **Save Profile**. The Save Profile screen opens.

2. Using the screen keyboard, enter a name for the profile.
3. Press **OK**. A confirmation screen displays.

Note: Before saving a profile, make sure that all settings are correct.

4. Press **OK**. Viper saves the profile information to the system.

Loading a Saved Profile


1. Select **Menu**, then **Setup, Local, Profile**, and **Load Profile**. The Select Profile screen displays.
2. Select a profile from the list.

3. Press **OK**. A confirmation screen displays.
4. Press **OK**. Viper restarts with the new profile loaded.

Profile Changes

If any of the settings saved within a profile are changed during operation of the field computer, the Viper Pro will prompt the operator to save the current profile settings before the field computer is powered down.

To save the current set up in a new profile, type in a new profile name and touch **OK**.




Note: Enable the 'Use this profile on next Viper startup' option to load and use the new profile the next time the field computer is powered on.


Powering Down the Viper Pro

It is always recommended to shutdown the Viper Pro prior to removing power from the field computer. To properly power down the field computer:

1. Touch the **Menu** button in the lower, right corner of the display.



2. Select the **Exit** button. The Exit Viper prompt will display on the field computer.



3. Select **Exit to Menu** to view the Program Selection Menu, **Shutdown Viper** to power down the field computer, or **Cancel** to resume the Viper Pro program.

Note: Refer to the Start Up section on page 23 for details on the Program Selection Menu options.

If a Job is in progress when the exit button is selected, the Viper Pro will display a warning alerting the operator. Raven recommends closing any open jobs before exiting the Viper Pro application to avoid losing job information.



CAUTION

Pressing and holding the Power button to shutdown the Viper Pro may result in a loss of field application data and is not recommended. Holding the power button to shut off the field computer should only be used in situations when the standard power down procedure is not possible.




Navigating the Viper Pro Interface

The following sections provide an overview to navigation of the Viper Pro user interface and may be used to familiarize operators to various information displays on the Viper Pro touchscreen and for help navigating through settings screens and menus. Detailed information about the individual settings may be found in Chapter 7, *Advanced Settings and Features*.

Main and Job Screen Displays

The following information can be found on the Viper Pro screen:



1. Active Profile or Product Selection	2. Vehicle Heading and Speed	3. Dual Pressure Displays	4. Map Area
5. Tabs	6. Map Tools	7. Display Data	8. Wireless Communication Status
9. Product Rates Area	10. Boom Status Display	11. GPS Status Display	12. SmarTrax Status Indicator (if present)
13. Product Control Status Display	14. AutoBoom System Status	15. Menu	

Active Profile and Product Selection

The active profile is displayed above the map area on the Main tab. Before starting a job, be sure that the correct profile is selected.

During an active job, the map area displays coverage or as-applied information based upon the product node or control channel selected in this area.

Note: The Viper Pro may also display an on-screen light bar at the top of the screen during an active job. Refer to the *Light Bar Guidance* section on page 159 to enable the on-screen light bar feature.

Vehicle Heading and Speed

The Viper Pro displays the current GPS course over ground, in compass degrees, and the reported speed from a ground speed sensor or GPS receiver.

Note: A heading of 000° indicates magnetic north.

The Viper Pro speed display indicates both the detected vehicle speed as well as the source and use of the displayed speed.

If 'CAN' is displayed in the speed area, the Viper Pro is registering speed from the Raven CANbus control system. The Viper Pro is also using the displayed speed value for speed compensated product rate control.


If 'GPS' is displayed in the speed area, the Viper Pro is monitoring speed from a GPS receiver (e.g. an Invicta or Phoenix series receiver). 'GPS' will be displayed when the Viper Pro is connected to an optional Raven serial control console. In this instance, the speed displayed on the Viper Pro is for reference only and is not used to adjust product rate. Verify that the speed reading on the serial controller is accurate.

Review the *Speed Sensor Type and Cal* section on page 39 if the speed reported by the Viper Pro does not approximate the actual vehicle speed.

Dual Pressure Displays

Note: Pressure readings are displayed for operator display only and do not affect product rate control.

Pressures monitored via electronic pressure transducers are displayed as P1 (Boom Pressure) and P2 (Sparge Pressure) on the Viper Pro.



Note: The Viper Pro will shutdown the liquid product pump if the boom pressure (P1) remains at zero for more than 20 seconds and the Valve Type is set to PWM.


The Viper Pro will display:

- All dashes if no pressure transducer is detected by the product node.
- CAL if a pressure transducer is detected but has not been calibrated.

Note: Refer to the *Pressure Transducer* section on page 235 for details on calibrating the pressure displays on the Viper Pro.

Pump RPM or Fan Speed

The RPM of a pump or fan may be displayed on the main screen. Contact a local Raven dealer for additional assistance with monitoring various system components during field operations.



Map Area and Tab Views

The map area displays the current GPS location of the vehicle. This area may be used both in the field during product application and when driving between fields to help identify target application areas for the operator.

The tabs displayed along the right side of the screen can be used to access different features of the application currently in progress or display specific application or field feature information.

Note: Refer to the *Tabs* section on page 83 for detailed information on the tab displays and additional features available from each tab view. Some tab views require additional features or system components to enable operator access. Refer to Chapter 5, *Using the Viper Pro System*, for details on starting jobs and enabling features during the job set up process. For assistance with adding additional features to the Viper Pro, contact a local Raven dealer.

Main Tab. The Main tab is only available when the field computer is not providing guidance or logging application or field data in an active job. The Main tab displays the current vehicle location with respect to previously saved field boundaries or on a street map (if available) to help navigate between fields.


Note: Refer to the *Street Maps* section on page 143 for assistance loading street maps on the Viper Pro field computer.

The Main tab view also displays the active profile at the top of the screen.

Guidance and Coverage Tabs. During an active job, the operator may select the tabs along the right side of the screen to review guidance or application and field information logged during the current job in the map area. Refer to Chapter 5, *Using the Viper Pro System*, for more details about the information displayed using the tab views.

Map Tools








Several screen navigation tools are located directly below the Maps area on the Viper Pro main screen.



A red box appears around an active screen tool. To use a tool, simply touch the desired tool icon and touch the area of the Map to perform the selected action.

The screen tools available in this area will vary slightly depending upon which tab is active on the display.


Note: Refer to the *Screen Icons* section on page 113 for information on additional screen tools available on the *Guide* tab during active guidance applications.

Icon	Description
	<p>When the Vehicle Lock tool is active, the field computer will automatically pan the display to show the current vehicle position as the vehicle indicator moves off of the screen.</p> <p>To activate the vehicle lock, touch the lock icon until a red box is displayed on the icon.</p>
	<p>The Information tool is available on the Main tab or on the Scout tab during an active job.</p> <p>Use the Information tool to view information on field specific features such as area contained within a boundary, field name, etc. To use the Information tool:</p> <ol style="list-style-type: none"> 1. Touch the Information icon until a red box displays on the icon. 2. On the Main tab, touch within a field boundary displayed in the map area to view job and field information. From the information window displayed, the operator may delete, view, or resume the previous job or begin a new job using the displayed field boundary. Refer to the <i>Using an Existing Field Boundary</i> section on page 79 for additional information. 3. On the Scout tab, touch within a field boundary (line displayed in black) to display field area. Note: If the field boundary has been used to create an application zone (line displayed in blue), the area information is no longer associated with the boundary.
	<p>The Prescription (Rx) tool is available on the Rx and Cov tabs if a prescription map has been loaded for the job in progress. The Prescription (Rx) tool may be used to view rate zone or applied coverage information. To use the Prescription (Rx) tool:</p> <ol style="list-style-type: none"> 1. Touch the Prescription (Rx) icon until a red box displays on the icon. 2. Touch the map area. The field computer displays rate information for the selected area.
	<p>The Pan icon may be used to manually pan the map area display. To use the pan tool:</p> <ol style="list-style-type: none"> 1. Touch the Pan icon until a red box displays on the icon. 2. Touch the map area. The selected area will become the center of the map view. Touch near the sides or corners of the map area repeatedly to pan to areas outside of the immediate field area display.
 	<p>The Zoom tools allow the operator to adjust the viewable area of the map display. Note: although map detail may be affected by zooming in or out on the display, the control system is not affected by the level of detail shown in the map area.</p> <p>To use the Zoom tools:</p> <ol style="list-style-type: none"> 1. Touch the Zoom In or Zoom Out icon until a red box displays on the desired icon. 2. Touch the map area. The field computer will increase or decrease the viewable area. Repeated zooming allows the operator to continue to adjust the map display.
	<p>The Map Extents tool quickly adjusts the map zoom to display all map features or field information. Use this tool to avoid using the zoom and pan tools to return to a complete field map or to display all field boundary areas currently stored on the Viper Pro regardless of current GPS location.</p> <p>Note: To return to the current GPS position, select the Vehicle Lock icon.</p>

Display Data

Note: *Display Data is only accessible if the Viper Pro is set as the CAN controller.*

Touch the Display Data icon to access an overview of the tally register or current active alarm information for each product node or control channel directly from the main screen.



The field volume, field area, tank volume, total volume, total area, and area per hour tallies are displayed within the display prompt. Touch the display data prompt to cycle through the available data displays including weather information if the optional hardware is installed. To hide the data prompt, touch the Display Data icon again.


Note: *The data tallies displayed are also available by touching within the Product Control area and selecting the **Tally Registers** button at the bottom of the CAN Controller Status screen.*

The display data prompt is for display purposes only and the tallied information cannot be modified from this view. To modify the data displayed, refer to the Tally Registers section on page 93. See Appendix G, Weather Station, for information on displaying weather data in this area using the optional weather station.

Information for any active alarm conditions is also displayed in this area. If an alarm condition is detected, the Display Data icon will change to a red alarm icon. Information for new alarm conditions will be displayed automatically when the field computer detects the issue. To review current alarm information, touch the alarm icon to display information such as the control channel and alarm type currently active.

Wireless Communication Status

The status of wireless communications is displayed on the Viper Pro main screen in the tool bar below the map.




Note: *For more information on using the wireless communication features with the Viper Pro, see Appendix H, Wireless Communications and Remote Service.*

For instructions on installing and setting up the Slingshot Field Hub, refer to the Field Hub Installation Guide provided with the wireless device.

Product Rates Area


The current target (R_T) and actual (R_A) application rate is displayed for each product node or control channel in the product rates area.



Note: When the field computer is configured for the 'Manual' application type, touch the application area to toggle logging the coverage area on or off during a job.

Boom Status Display

The 'Booms' area displays the status of each section currently configured on the Viper Pro field computer.




The status indicator or display character for each section displays green if the section is on or active. If a section is toggled off, the status indicator for the corresponding section will display gray.

Note: If an optional AccuBoom, automatic boom section control, system is installed with the Viper Pro, sections currently controlled by the AccuBoom feature will display with a blue background.

Touch within the Booms area accesses the AccuBoom Control Setup screen. If the required hardware has been installed, the Viper Pro can be used to automatically control boom sections based on the coverage map or other scouting information such as a field boundary. See Chapter 8, *Using AccuBoom™*, for a detailed description of the AccuBoom feature.

GPS Status Display

The current status of DGPS reception, as well as the current source for differential corrections is displayed in this area on the main screen.



Note: This indicator is not necessarily the status of the GPS Receiver or the availability of DGPS reception.

The DGPS Status Indicator displays a green “thumbs-up” if all required messages are being received and updated normally. The indicator changes to a red “X” if GPS information is unavailable or the field computer is not receiving GPS information from the receiver. A yellow “caution” symbol is displayed if the GPS differential data has not been updated in the last 15 seconds, if the HDOP (Horizontal Dilution of Precision) exceeds 2.0, or when any other system “cautionary conditions” are met. Touch the GPS Status Indicator to view the GPS Status screen.


Note: Touch the DGPS status indicator to display the GPS Status screen. Refer to the GPS Status Screens section on page 135 for details on using the GPS Status screen.

When connected to a compatible GPS receiver, the Viper Pro will display the source of GPS corrections currently received. An audible tone will sound anytime the correction source changes. The Viper Pro will display the following on the Main screen:

- SBAS - This mode displays with any Satellite Based Augmentation System such as WAAS, CDGPS, OmniSTAR VBS, etc.
- OmXP - This mode is displayed with the OmniSTAR XP service selected for differential corrections.
- OmHP - This mode is displayed with the OmniSTAR HP service selected for differential corrections.
- FLT (Float) - This mode indicates that the receiver is not able to provide a full RTK position lock due to the distance from the base station, visibility of the sky, time of day or interference around the base station location. In the float mode, the receiver is still providing a course RTK correction signal, but accuracy of the receiver may not be at a sub-inch level.
- RTK - This mode indicates that the receiver has a full RTK position fix and is providing sub-inch corrections.

Product Control Status Display

The Product Control Status of the Raven serial control console or the Raven CAN system is displayed in this area.




The status indicator displays a red 'X' if communication with the Raven serial control console or CANbus system is not available. A yellow 'caution' symbol is displayed if the Viper Pro detects a problem with the CANbus system such as an alarm condition. The status indicator will display a green 'thumbs-up' during normal operation.

Touch the Product Control Status or indicator to view the CAN Controller Status screen and access the Node Setup screens when connected to a Raven CANbus system.

Note: See the Controller Status Screen section on page 61 for an overview of the settings and information areas displayed on the CAN Controller Status screen. Refer to Review Chapter 7, Advanced Settings and Features, for more information on the Product Control status and using the CAN Controller Status screens on the Viper Pro field computer.

SmarTrax Status Area and Steering Indicator

If an optional SmarTrax or SmartSteer system is installed with the Viper Pro, the status of the system will be displayed in this area.




If the SmarTrax system is engaged, the steering indicator will display a green steering wheel with the 'A' as shown above. When the SmarTrax system is disengaged, the steering wheel will be grey and no A will appear.

Note: Refer to the SmarTrax or SmartSteer Calibration and Operation Manual for additional information.

AutoBoom Status

The status of the optional Raven AutoBoom system is displayed in this area.




Refer to the *CAN AutoBoom Calibration and Operation Manual* for complete calibration and operation instructions.

Note: The AutoBoom status is only displayed if a Glide Series AutoBoom™ system has been installed and connected to the Viper Pro field computer via the Raven CANbus system.

Menu

Various configuration and feature settings for the Viper Pro control system are accessible via the 'Menu' button in the lower, right corner of the Viper Pro display.




Access the menu to:

Note: Refer to Menu section on page 138 for details on the settings, features and options accessible through the main screen menu button.

- Exit or Restart the Viper Pro application or shutdown the field computer
- View field computer software and hardware version information
- Access the internet (if a wireless access device is connected and properly configured)
- Setup the following control and feature items:
 - Registration or authorization keys for optional Viper Pro features
 - AutoFold (if installed)
 - Map settings such as prescription (Rx) map colors, loading street maps (if available) and adjusting coverage and scout map displays
 - Display Language and Units, time zone settings and machine profiles
 - Communication port settings
 - Product control settings
 - Light bar settings
 - Boom configuration and settings
- File maintenance processes
- Begin or resume jobs or machine guidance

Controller Status Screen

Touch the Product Control Status indicator at the bottom of the main screen to view the Controller Status screen.



The Controller Status screen displays information from the product rate controller or a CANbus control system.

Controller Status

When connected to a separate product rate control console, the Viper Pro Controller Status screen displays boom section and product rate information provided by the rate controller. The following is an example of the Controller Status screen with the Viper Pro configured to interface with a Raven SCS 460 console.

Controller Status

Manufacturer: Raven

Model: SCS460

Booms Supported: 7

Products Supported: 1

Boom Status

Boom 1: Off	Boom 2: On	Boom 3: On
Boom 4: On	Boom 5: On	Boom 6: Off
Boom 7: Off		

Product Rate Information

Product	Target	Actual
1	0.00	0.00

View Data
OK

CAN Controller Status

When configured to interface with a CAN network, the current control settings for each product node or control channel are displayed on the CAN Controller Status screen.

The following information areas display on the CAN Controller Status screen:

CAN Controller Status			
Boom Cals Area	Boom Cals		Miscellaneous
	L 5	5 180	Speed Sensor Wheel
	1 180	* 0	Speed Cal 1000
	2 300	* 0	Self Test 0.00
	3 120	R 5	Pump RPM 0
	4 300		Speed 10.2
			Units US
Features Settings Area	Product 1 <input type="text"/>		
	Dual Flow % 50	Flow/Shaft Alarm Off	Smoothing On
	Off Rate % 30	Vac/Bin Alarm Off	Agitator Off
	Low Tank 0.0	Decimal Shift Off	Ratio Rate Off
	Low Limit 0.0	Zero Shutoff On	
Product Control Settings Area	Tank Vol 832.0	Spreader 0	Pre Set Pw 0
	Area/Hour 0.0	Valve Cal 2123	Pw Freq 122
	Vol/Min 0.0	Valve Cal 20	Ratio Rate 0.00
	Rate Cal 15.0	Valve Adv 3	Valve Delay 0.0
	Rate +/- 2.0	Pump Cal 0	PWM 0
	Meter Cal 700.0	Min Pw 0	
		Max Pw 253	
Pressure Area	Pressure 1 71	Application Liquid	
	Pressure 2 61	AIM	
Tally Registers and Current Alarms	<input type="button" value="Tally Registers"/> <input type="button" value="Current Alarms"/> <input type="button" value="OK"/>		

- The **Boom Cals Area** displays an overview of the current boom section widths and mapped display characters. Review the *Initial Set Up* section on page 37 for details on configuring the boom or implement. Refer to *Section Assignments* section on page 120 for more information on assigning products to specific sections.
- The **Miscellaneous Settings Area** displays an overview of current selections for the display units, speed sensor and current vehicle speed, etc. Information about the CANbus nodes is also accessible by touching within this area. Refer to the *Miscellaneous Settings Area* section on page 121 for more information.
- Use the **Node/Channel** selection to view the current settings for a specific product node or control channel. When modifying settings, be sure to select the appropriate product node or control channel before changing any settings.
- The **Feature Settings Area** displays an overview of the currently programmed alarm settings and features for the selected product node or control channel. Refer to the *Feature Settings Area* section on page 124 for more information on available features accessible through the feature settings area.
- The **Product Control Settings Area** displays the current calibration and application settings for the selected product node or control channel. Refer to the *Product Control Settings Area* section on page 128 for more information on the settings required for controlling rate of product application.
- The pressure registered by an optional transducer is displayed in the **Pressures Area**. Touch within the pressures area to calibrate the pressure transducer. Refer to the *Dual Pressure Area* section on page 133 for more information.
- The **Application Area** displays the selected application type and control valve selection for the selected product node or control channel. Refer to the *Application and Control Valve Type(s)* section on page 40 for more information on the control valve and application type settings.

- Touch the **Tally Registers** button to view or reset application volume and area tallies for each node or channel or the Viper Pro odometer.

Note: *The tally registers information may also be displayed by selecting the 'Display Data' icon on the main screen.*

- The **Current Alarms** button is displayed only when an alarm condition is detected by the Viper Pro during an active job. Refer to the *Alarms* section on page 96 for detailed information on alarm conditions.



CHAPTER 5

Using the Viper Pro System

Overview of Job Files and Features

The Viper Pro uses jobs and job files to automatically log data in the field during operations using the application management system. During an active job, the Viper Pro collects the following information:

- Target rate (min and max) for each enabled product
- Coverage area and area within a field boundary
- Volume of product applied
- Prescription map information (if applicable)

The job file also collects GPS location information to display the above information in an as-applied or coverage map of the field or areas where coverage or product application has been completed. When application or coverage has been completed for a field, the as-applied map may be transferred to a home or office computer to archive the job data or to create customer application reports.

Note: *A DGPS receiver is not required to control product rates as long as a wheel or radar speed sensor is connected to the Viper Pro. An as-applied or coverage map will not be created and an application report will not be available when operating without DGPS information being input into the Viper Pro.*

A DGPS receiver is required to allow the Viper Pro to control product rate based upon GPS speed, log as-applied or coverage map information or to provide swath guidance. Refer to the DGPS Receiver Connection section on page 21 for details on connecting a DGPS receiver to the Viper Pro.

Job files allow application and field data for multiple operations or fields to be saved on the field computer at any given time without erasing or modifying existing job information and also provides the ability to transfer data to another Viper Pro field computer to begin operations using data previously created or collected or to complete an operation previously started with a different Viper Pro.

Note: *To ensure memory resources are available, Raven recommends performing file maintenance periodically to remove unused job files from the memory on the field computer. Refer to Chapter 10, File Maintenance and Editing Reports for more information.*

Prior to starting a job, be sure that the Viper Pro has been configured for the machine, product control hardware and products to be applied. During an active job, the Viper Pro uses the programmed settings and calibration values to monitor or control product rate(s), calculate area and volume applied and to provide swath guidance in the field.

Note: *Refer to Chapter 4, Initial Set Up and Navigation, to configure the Viper Pro product control system and verify the required product control settings are correctly entered.*

Overview of Job Types

The Viper Pro is compatible with the following job types for operation as a stand alone system or as a part of a full crop data software package.

Standard Jobs

The operator can use the Viper Pro to create the job scouting and application information in the field and during application of products or covering field area during various operations. A standard job does not require additional software to set up or begin using guidance, product control or scouting features of the Viper Pro.

Prescription maps may be uploaded to the Viper Pro via a Slingshot user account or USB flash drive and loaded for standard jobs for variable rate control.

AgX™ Pre-populated Jobs

Jobs may also be pre-populated using AgX standards to create recommendations for product application rates. Prepopulated jobs require a software program installed on a home or office PC with the ability to create AgX compliant product application data package recommendations. These packages must contain a prescription map and field boundary shape file as well as a recommendation file.

Note: *The SST Summit software is required to utilize the AgX pre-populated job files and recommendations on the Viper Pro. Contact a local Raven dealer for more information or to acquire an activation code for the AgX features on the Viper Pro field computer.*

Overview of Job Features

The following features may be enabled or disabled for any operation with the Viper Pro field computer:

- Product Application
- Swath Guidance
- AccuBoom Control

The following sections offer a brief description of these features used with the Viper Pro field computer.

Product Application

The product application feature allows the Viper Pro to:

- Control a Raven CANbus system or communicate with a Raven control console
- Log application data such as coverage and rate information
- Control product application according to a prescription map for variable rate control or send variable rate information to a Raven console

CANbus Rate Control. The Viper Pro field computer is capable of controlling product application directly via a Raven CANbus using Raven product nodes. Each node provides a single control channel for controlling the application of a single product. So, if the Viper Pro is connected to a CANbus with a single product node, the Viper Pro will monitor or control for one product during an active job. Up to five product nodes may be connected to the Viper Pro to control any combination of liquid, granular, injection or spinner channels as necessary. In this configuration, the Viper Pro is directly controlling the product control valves and other hardware.

Note: *A multi-product variable rate key must be purchased and authorized in order to provide multi-product VRA within a job. Contact a local Raven dealer to acquire the activation key and refer to the Registering the Viper Pro section on page 27 for assistance entering the activation code on the Viper Pro field computer.*

External Rate Controller. The Viper Pro is also capable of interfacing with an external rate control console such as the Raven SCS 460 or 4600 to add guidance and data mapping to an existing rate control system. In this configuration, the Viper Pro may be used to log application information for application maps and reports, provide swath guidance or interface with the optional AccuBoom, automatic section control, feature.

Note: *The external rate control console must be used as the primary rate control display and all feature and alarm settings must be programmed into this console.*

While interfacing with an external rate controller, the Viper Pro send prescription rate changes to the external console for variable rate applications.

Note: *A multi-product variable rate key is required to variable rate all products controlled by a multi-product rate controller. Contact a local Raven dealer to acquire the activation key and refer to the Registering the Viper Pro section on page 27 for assistance entering the activation code on the Viper Pro field computer.*

Swath Guidance

When the swath guidance feature is enabled, the Viper Pro may provide on-screen guidance paths based upon the programmed machine or equipment width. The swath guidance path displayed on the Viper Pro provides a quick reference to the vehicle location in relation to previous coverage and may be used with an automated steering system such as the Raven SmarTrax or SmartSteer systems to automatically steer the vehicle using the displayed guidance path.

The Viper Pro is capable of providing guidance for several crop or field patterns to suit field conditions and application types.



AccuBoom™ Control

The AccuBoom control feature allows the Viper Pro to automatically turn the boom sections on or off in reference to a coverage or as-applied map. As the boom enters an area where product has previously been applied, AccuBoom will control boom sections off. When the boom section returns to area not yet covered, the AccuBoom feature will turn the sections back on.

Note: AccuBoom turns booms off when the vehicle location goes outside an Rx Map. AccuBoom will also turn boom sections off when entering zero rate zones on an Rx map if Enable Zero Rate Shut-off has been enabled in the AccuBoom setup.


See Chapter 8, *Using AccuBoom™*, for more information on using the AccuBoom feature with the Viper Pro field computer.

Starting a New AgX Job


Note: Make sure all nodes connected to the CANbus are recognized and programmed correctly. Refer to Chapter 4, *Initial Set Up and Navigation* if nodes do not appear to be recognized by the field computer.

To begin a job using AgX recommendations and pre-populated job and product information:

1. Select **Menu**, then **Start Job**.



2. Select **New AgX Job**.



Note: If AgX recommendations have not been transferred to the field computer, or if the AgX activation code has not been entered and validated, the Viper Pro will display a prompt. Contact a local Raven dealer to acquire an AgX activation code or refer to AgX File Maintenance section on page 190 for assistance transferring recommendations from a USB flash drive to the Viper Pro.

3. The Select Field screen will be displayed.

Select the **Grower**, **Farm** and **Field** to use for the job.

Note: Select the **Order by Nearest** option at the top of the screen to display pre-populated jobs closest to the current vehicle location at the top of each list.

To view a complete list of recommendations stored on the Viper Pro, select the **Show All** option. A list of recommendations currently stored on the field computer will be displayed.

4. Once a field has been selected, a field boundary for the selected field will be displayed in the map preview display. Use the zoom and vehicle lock icons below the preview to adjust the map display if necessary.

- When the correct recommendation is selected, touch the **Next** button to display the Assign Recommendation to Channel screen.

This screen displays the available control channels and any recommendations available for the selected field.

For instructions on completing the job set up process, continue to the *Selecting Control Channels* section on page 70.

Selecting Control Channels

Selecting Control Channels

The channel indicators display the currently selected channel and which channels are enabled or disabled for the job. The channel indicators will display as follows:

- Green - Currently selected channel. Touching any channel indicator once selects the channel and enables the channel for the job. Touch the green channel indicator again to disable the selected channel for the job.
- Dark - Channel is enabled.
- Light - Channel is disabled.

- Touch the channel to which a recommendation will be applied.

Assigning Recommendations

Note: While recommendations are not required, product control channels selected on this screen should have a recommendation assigned before the job is started. A single recommendation may be assigned to multiple channels if more than one channel will apply the same product.

A target rate may be entered for channels used to control pump, fan, or spinner speeds as necessary after the job is started. Do not select control channels for these functions during the job setup process.

2. Touch the recommendation for the product to be applied using the selected control channel. A red box will display around the selected recommendation and the preview information will be displayed.
3. Select other channels and assign recommendations as the job requires.

Note: A recommendation assigned to a different product channel will display a green check mark to the right of the recommendation name. The red box and preview information will only display if the recommendation is assigned to the selected channel.


4. Confirm the section assignments, default rate and conversion factor settings are correct for each product channel before touching the **Next** button to continue the job set up. Refer to the following sections for details on these settings.

Note: Recommendations may be assigned to any product during the job setup. During the job, Viper Pro will display any “skipped” control channels and the operator may control application of a product using these channels if necessary. “Skipped” channels will not have a product name associated with the control channel and the application report will need to be adjusted for these skipped products.

It is recommended to assign recommendations to any control channels to be used during an active job in sequential order to avoid “skipped” channels whenever possible.

Booms

Sections assigned to the selected channel can be changed by touching the **Booms** button at the bottom of the screen.



Confirm the boom or section selections are correctly set up for the equipment being used.

Note: The boom or section selections are also accessible before setting up a job through the Product Control area on the Viper Pro Main screen. Refer to the Section Assignments section on page 120 for more information.

Default Rate

Touch the **Default Rate** button to enter a standard rate of application for the channel when no prescription information is available. The default rate only affects areas where prescription rate information has not been entered.

Note: Zero rate zones will not be affected by the default rate setting.

Conversion Factor

Rate Conversions may be used to calibrate a prescription map recommendation for the application or a different product.

For Example:

Enter a value of '2' to double the prescription rates on the selected prescription map or a value of "0.8" to apply 80% of the prescribed rate.

The Rate Conversions may also be used to convert a prescription map from liters or ounces to gallons, or gallons to ounces or liters. Press the **Common Factors** button to view some common rate conversion values.

Note: The Rate Conversion value must be greater than zero. In most applications, the conversion factor will be left at the default setting of 1.0.

Machine Control Settings

1. Touch the **Next** button on the Assign Recommendations to Channel screen to proceed with the job set up process and display the Machine Control Settings screen.

2. The Viper Pro will automatically enter the current date and time as a default job name.
To simplify working with job files, or if job files will be accessed at a later date to finish product application, it is recommended to rename the job. Use the on-screen keyboard to enter a job name.
3. Select the guidance pattern best suited to the field area and application. Refer to the *Swath Guidance Patterns* section on page 106 for details on the available patterns and using guidance during a job.
4. Select one of the following AccuBoom mapping modes for the job:
 - **Standard AccuBoom** - This method requires no action or additional setup by the operator. The operator simply begins to apply product to the field and the Viper Pro monitors the coverage map and will turn sections off if the boom enters into a previously applied area.
 - **Create AccuBoom No-Spray Map** - This method allows the operator to define spray/no-spray zones within the field. This method is typically used if no previous map has been created and the operator wants to define the field boundaries and other boundaries such as waterways, well heads, etc.
 - **Load AccuBoom No-Spray Map** - This method allows the operator to load a previously created zone map. Select the desired map from the list of available AccuBoom maps currently stored on the Viper Pro.
 - **Map From Field Boundary** - This method allows the Viper Pro to generate a no-spray boundary map from the current field boundary.

Note: See Chapter 8, *Using AccuBoom™*, for details on setting up the AccuBoom feature.

5. Touch **OK** to start the job, **Prev** to return to previous job settings screens or **Cancel** to return to the main screen without beginning the configured job.


Note: *If the job is cancelled, all job settings and selections will need to be reselected if the job is restarted.*

If the field computer is enabled to receive web notifications via the Slingshot server, a prompt or dialogue may be displayed after the Start Viper button is selected and the Main screen is displayed. Refer to the Wireless File Transfer section on page 183 for more information.


Starting a Standard Job

To begin a standard job and use the Viper Pro to enter all product and job information:

1. Select **Menu**, then **Start Job**.



2. Select **New Job**.



- The New Job screen displays.

Note: A Program D or later boom/speed node is required to use AccuBoom™ control. If the AccuBoom control feature option shows 'No Node' beside it, a boom/speed node with program "D" or later is not present on the CANbus.

- The Viper Pro will automatically enter the current date and time as a default job name. To simplify working with job files, or if job files will be accessed at a later date to finish product application, it is recommended to rename the job. Use the on-screen keyboard to enter a job name.
- Select the desired job feature options from the list. If no additional features will be used with the job, touch the **OK** button to open the selected job file. To setup additional features, select the features to be used and touch the **Next** button.
- If Swath Guidance was selected, select the guidance pattern best suited to the field area and application. Refer to the *Swath Guidance Patterns* section on page 106 for details on the available patterns and using guidance during a job.

- Press **Next**. If AccuBoom Control was selected on the New Job screen, select one of the following AccuBoom mapping modes for the job:

- **Standard AccuBoom** - This method requires no action or additional setup by the operator. The operator simply begins to apply product to the field and the Viper Pro monitors the coverage map and will turn sections off if the boom enters into a previously applied area.

- **Create AccuBoom No-Spray Map** - This method allows the operator to define spray/no-spray zones within the field. This method is typically used if no previous map has been created and the operator wants to define the field boundaries and other boundaries such as waterways, well heads, etc.
- **Load AccuBoom No-Spray Map** - This method allows the operator to load a previously created spray zone map. Select the desired map from the list of available AccuBoom maps currently stored on the Viper Pro.
- **Create Map From Field Boundary** - This method allows the operator to select an existing field boundary and generate a no-spray boundary map from the field boundary map. The operator is given a list of all scout files available and allowed to select the desired map. The boundary must be one previously created by the Viper.

Note: See Chapter 8, *Using AccuBoom™*, for details on setting up the AccuBoom feature.

8. Press **Next**. If Product Application was selected, the Product Selection screen displays.

Product Selection

How many products will you be applying?

(A value from 1 to 10 is required)

5

CAN nodes are controlled in a sequential manner and each single product node provides one product control channel. The operator may only enable the number of control channels currently available on the machine when setting up a new job. It is recommended to select the maximum number of product control channels available on the machine each time a new job is started to allow the most flexibility during product application.

For Example:

If product will be applied from a single tank, but the tank contains a mixture of three products, the operator must enable one control channel to control rate for the mixture.

To only apply products associated with control nodes 4 and 5, the operator must select 5 on the Product Selection screen during job setup. If only product nodes 1 and 2 in a 5 product CANbus system will be used during a job, it is still recommended to select 5 products to allow the operator to enable or disable remaining product nodes during the job as necessary without beginning a new job. This also allows the job to be re-opened at a later date to apply additional products using other product nodes.


9. Enter the number of products which will be applied during the job application.

Product Setup

1. Press **Next**. The Product #1 Setup screen displays.


Note: *If a product chain is set up for the new job, the product setup screen for the next available non-chained product will be displayed.*

2. Using the screen keyboard, enter a product name in the **Product Name** field.



The screenshot shows the 'Product #1 Setup' screen. At the top, the title 'Product #1 Setup' is centered. Below it, the 'Product Name' field contains '2-4D' and has a dropdown arrow. To the right of this field are 'Booms' and 'All' buttons. Below the product name field is a checked checkbox labeled 'VRC' followed by the text 'Using Default Colors' and a 'Select' button. The 'Prescription File and Rate Field' section contains a text field with '*.shp' and a 'Browse' button. On the right side, there are four stacked buttons: 'Prev', 'Next', 'Cancel', and 'OK'. At the bottom, there is a navigation bar with various icons including arrows, a plus sign, a minus sign, an equals sign, and a decimal point.

3. Touch the **Booms** button. Select the desired boom sections which will be used to apply the product and touch **OK**.
4. To apply a prescription map to the job, enable the **VRC** option.
5. Press **Browse** to display a list of folders or prescription maps stored in the Viper Pro file structure.



The screenshot shows the 'Select Rx Shape File' screen. The title 'Select Rx Shape File' is centered at the top. Below the title, the file explorer shows the path 'D:\viper\data\rxMaps\'. Under this path, there is a folder named 'colors'. Below the folder, a list of files is displayed with their names and timestamps: 'Forbes Soybeans.shp' (04Nov11 12:40), 'Kevin Fallow.shp' (04Nov11 12:41), 'Scott Farm Corn.shp' (04Nov11 12:25), and 'Seeley Wheat.shp' (04Nov11 12:29). At the bottom right, there are 'Cancel' and 'OK' buttons. The same navigation bar from the previous screen is at the bottom.

Note: *If an AgX recommendation is available on the Viper Pro, the AgX prescription map files can be loaded into a standard job by accessing the AgXRec folder on the above screen.*

Prescription map files within the AgXRec folder will have several data fields associated with the file. Be certain to select the appropriate prescription rates field to ensure that product rates are applied as expected. Contact the prescription map creator for help if necessary to assist with the rate field selection if necessary.

6. Select the appropriate prescription map from the list and touch **OK**.

Product #1 Setup

Product Name: 2-4D

Booms: All

☒ VRC Using Default Colors Select

Prescription File and Rate Field: Seeley Wheat.shp Browse

Rate: [Empty field]

Navigation buttons: Prev, Next, Cancel, OK

7. Select the appropriate rate information field for rate conversion and touch **Next**.

Note: Depending upon how the selected map was created, there could be more than one rate field in the prescription map file. Be sure to select the appropriate rate field for the product to ensure correct application for each product.

8. Repeat step 2 through step 7 as necessary to set up additional products.
9. If prescription maps have been assigned to products, proceed to the *Prescription Rate Conversions and Default Rates* section below for details on using these values with product application using a prescription map. If all products enabled will be applied using a “straight” or single rate, touch **OK** to complete the job set up and begin product application.

Prescription Rate Conversions and Default Rates

1. When product setup is complete for each enabled product, the Rate Conversion screen will be displayed if any prescription maps have been assigned to products.

Rate Conversions

Enter a Rate conversion factor for each product. Rx Map Rates are multiplied by this factor before being sent to the Spray Controller.

2-4 D: 1.0

Herbic.: 1.0

Common Factors keypad:

1	2	3	4	5	←←←←←
6	7	8	9	0	- .

Navigation buttons: Prev, Next, Cancel

Rate Conversions may be used to calibrate prescription maps for the application. Enter a value of ‘2’ to double the prescription rates on the selected prescription map or a value of “0.8” to apply 80% of the prescribed rate.

The Rate Conversions may also be used to convert a prescription map from liters or ounces to gallons, or gallons to ounces or liters. Press the **Common Factors** button to view some common rate conversion values.

Note: *The Rate Conversion value must be greater than zero. In most applications, the conversion factor will be left at the default setting of 1.0*

2. Enter a conversion factor for each product that will be applied according to a prescription map and touch **Next**. Viper displays the Rx Map Default Value screen.
3. Enter a standard rate of application for the channel when no prescription information is available. The default rate only affects areas where prescription rate information has not been entered.

Note: *Zero rate zones will not be affected by the default rate setting.*

4. When the default rates values are set for each product, touch **OK** to complete the job set up process. If the AccuBoom feature is enabled for the job, select whether to start the job now or later.

Existing Jobs

Jobs previously created on the Viper Pro may be reopened to complete report information or to resume a field operation. The following options are available when opening an existing job file:

- View the existing job
- Add to the existing job

Viewing an Existing Job

When viewing an existing job, application information may not be added. Use this feature to view job information without editing or modifying any application data.

1. Press **Menu**, then **Start Job, From File** and **View Only**. The Select Existing Job File screen opens.
2. Select a job from the list and touch **OK**. Viper opens the job.
3. Press **Menu, Close Job** to close the job.

Note: *If the field computer is enabled to receive web notifications via the Slingshot server, a prompt or dialogue may be displayed after the Close Job button is selected. Refer to the Wireless File Transfer section on page 183 for more information.*

Adding to an Existing Job

Previously closed jobs may be reopened and the application or coverage map may be modified by adding to the application. This feature is useful if a job has been closed because of a change in weather conditions, lack of materials, etc.

Note: *When re-opening an existing job, Viper will automatically pause the application. To add to the job, un-pause the job before starting product application to allow the Viper to modify the job information.*

The original data is used when adding to the job file. Make sure that all files created in or used by the existing job are still available on the Viper Pro field computer and verify that the original machine configuration is the

same as when the job was initially started. These parameters include number of booms, boom widths, boom offsets, etc.


Note: *The original swath pattern will be used to provide guidance when the existing job is restarted. Due to shifts in satellite geometry between active job sessions, the operator should perform a swath recalibration to update the guidance information and swath position for the actual machine location.*

1. Select **Menu**, then **Start Job, From File**, and **Add to Job**. The Select Existing Job File screen displays.
2. Select the existing job to open from the list and touch **OK**. Viper loads the job information.
3. Press **Menu**, and **Cont. Job** to add to the job.


Note: *If the field computer is enabled to receive web notifications via the Slingshot server, a prompt or dialogue may be displayed after the Cont Job button is selected. Refer to the Wireless File Transfer section on page 183 for more information.*

Using an Existing Field Boundary

1. On the Main tab, select the Information icon displayed below the Map area and touch within the field boundary displayed on the screen.



2. A preview of the selected job and field boundary area is displayed.



3. Select the desired action to perform using the displayed field boundary.
 - a. Touch 'Delete This Job' to delete the job shown in the preview area. The as-applied or coverage information associated with the selected boundary will be deleted. The field computer will prompt the operator to save or discard the associated field boundary.
 - b. Touch 'View This Job' to view the coverage or as-applied data logged during the previous job associated with the selected field boundary.
 - c. Touch 'Open This Job' to open the selected job and resume product application using the previous coverage information.
 - d. Touch the 'Start New Job' button to begin a new job using the displayed in the preview. The Viper Pro will begin the job set up process for a new job. Refer to the *Starting a New AgX Job* section on page 68 for information on completing the job set up process. When the new job is ready to begin, Viper will prompt the operator to select whether the previous job coverage information should be saved or deleted.
 - e. Touch 'Cancel' to exit the job preview screen and return to the main screen.

Pausing and Resuming Jobs

While a job is in progress, the Viper Pro is continuously logging GPS location and other equipment status information. This may not be desired at all times during an operation such as refilling tanks or bins or if the machine will not be moving for a brief period. To help reduce the file size of completed jobs and to help minimize the time required to perform file maintenance, jobs may be paused to keep the Viper Pro from logging data not necessary for the job report.

Pause a Job

To pause an active job, touch **Menu**, then select **Pause Job**. The field computer will stop logging information for the job report and "Job Paused" will begin flashing at the top of the Viper Pro display.

Note: *The Viper Pro will continue to display the current vehicle position, but GPS location data will not be logged.*

If the field computer is enabled to receive web notifications via the Slingshot server, a prompt or dialogue may be displayed after the Pause Job button is selected. Refer to the Wireless File Transfer section on page 183 for more information.


Resume a Paused Job

To resume logging data for the job report, touch **Menu**, then select **Cont Job**. The field computer will resume logging of GPS and application data for the job report.

Note: *If the field computer is enabled to receive web notifications via the Slingshot server, a prompt or dialogue may be displayed after the Cont Job button is selected. Refer to the Wireless File Transfer section on page 183 for more information.*

Application Rates Area

Use the Application Rates area to quickly check the status of each configured product node or control channel during product application.




Note: The “Application Rates” heading will be hidden if multiple product nodes or control channels are enabled to allow all information to be displayed on the main screen.

The application rates area displays the target (R_T) and actual (R_A) product application rates for each node or channel and the selected control mode for each product. The following control mode indicators are displayed in the application rates area.

Letter	Description
O	The product is off.
M	The product is being applied in the manual mode.
A	The product is being applied in the automatic mode.

The application area also provides quick and convenient access to make adjustments to the product application rates and control mode for each product in the display. Touch within the application rates area to view the Application Control prompt.



Control Mode. Touch the **Off**, **Man** (manual), or **Auto** (automatic) to select the control mode for the available product nodes or control channels.


Target Rates and Rate Bump. To change the target rate for a product, touch the product node or control channel number from the Application Control prompt. Touch the desired value to modify and use the on-screen keypad to enter a new value. Touch the OK button to save the new value and return to the Application Control prompt.

If a non-zero rate bump (+/-) value has been programmed, touch the rate bump buttons to increase or decrease the target rate by the rate bump value. Use the rate bump buttons in manual mode to manually open or close the control valve for the corresponding product or channel. Refer to the *Product Control Settings Area* section on page 128 for more information about the rate bump feature.

Default Rate. If the Viper Pro will reference a prescription (Rx) map for product application, touch the Default Rate button to display the Rx Map Default Value screen. Touch the default value field for the desired product and use the on-screen keypad to enter a default value. Touch OK to save the new value and return to the Application Control prompt.

Note: *The default value only applies to zones or areas with no prescription information and does not affect areas where rate information has been entered. If the prescription map contains zero rate zones, the field computer will continue to reference the prescription map for rate information in that area.*

Product Node Switches. Select the “Enable Product Node Control Switches” option to display Product Switches on the main screen.



During product application, touch the product node switches in the upper, right corner of the map area to toggle the product between Off and Automatic control. When a Product Control Switch is illuminated green, the corresponding product node is in automatic control mode. A white background indicates that the product is Off.


Tabs

The tabs displayed along the right side of the screen allow the vehicle operator to select the information displayed in the map area. The tabs may be used during field operations to toggle coverage, scouting or guidance information at any time and can be used to help the vehicle operator manage the various operations and systems during an application.

Note: When a job is not currently in progress on the Viper Pro field computer, the main tab will display all accessible information. The other tabs will be available only when a job is in progress. Some tabs may not be available unless an optional feature or hardware has been purchased and installed.


Main Tab

The main tab is only available when a job is not in progress on the Viper Pro. This tab displays county street maps (if available) to help the operator locate fields or areas for product application and any saved field boundary features currently stored on the Viper Pro internal memory.



Guide Tab


If the swath guidance feature is enabled during the job setup process, touch the Guide tab during the job to access the swath guidance tools and features or to toggle between the available guidance patterns.



Note: Refer to Chapter 6, *Viper Pro Guidance*, for detailed information on using the guidance features on the Viper Pro field computer.

Rx+Cov+Scout Tab


Access the Rx+Cov+Scout tab to view scouting, coverage and any prescription map information in the same map view. This view will allow the machine operator to compare the as-applied or coverage map with scouting or prescription map data to ensure that the operation is progressing as expected. The Rx+Cov+Scout tab will display the coverage map over the top of a prescription map as a reference for the current application.



Note: Review the Rx, Cov or Scout tab sections below for details on the individual tab displays. Scouting information created using the Scout tab will be displayed on the Rx+Cov+Scout tab. To create or edit scout map features, access the Scout tab.

Rx Tab

The Rx tab is only accessible if a prescription map is loaded for at least one product during the job setup process. The Rx tab displays the target, or the total, area of the prescription map.




Accessing Prescription Map Information

Additional information contained within the prescription map is accessible through the Rx tab. The operator may access the following information using the tools available on the Rx tab:

- Latitude
- Longitude
- Product associated with the prescription map
- Prescription application rates

To display the above information:


1. Load a job with a valid prescription map.
2. Touch the **Rx** tab and select the appropriate product node or control channel above the map display.
3. Select the **Prescription icon** from the map tools display below the map area.
4. Touch an area or zone on the map. The Viper Pro displays prescription rate information for the selected map area.



Note: For more information on prescription maps, see the *Prescription (Rx) Maps* section on page 148.

Cov Tab

The Cov tab displays the area covered by active boom sections which create the coverage map for each product. The coverage map displays covered area in green (default) if the actual application rate matches the target or prescription rate. Any areas where the actual application rate does not meet the expected target range will be highlighted in the colors assigned for the rate high and rate low values.




Accessing Coverage Map Information

Additional coverage or as-applied information is accessible through the Cov tab. The operator may access the following information using the tools available on the Cov tab:

- Latitude
- Longitude
- Products associated with the coverage map

To view information regarding the currently displayed coverage map:

1. Load a job with valid coverage information or begin applying products in a new job.
2. Touch the **Cov** tab and select the appropriate product node or control channel above the map display.
3. Select the **Prescription** icon from the map tools located below the map area.
4. Touch a field area or zone on the map. Viper Pro displays product coverage information for the selected area.



Note: See the Coverage Maps section on page 146 for more information about using coverage maps.

Scout Tab


The Scout tab allows the vehicle operator to create a map of field features or locate areas of interest during an active job. The scout map features may be recorded during a field operation or a scout map may be created prior to an operation, stored on the Viper Pro and then reloaded for a new job.

Note: *GPS drift may cause issues with pre-recorded scout maps. Prior to beginning any applications using a previously recorded scout map, check that the scout map location is accurate enough for the field operation(s) being performed.*

Contact a local Raven dealer for more information about available GPS correction sources and services which may help avoid issues with GPS drift and scout maps.

Field features may include, but are not limited to:

- Field boundaries
- Weed or insect infestations
- Tile lines or waterways
- Rocks
- Trees
- AccuBoom Spray/No-Spray zones




Access the Scout tab to record a zone, path or point to mark a field feature during an active job. Refer to the *Scout Tab* section on page 87 to customize the scout map display on the Viper Pro. Refer to the *Marking a Field Feature* section on page 88 for details on the available features and zones.

AccuBoom™ Tab

The AccuBoom tab is not available for Standard AccuBoom applications. The AccuBoom tab displays the current AccuBoom Spray Zone map.

See Chapter 8, *Using AccuBoom™*, for more information about using the AccuBoom feature.



Marking a Field Feature

Recording field features, zones and boundaries for the scout map feature are all similar operations accomplished by accessing the Scout tab during an active job. Each scout map may contain several field features and zones to help the operator or land owner locate areas of interest at a later time or to avoid applying chemicals in waterways or near well heads.

Note: Refer to the Scout Tab section on page 87 for details on creating custom features for the scout map.

If no scout map features are configured prior to starting a job, the scout map may not be used to map any field features other than a field boundary or AccuBoom zones (spray or no-spray).

While several zones may be created within a field, the scout map may only contain one field boundary. When a field boundary is completed, the Viper Pro will calculate the area contained within the completed field boundary. Field features, zones and areas may be mapped using the following types of paths or points:

Single Point. Select the single point feature to plot a single location on the scout map. The Viper Pro automatically plots the point at the selected location.

Note: The point will be plotted at the vehicle location where the OK button is selected on the Record Field Feature screen.

Group of Points. Select this option to allow the operator to quickly plot multiple points of the same type during an active job.

For example, select the 'Group of Points' option and a custom entry for "Rocks." During the job application, the operator can access the Scout tab and touch the "Rocks Point" button displayed in the map area to plot a point at the current vehicle location. The Viper Pro scout map may then be used to help re-locate the rocks at a later date for removal.

Line. The line option may be used to plot a path through a field such as drainage tile or a wash out.

Zone. A zone creates a closed path or shape on the scout map. Specific zones may be used by the optional AccuBoom system to automatically control boom sections based upon a completed AccuBoom spray or no-spray zone map and field boundary. See Chapter 8, *Using AccuBoom™*, for more information about using the AccuBoom feature with the Viper Pro field computer.

How to Mark a Field Boundary

Note: Other zones, lines or points may be recorded using a similar process as the one explained below.

Within an active job:

1. Select the **Scout** tab.
2. Touch the **Record** button, then **Zone**.

3. Select **Field Boundary** from the available features.
4. Select the preferred method for recording or plotting points along the boundary path.

Manual Point Entry. The operator enters feature or boundary points manually. The Viper Pro will automatically connect each point with a straight line to create a field or zone boundary.

Auto Point Entry. The Viper Pro automatically records points along the driven path to create the boundary in real-time. The field computer will also automatically close the field boundary when the vehicle comes within one boom or implement width of the starting point. The operator may also close the boundary manually if desired.

Note: *Before closing a boundary manually, check the current vehicle position in relation to the point where recording of the boundary was started.*

The Viper Pro will create a straight line from the boundary starting point to the current vehicle location. The field area within the marked boundary will be included in the zone while area outside of this boundary will not be included.

Manual Point Entry: Rubber Banded Zone. This method allows the operator to set boundary points as the machine drives along the boundary. When the operator closes the boundary, the Viper Pro will automatically connect and smooth the boundary line when completing the boundary path.

5. Enter the offset in feet [meters] from the center of the swath, or guidance, width.


Note: *Entering a value 1-1/2 to 2-1/2 times the swath width will record the field boundary so that the headlands passes of the field area may be completed last.*

6. Select the direction of the offset:

- a. Selecting the **Left** offset places the reference point for the boundary to the left of the swath center point by the entered distance.
- b. Selecting the **Right** offset places the reference point to the right of the swath center point by the entered distance.

Note: *To record the field feature boundary at the center of the swath width, enter a value of zero and select either the left or right option.*

7. Touch **OK**. The Viper Pro will begin plotting points or recording manually input points for the boundary based upon the selected Point Entry mode.



Note: *Refer to Chapter 8, Using AccuBoom™, for detailed AccuBoom setup and operation and for detailed information on creating AccuBoom Spray/No-Spray zones.*

8. Drive the perimeter of the field while keeping the selected reference point at or near the field boundary.

9. To close the field boundary, select one of the following options:

- Continue driving the field boundary until the Viper Pro automatically closes the boundary. Viper Pro will automatically close the boundary if the vehicle returns to a position within one boom or implement width of the boundary start point.
- Touch the **Finish** button in the map area and select the 'Field Zone Auto' button to manually close the field boundary. Viper automatically connects the boundary line from the current position to the boundary starting point.

Importing a Field Boundary

If a boundary has been recorded previously and is in the shapefile format (.shp), the boundary may be imported into the current job.

Note: Shapefiles must contain only one polygon. For help using the File Maintenance feature, see Chapter 10, File Maintenance and Editing Reports.

How to Import a Field Boundary

1. Select the **Scout** tab.
2. Touch **Record**, then **Zone**. The Record Field Feature screen displays.

Record Field Feature

Field Boundary

Spray Zone/Boundary

Spray

No-Spray

Rocks

Thistles

Grasshoppers

☐ Manual Point Entry

☒ Auto Point Entry

☐ Manual Point Entry: Rubber banded zone

45.0 Offset from center of swath (feet)

☒ Left ☐ Right


1	2	3	4	5	←←←
6	7	8	9	0	.

Import Field


Cancel

OK

3. Select '**Field Boundary**' and then touch the **Import Field** button. The Select Field Shape File screen displays.



4. Select a file from the list and touch **OK**. The Viper Pro will import a compatible shapefile into the job in progress.




Tally Registers

The tally registers feature of the Viper Pro may be used to track area and volume totals over the course of a field application or over the course of an application season.

To view or reset current tally totals from the Viper Pro main screen:

1. Touch the **Product Control** area at the bottom of the main screen.
2. Touch the **Tally Registers** button at the bottom of the CAN Controller Status screen.

CAN Controller Status			
Boom Cals		Miscellaneous	
L	5	5	180
1	180	*	0
2	300	*	0
3	120	R	5
4	300		
		Speed Sensor	Wheel
		Speed Cal	1000
		Self Test	0.00
		Pump RPM	0
		Speed	10.2
		Units	US
Product 1 			
Dual Flow %	50	Flow/Shaft Alarm	Off Smoothing On
Off Rate %	30	Vac/Bin Alarm	Off Agitator Off
Low Tank	0.0	Decimal Shift	Off Ratio Rate Off
Low Limit	0.0	Zero Shutoff	On
Tank Vol	832.0	Spreader	0 Pre Set Pw 0
Area/Hour	0.0	Valve Cal	2123 Pw Freq 122
Vol/Min	0.0	Valve Cal	20 Ratio Rate 0.00
Rate Cal	15.0	Valve Adv	3 Valve Delay 0.0
Rate +/-	2.0	Pump Cal	0 PWM 0
Meter Cal	700.0	Min Pw	0
		Max Pw	253
Pressure 1	71	Application Liquid	
Pressure 2	61	AIM	
Tally Registers		OK	

The Tally Registers screen displays the following for each product node or control channel:

- Total Volume (Ttl Vol)
- Field Volume (Fld Vol)
- Tank Volume (Tnk Vol)
- Total Area (Ttl Area)
- Field Area (Fld Area)



This screen also displays the overall distance traveled by the vehicle as calculated by the Viper Pro using the speed sensor and programmed speed cal.

Tally Registers

Reset

Reset

Reset

Reset

Reset

Node	Ttl Vol	Field Volume	Tnk Vol	Ttl Area	Fld Area
1	0.0	0.0	0.0	0.0	0.0
2	0.0	0.0	0.0	0.0	0.0
3	0.0	0.0	0.0	0.0	0.0
4	0.0	0.0	0.0	0.0	0.0
5	0.0	0.0	0.0	0.0	0.0

Distance

0 Miles

2250 Feet

Reset

Next

OK

Touch the **Next** button on the Tally Registers screen to view the Odometer screen. Continue touching the **Next** button to view the Tally Registers for each product control node in the Viper Pro CANbus system.

Resetting the Tally Registers

Selecting the **Reset** button for any group of totals on the Tally Registers screen will reset the selected tally for all nodes at the same time.

For example, touching the reset button above the field volume tally with three product nodes in the system, the field volume for all three nodes will be reset to zero. Touch the tank volume reset button to reset the tank or bin volumes to the preset volume value.

Note: Review the Feature Settings Area section on page 124 or the following Setting or Resetting Distance and Individual Nodes section for information on setting the tank volume.

Setting or Resetting Distance and Individual Nodes

To reset an individual node, or the Viper Pro odometer from the main screen:

1. Touch the **Product Control** area at the bottom of the main screen.
2. Touch the **Tally Registers** button at the bottom of the CAN Controller Status screen.
3. Touch the **Next** button on the Tally Registers screen to display the Viper Pro Odometer screen.

4. Using the on-screen keyboard, enter the desired distance values in the appropriate fields. Touch the **Set** button to save the entered values. To reset the Odometer, touch the **Reset** button. The Viper Pro odometer is reset to zero.
5. Press **Next**. The Node 1 screen displays.

6. To set tally data for any of the displayed totals:
 - a. Touch the desired field to modify.
 - b. Enter the desired value and touch the **Set** button next to the entered value.
7. To reset the data in the fields, touch the **Reset** button to the right of the value to reset.
8. Repeat step 6 or step 7 for each node.
9. Press **OK**. Viper Pro saves the changes.


Note: *Field volume, field area, and tank volume can be reset while in a job. Total volume and total area can only be reset while a job is not in progress.*




Alarms

If the Viper Pro is configured as the CANbus controller, the field computer will display a specific warning prompt for any configured alarm conditions encountered. Any new warning conditions encountered by the field computer will be displayed automatically when the condition is detected and will contain information to assist the operator with addressing the alarm condition.

If Touch the Display Data icon to access an overview of the tally register or current active alarm information for each product node or control channel directly from the main screen.



In addition to the warning prompt, the Product Control area on the main screen will display a yellow 'warning' indicator instead of the green 'thumbs up' symbol and a **Current Alarms** button will be displayed at the bottom of the CAN Controller Status screen if an alarm condition is active.




Note: Off rate and low limit alarms will automatically clear once the condition has corrected itself. All other alarms will need to be cleared by touching the **OK** button on the warning prompt.

Addressing Alarm Conditions

To view any current alarms detected on the CANbus system from the Viper Pro main screen:

1. Touch the **Product Control** area at the bottom of the screen.
2. Select the **Current Alarms** button at the bottom of the CAN Controller Status screen. The Current CAN Node Alarms screen displays:



3. To acknowledge the warning, but keep the warning information accessible, touch the **OK** button. To clear the warning condition from the Viper Pro, touch the **Clear Alarms** button.

Note: Touching the *Clear Alarms* button will clear the current alarm prompts from the Viper Pro display. However, the alarm condition may still be present in the application system and the condition may need to be corrected.

The following table discusses the alarms and the conditions that will set off the alarm.

Alarm	Condition
Off Rate	This alarm activates when the actual application rate differs from the specified percentage rate for more than five seconds. This alarm activates only when the system is in Auto mode. The alarm automatically clears when the target rate and actual rate are within the specified range or when the product mode is switched to either Manual or Off.
Low Limit	This alarm activates when the volume per minute has dropped below the specified limit. This alarm activates only when the system is in Auto Mode. The alarm automatically clears when the volume per minute rises above the specified limit or when the product mode is switched to either Manual or Off.
Low Tank	This alarm activates when the tank volume has dropped below the specified limit. The alarm may be cleared by either entering a value that is above the low tank value or by entering a zero in the Low Tank field.
Flow/Shaft	For an injection application, the Flow alarm is active. This alarm activates to indicate a loss of product flow. For a granular application, the Shaft alarm is active. This alarm activates when the shaft sensor in a granular application does not detect shaft rotation. Troubleshoot the system to determine the cause of the alarm and clear it.
Vac/Bin	For an injection application, the Vac alarm is active. This alarm activates when the vacuum sensor detects a vacuum in the tank. Troubleshoot the system to determine the cause of the alarm and clear it. For a granular application, the Bin alarm is active. This alarm activates when the bin level sensor detects that the granular level in the bin drops below the sensor.

Alarm	Condition
Dual Flow	This alarm activates for an injection application system when the flow switch monitor and the actual flow readings are out of the specified tolerance. This alarm also activates when Gran 3 is selected as the application type and the rates sensed by the dual encoders are out of the specified tolerance.
Zero Speed	This alarm activates when the speed of the vehicle drops below 0.7 MPH [1.1 km/h] and the Zero Speed Shutoff function is enabled. Cycle the master switch to clear the alarm and resume product control.

Creating Application Reports

When a field operation is completed, the operator may have the Viper Pro create a job report with the coverage map and application or coverage data collected within the open job. The job report may then be transferred to a home or office computer for viewing and archiving or printed as a visual report for a customer.

Information such as field, product(s) and weather information contained in the application report may be entered during the job on the Viper Pro or on a home or office PC. The Viper Pro creates reports in both shapefile and bitmap (.bmp) formats. The shapefile report will require a shapefile editing program to enter report information while the bitmap report may be edited using a simple image editing tool such as Microsoft® Paint.

Note: *The job information is also provided in the .jdp (job data package) used with Slingshot web services for creating application reports.*

Refer to the following sections to enter report information in an job file before creating the job report. Report information must be entered while the job is open or in progress and may be entered at any time while the job is open. If a job is closed prior to entering report information, the job file must be re-opened to edit or complete report information.

Note: *To re-open a job file and add report information, be sure to select the **Add to Job** option when opening the job file.*

An application report consists of:

- Customer Information
- Field Information
- Field Conditions
- Weather Information
- Applicator Information
- Vehicle Information
- Product Information
- Report Notes

To Enter Report Information

1. With the job file open, touch the **Menu** button in the lower, right corner of the display and select **Report**.
2. The Customer Information screen will display.

Customer Information

3. Use the Customer Information screen to enter the date of the application and the customer name, address, and any identification information associated with the customer file.

Note: The Viper Pro will store customer information entered on the field computer. For future jobs, the operator may select the customer name from the drop down list and Viper Pro will automatically enter the associated customer data.

4. Verify the customer information and touch **Next** to display the Field Information screen.

Field Information

5. Use the Field Information screen to enter field information and the crop type if applicable.

Note: The Viper Pro will store field and crop information entered on the field computer. Select a field name or crop type entered during a previous operation and the field computer will automatically enter the information from the previous job.

6. Verify the field and crop information and, if necessary, edit the displayed report information before touching the **Next** button to display the next Field Information screen.

Field Conditions

- 7. Use the second Field Information screen to enter application type, soil condition, and moisture information for an operation.

Field Information

Application Type

LIQUID

Soil Conditions

NORMAL

Moisture

DRY

Prev

Next

Cancel

OK

Conditions entered for previous jobs may be selected from the drop down lists if applicable. The Viper Pro will automatically store any field information entered on the field computer.

- 8. Touch the **Next** button to display the Weather Information screen.

Weather Information

- 9. Use the Weather Information screen to enter observed weather conditions during an operation. The Viper Pro offers fields for the operator to enter wind speed, wind direction, temperature, and humidity levels.

Weather Information

Time Observed

06Dec30-09:31

Wind Speed

7 MPH

Wind Direction

SE

Temperature

78 F

Humidity

67 %

Prev

Next

Cancel


OK

Note: If an optional Watchdog Weather Station is installed, the Viper Pro can log weather data into the job report automatically. See Appendix G, Weather Station, for more information.

- 10. Touch the **Next** button to display the Applicator Information screen.

Applicator Information

11. Use the Applicator Information screen to enter the operator or custom applicator address and license number.




The Viper Pro will store any applicator information entered on the field computer. Select the operator name from the drop down list to automatically enter the applicator information for future jobs.

12. Touch the **Next** button to display the Vehicle Information screen.

Vehicle Information

13. Use the Vehicle Information screen to enter the tip size for a liquid application if applicable.



14. Touch the **Next** button to display the next report information screen.

Product Information

Note: The Product Information screen(s) will not be available if the Product Application option is not selected during the job setup process. Skip to the Report Notes Information section on page 103 to finish entering report notes.

15. The Product Information screen allows the operator to enter chemical product information such as the manufacturer, EPA number, and targeted pests as applicable.

The Viper Pro will store any chemical information entered on the field computer. If the operator selects the product for a future job, the manufacturer and EPA number will be automatically entered on this screen.

Product Mix. Select the product mix option at the top of the Product Information screen to provide additional ingredient information on the next report information screen.

NH3 Tank Number. For anhydrous ammonia applications, the anhydrous tank number may be entered to display the tank number on the job report.

Single Color Coverage Map. If desired, the Viper Pro can create a report showing coverage only. A single color report will not display high and low rate areas on the coverage map (default).

16. Verify the product information has been entered correctly and touch the **Next** button to continue entering report information. If the product mix option is selected, proceed to the *Ingredient Information* section below, otherwise, skip to the *Report Notes Information* section on page 103 to finish entering report information.

Ingredient Information

Note: The Ingredient Information screen is only displayed if the Product Mix option is selected on the Product Information screen. Skip to the Report Notes Information section on page 103 to finish entering report information if product mix is not selected.

17. Use the Ingredient Information screen(s) to enter the ingredients of a mixed product solution. Enter the manufacturer, EPA number, target pests, and mixture rate for the mixture as necessary.

The operator may enter up to five ingredients for a mixed product.

18. After the last ingredient in the chemical mixture is entered, touch the **OK** button. The following screen will be displayed.

19. Select the **View** button to review the entered product mixture information.

Note: Refer to the *Single Color Coverage Map* section on page 102 for information on the “1 Color Coverage Map” option.

20. Verify that the correct mixture information has been entered and touch the **Next** button to display the Report Notes Information screen.

Report Notes Information

21. Use the Report Notes screen to enter any additional notes for the job report.

22. Use the **Prev** and **Next** buttons as necessary to review and modify the job report information before touching **OK** to accept the displayed information and return to the Viper Pro main screen.



CHAPTER

6

Viper Pro Guidance

Note: A DGPS receiver is required to use the Guidance features of the Viper Pro. Contact a local Raven dealer for additional assistance with compatible receiver options.


Non-Raven DGPS receivers may also be used with the Viper Pro. To avoid issues with connection and compatibility, contact the receiver manufacturer or a local dealer for additional information and receiver capabilities before purchasing.

Guidance Views


The Viper Pro provides two viewing options for guidance control, the '**Down Field View**' and the '**Bird's Eye View**.'

The '**Down Field View**' shows a three dimensional display of the field much like the view from the vehicle cab. The '**Bird's Eye View**' shows the field and the vehicle as viewed from a distance above.

Down Field View




Bird's Eye View



All guidance features can be used in either the '**Down Field View**' or the '**Bird's Eye View**.'

Swath Guidance Patterns

If 'Swath Guidance' is enabled during the start job process, the operator must select a swath pattern to use during the job.



The following swath patterns are available.


Pattern	Description
Straight A-B	A straight A-B line pattern for parallel guidance.
Pivot	A 360 degree (or circle) pattern.
Last Pass	Guidance based on the last nearest pass driven.
Fixed Contour	Allows the operator to set an irregular A-B Line for swath guidance.

Setting the Straight (A-B) Line Pattern


If Swath Guidance is enabled, the Viper Pro will automatically display the 'Guide' tab when a job is opened.

To begin swath guidance with the straight (A-B) line pattern:


1. Touch the **Set A** button to set the first point on the path at the current vehicle location.



2. Drive to the end of the swath and touch the **Set B** button on the screen.




Once the B point is set, Viper will create a straight guidance line displayed in blue.




Set A-B Line by Heading

An A-B Line can also be created by using the Set B by Heading feature. To set an A-B path using a compass heading:

1. Touch the 'Set B by Heading' icon along the bottom of the Guidance display.



The A point is set when the 'Set B by Heading' icon is selected. The Set A-B Line By Heading screen will display.



2. Select one of the following to enter the heading for the A-B Line:
 - a. Touch one of the compass heading arrows to set the heading along a compass heading.
 - b. Touch the Use Current Heading button to use the current vehicle heading shown in the center of the compass display.
 - c. Use the on-screen keypad to enter any heading between 0 and 360°.

Setting the Fixed Contour Pattern


The fixed contour pattern allows the operator to set an irregular A-B Line pattern. To begin swath guidance with the fixed contour pattern:

1. Touch the **'Set A'** button to begin recording an irregular A-B line path. Viper Pro will begin plotting the vehicle position as the machine moves along the desired path.
2. Drive the desired path to the end of the swath.
3. At the end of the swath, touch the **'Set B'** button on the screen. Viper will connect the points plotted along the contour and display the driven path with a blue line. Guidance for subsequent swaths will be based on the original contour and the swath number will be displayed in the upper right corner of the screen.

Note: *Curvature of the Fixed Contour guidance path should not be too aggressive. Overly aggressive curves may produce undesirable results.*

Setting the Last Pass Pattern

If Swath Guidance is enabled, the Viper Pro will automatically display the 'Guide' tab when a job is opened.




The last pass pattern provides guidance based upon the nearest covered area so the operator does not need to set points or record a swath path. To begin Last Pass guidance, begin applying product. Once the first swath path is completed, Viper will detect the nearest area previously covered and use the programmed overall width to determine the next guidance path.

Note: *Last Pass Guidance is based on the nearest covered area so the booms must be on in order to utilize this guidance pattern.*

Turn Around Lock

The Last Pass pattern uses the nearest, previously applied area, or last pass, to determine the guidance for the next swath. If headlands areas are present and the Last Pass mode is active, the Viper Pro may display a guidance line along the headlands area instead of the next swath.



Touch the icon to toggle the turn around lock feature on to provide guidance back along the last swath and ignore the headlands area. Touch the icon again to toggle the turn around lock feature off to allow guidance along the headlands area.


Note: If an optional SmarTrax or SmartSteer system is installed with the Viper Pro, a reverse sense icon may display in the map area during operation. Refer to the SmarTrax or SmartSteer Operation Manual for more information about operating the SmarTrax or SmartSteer system on the Viper Pro field computer.




Setting the Pivot Pattern

If Swath Guidance is enabled, the Viper Pro will automatically display the 'Guide' tab when a job is opened. To begin swath guidance with the pivot pattern:

1. Start with the machine located at a point on the outside of the center pivot area and touch the 'Set A' button on the screen.




2. Drive along the outside of the pivot pattern area and touch the 'Set B' button on the screen. Viper will create a circular guidance path using the 'A' and 'B' points selected and display guidance paths toward the inside of the circle.



Note: Currently, this pattern does not require that a complete pivot pass be driven to create a guidance path, however, best results are usually obtained by driving further along the initial pivot swath before setting the 'B' point.

Using the Guide Tab

Viper Pro will automatically display the Guide tab when a job is opened. The map area displays a Course Direction Indicator in the form of an arrow with the arrow pointing in the direction of travel of the vehicle. The operator may access additional guidance information and features by selecting the displayed areas or on-screen buttons.



The following features display on the Guide tab:

• Light bar Display	• Guide Menu Icon	• Course Direction Indicator
• Off-Swath Distance	• Bright Button	• Save A-B
• Off-Swath Direction	• Dim Button	• Recal A-B
• Swath Number	• Alternate View Button	• Reset A-B
• Alternate Guidance Pattern Button	• Zoom Level	

Light Bar Display

If previously set up, the on-screen light bar will display along the top of the screen during an active job regardless of which tab is currently displayed and allows the operator to use the Guidance feature at all times during product application.

Off-Swath Distance

The Off-Swath Distance displays the actual distance the vehicle is away from the swath pattern.

Off-Swath Direction

The Off-Swath Direction indicator displays the direction from the displayed path to the vehicle. A right arrow indicates that the vehicle is to the right of the displayed path. A left arrow indicates that the vehicle is to the left of the guidance path.

Swath Number

The Swath Number displays the number of passes completed by the vehicle.

Alternate Swath Pattern Button

The Alternate Swath Pattern Button displays the alternate guidance pattern available for the current job.

Bright Button

The Bright button displays only if the Guidance system is configured to use an external light bar.

Press the Bright button to increase the brightness of the external light bar. Viper will display the current intensity level of the light bar display each time the button is selected.

Dim Button

The Dim button displays only if the Guidance system is configured to use an external light bar.

Press the Dim button to decrease the brightness of the external light bar. Viper will display the current intensity level of the light bar display each time the button is selected.

Alternate View Button

The Alternate View button allows the operator to toggle back and forth from 'Down Field View' to 'Bird's Eye View.' The button shows the alternate view that will be displayed when the button is selected.

Guidance Menu Icon

The Guidance Menu icon displays if additional options are available for the guidance pattern currently in use. Touch this icon to access special features, save, or modify the current guidance path.

Note: *The Guidance Menu icon will not display if no additional options are available for the active guidance pattern.*

Zoom Level

Select the Zoom In or Zoom Out icons to change the Guidance display for personal preferences or review the coverage map.

Vehicle Indicator

The Vehicle Icon provides an indication of where the vehicle is positioned with respect to the overall field. The tip of the arrow represents the antenna position of the vehicle and where it is in reference to the swath line, field, etc.

Save A-B Button

The Save A-B button allows the operator to save an A-B line once the line has been set using the Set A and Set B buttons or if the A-B line has been re-calibrated or reset.

ReCal A-B Button












When using the Straight (A-B) Line guidance pattern, touch the Guidance Menu icon to access the Recal A-B button. Touch the Recal A-B button to recalibrate the displayed A-B line to the current machine location.

Reset A-B Button

When using the Straight (A-B) Line guidance pattern, touch the Guidance Menu icon to access the Reset A-B button. Select the Reset A-B button to clear the current A-B guidance points and set new points without closing the current job.

Screen Icons

The following screen icons appear on the Guidance screen.

Icon Name	Description
	Guidance Menu Icon: Touch this icon to view the available options for the current guidance path.
	Straight A-B Pattern: Touch this icon to switch to the Straight A-B pattern.
	Last Pass Pattern: Touch this icon to switch to the Last Pass pattern.
	Pivot Pattern: Touch this icon to switch to the Pivot pattern.
	Vehicle Icon: The tip of the arrow indicates the antenna position and current vehicle location in reference to the swath path, field area, etc.
	Zoom Out: Touch the icon to zoom the current display area out.
	Zoom In: Touch this icon to zoom the current display area in.
	Increase Brightness: Touch this icon to increase the brightness of an external light bar.
	Decrease Brightness: Touch this icon to decrease the brightness of an external light bar.
	Bird's Eye View: Touch this icon to switch to the 'Bird's Eye View' or view looking down on the current machine location.
	Down Field View: Touch this icon to switch to the 'Down Field View' or a view from the vehicle cab.

A-B Lines

The straight A-B and fixed contour guidance patterns allow the operator to set a swath guidance based upon the first pass driven. This A-B line can be saved for later use.


Note: Multiple A-B lines may be saved per job. When saving lines, use unique names to help distinguish each line from other saved A-B lines.

Saving an A-B Line


During the job setup, select Straight A-B or Fixed Contour as the swath pattern.

Once the job is started:

1. Press **Set A** to start the first swath path.
2. Drive to the end of the first swath.
3. Press **Set B**. The first swath path is now set.
4. Touch the Guide Menu icon in the guidance screen. The A-B feature buttons will display.



5. Press the **Save A-B** button. The Save A-B Line screen will display.




6. Using the on-screen keyboard, enter a name for the A-B line in the box. If no name is entered, the date and time are used for the A-B line.
7. Press **OK**. The A-B line will be saved and Viper will display the guidance screen.

Note: When saving lines, use unique names to help distinguish each line from other saved A-B lines. Avoid using dates and times as this will make selecting a previously stored A-B line more difficult.


Loading an A-B Line

During the job setup, select straight A-B or fixed contour for the swath pattern. Once the job is started:

1. Press the **Guide Menu** icon in the guidance screen.



2. Press the **Load A-B** button. The Select A-B Line File screen will display.



If several A-B lines are saved on the Viper Pro, the following filtering options may be used to help locate a specific guidance path:

Show all guidance files. This option shows all currently saved paths of the same type selected when the job was created.

Show within field boundary. If a field boundary has been created or loaded into the current job, select this option to view only saved A-B paths within the current boundary.

Show within distance. Select the distance filter option to locate an A-B line within a set distance of the current GPS position. The operator may select the distance to use as a filter up to a maximum of 10 miles [16 km] (straight A-B) or 2 miles [3.2 km] (fixed contour). The distance filter is not limited when the pivot pattern is used.

3. Select the desired A-B line from the list provided.
4. Press **OK**. The A-B line will be loaded and Viper will display to the guidance screen.

Nudge Feature

The Nudge Feature allows the operator to adjust the calculated guidance path to match field conditions. The default Nudge values for a new Profile are 1 inch [1 cm] and 10 inches [10 cm]. The operator may modify these values for specific machines and implement configurations. The Nudge settings can also be adjusted within a job to modify this feature's characteristics for a particular application.


Configuring Nudge Settings

A Profile's Nudge settings can be adjusted to match particular requirements of a job.

Note: *The in-job nudge settings will only be accessible with an A-B type guidance path (i.e. Straight Line, Fixed Contour, Pivot).*

To configure the nudge settings in a job:

1. Touch the Guide Menu icon on the Guidance screen.



2. Select Adjust Nudge to display the Nudge Settings screen.

Nudge Settings

Nudge 1 (N1): ☒ inches ☐ feet

Nudge 2 (N2): ☒ inches ☐ feet


☐ Save these settings as default for future jobs.

Cancel
OK

3. Use the on-screen keyboard to enter the nudge value for the Nudge 1 and 2 values.
4. Select the 'inches' or 'feet' option to set the units for the entered nudge value.
5. Select the 'Save these settings as default for future jobs' option to save these nudge values with the Profile. If this option is selected, the nudge values will be available at the start of each job started on the Viper Pro. If this option is not selected, nudge values must be programmed for each job.

Using the Nudge Feature

In order to nudge a guidance pattern, the user must first start a “Swath Guidance” enabled job and set A and B points. Switching to “Last Pass” will cause the nudge controls to be hidden on the Guidance screen.



If the Nudge buttons are not available on the Guidance screen, touch the Menu button on the Guidance screen and select Show Nudge Ctrl's. The user will then be able to nudge the swath as desired from the “Guide” tab on the Viper Pro main screen as shown above.

Two nudge values can be applied by selecting either “N1” or “N2” and then touching the nudge left or right button. The Guidance screen also displays the current total amount a swath pattern has been nudged. When the Reset Nudge button is selected, the accumulated nudge distance is applied in the opposite direction, effectively removing any nudge adjustment from the current guidance pattern.

CHAPTER 7

Advanced Settings and Features

Overview

This chapter contains descriptions of advanced settings and features available when controlling a CANbus product control system with the Viper Pro field computer.

The following settings and features are not required for operation of the Viper Pro system and are intended to assist with various operations using the Viper Pro field computer.

Advanced Product Control Settings and Features

Additional settings and features may be configured to help the operator monitor and control application of products during an actual job. This section provides details on the settings available through the CAN Controller Status screen when the Viper Pro is configured as the CANbus controller.

The following settings and features are accessible through the CAN Controller Status screen:

- Boom or implement section assignments
- Miscellaneous settings and node version information
- Feature and alarm settings
- Product control settings
- Pressure display and calibration
- Application and control valve type selection

Section Assignments

Some equipment configurations require the Viper Pro to either control hardware in reference to specific product nodes or control channels or apply or not apply products in reference to a specific boom or implement section.


For Example:

Granular or dry application equipment may be configured to supply product to the left and right booms from separate bins.


A liquid chemical is not supplied to fence row nozzle sections.

To configure the Viper Pro for these equipment configurations, the Boom Select feature must be used. To access the Boom Select screen:

1. Touch within the **Product Control** area on the main screen and then touch the **Boom Cals** area on the CAN Controller Status screen.



The Boom Select screen for sections 1 through 5 will display.



2. Assign products to boom sections as appropriate for the application equipment or system configuration. The system plumbing or configuration must be capable of the assignments shown on the Boom Select screen.
3. Touch **Next** to view the Boom Select screen for sections 6 through 10 (if applicable).
4. Once the section assignments are configured properly for each section, touch the **OK** button to accept the displayed settings and return to the CAN Controller Status screen. Touch the **Cancel** button to exit the Boom Select screen without saving changes to the section assignments.

Miscellaneous Settings Area

The information displayed in the Miscellaneous area is an overview of the settings and current system status.

CAN Controller Status			
Boom Cals		Miscellaneous	
L	5	5	180
1	180	*	0
2	300	*	0
3	120	R	5
4	300		
Product 1 ▼			
Dual Flow % 50		Flow/Shaft Alarm Off Smoothing On	
		Speed Sensor Wheel	
		Speed Cal 1000	
		Self Test 0.00	
		Pump RPM 0	
		Speed 10.2	
		Units US	

The Miscellaneous area displays an overview of several current system settings for the system.

Note: Touching within the Miscellaneous area will display the Miscellaneous Settings screen.

The following information displays are for reference and monitoring purposes only:

Fan/Pump RPM Display. The fan or pump RPM is a display only. This read out displays the fan RPM if a fan sensor is being used with a granular application or a pump RPM if a pump sensor is equipped for a liquid application.

Speed Display. Speed is a display only. The speed shown in this area is the current ground speed of the vehicle or the entered self test speed. See the *Using the Calibration Assistance* section on page 216 for information on entering and using the self test speed feature.

Miscellaneous Settings Screen

Touch within the Miscellaneous area on the CAN Controller Status screen to display the Miscellaneous Settings screen.

Miscellaneous Settings	
Speed Sensor	<input checked="" type="checkbox"/> Radar <input type="checkbox"/> Wheel
Speed Cal	1000
	Calibration Assistance
Self Test	0.00
AccuBm Node	<input type="checkbox"/> Combo <input checked="" type="checkbox"/> AccuBm Only
Audible Alarm	<input type="checkbox"/> Off <input checked="" type="checkbox"/> On
Enable Injection Flush	<input checked="" type="checkbox"/>
Boom Capacity	<input checked="" type="checkbox"/> Off <input type="checkbox"/> On
Max Capacity	10000.0
	Default
	Load Cell
	Next
	Cancel
	OK

Speed Sensor and Cal. This is the type of speed sensor from which the field computer is receiving speed signal and the calibration value entered for the selected sensor. Review the *Speed Sensor Type and Cal* section on page 39 for details on the sensor type setting or the speed cal value. Refer to the *Speed Cal* section on page 215 for information on using the Calibration Assistance feature to refine the current speed cal value.

Self Test Speed. The self test speed allows the field computer to control product application functions while the vehicle remains stationary. This feature allows the operator to test or troubleshoot the CAN and product control systems. For best results, enter a value approximately equal to normal application speeds.

Note: *A speed cal must be entered to allow the test speed feature to function.*

The test speed will reset to zero if the field computer receives a pulse from the actual speed sensor. To keep the test speed from disengaging, disconnect the speed sensor from the system.

AccuBoom Node. Select the type of AccuBoom node connected to the CANbus. If no AccuBoom node is installed, ensure “Combo” is selected.

Audible Alarm. When the audible alarm setting is enabled, the Viper Pro will sound a five second alarm tone if an alert condition or alarm setting is detected on the CANbus (i.e. low tank or bin, zero speed, off rate percent etc.).

The following alarms conditions may be enabled and will sound a tone if the audible alarm feature is enabled:

• Dual Flow % (Percent)	• Flow/Shaft Alarm
• Off Rate % (Percent)	• Vacuum/Bin Alarm
• Low Tank	• Zero Speed Shutoff
• Low Limit	


Note: *Audible Alarms are enabled by default. Refer to the Feature Settings Area section on page 124 for additional information about the above alarm settings.*

Enable Injection Flush. If a Raven Sidekick Pro with Rinse Assist enabled is connected to the field computer, enable the rinse assist feature to allow the operator to engage the Rinse Assist feature via the Viper Pro interface. Refer to the *Sidekick Pro Installation and Operation Manual* for additional information on the Rinse Assist feature.


Boom Capacity. Enable the boom capacity feature on the Miscellaneous Settings screen to allow the field computer to monitor the overall volume per minute for all products being applied. To display the current boom capacity used during a field operation:

To display the current boom capacity used during a field operation:

1. Touch the Display Data button on the main screen.



2. Touch within the Display Data prompt until the boom capacity information is displayed.



The current percentage of the entered maximum boom capacity is displayed. If the actual rate of application reaches 90% or more of the maximum boom capacity, the Viper Pro will display the Boom Capacity Display Data prompt to alert the operator to the application condition.


Maximum Capacity. Touch the maximum capacity value and use the key pad at the bottom of the Miscellaneous Settings screen to enter the maximum boom capacity for the application equipment. Consult the equipment documentation or contact a local equipment dealer or the equipment manufacturer for more information on the maximum application capacity for the specific machine model.

Default Capacity Button. Touch the Default button on the Miscellaneous Settings screen to reset the Maximum volume per minute value to 10,000.

Load Cell. Touch the **Load Cell** button if a Digi-Star load cell will be used for calibration of product remaining in a bin. Refer to the Digi-Star load cell documentation for additional information on using a load cell with the Viper Pro.


Node Version Information Screen

Version information is available on the Viper Pro field computer. The Node Version Information screen displays the software version, software revision, and program number of each node currently detected on the CANbus.



To access the Node Version Information screen from the main screen:

1. Touch in the **Product Control** area on the main screen.
2. Touch within the **Miscellaneous** area on the CAN Controller Status screen.
3. Touch the **Next** button. The Node Version Information screen displays.



4. Touch **OK** or **Cancel** to return to the CAN Controller Status screen or **Prev** to go back to the Miscellaneous Settings screen.

Feature Settings Area

The information displayed in the Feature Settings area is an overview of the following settings for the selected product control node.

• Dual Flow %/FER Cal	• Vacuum/Bin Alarm	• Low PSI Alarm
• Off Rate %	• Decimal Shift	• Max PSI Alarm
• Low Tank	• Zero Speed Shutoff	• Standby Pressure Enable
• Low Limit	• Display Smoothing	• Dual Loop Control
• Flow/Shaft Alarm	• Agitator	• Smart Control
	• Ratio Rate	•

To modify the feature or alarm settings for the above features, touch within the feature settings area on the CAN Controller Status screen.

CAN Controller Status

Boom Cals				Miscellaneous	
L	5	5	180	Speed Sensor	Wheel
1	180	*	0	Speed Cal	1000
2	300	*	0	Self Test	0.00
3	120	R	5	Pump RPM	0
4	300			Speed	10.2
				Units	US

Product 1

Dual Flow %

50

Flow/Shaft Alarm

Off

Smoothing

On

Off Rate %

30

Vac/Bin Alarm

Off

Agitator

Off

Low Tank

0.0

Decimal Shift

Off

Ratio Rate

Off

Low Limit

0.0

Zero Shutoff

On

Tank Vol

832.0

Spreader

0

Pre Set PW

0

Note: Before changing any of the feature or alarm settings, be sure to select the correct product node or control channel by touching the corresponding radio button displayed at the top of the feature settings area.

Node Feature Settings Screen (Page 1)

Touch within the Feature Settings area to view the first screen of settings for the selected product node or control channel.

Node 1 Settings

Dual Flow %

50

Off Rate %

30

Low Limit

0.00

Low Tank

0.00

Next

Cancel

OK

Note: Touch the **Next** button to access additional alarm and feature settings for the selected product node or control channel.

Dual Flow % / FER Cal. The dual flow percent feature is only used when controlling a chemical injection or Granular 3 application.

Note: *The default value for the dual flow percent in either a chemical injection or dual bed system is 50.*

For applications using a CAN motor control node to control an injected chemical, the dual flow percent value sets the tolerance for error allowed between the flow switch and pump encoder before a flow alarm will be activated. Enter a value between 0 and 100 for the allowable tolerance between the switch and encoder. For example, set this value to 100 to disable the dual flow alarm or 0 to display an error any time the flow switch and pump encoder do not match. The flow switch alarm activates when out of tolerance conditions have been met for at least five seconds.

Note: *The dual flow percent is replaced with a FER Cal value when operating a Raven Sidekick Pro™. Refer to the Sidekick Pro Installation and Operation Manual for more information about operation with the Viper Pro field computer.*

When controlling a dual bed system in Gran 3 mode, the dual flow percent sets the tolerance between the belt encoder readings before the dual flow alarm is activated. This alarm may be used to indicate that the belts are moving at different rates or one belt is not moving. Enter a value 100 to disable the dual flow percent alarm or 0 to display an error any time the belt encoders do not match. The dual flow alarm activates when out of tolerance conditions have been met for at least five seconds.

Off Rate %. The off rate percent value sets the allowable difference between the target and actual product application rates. If a non-zero value is entered for this setting and the difference between target and actual rate exceeds the set value for longer than five seconds, the Viper Pro will display an off rate alarm. Enter a value of zero to disable the off rate alarm.

Low Limit. The low limit value sets the lowest volume per minute acceptable during application of a product. If the flow rate drops below the low limit value, the field computer will stop closing the control valve and display a flow alarm.

The field computer automatically adjusts the low limit value for active boom or implement sections. For example, if a low limit of 4 is entered but only half of the total boom width is currently applying product, the Viper Pro will only display a flow alarm if the volume per minute drops below 2.


Low Tank. The low tank value displays an alert when the volume remaining in a tank or bin is reduced to the entered value. When the calculated volume remaining in the tank or bin is reduced to the entered value, the Viper Pro will display an alert.

Note: *To utilize the low tank alarm feature, an initial tank or bin volume must be entered for the corresponding product node or control channel. Refer to Tank Volume section on page 129 for details on setting the initial tank or bin volume.*

The alarm condition is cleared either when all sections are turned off or if a new low tank value less than or equal to the current calculated tank volume is entered. Enter a value of zero to disable the low tank alarm.

Node Feature Settings Screen (Page 2)

From the CAN Controller Status screen, touch within the Features Settings area to display the first Node Settings screen and select the **Next** button to access the following alarm and feature settings.



Zero Speed Shutoff. Enable the zero speed shutoff feature to allow the field computer to automatically shut off product application if the vehicle speed is slower than 0.7 mph [1.1 km/h]. If the zero speed shutoff feature is engaged during a job, the Viper Pro will also display a zero speed alert.

Note: *The zero speed shutoff feature only affects products set to automatic control. Products controlled manually will continue to be applied even if the zero speed shutoff feature is engaged.*

To restart product application after the zero speed shutoff feature has engaged, cycle the master switch 'Off' and then back 'On.' The zero speed shutoff feature will reactivate if the vehicle does not achieve a speed greater than 0.7 MPH [1.1 km/h] and maintain that speed for more than 10 seconds.

Note: *If an optional AccuBoom system is connected, the AccuBoom override may be enabled to begin product application from a complete stop. Refer to the Enabling AccuBoom™ Override section on page 168 for more information.*

Vacuum/Bin Alarm. The vacuum/bin alarm must be disabled for nodes or channels configured for standard (non-injection) liquid product application control.

- Enable the vacuum alarm feature if an injection pump is controlled via a CAN product control or motor control node. When activated, the vacuum alarm displays an alert if the injection pump cannot draw product from the supply tank.
- Enable the bin alarm for granular applications if an optional bin level sensor is installed. With this feature enabled, the Viper Pro will display an alert when the sensor detects the product level in the bin falls below the sensor level.

Note: *Contact a local Raven dealer for information on injection systems or bin level sensors.*

Flow/Shaft Alarm. Enable the flow/shaft alarm to display an alert if the field computer does not detect a signal from the pump shaft encoder or flow switch. This alarm may be used to help troubleshoot flow errors with a CAN motor control node.

Note: *This feature is currently not used with the Raven Sidekick Pro injection system.*

Decimal Shift. Enable the decimal shift feature to increase the system accuracy for low application rates. In the standard mode, the Viper Pro displays values to one decimal place. With the decimal shift feature enabled, values will be displayed to two decimal places.

Note: *Verify all calibration values after the decimal shift feature is either enabled or disabled. Change settings as necessary.*

Agitator. The Viper Pro may be used to enable or disable an agitator to continuously mix a chemical suspension. Contact a local Raven dealer for required hardware.

Display Smoothing. Enable the display smoothing feature to allow the field computer to smooth the rate displayed during product applications. With this feature enabled, the actual rate (R_A) in the rates area will display the target rate (R_T) as long as the actual monitored application rate remains within $\pm 10\%$ of the target rate. The actual rate shown on the main screen will display the actual monitored rate if the application system does not reach the target rate dead band ($\pm 10\%$) within 10 seconds.

Disable the display smoothing feature to monitor the actual application rate at all times.

Note: *The display smoothing feature is only active for products in automatic control mode.*

Ratio Rate. The ratio rate feature should only be enabled for chemical injection applications. Enabled the ratio rate feature to allow an injected chemical to be applied in ratio to the amount of the carrier. See the *Ratio Rate* section on page 132 to enter the ratio of injected chemical to carrier product.

Standby Pressure. The standby pressure feature may be enabled in either the standard or dual loop control modes. When enabled in the standard control mode, the Sgain value is not displayed on the screen, but is still used to set the response of the system to the application system pressures.

Note: *Refer to the Standby Pressure section on page 131 for information about setting the standby pressure value.*

Dual Loop Control. The dual loop control feature is designed for use with low application rates and requires a pressure transducer with a liquid application system controlled with a PWM valve. The dual loop feature uses both the flow meter, to monitor liquid product flow, and a pressure transducer, to monitor liquid product pressure, while controlling a pump to enhance the control response during operation at low application rates. The default setting for this feature is disabled.

Note: *If the dual loop control feature is enabled, the valve cal and valve cal 2 values programmed during the initial field computer configuration will be replaced with the flow cal and pressure Sgain values.*

Smart Control. The smart control feature may be enabled for control channels using a PWM or PWM Close valve. This feature allows the control system to estimate the required PWM duty cycle for changes in vehicle speed or target rate, or when the hydraulic valve is toggled on. When this feature is enabled, control response will be much more aggressive.

Note: *Smart control will be tuned during the PWM calibration. Refer to the PWM Control Valve Tuning section on page 226 for additional information on performing calibration or adjustments for PWM type control valves.*

Low PSI Alarm. When controlling a Raven Sidekick Pro™ direct injection system, the 'Low PSI Alarm' feature will be displayed on the Node Settings screen. When enabled, this alarm indicates that the injection pressure is below the carrier line pressure. Check the injection plumbing for leaks and correct hand valve positions. Refer to the *Sidekick Pro Installation and Operation Manual* for more information.

Max PSI Alarm. When controlling a Raven Sidekick Pro™ direct injection system, the 'Max PSI Alarm' feature will be displayed on the Node Settings screen. When enabled, this alarm indicates that the injection pressure is greater than the rated 150 PSI [1034.21 kPa]. Check the injection plumbing for blockages or reduce the carrier product pressure. Refer to the *Sidekick Pro Installation and Operation Manual* for more information.

Product Control Settings Area

The Product Control Settings area displays an overview of the following calibration settings and values used by the control system to monitor or adjust the rate of product application:

• Tank Volume	• Spreader (Constant)	• Standby Pressure
• Area/Hour (Display only)	• Valve Cal	• Pre Set PW
• Vol/Min (Display only)	• Valve Cal 2	• PW Freq
• Rate Cal	• Valve Advance	• Ratio Rate
• Rate Bump (+/-)	• Fan/Pump Cal	• Valve Delay
• Meter Cal/Density	• Min PW	• PWM (Display only)
	• Max PW	• Max PSI (not applicable for granular applications)

The following data displays are shown in the Product Control Settings area for reference and monitoring purposes only:

Area/Hour. Displays the current area per hour covered during product application. This value is calculated using the programmed section set up and the vehicle speed.

Vol/Min. Displays the current volume per minute monitored by the selected product node or control channel during active application. This value is calculated using the flow of product monitored by the flow meter.

PWM. Displays the current duty cycle of the PWM valve controlling product application (if applicable).

To modify product control settings, touch within the product control settings area on the CAN Controller Status screen.

CAN Controller Status

Boom Cals		Miscellaneous	
L	5 180	Speed Sensor	Wheel
1	180 * 0	Speed Cal	1000
2	300 * 0	Self Test	0.00
3	120 R 5	Pump RPM	0
4	300	Speed	10.2
		Units	US

Product 1 ▼

Dual Flow %	50	Flow/Shaft Alarm	Off	Smoothing	On
Off Rate %	30	Vac/Bin Alarm	Off	Agitator	Off
Low Tank	0.0	Decimal Shift	Off	Ratio Rate	Off
Low Limit	0.0	Zero Shutoff	On		
Tank Vol	832.0	Spreader	0	Pre Set Pw	0
Area/Hour	0.0	Valve Cal	2123	Pw Freq	122
Vol/Min	0.0	Valve Cal 20		Ratio Rate	0.00
Rate Cal	15.0	Valve Adv	3	Valve Delay	0.0
Rate +/-	2.0	Pump Cal	0	PWM	0
Meter Cal	700.0	Min Pw	0		
		Max Pw	253		
Pressure 1	71	Application	Liquid		
Pressure 2	61	AIM			

Tally Registers OK

Note: Before changing any of the product control settings, be sure to select the correct product node or control channel by touching the corresponding radio button displayed at the top of the feature settings area.

Node Control Settings Screen (Page 1)

Touch within the Product Control Settings area to view the first screen of settings for the selected product node or control channel.

Note: Touch the **Next** button to access additional product control settings for the selected product node or control channel.

Tank Volume. Enter the initial volume of product in a tank or bin. As product is applied using the corresponding node or control channel, the Viper Pro will calculate the volume remaining in the tank or bin and display the value on the CAN Controller Status screen, the Tally Registers screen and in the Display Data prompt.

A tank volume is required when using the low tank alarm value. Refer to the *Low Tank* section on page 125 for more information on the low tank alarm.

When refilling a tank or bin during an application, the tank volume may be quickly reset using the Tally Registers screen. Refer to the *Tally Registers* section on page 93 for information on resetting the tank volumes to a preset value.

Rate Cal. The rate cal value is the target rate to which the system will adjust while applying the corresponding product. Review the *Rate Cal(s)* section on page 42 for more information about the rate cal setting.

Note: Refer to Appendix B, *Calculating the Calibration Values*, to verify the flow rate limits for the flow meter and spray nozzles installed on the sprayer. Contact a local Raven or sprayer supply dealer for additional information or assistance.

Rate Bump (+/-). The rate bump feature allows the equipment operator to quickly adjust the rate of product application during a job. Enter the value by which the target rate will be increased or decreased when the rate bump buttons are selected on the Application Control prompt.

See the *Application Rates Area* section on page 81 for more information about the Application Rates Area on the main screen and using the rate bump feature during a field application.

Meter Cal or Density. Depending upon the selected application type, either the meter cal or product density setting will be displayed. See the *Application and Control Valve Type(s)* section on page 40 for configuring the type of product application or the *Meter Cal* section on page 230 for more information on calibrating the meter cal or density values.

- For liquid product applications, the meter cal must be entered to calibrate the Viper Pro to the specific flow meter used to measure the flow of product going to the booms. The meter cal value is typically found on the flow meter.
- When controlling spinner or fan speed, the meter cal is the number of pulses detected per rotation of the spinner or fan multiplied by 10.

Note: *A meter cal value is required to control spinner or fan speed. A fan cal value will only be used to monitor fan speeds.*

- For dry or granular products, enter the density or weight of 1 cubic foot of product. This value is the density of a dry or granular product entered for rate control.

Spreader. The current spreader constant value used by the Viper Pro control system.

Note: *Enter a value of zero for the spreader constant when applying liquid products.*

Node Control Settings Screen (Page 2)

Touch within the Product Control Settings area and then select the **Next** button on the first Node Settings screen to access the following settings.

Node 1 Settings	
Valve Cal	743
Valve Cal 2	0
Valve Adv	0
Fan Cal	0
Min Pw	0
Max Pw	253

PWM Calibration Assistance

Prev
Next
Cancel
OK

Valve Cal and Valve Cal 2. The valve cal value is used by the field computer to make adjustments to a product or hydraulic control valve connected to the CANbus system. Refer to the *Valve Cal(s)* section on page 43 for information on the recommend initial valve cal and valve cal 2 values. Instructions for refining the product or hydraulic control valve using the valve cal values may be found in Appendix B, *Calculating the Calibration Values*.

Note: *If the dual loop control feature is enabled, the valve cal and valve cal 2 values will be replaced by the "flow cal" and "pr sgain" (pressure system gain) values. Refer to the Dual Loop Control Cals section on page 44 for details on setting and using these calibration values for field operations.*

Flow Cal and Pr Sgain (Dual Loop Control Mode Only). The dual loop control feature uses a flow meter and a pressure transducer to enhance the control response during operation at low application rates. The flow cal and pr sgain (pressure system gain) values are used by the field computer to make appropriate adjustments to the control valve and product pump via the CANbus system. Refer to the *Dual Loop Control Cals* section on page 44 for more information on setting up the flow cal and gain values.

Valve Adv. (Advance - Standard, or Fast Valves). While in the automatic rate control mode, the value entered in the valve advance field sets the time (in seconds) which the field computer will allow the control valve to remain open after boom sections are toggled off. The valve advance feature is best used in conjunction with the valve delay value to build up boom pressure for low rate product applications or with valves with “flow back” features.

Enter a value between 1 and 9 seconds to enable the valve advance feature or a value of 0 to disable this feature if a Fast Close, PWM, or PWM Close control valve is used for product control.

Note: *For best results, approach headlands areas at a consistent speed while turning boom sections off.*

The Valve Advance feature should only be used with Standard or Fast valves and the assigned product control node must have software version 1.50 or higher. This setting must remain at zero for products using a Fast Close, PWM, or PWM Close control valve.

Fan/Pump Cal. The fan/pump cal value is only used to monitor product pump speed during standard liquid applications or to monitor fan or spinner speed during granular applications.

Enter the number of pulses detected per one revolution of the fan, spinner or pump shaft.

Note: *The fan/pump cal value is only used to monitor the RPM of a fan, spinner or product pump.*

Min PW. Use the Min PW (Pulse Width) feature to set the minimum desired RPM or hydraulic output (zero point or shutoff point) for a Pulse Width Modulated (PWM) control valve.

Note: *Refer to PWM Calibration Assistance section on page 226 for details on using the calibration assistance to calculate the Min and Max PW values.*

Max PW. Use the Max PW (Pulse Width) feature to set the maximum desired RPM or hydraulic output (zero point or shutoff point) for a Pulse Width Modulated (PWM) control valve.

Note: *Refer to PWM Calibration Assistance section on page 226 for details on using the calibration assistance to calculate the Min and Max PW values.*

Node Control Settings Screen (Page 3)

Standby Pressure. When controlling a liquid product with a PWM valve selected (not PWM close), the standby pressure value sets the pressure which the system will maintain in the product lines when the master or all boom sections are toggled off.

Note: *The standby pressure setting is only accessible when controlling products in liquid control modes with a boom pressure transducer detected by the field computer. Refer to the Standby Pressure section on page 127 for details. If the system pressure does not reach the set standby pressure, or if the observed pressure oscillates, when the master switch is toggled off, the Sgain value will need to be adjusted. See the Sgain (Pressure System Gain - Dual Loop Control Mode) section on page 225 to adjust the Sgain value.*

Pre Set PW. Use the pre-set PW (Pulse Width) setting to set an initial target pulse width value when using a valve that is programmed in PWM Close mode. Enter a value between 1 (slow pulsed width) to 255 (full-scale pulsed width). Viper uses this value to send an initial pulse width to the valve when the booms or nodes are turned on. When a value is entered in this field, the PWM output will not exceed this value when any sections with a non-zero boom cal are off.

When the pre-set PW value is set to zero, the initial pulse width will be equal to the previous state.

PW Freq. This value sets the frequency of the pulses that are sent to the PWM valve. The default value is 122 Hz for Raven valves, or a value specified by the valve manufacturer.

Ratio Rate. Enter a ratio rate value when using a product in an injection system that uses a hand-held spray gun. The product is injected as a ratio to the amount of carrier product applied. For example, to apply 12.0 oz. [0.35 L] of product with every gallon of carrier product, enter 12.0 [0.35] in this field. This function works in manual rate control mode only.

Note: *This value must be set to zero (0) in a non-chemical injection application.*

Valve Delay. Set the valve delay to include a time delay between when the booms are turned on and when the product nodes start to control the flow rate. Viper Pro activates this delay if the time between turning the boom on and off is less than 30 seconds.


Note: *A value of zero must be entered if a Fast Close or PWM Close valve is used as the control valve or when the Valve Type is programmed as a standard valve with an injection system.*

Appl (Application) Delay. The application delay is used with the product chaining feature when advancing to the next bin in the product chain. Enter the time, in seconds, necessary for the product to travel from the bin to the boom or spinner. The field computer will use the application delay for each product control channel to ensure that product application is not interrupted and that the correct target rate is maintained when switching to the next bin in the product chain.

Max PSI. When the boom pressure exceeds the maximum set pressure, a control valve will close to reduce pressure until the boom pressure is once again under the maximum pressure.

Setting the Max PSI:

1. Touch the **Product Control** area on the main screen.
2. Select the appropriate product node or control channel and then touch within the Product Control Settings area.

CAN Controller Status			
Boom Cals		Miscellaneous	
L 5	5 180	Speed Sensor	Wheel
1 180	* 0	Speed Cal	1000
2 300	* 0	Self Test	0.00
3 120	R 5	Pump RPM	0
4 300		Speed	10.2
		Units	US
Product 1 			
Dual Flow %	50	Flow/Shaft Alarm	Off Smoothing On
Off Rate %	30	Vac/Bin Alarm	Off Agitator Off
Low Tank	0.0	Decimal Shift	Off Ratio Rate Off
Low Limit	0.0	Zero Shutoff	On
Tank Vol	832.0	Spreader	0 Pre Set Pw 0
Area/Hour	0.0	Valve Cal	2123 Pw Freq 122
Vol/Min	0.0	Valve Cal	20 Ratio Rate 0.00
Rate Cal	15.0	Valve Adv	3 Valve Delay 0.0
Rate +/-	2.0	Pump Cal	0 PWM 0
Meter Cal	700.0	Min Pw	0
		Max Pw	253

3. The Node 1 or mn (Main) Settings screen displays.
4. Touch the **Next** button until the Max PSI value is displayed at the bottom of the Node Settings screen.

- In the Max PSI field, enter the maximum pressure allowed for the boom.

Node 1 Settings

Pre Set Pw	0	Prev
Pw Freq	122	
Ratio Rate	0.00	
Valve Delay	0.00	
Max psi	150	Cancel
		OK

Navigation icons: Left, Right, Home, Back, Forward, Search, etc.

- Touch **OK** to accept the displayed settings and return to the CAN Controller Status screen.

Dual Pressure Area

Note: The pressure displays calibrated in this area are designed for monitoring product pressures via a product control node.

Pressures monitored by the Viper Pro, via electronic pressure transducers, are displayed as P1 (Boom Pressure) and P2 (SpargePressure) on the Viper Pro main screen.

CAN Controller Status

Boom Cals		Miscellaneous	
L 5	5 180	Speed Sensor	Wheel
1 180	* 0	Speed Cal	1000
2 300	* 0	Self Test	0.00
3 120	R 5	Pump RPM	0
4 300		Speed	10.2
		Units	US

Product 1 [Dropdown]

Dual Flow % 50	Flow/Shaft Alarm Off	Smoothing On
Off Rate % 30	Vac/Bin Alarm Off	Agitator Off
Low Tank 0.0	Decimal Shift Off	Ratio Rate Off
Low Limit 0.0	Zero Shutoff On	

Tank Vol 832.0	Spreader 0	Pre Set Pw 0
Area/Hour 0.0	Valve Cal 2123	Pw Freq 122
Vol/Min 0.0	Valve Cal 20	Ratio Rate 0.00
Rate Cal 15.0	Valve Adv 3	Valve Delay 0.0
Rate +/- 2.0	Pump Cal 0	PWM 0
Meter Cal 700.0	Min Pw 0	
	Max Pw 253	

Pressure 1 71
Pressure 2 61

Application Liquid
AIM

Tally Registers OK

Profile: SPRAYER

Map showing streets: 252nd St, 254th St, 256th St, 258th St, 260th St, 262nd St, 264th St, 266th St, 268th St, 270th St, 272nd St, 274th St, 276th St, 278th St, 280th St, 282nd St, 284th St, 286th St, 288th St, 290th St, 292nd St, 294th St, 296th St, 298th St, 300th St, 302nd St, 304th St, 306th St, 308th St, 310th St, 312nd St, 314th St, 316th St, 318th St, 320th St, 322nd St, 324th St, 326th St, 328th St, 330th St, 332nd St, 334th St, 336th St, 338th St, 340th St, 342nd St, 344th St, 346th St, 348th St, 350th St, 352nd St, 354th St, 356th St, 358th St, 360th St, 362nd St, 364th St, 366th St, 368th St, 370th St, 372nd St, 374th St, 376th St, 378th St, 380th St, 382nd St, 384th St, 386th St, 388th St, 390th St, 392nd St, 394th St, 396th St, 398th St, 400th St, 402nd St, 404th St, 406th St, 408th St, 410th St, 412nd St, 414th St, 416th St, 418th St, 420th St, 422nd St, 424th St, 426th St, 428th St, 430th St, 432nd St, 434th St, 436th St, 438th St, 440th St, 442nd St, 444th St, 446th St, 448th St, 450th St, 452nd St, 454th St, 456th St, 458th St, 460th St, 462nd St, 464th St, 466th St, 468th St, 470th St, 472nd St, 474th St, 476th St, 478th St, 480th St, 482nd St, 484th St, 486th St, 488th St, 490th St, 492nd St, 494th St, 496th St, 498th St, 500th St, 502nd St, 504th St, 506th St, 508th St, 510th St, 512nd St, 514th St, 516th St, 518th St, 520th St, 522nd St, 524th St, 526th St, 528th St, 530th St, 532nd St, 534th St, 536th St, 538th St, 540th St, 542nd St, 544th St, 546th St, 548th St, 550th St, 552nd St, 554th St, 556th St, 558th St, 560th St, 562nd St, 564th St, 566th St, 568th St, 570th St, 572nd St, 574th St, 576th St, 578th St, 580th St, 582nd St, 584th St, 586th St, 588th St, 590th St, 592nd St, 594th St, 596th St, 598th St, 600th St, 602nd St, 604th St, 606th St, 608th St, 610th St, 612nd St, 614th St, 616th St, 618th St, 620th St, 622nd St, 624th St, 626th St, 628th St, 630th St, 632nd St, 634th St, 636th St, 638th St, 640th St, 642nd St, 644th St, 646th St, 648th St, 650th St, 652nd St, 654th St, 656th St, 658th St, 660th St, 662nd St, 664th St, 666th St, 668th St, 670th St, 672nd St, 674th St, 676th St, 678th St, 680th St, 682nd St, 684th St, 686th St, 688th St, 690th St, 692nd St, 694th St, 696th St, 698th St, 700th St, 702nd St, 704th St, 706th St, 708th St, 710th St, 712nd St, 714th St, 716th St, 718th St, 720th St, 722nd St, 724th St, 726th St, 728th St, 730th St, 732nd St, 734th St, 736th St, 738th St, 740th St, 742nd St, 744th St, 746th St, 748th St, 750th St, 752nd St, 754th St, 756th St, 758th St, 760th St, 762nd St, 764th St, 766th St, 768th St, 770th St, 772nd St, 774th St, 776th St, 778th St, 780th St, 782nd St, 784th St, 786th St, 788th St, 790th St, 792nd St, 794th St, 796th St, 798th St, 800th St, 802nd St, 804th St, 806th St, 808th St, 810th St, 812nd St, 814th St, 816th St, 818th St, 820th St, 822nd St, 824th St, 826th St, 828th St, 830th St, 832nd St, 834th St, 836th St, 838th St, 840th St, 842nd St, 844th St, 846th St, 848th St, 850th St, 852nd St, 854th St, 856th St, 858th St, 860th St, 862nd St, 864th St, 866th St, 868th St, 870th St, 872nd St, 874th St, 876th St, 878th St, 880th St, 882nd St, 884th St, 886th St, 888th St, 890th St, 892nd St, 894th St, 896th St, 898th St, 900th St, 902nd St, 904th St, 906th St, 908th St, 910th St, 912nd St, 914th St, 916th St, 918th St, 920th St, 922nd St, 924th St, 926th St, 928th St, 930th St, 932nd St, 934th St, 936th St, 938th St, 940th St, 942nd St, 944th St, 946th St, 948th St, 950th St, 952nd St, 954th St, 956th St, 958th St, 960th St, 962nd St, 964th St, 966th St, 968th St, 970th St, 972nd St, 974th St, 976th St, 978th St, 980th St, 982nd St, 984th St, 986th St, 988th St, 990th St, 992nd St, 994th St, 996th St, 998th St, 1000th St, 1002nd St, 1004th St, 1006th St, 1008th St, 1010th St, 1012nd St, 1014th St, 1016th St, 1018th St, 1020th St, 1022nd St, 1024th St, 1026th St, 1028th St, 1030th St, 1032nd St, 1034th St, 1036th St, 1038th St, 1040th St, 1042nd St, 1044th St, 1046th St, 1048th St, 1050th St, 1052nd St, 1054th St, 1056th St, 1058th St, 1060th St, 1062nd St, 1064th St, 1066th St, 1068th St, 1070th St, 1072nd St, 1074th St, 1076th St, 1078th St, 1080th St, 1082nd St, 1084th St, 1086th St, 1088th St, 1090th St, 1092nd St, 1094th St, 1096th St, 1098th St, 1100th St, 1102nd St, 1104th St, 1106th St, 1108th St, 1110th St, 1112nd St, 1114th St, 1116th St, 1118th St, 1120th St, 1122nd St, 1124th St, 1126th St, 1128th St, 1130th St, 1132nd St, 1134th St, 1136th St, 1138th St, 1140th St, 1142nd St, 1144th St, 1146th St, 1148th St, 1150th St, 1152nd St, 1154th St, 1156th St, 1158th St, 1160th St, 1162nd St, 1164th St, 1166th St, 1168th St, 1170th St, 1172nd St, 1174th St, 1176th St, 1178th St, 1180th St, 1182nd St, 1184th St, 1186th St, 1188th St, 1190th St, 1192nd St, 1194th St, 1196th St, 1198th St, 1200th St, 1202nd St, 1204th St, 1206th St, 1208th St, 1210th St, 1212nd St, 1214th St, 1216th St, 1218th St, 1220th St, 1222nd St, 1224th St, 1226th St, 1228th St, 1230th St, 1232nd St, 1234th St, 1236th St, 1238th St, 1240th St, 1242nd St, 1244th St, 1246th St, 1248th St, 1250th St, 1252nd St, 1254th St, 1256th St, 1258th St, 1260th St, 1262nd St, 1264th St, 1266th St, 1268th St, 1270th St, 1272nd St, 1274th St, 1276th St, 1278th St, 1280th St, 1282nd St, 1284th St, 1286th St, 1288th St, 1290th St, 1292nd St, 1294th St, 1296th St, 1298th St, 1300th St, 1302nd St, 1304th St, 1306th St, 1308th St, 1310th St, 1312nd St, 1314th St, 1316th St, 1318th St, 1320th St, 1322nd St, 1324th St, 1326th St, 1328th St, 1330th St, 1332nd St, 1334th St, 1336th St, 1338th St, 1340th St, 1342nd St, 1344th St, 1346th St, 1348th St, 1350th St, 1352nd St, 1354th St, 1356th St, 1358th St, 1360th St, 1362nd St, 1364th St, 1366th St, 1368th St, 1370th St, 1372nd St, 1374th St, 1376th St, 1378th St, 1380th St, 1382nd St, 1384th St, 1386th St, 1388th St, 1390th St, 1392nd St, 1394th St, 1396th St, 1398th St, 1400th St, 1402nd St, 1404th St, 1406th St, 1408th St, 1410th St, 1412nd St, 1414th St, 1416th St, 1418th St, 1420th St, 1422nd St, 1424th St, 1426th St, 1428th St, 1430th St, 1432nd St, 1434th St, 1436th St, 1438th St, 1440th St, 1442nd St, 1444th St, 1446th St, 1448th St, 1450th St, 1452nd St, 1454th St, 1456th St, 1458th St, 1460th St, 1462nd St, 1464th St, 1466th St, 1468th St, 1470th St, 1472nd St, 1474th St, 1476th St, 1478th St, 1480th St, 1482nd St, 1484th St, 1486th St, 1488th St, 1490th St, 1492nd St, 1494th St, 1496th St, 1498th St, 1500th St, 1502nd St, 1504th St, 1506th St, 1508th St, 1510th St, 1512nd St, 1514th St, 1516th St, 1518th St, 1520th St, 1522nd St, 1524th St, 1526th St, 1528th St, 1530th St, 1532nd St, 1534th St, 1536th St, 1538th St, 1540th St, 1542nd St, 1544th St, 1546th St, 1548th St, 1550th St, 1552nd St, 1554th St, 1556th St, 1558th St, 1560th St, 1562nd St, 1564th St, 1566th St, 1568th St, 1570th St, 1572nd St, 1574th St, 1576th St, 1578th St, 1580th St, 1582nd St, 1584th St, 1586th St, 1588th St, 1590th St, 1592nd St, 1594th St, 1596th St, 1598th St, 1600th St, 1602nd St, 1604th St, 1606th St, 1608th St, 1610th St, 1612nd St, 1614th St, 1616th St, 1618th St, 1620th St, 1622nd St, 1624th St, 1626th St, 1628th St, 1630th St, 1632nd St, 1634th St, 1636th St, 1638th St, 1640th St, 1642nd St, 1644th St, 1646th St, 1648th St, 1650th St, 1652nd St, 1654th St, 1656th St, 1658th St, 1660th St, 1662nd St, 1664th St, 1666th St, 1668th St, 1670th St, 1672nd St, 1674th St, 1676th St, 1678th St, 1680th St, 1682nd St, 1684th St, 1686th St, 1688th St, 1690th St, 1692nd St, 1694th St, 1696th St, 1698th St, 1700th St, 1702nd St, 1704th St, 1706th St, 1708th St, 1710th St, 1712nd St, 1714th St, 1716th St, 1718th St, 1720th St, 1722nd St, 1724th St, 1726th St, 1728th St, 1730th St, 1732nd St, 1734th St, 1736th St, 1738th St, 1740th St, 1742nd St, 1744th St, 1746th St, 1748th St, 1750th St, 1752nd St, 1754th St, 1756th St, 1758th St, 1760th St, 1762nd St, 1764th St, 1766th St, 1768th St, 1770th St, 1772nd St, 1774th St, 1776th St, 1778th St, 1780th St, 1782nd St, 1784th St, 1786th St, 1788th St, 1790th St, 1792nd St, 1794th St, 1796th St, 1798th St, 1800th St, 1802nd St, 1804th St, 1806th St, 1808th St, 1810th St, 1812nd St, 1814th St, 1816th St, 1818th St, 1820th St, 1822nd St, 1824th St, 1826th St, 1828th St, 1830th St, 1832nd St, 1834th St, 1836th St, 1838th St, 1840th St, 1842nd St, 1844th St, 1846th St, 1848th St, 1850th St, 1852nd St, 1854th St, 1856th St, 1858th St, 1860th St, 1862nd St, 1864th St, 1866th St, 1868th St, 1870th St, 1872nd St, 1874th St, 1876th St, 1878th St, 1880th St, 1882nd St, 1884th St, 1886th St, 1888th St, 1890th St, 1892nd St, 1894th St, 1896th St, 1898th St, 1900th St, 1902nd St, 1904th St, 1906th St, 1908th St, 1910th St, 1912nd St, 1914th St, 1916th St, 1918th St, 1920th St, 1922nd St, 1924th St, 1926th St, 1928th St, 1930th St, 1932nd St, 1934th St, 1936th St, 1938th St, 1940th St, 1942nd St, 1944th St, 1946th St, 1948th St, 1950th St, 1952nd St, 1954th St, 1956th St, 1958th St, 1960th St, 1962nd St, 1964th St, 1966th St, 1968th St, 1970th St, 1972nd St, 1974th St, 1976th St, 1978th St, 1980th St, 1982nd St, 1984th St, 1986th St, 1988th St, 1990th St, 1992nd St, 1994th St, 1996th St, 1998th St, 2000th St, 2002nd St, 2004th St, 2006th St, 2008th St, 2010th St, 2012nd St, 2014th St, 2016th St, 2018th St, 2020th St, 2022nd St, 2024th St, 2026th St, 2028th St, 2030th St, 2032nd St, 2034th St, 2036th St, 2038th St, 2040th St, 2042nd St, 2044th St, 2046th St, 2048th St, 2050th St, 2052nd St, 2054th St, 2056th St, 2058th St, 2060th St, 2062nd St, 2064th St, 2066th St, 2068th St, 2070th St, 2072nd St, 2074th St, 2076th St, 2078th St, 2080th St, 2082nd St, 2084th St, 2086th St, 2088th St, 2090th St, 2092nd St, 2094th St, 2096th St, 2098th St, 2100th St, 2102nd St, 2104th St, 2106th St, 2108th St, 2110th St, 2112nd St, 2114th St, 2116th St, 2118th St, 2120th St, 2122nd St, 2124th St, 2126th St, 2128th St, 2130th St, 2132nd St, 2134th St, 2136th St, 2138th St, 2140th St, 2142nd St, 2144th St, 2146th St, 2148th St, 2150th St, 2152nd St, 2154th St, 2156th St, 2158th St, 2160th St, 2162nd St, 2164th St, 2166th St, 2168th St, 2170th St, 2172nd St, 2174th St, 2176th St, 2178th St, 2180th St, 2182nd St, 2184th St, 2186th St, 2188th St, 2190th St, 2192nd St, 2194th St, 2196th St, 2198th St, 2200th St, 2202nd St, 2204th St, 2206th St, 2208th St, 2210th St, 2212nd St, 2214th St, 2216th St, 2218th St, 2220th St, 2222nd St, 2224th St, 2226th St, 2228th St, 2230th St, 2232nd St, 2234th St, 2236th St, 2238th St, 2240th St, 2242nd St, 2244th St, 2246th St, 2248th St, 2250th St, 2252nd St, 2254th St, 2256th St, 2258th St, 2260th St, 2262nd St, 2264th St, 2266th St, 2268th St, 2270th St, 2272nd St, 2274th St, 2276th St, 2278th St, 2280th St, 2282nd St, 2284th St, 2286th St, 2288th St, 2290th St, 2292nd St, 2294th St, 2296th St, 2298th St, 2300th St, 2302nd St, 2304th St, 2306th St, 2308th St, 2310th St, 2312nd St, 2314th St, 2316th St, 2318th St, 2320th St, 2322nd St, 2324th St, 2326th St, 2328th St, 2330th St, 2332nd St, 2334th St, 2336th St, 2338th St, 2340th St, 2342nd St, 2344th St, 2346th St, 2348th St, 2350th St, 2352nd St, 2354th St, 2356th St, 2358th St, 2360th St, 2362nd St, 2364th St, 2366th St, 2368th St, 2370th St, 2372nd St, 2374th St, 2376th St, 2378th St, 2380th St, 2382nd St, 2384th St, 2386th St, 2388th St, 2390th St, 2392nd St, 2394th St, 2396th St, 2398th St, 2400th St, 2402nd St, 2404th St, 2406th St, 2408th St, 2410th St, 2412nd St, 2414th St, 2416th St, 2418th St, 2420th St, 2422nd St, 2424th St, 2426th St, 2428th St, 2430th St, 2432nd St, 2434th St, 2436th St, 2438th St, 2440th St, 2442nd St, 2444th St, 2446th St, 2448th St, 2450th St, 2452nd St, 2454th St, 2456th St, 2458th St, 2460th St, 2462nd St, 2464th St, 2466th St, 2468th St, 2470th St, 2472nd St, 2474th St, 2476th St, 2478th St, 2480th St, 2482nd St, 2484th St, 2486th St, 2488th St, 2490th St, 2492nd St, 2494th St, 2496th St, 2498th St, 2500th St, 2502nd St, 2504th St, 2506th St, 2508th St, 2510th St, 2512nd St, 2514th St, 2516th St, 2518th St, 2520th St, 2522nd St, 2524th St, 2526th St, 2528th St, 2530th St, 2532nd St, 2534th St, 2536th St, 2538th St, 2540th St, 2542nd St, 2544th St, 2546th St, 2548th St, 2550th St, 2552nd St, 2554th St, 2556th St, 2558th St, 2560th St, 2562nd St, 2564th St, 2566th St, 2568th St, 2570th St, 2572nd St, 2574th St, 2576th St, 2578th St, 2580th St, 2582nd St, 2584th St, 2586th St, 2588th St, 2590th St, 2592nd St, 2594th St, 2596th St, 2598th St, 2600th St, 2602nd St, 2604th St, 2606th St, 2608th St, 2610th St, 2612nd St, 2614th St, 2616th St, 2618th St, 2620th St, 2622nd St, 2624th St, 2626th St, 2628th St, 2630th St, 2632nd St, 2634th St, 2636th St, 2638th St, 2640th St, 2642nd St, 2644th St, 2646th St, 2648th St, 2650th St, 2652nd St, 2654th St, 2656th St, 2658th St, 2660th St, 2662nd St, 2664th St, 2666th St, 2668th St, 2670th St, 2672nd St, 2674th St, 2676th St, 2678th St, 2680th St, 2682nd St, 2684th St, 2686th St, 2688th St, 2690th St, 2692nd St, 2694th St, 2696th St, 2698th St, 2700th St, 2702nd St, 2704th St, 2706th St, 2708th St, 2710th St, 2712nd St, 2714th St, 2716th St, 2718th St, 2720th St, 2722nd St, 2724th St, 2726th St, 2728th St, 2730th St, 2732nd St, 2734th St, 2736th St, 2738th St, 2740th St, 2742nd St, 2744th St, 2746th St, 2748th St, 2750th St, 2752nd St, 2754th St, 2756th St, 2758th St, 2760th St, 2762nd St, 2764th St, 2766th St, 2768th St, 2770th St, 2772nd St, 2774th St, 2776th St, 2778th St, 2780th St, 2782nd St, 2784th St, 2786th St, 2788th St, 2790th St, 2792nd St, 2794th St, 2796th St, 2798th St, 2800th St, 2802nd St, 2804th St, 2806th St, 2808th St, 2810th St, 2812nd St, 2814th St, 2816th St, 2818th St, 2820th St, 2822nd St, 2824th St, 2826th St, 2828th St, 2830th St, 2832nd St, 2834th St, 2836th St, 2838th St, 2840th St, 2842nd St, 2844th St, 2846th St, 2848th St, 2850th St, 2852nd St, 2854th St, 2856th St, 2858th St, 2860th St, 2862nd St, 2864th St, 2866th St, 2868th St, 2870th St, 2872nd St, 2874th St, 2876th St, 2878th St, 2880th St, 2882nd St, 2884th St, 2886th St, 2888th St, 2890th St, 2892nd St, 2894th St, 2896th St, 2898th St, 2900th St, 2902nd St, 2904th St, 2906th St, 2908th St, 2910th St, 2912nd St, 2914th St, 2916th St, 2918th St, 2920th St, 2922nd St, 2924th St, 2926th St, 2928th St, 2930th St, 2932nd St, 2934th St, 2936th St, 2938th St, 2940th St, 2942nd St, 2944th St, 2946th St, 2948th St, 2950th St, 2952nd St, 2954th St, 2956th St, 2958th St, 2960th St, 2962nd St, 2964th St, 2966th St, 2968th St, 2970th St, 2972nd St, 2974th St, 2976th St, 2978th St, 2980th St, 2982nd St, 2984th St, 2986th St, 2988th St, 2990th St, 2992nd St, 2994th St, 2996th St, 2998th St, 3000th St, 3002nd St, 3004th St, 3006th St, 3008th St, 3010th St, 3012nd St, 3014th St, 3016th St, 3018th St, 3020th St, 3022nd St, 3024th St, 3026th St, 3028th St, 3030th St, 3032nd St, 3034th St, 3036th St, 3038th St, 3040th St, 3042nd St, 3044th St, 3046th

Low Limit Pr (Pressure)

The low limit pressure feature requires a pressure transducer to monitor product pressure during application and will allow the operator to set the lowest pressure tolerable during field operations. If the application system reaches the low limit pressure, the field computer will display an alert and application system will maintain the flow rate to keep the boom pressure consistent and to maintain the spray pattern.

The low limit pressure feature will result in higher than desired application rates. If the low limit pressure feature will be used during field operations, be sure to enter a value that will not interfere with normal field application.

Zero Boom Pressure

The Viper Pro will shutdown the liquid product pump if the boom pressure (P1) remains at zero for more than 20 seconds and the Valve Type is set to PWM.

Application Area


The application area on the CAN Controller Status screen displays the current application type and control valve type configured on for the Viper Pro control system.

Rate Cal	15.0	valve Adv	3	valve Delay	0.0
Rate +/-	2.0	Pump Cal	0	PWM	0
Meter Cal	700.0	Min Pw	0		
		Max Pw	253		
Pressure 1	71	Application Liquid AIM			
Pressure 2	61				
Tally Registers				OK	

Refer to the *Application and Control Valve Type(s)* section on page 40 for information on these settings.

GPS Status Screens

The GPS Status area provides a quick reference for DGPS signals transmitted to the Viper Pro from the connected DGPS receiver. To view additional information and access features for the DGPS information on the Viper Pro field computer, touch the GPS Status area on the main screen.



The GPS Status screen displays information provided by the DGPS receiver. This screen may also display information to help address issues with DGPS reception.


GPS Status	
GPS Status:	OK
Latitude:	N43°33'3.223260"
Longitude:	W096°43'29.478840"
Elevation:	1388.45 Feet
Satellites:	7
Differential ID:	138
Differential Age:	09
HDOP:	1.2
UTC Time:	19:53:05
UTC Date:	2010/11/10
Messages	GGA:10Hz RMC:<1Hz VTG:10Hz ZDA:<1Hz PSLIR:<1Hz PSLIQ:<1Hz
Solution: No Problems Detected	
<div>Rev Sense</div> <div>COG Filter</div> <div>View Data</div> <div>OK</div>	

Reverse Sense. The reverse sense feature enables the field computer to detect when the vehicle is backing up. With the reverse sensing feature turned off, the Viper Pro will always display any vehicle motion in the forward direction.

Note: *The reverse sense button will not be displayed if an optional SmarTrax system is connected to the CANbus system. Refer to the SmarTrax operation manual for information on reverse sense with these systems.*

Touch the **Rev Sense** button to display the Reverse Sense screen. Review the on-screen feature description and select the desired mode of operation. When the Rev Sense feature is enabled, the field computer will

prompt the operator for the direction of travel each time the field computer is powered up.




While travelling at least 2 mph [3.2 km/h], select the current direction of travel to calibrate the Viper Pro for automatic reverse detection. This feature may be helpful when backing into corners while spraying with AccuBoom enabled. Touch the **For**(ward) or **Rev**(erse) button to manually select the direction of travel.

Course Over Ground (COG) Filter. The course over ground filter may be used to smooth the reported GPS course displayed in the map area on the Viper Pro field computer. Touch the **COG Filter** button to display the Course Over Ground Filter Selection screen. Review the feature description on the display and select the appropriate filtering level.

View Data. Select the **View Data** button to view “raw” GPS data coming from the DGPS receiver into the Viper Pro field computer via the ‘GPS Receiver/DGPS’ port on the main interface or chassis interface cable.

SmarTrax Settings Screens

If an optional SmarTrax or SmartSteer system is detected on the CANbus, the status of the system will be displayed on the main screen.




If the SmarTrax system is engaged, the steering status display above the Menu button will show a green steering wheel with the ‘A’ as shown in the image above. When the SmarTrax system is disengaged, the steering wheel will be grey and no A will appear.

Note: Refer to the *SmarTrax or SmartSteer Calibration and Operation Manual* for detailed calibration and operation information.

AutoBoom™ Status Indicator

The status of an optional Glide Series AutoBoom system is displayed at the bottom of the main screen.




The AutoBoom status is only displayed if a Glide Series AutoBoom system has been installed and on the Raven CANbus system.

For complete calibration and operation procedure, refer to the *AutoBoom Calibration & Operation Manual*.

Wireless Communication Status

The status of wireless communications is displayed along the right side of the main screen below the map area.



Note: For more information on using the wireless communication features with the Viper Pro, see Appendix H, *Wireless Communications and Remote Service*.

For instructions on installing and setting up the Slingshot Field Hub, refer to the *Field Hub Installation Guide* provided with the wireless device.

Menu

The Viper Pro menu contains additional settings and features for working with the control system, managing field application data or interfacing the field computer with optional hardware features. Review the following sections for information about each menu option and the settings, features and available options for operating the Viper Pro field computer.

Exit Button

From the Viper Pro main screen, touch **Menu** and select the **Exit** option to display the Exit Viper prompt. Select the following options to:

Note: *If a Job is in progress when the exit button is selected, the Viper Pro will display a warning alerting the operator. Exit the Viper Pro application without closing the job, touch **Yes**. Raven recommends closing any open jobs before exiting the Viper Pro application to avoid losing job information.*

Pressing and holding the Power button to shutdown the Viper Pro is not recommended. This procedure should only be used in situations when normal shutdown is not possible.

Exit to Menu. Close the Viper Pro application management system and view the Program Selection Menu screen. Review the *Start Up* section on page 23 for details on the Program Selection Menu options.

Shutdown Viper. Close the Viper Pro application management system and power down the field computer. It is always recommended to shutdown the Viper Pro prior to removing power from the field computer.



Cancel. Select this option to return to the Viper Pro application management system.

About Button

From the Viper Pro main screen, touch **Menu** and select the **About** button to view the current software and build version installed on the Viper Pro. The About Viper screen also displays the space remaining on the Viper Pro internal memory.



The following memory indicators may be shown when the internal memory is running low.

	<p>Memory Low Less than 30 MB of space remaining</p>
	<p>Memory Critical Less than 25 MB of space remaining</p>

The Viper Pro automatically checks remaining internal storage space and will display an alert if the internal storage space is almost full. This warning can be cleared by touching the **OK** button.

Runtimes. The application runtime is the overall time that the Viper Pro application management system has been in operation on the field computer. The version runtime displays the run time of the currently installed software version.

CAN Firmware Version. This value displays the current version of firmware used for CAN communication.


Note: *Version 16 or higher CAN firmware is required to allow the Viper Pro to update nodes over the CANbus.*

BIOS Version. The BIOS version currently used by the Viper Pro field computer.


Windows™ OS Version. This value is the image version of the Windows operating system installed on the field computer.

Adjust Brightness

Touch the Adjust Brightness button at the bottom of the About Viper prompt to display the Adjust Brightness settings.



Mode Selection Button -
Day Mode Enabled



Mode Selection Button -
Night Mode Enabled

The Adjust Brightness settings prompt displays the following:

Day/Night Mode Selection Button. The mode selection button also displays the current mode enabled. Touch this button until the desired mode is displayed.

Increase/Decrease Arrows. Touch the arrows pointing up and down to either increase or decrease the display brightness. Touch and hold for five seconds to change the brightness value in increments of 5.


Brightness Value. The current display brightness setting is displayed in the center of the window. In Day mode, this value may be set between 50 and 100. In Night mode, the brightness value may be set between 0 and 100.

OK. Touch the OK button to accept the current mode and brightness value and return to the Viper Pro main screen.

Note: The Viper Pro will always default back to the day mode when powered up or restarted.

Web Button

If the Slingshot Field Hub, or similar hardware, is connected to the ethernet port on the back of the Viper Pro, touch **Menu**, and select the **Web** button to access the world wide web on the Viper Pro touch screen.



Note: The Field Hub will need a registered user account on the Slingshot web page.

On-Screen Keyboard. Place the cursor in a text or value field on a web site or in the web address field and touch the keyboard icon to display an on-screen keyboard for use with the web application on the Viper Pro.

Favorites. Touch the favorites icon to access or edit saved favorites for quick web browsing.

Home. Touch the home icon to return to the initial web page in the Viper Pro web browser.

Back. Select the back button when available to return to the previous web page.


Forward. Select the forward button when available to advance to the next available web page. This button is normally only available if the back button has been used previously.

Add. Select the add button to add the current web site displayed on the screen to the web favorites.

Close. Touch the close button to close the web browser and return to the Viper Pro application management system.

Setup Button

Touch **Menu** and select the **Setup** button to access the following menu items:



• Registration Keys	• Maps	• Local
• Communication Ports	• Product Control	• Light Bar
• Boom		

Note: See the *Setup Menus* section on page 142 for a description of the features accessible through the Setup Menu.

File Maintenance

From the Viper Pro main screen, touch **Menu** and select **File Maintenance** to display the available file maintenance options available for use on the field computer.

This feature allows the operator to transfer files to or from the Viper Pro field computer using either a USB flash drive or to set up automatic file transfer options when using a Slingshot Field Hub.

Note: Do not use the Automatic File Maintenance feature to create reports for a Slingshot account.

The Automatic File Maintenance feature does not export the types to a USB flash drive necessary for creating Slingshot reports and will remove job data from the Viper Pro. Job data transferred using the Automatic File Maintenance feature cannot be reinstalled onto the field computer for export to Slingshot. Refer to the USB File Transfer and Advanced File Maintenance section on page 185 for instructions on outputting the necessary file types.

Refer to Chapter 10, *File Maintenance and Editing Reports*, for a detailed description of the File Maintenance feature. For information on creating application reports and entering report information on the Viper Pro field computer, see *Creating Application Reports* section on page 98.

Start Job

To create an as-applied or coverage map, and create an application report, the machine operator must start a job. The job file automatically logs coverage information for reference at a later date and creates coverage reports for viewing on a home or office PC.

Refer to Chapter 5, *Using the Viper Pro System*, for detailed information about using the Viper Pro during field applications.

Setup Menus

The Setup menu contains several advanced settings, features and options to configure the Viper Pro field computer for communication with optional equipment on the machine, to customize the map displays or to configure the Viper Pro for the specific vehicle or equipment.

Touch **Menu** and select the **Setup** button to access the following menu items:

- Registration Keys
- Maps
- Local
- Communication Ports
- Product Control
- Light Bar
- Boom

Refer to the following sections for detailed information about the settings and features accessible through the Setup menu.

Note: *The following Setup menu features are not available during an active job. Be sure to configure any necessary settings prior to starting a job.*

Registration Keys

From the Viper Pro main screen, touch **Menu** and select **Setup, Reg. Keys** to display the Validation Data screen.


The Viper Pro offers a number of optional features which may be purchased individually and added at any time. See Chapter 3, *Installation, Start Up and Registration*, for instructions on registering and activating features on the field computer.

Note: *Contact a local Raven dealer for additional information or to purchase an optional feature not currently enabled on the Viper Pro system.*

Maps

Coverage, scout and prescription (Rx) map displays may be customized to suit the equipment operator or application through the map option in the setup menu.

To set map display options from the Viper Pro main screen, touch **Menu** and select **Setup** and **Maps**.



The following actions may be performed through the Maps setup menu:

- load and delete streetmaps
- customize scout map displays
- customize coverage map displays
- customize prescription (Rx) map displays

Street Maps

The street maps feature allows the operator to view a county map on the Main tab map area display. The current vehicle location will be displayed on the street map to assist with locating or identifying specific field or application areas.

Note: Street maps are only displayed on the Main tab.

Maps are available free of charge for counties within the United States in a compressed, or “zipped,” format. A program to extract, or “unzip,” these files (i.e. WinZip™) will be required to prepare the files for use with the Viper Pro.

Note: If the computer does not already have the ability to unzip a file, a trial version of WinZip™ software tool is available at:

www.winzip.com


A free version of an unzip program is also available from the following web site:

www.freebyte.com/fbzip/

To Download Street Maps

1. Create a folder on the computer in which to store the download files.
2. Access the Tiger web page at:

http://arcdata.esri.com/data/tiger2000/tiger_download.cfm



3. Select the desired state in the map. The "Download Census 2000 TIGER/Line® Shapefiles" page displays.
4. From the **Select by Layer** drop-down list, select the **Line Features-Roads** option.
5. Click **Submit Selection**. The Available Counties page displays.
6. Check the option for the desired county to download and click the **Proceed to Download** button at the bottom of the list. The Data File Ready page will be displayed.
7. Click **Download File**. The File Download screen displays.
8. Click **Save**. The Save As screen displays.
9. Select the folder created in step 1 and click **Save**. The file is saved to the selected folder.
10. To download additional street maps, repeat step 5 through 9.

Note: Before loading the compressed map files to the Viper Pro, extract the map files to the folder created in step 1.

To Load Street Maps to the Viper Pro

1. Rename the three files to the name of the county. For example, rename the "tgr46087lka.shp" file for Dallas county to "Dallas.shp."

Note: To rename a file, right-click on the file and select **Rename**. Type in the new file name. Be sure to keep the same file extension or the file will not work with the Viper Pro system.

2. Copy the files to the streetmaps folder within the Viper directory of a USB flash drive.

Note: The streetmaps folder should be located in: F:\viper\misc\streetmaps, where F is the root drive letter of the USB device. Do not copy the files into sub-folders. Viper will not be able to locate files within sub-folders.

3. From the Viper Pro main screen, select **Menu**, then **File Maint.**, and then select the option labeled **Advanced File Maintenance**.
4. On the Advanced File Maintenance screen, select:
 - a. **Street Map**, then **Copy** or **Move**.
 - b. To move files from the USB drive to the Viper Pro, select the **External --> Viper** option, and **Copy All** or **Copy Selected**.
 - c. Viper will upload streetmaps files to the internal memory.
5. Press **OK** to exit the File Maintenance feature.
6. Select **Menu**, then **Setup, Maps, Street Map, Install Streets**, and **OK**. Viper loads the map files for viewing on the Main tab of the Viper Pro.

To Delete Street Maps

Street maps not used frequently may be removed to clear up internal memory for job data and other information. To delete a street map from the Viper Pro:

1. Select **Menu**, then **Setup, Maps, Street Map, Delete Streets**, and **OK**. Viper deletes the .sct files from the field computer.
2. Delete the associated map files from the internal storage using the Advanced File Maintenance feature if the files are no longer needed.

Scout Maps

The scout map feature may be used to locate areas of interest during field applications. For example, if the operator locates an area of rocks, weeds or insects during an application, he or she may place a marker on the scout map to help relocate the area for spot spraying or other field work.

Scout maps are also used to create spray or no-spray areas for the optional AccuBoom or AccuRow, automatic boom or planter section control, systems. Four preset features and up to twelve (12) user defined areas may be used to map field features.

Note: Scout map features must be defined prior to starting a job on the Viper Pro field computer.

Field features may include, but are not limited to:

- weed or insect infestations
- tile lines or waterways
- rocks
- trees

Note: Scout map features may be recorded at any time during an active job.

To Configure the Scout Map Features and Mapping Colors

1. From the Viper Pro main screen, touch the **Menu** button, then select **Setup, Maps, and Scout Map**. The Enter Feature Names and Colors screen is displayed.

Enter Feature Names and Colors.	
Field Boundary	Color
Spray Zone/Boundary	Color
Spray	Color
No-Spray	Color
Rocks	Color
Thistles	Color
Grasshoppers	Color
	Color

Next Cancel OK

← → * / + - = . ↩ ↪

2. Using the on-screen keyboard, enter the name of the feature in an available field.

3. Touch the corresponding **Color** button. The Feature Colors screen displays.



4. Select a color for the feature and touch **OK**. Viper assigns the color to the feature and returns to the Enter Feature Names and Colors screen.
5. To setup more field features, repeat step 2 through 4.
6. Press **OK** to finish configuring features and return to the main screen.

To Record Field Features

For a step-by-step procedure for recording field features, review the *Marking a Field Feature* section on page 88.

Coverage Maps

During an active job, the Viper Pro creates an as-applied or coverage map containing real-time product rate information for each active product. The equipment operator may reference the coverage map to view areas of a field application in which:

- product application is on or off,
- product rates are within an acceptable range of the target application rate, or
- product rates are above or below the acceptable range of the target application rate.

The equipment operator may access the coverage map for each product individually during an application to make adjustments to the application system or to help identify and correct issues with the application system.

Note: The as-applied or coverage map information may be displayed on the 'Guide,' 'Rx+Cov+Scout,' or the 'Cov' tabs during job applications.

When creating reports for completed jobs, coverage map data is included with the report to provide an overall field or coverage view.

Customizing the Coverage Map Displays

1. To customize the coverage map display from the Viper Pro main screen, touch **Menu** and then select **Setup, Maps**, and **Cov Map**. The Coverage Maps Colors screen displays.

2. Touch within the maximum rate OK field and use the on-screen keyboard to enter the maximum percentage of the target application rate acceptable for the application.

Note: Enter a value at or above 100% for the maximum range. The default setting is 120%.

3. Touch within the minimum rate OK field and use the on-screen keyboard to enter the minimum percentage of the target application rate acceptable for the application.

Note: Enter a value at or below 100% for the minimum range. The default setting is 80%.

The range between the maximum and minimum rate OK values sets the allowable range for the coverage map display in the maps area during an active application.

While creating the coverage map, Viper Pro will display areas where application rates do not meet the acceptable minimum or maximum range by “painting” the coverage area in a different color. To customize the coverage map display colors:

1. Touch the color **Select** button next to the rate too high, rate OK or rate too low field.
2. Select the desired color to display on the coverage map for the selected range and touch **OK** to accept the change.
3. Touch the remaining color **Select** buttons as necessary to customize the remaining ranges.
4. Touch **OK** to accept the coverage map display changes or touch **Next** to configure a zero rate tolerance for specific product nodes or control channels.

Note: Proceed to the next section for details on the zero rate tolerance setting.

Zero Rate Tolerance

The zero rate tolerance values set the minimum number of pulses detected by an encoder before the Viper Pro will record coverage for the product.

For Example:

While monitoring product rates in rough field areas, an encoder may register false rate pulses due to excess “bouncing” or “jarring” of equipment. These false signals will be recorded by the Viper Pro as an area of product application. If these pulses are received in zero rate zones, the coverage map will display an over application and false data will be included on the application report at the end of the job.

The zero rate tolerance feature may be used to eliminate encoder “chatter” due to these false rate pulses. Each product may be set up with a different rate tolerance value to ensure each product is displayed accurately on the coverage map and application report. On some machines, the main bin will supply a

relatively high volume of product and the tolerance may be set relatively high. Other bins that supply micro-nutrients may apply material at a much lower rate and will require a lower zero rate tolerance value.

Setting the Zero Rate Tolerance.

1. To set the zero rate tolerance for each node from the Viper Pro main screen, touch **Menu**, then **Setup**, **Maps**, and **Cov Map**.
2. Select the **Next** button on the Coverage Map Colors screen to display the Zero Rate Tolerance screen.

3. Touch the desired product field and use the on-screen keyboard to enter the minimum rate allowed before the field computer will record coverage.

Prescription (Rx) Maps

Prescription (Rx) maps may be loaded onto the Viper Pro field computer for automatic variable rate applications based upon rate zones referenced within the prescription map shapefile. The Viper Pro is capable of controlling up to five products in reference to individual maps for each product or a single map containing the prescription rate information for each product in the .dbf file of the shapefile format.

The following table is an example of the .dbf file for a single map that contains multiple product information.

Nitrogen	Potassium	Phosphorus	Lime
100.0	20.0	15.0	750.0
125.0	17.0	33.0	200.0
85.0	45.0	21.0	600.0
50.0	0.0	18.0	925.0

Note: In order to control multiple products according to a prescription map, a multi-product activation key must be entered on the Viper Pro. Contact a local Raven dealer to obtain a multi-product VRA activation key and refer to the Registering the Viper Pro section on page 27 for information on entering activation keys on the Viper Pro field computer.

If the prescription map contains zero rate zones, the product node or control channel must have either a PWM close or fast close valve controlling the corresponding product. Refer to the Application and Control Valve Type(s) section on page 40 for information on setting the valve type on the Viper Pro.

If the system contains a fast valve, the valve must be plumbed into the main product line. Do not plumb the valve into a bypass line.

Prescription maps used with the Viper Pro must be in the shapefile format and must be created using GIS (Geographic Information System) software capable of creating shapefiles. These shapefiles must be in the polygon shape format that complies with the ESRI (Environmental Systems Research Institute) shapefile specifications. Shapefiles must also be in the WGS84 datum.

For best results, prescription maps used with the Viper Pro should contain as few rate zones as possible. Maps with too many zones may affect performance of the field computer during the application. Raven recommends that the smallest zone(s) contained within the prescription map should be no smaller than the width of the boom or implement applying product.

For Example:

If the machine swath width is 90 feet [27.4 m], zones on the prescription map should be no less than 90 feet [27.4 m] wide.

To load a prescription map shapefile onto the Viper Pro, the .shp, .shx and .dbf files must be copied into the RxMaps folder on the USB flash drive used with the Viper Pro. Refer to the *Uploading Prescription Maps from a USB Flash Drive* section on page 184 for detailed instructions.

Prescription (Rx) Map Look-Ahead


The prescription map look-ahead value is the number of seconds (determined by vehicle speed) which the field computer is allowed to scan in front of the current vehicle position to find rate changes on a prescription map. This feature may be used to help compensate for the time it takes a valve to fully adjust to a different rate.

For Example:

If the control valve takes four seconds to adjust to a rate change, set a prescription look-ahead value of 2 seconds to allow the field computer to begin adjusting the valve prior to the vehicle entering the new rate zone.

Note: *The prescription Look-Ahead value only affects products controlled in reference to a prescription map.*

1. To access the prescription map look ahead value from the Viper Pro main screen, touch **Menu**, then **Setup**, **Maps**, **Rx Map**, and **Look Ahead**. The Rx Map menu is displayed.



2. Touch within the look-ahead seconds field and use the on-screen keyboard to set the desired look ahead value.
3. Touch **OK** to save the new look-ahead setting and return to the Viper Pro main screen.

Prescription (Rx) Map Colors

The rate zone colors displayed on a prescription map may be customized for different applications or to suit the equipment operator's preferences.

The screenshot shows the 'Rx Map Colors' screen. It has two columns: 'Rate Range' and 'Color'. Under 'Rate Range', there are input fields for 'Minimum', '5', '7.5', and '12.5' (which is highlighted with a red border). Below these is a 'Next Page' button. Under 'Color', there are four 'Select' buttons. To the right of these are four buttons: 'Prev', 'Next', 'Cancel', and 'OK'. At the bottom, it says 'Page 1 of 3' and there is a navigation bar with various icons.

Note: If no color template is selected by the operator, the Viper Pro will use the default colors.

Adding a Prescription (Rx) Map Color Template

1. To add or create a prescription map color template from the Viper Pro main screen, touch **Menu**, then **Setup**, **Maps**, **Rx Maps**, and **Rx Colors**. The Rx Map Colors prompt will display.

The screenshot shows the 'Rx Map Colors' screen with the prompt 'Select an Rx Map Color Template Operation'. At the bottom, there are four buttons: 'Add', 'Edit', 'Delete', and 'Cancel'. The 'Add' button is highlighted with a red border.

2. Select **Add**. The Rx Map Colors screen displays.

The screenshot shows the 'Rx Map Colors' screen with the prompt 'Enter a name for this template (up to 15 characters)'. There is an input field with the text 'Lime' inside. To the right of the input field are three buttons: 'Next', 'Cancel', and 'OK'. At the bottom, there is a navigation bar with various icons.

3. Using the on-screen keyboard, enter a name for the color template.

4. Touch **Next**. The Rate Range and Color Selection screen will display.

5. In the top field, enter the maximum rate for the lowest rate range displayed on a prescription (Rx) map. Any rate zone within the range between the minimum prescription rate and the value entered in this field will be displayed as the color selected in the following step.
6. Touch the **Select** button corresponding to the first rate range. The Rx Map Colors screen displays.

7. Select the desired rate range display color and select **OK**.
8. To add more ranges for prescription rate zone displays, repeat step 4 through 7. Rate ranges entered for each field must be higher than the previous range to complete the template creation.

Note: Make sure to enter a value for each range and select a display color. Ranges may be assigned with the same colors to create wider rate ranges for the prescription map display. The last range value entered will be the minimum rate for the highest rate range.

9. When a rate range and display color have been entered for each field, touch **OK**. The Viper Pro will display a confirmation prompt.
10. Touch **OK**. The prescription map color template will be saved.

Editing a Rx Color Template


1. Touch **Menu**, then **Setup, Maps, Rx Maps**, and **Rx Colors**. The Select Rx Map Colors Template prompt will display.
2. Select **Edit**. The Select Existing Rx Color Template screen displays.



3. Select an existing template from the list to edit and touch **OK**.
4. Use the on-screen keyboard to rename the prescription map color template. If the template is not renamed, any changes to the template will be saved over the existing prescription map template.
5. Touch **Next**. The Rx Map Colors screen displays.
6. Refer to the *Adding a Prescription (Rx) Map Color Template* section on page 150 for details on entering rate ranges and assigning rate zone colors.
7. Touch **OK** when all necessary changes have been made to the prescription map template to save the template and return to the Viper Pro main screen.

Deleting a Rx Color Template

1. Touch **Menu**, then **Setup, Maps, Rx Maps**, and **Rx Colors**. The Rx Map Colors prompt will display.
2. Select **Delete**. The Select Rx Color Template to Delete screen displays.



3. From the list of existing templates stored on the Viper Pro, select the desired template to delete and touch **OK**.
4. The Viper Pro will display a prompt to confirm that the template file will be deleted. Touch **Yes** to delete the selected template.
5. Touch **OK** to return to the Viper Pro main screen.

Local Settings

The Local settings allow the operator to set up preferences for:

- Language
- Profile Configuration
- Units Configuration
- Time Zone Configuration

Refer to the *Initial Set Up* section on page 37 for detailed information on setting up these settings and saving a machine profile. Refer to the following section for more information on the automatic power down feature.

Power Option

The automatic power down feature allows the Viper Pro to automatically close any active job file and power down the console when the vehicle ignition is switched off. This feature may be enabled to help ensure that job information is saved and the field computer is properly powered down.

Note: *The default setting for the power down feature is enabled. To monitor the vehicle ignition status, the field computer will require the appropriate wiring harness and a connection to the vehicle ignition. Without the appropriate harness, the power down feature will have no affect on operation of the Viper Pro field computer.*

1. Touch **Menu, Setup, Local** and **Power Option** to display the Automatic Power Down screen.
Select the 'Enable automatic power down' option to allow the field computer to shutdown when the ignition is switched off.
Disable this feature to keep the field computer powered on until the operator powers down the console manually. Review the *Powering Down the Viper Pro* section on page 50 for proper shut down procedures.
2. If enabled when the ignition is switched off, the field computer will display an alert to the operator and allow the operator to cancel the automatic power down. Cancel the power down to keep the field computer powered on after the ignition is switched off.

Serial Communication Port Setup

The Viper Pro features three serial communication ports which may be configured to provide communication between the field computer and various external devices. The serial ports are labeled as follows:

- GPS Comm Port
- Console Comm Port
- Auxiliary Comm Port

GPS Comm Port Setup

To use the guidance capabilities of the Viper Pro field computer, a DGPS receiver must be connected to the 9-pin serial connector labeled 'DGPS' on the main interface or chassis interface cable. The GPS Comm Port Setup screen is used to configure the Viper Pro field computer to receive GPS messages from the connected receiver.

1. To configure the GPS communication port from the Viper Pro main screen, touch **Menu**, and select **Setup, Comm Ports**. The GPS Comm Port Setup screen will display.

GPS Comm Port Setup

Baud	Data Bits	Parity
<input type="radio"/> 4800	<input checked="" type="radio"/> 8	<input type="radio"/> Odd
<input type="radio"/> 9600	<input type="radio"/> 7	<input type="radio"/> Even
<input checked="" type="radio"/> 19200	Stop Bits	<input checked="" type="radio"/> None
<input type="radio"/> 38400	<input checked="" type="radio"/> 1	
<input type="radio"/> 57600	<input type="radio"/> 2	
<input type="radio"/> 115200		

☒ Generic GPS
☐ Raven GPS

Auto Baud View Data Next Cancel OK

Communication settings must match the receiver settings exactly for proper communication between the Viper Pro and the connected DGPS receiver. The following presets are available to help configure the GPS Comm Port Setup screen:

- Generic GPS - for RPR 410, Phoenix 300 and non-Raven receivers or with an optional guidance or steering component (e.g. TM-1 Tilt Module, SmarTrax, etc.) connected between the receiver and field computer
- Raven GPS - for all other Raven receivers

2. Select the appropriate preset to begin configuration of the GPS communication port.

Note: Touch the **View Data** button to display the actual NMEA strings received by the field computer. NMEA strings will not be displayed if the GPS Comm Port Setup does not match the communication settings of the connected DGPS receiver.

3. Refer to the following sections for details on completing the GPS Comm Port Setup for the available preset settings.

Generic (Non-Raven) GPS Setup

Select the Generic GPS option to configure the Viper Pro to communicate with the following receivers:

- Raven RPR 410
- Raven Phoenix 300
- a non-Raven DGPS receiver
- if an optional guidance or steering component (e.g. TM-1 Tilt Module, SmarTrax, etc.) is connected between the receiver and field computer

Note: The DGPS receiver must be powered up and connected to the 'GPS Receiver/DGPS' connector on the Viper Pro main interface or chassis interface cable. The receiver must also output the GGA, VTG, and either the RMC or ZDA NMEA messages to communicate properly with the Viper Pro.

1. To configure the Generic GPS preset from the Viper Pro main screen, touch **Menu**, then **Setup**, and **Comm Ports**. The GPS Comm Port Setup screen displays.
2. Select the **Generic GPS** option.

GPS Comm Port Setup

Baud	Data Bits	Parity
<input type="radio"/> 4800	<input checked="" type="radio"/> 8	<input type="radio"/> Odd
<input type="radio"/> 9600	<input type="radio"/> 7	<input type="radio"/> Even
<input checked="" type="radio"/> 19200	Stop Bits	<input checked="" type="radio"/> None
<input type="radio"/> 38400	<input checked="" type="radio"/> 1	
<input type="radio"/> 57600	<input type="radio"/> 2	
<input type="radio"/> 115200		

☒ Generic GPS
☐ Raven GPS

Auto Baud View Data Next Cancel OK

3. Touch the **Auto Baud** button to allow the Viper Pro to attempt to establish communication with the DGPS receiver automatically.
 - a. If the field computer is able to receive messages from the connected receiver, touch **OK** to finish the GPS Comm Port Setup.
 - b. If no communication is established, the Viper Pro will display a 'Not Found' message. Touch **OK** and re-check the receiver and cables and repeat step 3.
If the Viper Pro is still unable to communicate with the receiver, refer to Chapter 11, *Troubleshooting the Viper Pro System*, or contact the receiver manufacturer for additional assistance.
 - c. If an optional SmarTrax or SmartSteer, automated steering system, will be used with the Viper Pro, for SmarTrax software versions:
 - 3.2 and lower, set the baud rate to 38400.
 - higher than 3.2, set the baud rate to 115200.

Raven GPS Setup

1. To automatically configure the GPS Comm Port Setup for a Raven DGPS receiver, touch **Menu**, then **Setup** and **Comm Ports**. The GPS Comm Port Setup screen displays.

GPS Comm Port Setup

Baud	Data Bits	Parity
<input type="radio"/> 4800	<input checked="" type="radio"/> 8	<input type="radio"/> Odd
<input type="radio"/> 9600	<input type="radio"/> 7	<input type="radio"/> Even
<input checked="" type="radio"/> 19200	Stop Bits	<input checked="" type="radio"/> None
<input type="radio"/> 38400	<input checked="" type="radio"/> 1	
<input type="radio"/> 57600	<input type="radio"/> 2	
<input type="radio"/> 115200		

Auto Baud View Data

☐ Generic GPS

☒ Raven GPS

Next Cancel OK

2. Select the Raven GPS preset to automatically configure the communication ports for the following receivers:

- RPR 100S
- RPR 100G
- Invicta 110
- Invicta 115
- Invicta 210
- Invicta 310
- Phoenix 50
- Phoenix 200
- Phoenix 250

Note: Make sure that the Raven receiver is properly connected and powered up before configuring it with the Viper Pro system. Viper will automatically configure the GPS comm port to the following settings:

- Baud = 19200
- Data Bits = 8 bits
- Stop Bit = 1
- Parity = None

3. Touch the **View Data** button to confirm that the Viper Pro is receiving GPS messages or touch **OK** to return to the Viper Pro main screen.

Note: If the Viper Pro is unable to receive GPS messages from the Raven receiver, refer to Chapter 11, *Troubleshooting the Viper Pro System*, or contact a local Raven dealer for assistance.

Console Comm Port Setup

The Viper Pro may be configured to log product rate data received from a separate rate control console connected to the field computer via the 9-pin serial connector labeled 'Console' on the main interface or chassis interface cable. The Console Comm Port Setup screen is used to configure the Viper Pro field computer to receive rate messages from the connected console.

1. To configure the Viper Pro to receive rate information from a separate rate control console through from the Viper Pro main screen, touch **Menu**, and select **Setup, Comm Ports**.
2. Touch **Next** on the GPS Comm Port Setup screen to display the Console Comm Port Setup screen.

Note: The Console Comm Port Setup screen will not be displayed unless a serial controller is set as the product controller. Refer to the Product Control Type section on page 38 for information on selecting a product controller.

If the Viper is connected to a CANbus system, skip to the Auxiliary Comm Port Setup section on page 158.

3. Select the following communication settings to communicate with a separate Raven control console:
 - Baud = 9600
 - Data Bits = 8
 - Parity = None
 - Stop Bits = 2
4. Touch **View Data** to view the communication strings received through the Console connection.

Note: If no data appears on the View Data screen, touch **Cancel** and re-check the serial control console and connections. Verify that the console is set up properly to communicate with the Viper Pro and then repeat step 4.

If the Viper Pro still does not display console data messages, refer to Chapter 11, Troubleshooting the Viper Pro System, or contact a local Raven dealer for assistance.

5. Touch **OK** to save the displayed communication settings and return to the Viper Pro main screen.

Auxiliary Comm Port Setup

The Auxiliary Comm Port or 'Aux' connector on the optional auxiliary interface cable may be used to connect optional serial equipment as necessary. Access the Auxiliary Comm Port Setup screen to configure the Viper Pro for communication through the auxiliary port.

Note: *The Viper Pro will automatically configure the auxiliary comm port settings for an external Raven light bar or the Spectrum Technologies® WatchDog Sprayer Station. Refer to the Light Bar Guidance section on page 159 or Appendix G, Weather Station, to configure the Viper Pro for these components.*

1. To configure the auxiliary comm port settings from the Viper Pro main screen, touch **Menu**, and select **Setup, Comm Ports**.
2. Touch **Next** until the Auxiliary Comm Port Setup screen is displayed.
3. Adjust the baud rate, data bits, stop bits and parity as described in the instructions provided with the device.

The default values for the Auxiliary Comm Port are:

- Baud Rate - 19200
- Data Bits - 8
- Stop Bits - 1
- Parity - None

Weather Module Setup

The Weather Module Setup screen is only accessible if the optional activation key has been entered on the Viper Pro.

1. To access the Weather Module Setup screen from the Viper Pro main screen, touch **Menu**, and select **Setup, Comm Ports**.
2. Touch **Next** until the Weather Module Setup screen is displayed.

Note: *For information on entering activation keys on the Viper Pro, refer to the Registering the Viper Pro section on page 27. Refer to Appendix G, Weather Station, for details on setting up the weather module.*


Light Bar Guidance

Light bar guidance features of the Viper Pro may be used to display guidance information on the Viper Pro touch screen or to send guidance information to an external Raven light bar connected to the auxiliary comm port connector on the auxiliary interface cable. The Light Bar Setup screen offers the ability to quickly configure the Viper Pro for either, or both, of these light bar guidance options.

The Viper Pro may also forward guidance information to an optional Raven SmarTrax or SmartSteer automated steering system connected to the guidance system.

Note: To use the light bar features of the field computer, a receiver capable of sending DGPS messages at a minimum of 5 Hz must be connected to the Viper Pro.

1. To configure the light bar guidance features from the Viper Pro, touch **Menu**, then **Setup, Lightbar**. The Light Bar Setup screen displays.



2. Enable the desired light bar options:

On-Screen Lightbar. Enable this option to display a light bar at the top of the Viper Pro touch screen while guidance is enabled during an active job. The on-screen light bar will be displayed regardless of which tab is active during the job.

External Lightbar. Enable this option to allow the Viper Pro to display guidance information on an external Raven light bar.

Send Guidance Message. Enable this option to send guidance messages from the Viper Pro to an optional Raven SmarTrax or SmartSteer automated steering system.

Note: If the Send Guidance Message option is selected, either the on-screen or an external light bar, or both, must be selected to properly configure the output.

Configuring the Light Bar Display

When the on-screen or external light bar options are enabled, the Viper Pro field computer may be used to configure the light bar display. These settings can help the operator set the accuracy of the light bar for different operations or display preferences.

1. To configure the light bar guidance features from the Viper Pro, touch **Menu**, then **Setup, Lightbar**.
2. Touch the **Next** button. Review the on-screen description of the LED values and enter the desired distances from the swath required to illuminate the light bar.

3. Standard light bar operation will illuminate the light bar in the direction of the guidance path from the current vehicle position. In this mode, the operator will need to steer toward the lights to get back onto the guidance path. To reverse the light bar display, select the **Reverse LEDs** option. This mode will require the operator to steer away from the illuminated lights. Select the option that best suited for the operator.

Boom and Implement Setup

The applicator boom or implement section configuration is required to set up the Viper Pro system to monitor or control product application. Refer to the *Boom or Section Cal* section on page 45 for a detailed description of the boom or implement setup procedure.

CHAPTER

8

Using AccuBoom™

The AccuBoom, automatic boom section control feature, allows the Viper Pro system to automatically control boom sections in reference to coverage or spray/no-spray zone maps. In addition, field boundaries recorded with the AccuBoom feature enabled will automatically set up a no-spray boundary around the target area to help eliminate over spray and wasted chemicals.

When enabled, the AccuBoom feature will automatically turn off an active boom section as it enters an area where product has previously been applied. As the boom section leaves the previously applied area, AccuBoom turns the boom section back on.

The following sections offer instructions on setting up and using the AccuBoom feature with the Viper Pro field computer. Contact a local Raven dealer for more information and available kits for specific machines.

FIGURE 1. CAN AccuBoom™ with Viper Pro System Example






FIGURE 2. CAN AccuBoom™ with Serial Control Console and Viper Pro System Example




AccuBoom™ Control Setup

Note: The required hardware must be purchased and installed before the AccuBoom system may be configured.

The AccuBoom Control Setup screen allows the operator to configure AccuBoom functionality. To access this screen, touch the Booms area on the main screen.



The following screen will be displayed.



The image shows a screenshot of the 'AccuBoom Control Setup' screen. It contains five input fields: 'Turn-On' Look-Ahead Sec (0.00), 'Turn-Off' Look-Ahead Sec (0.00), 'Turn-Off' % Coverage (80), Accuboom Override Sec (5.00), and Enable Zero-Speed Override (checked). To the right of the fields are three buttons: 'Next', 'Cancel', and 'OK'. At the bottom of the screen is a navigation bar with various icons including arrows and mathematical symbols.

Note: If AccuBoom will be used as a feature in a Raven CANbus system, a boom/speed node with Program 'D' or newer is required for operation. If the boom/speed node on the CANbus does not have Program 'D,' the AccuBoom tab will not be accessible and Viper Pro will display a warning message when an AccuBoom enabled job is opened.

Turn-On/Turn-Off Look-Ahead

Depending upon the type of valve installed on the machine, control valves may take several seconds to adjust when opening or closing. To help compensate for the valve's response time and lag due to product lines building or relieving pressure, the Look-Ahead values allow the Viper Pro to begin adjusting control valves for spray/no-spray zones and previously applied areas.

Turn-On Look-Ahead. Enter the number of seconds ahead of the vehicle (based on vehicle speed) which the Viper Pro will scan for zone boundaries and changes when turning product application on.

Note: The turn-on look ahead value should always be higher than the turn-off look ahead value.

Turn-Off Look-Ahead. Enter the number of seconds ahead of the vehicle (based on vehicle speed) which the Viper Pro will scan for zone boundaries and changes when turning product application off.

Note: The AccuBoom Aggressiveness Factor uses the turn-on and turn-off look-ahead values to adapt the responsiveness of the AccuBoom system for different driving styles and field conditions or layout. See the AccuBoom™ Aggressiveness Factor section on page 167 for more information on using the AccuBoom aggressiveness.

Turn-Off % Coverage

This value controls the percentage of the boom that must be inside a previously applied area in order for the boom to turn off. The default value is 80%. This would require that 80% of a boom section be in a previously applied area before AccuBoom would turn off that boom section.

Note: If the value is set to 0%, the boom will not turn off automatically.

AccuBoom™ Override Sec

The AccuBoom Override feature allows the operator to momentarily apply product to a previously applied area while in a job. This feature is useful when backing into a corner during boundary spraying, to start product application while the vehicle or implement is at a complete stop, or to apply additional product on a heavily infested area of the field.

Enter the number of seconds for AccuBoom to apply product when the AccuBoom Override is selected.

Note: The Override Sec value is not used if a SwitchPro or CAN switch box is installed on the CANbus.

Enable Zero-Speed Override

Select this option to display the AccuBoom Override button automatically when the machine speed is zero.

Configuring AccuBoom™ Control

1. Touch the **Booms** area in the main Viper screen. The AccuBoom Control Setup screen displays.
2. Using the screen keyboard, enter a value, in seconds, in the '**Turn-On**' Look-Ahead field.
3. Using the screen keyboard, enter a value, in seconds, in the '**Turn-Off**' Look-Ahead field.
4. Using the screen keyboard, enter a value, in percentage, in the '**Turn-Off**' % Coverage field.
5. Using the screen keyboard, enter a value, if desired, in seconds, in the **AccuBoom Override Sec** field.
6. Select the 'Enable Zero-Speed Override' option to display the AccuBoom Override button automatically when the machine is stopped.

Note: It is recommended to select the AccuBoom Override when accelerating from a complete stop to allow the valves time to open and tips to develop a proper spray pattern.

7. Touch the Next button to setup the boom sections which AccuBoom may control automatically.

AccuBoom™ Boom Disable

The AccuBoom Boom Disable feature allows the operator to select which booms AccuBoom will automatically control.

For example, if a machine has fence row nozzles that will be controlled manually, this feature allows the operator to disable AccuBoom control of these booms.


Zero Rate Shut Off

Zero Rate Shut Off refers to products for which an Rx Map is used. If the target rate for an area is zero for all Rx Maps, AccuBoom will shut off any controlled boom section that enters that area.

The Zero Rate Shutoff feature allows the operator to use AccuBoom to automatically turn off product control in areas of an Rx map that has zero rate zones. This is particularly useful for spreader applications. By setting the belt valve setting to PWM Close or Fast Close, AccuBoom will automatically turn off the belt when a zero rate zone is entered. In addition, for a liquid machine, AccuBoom will automatically shut off any boom section that has all Rx map products listing a zero rate zone.

Disabling Booms and Enabling Zero Rate Zone Shut Off

1. Touch the boom area on the main screen.
2. From the AccuBoom Control Setup screen, touch **Next**. The AccuBoom Control Setup screen displays.
3. Select the **Enable** option to allow AccuBoom control for selected boom sections or select the **Disable** option to disable the AccuBoom feature.
4. Un-check boom sections which should not be controlled by the AccuBoom feature.



Note: AccuBoom will only control boom sections which have a check mark. Be sure that the same sections enabled for AccuBoom Control are also selected on the Boom Select screen. See the Section Assignments section on page 120 for information on selecting boom sections.

In a granular system with spinner control, disable the node associated with the spinner to allow the spinner to run regardless of previous coverage or AccuBoom no-spray zones.


5. Check **Enable Zero Rate Shut Off** to enable this feature.
6. Touch the **Next** button to proceed to the AccuBoom Aggressiveness Factor screen.

AccuBoom™ Aggressiveness Factor

The look-ahead values set the amount of time ahead of the vehicle (based on vehicle speed) which the Viper Pro will scan for zone boundaries or unapplied areas when turning boom sections on or off. By default, AccuBoom overrides any additional zone boundaries detected until the look-ahead time has passed. For example, if the turn-on look-ahead value is set to 5 seconds and AccuBoom detects an unapplied area 5 seconds ahead of a boom section, AccuBoom toggles that section on and will ignore subsequent commands to turn that section off until the section has entered the unapplied area.

For sections at the end of larger booms or where sharp turns or aggressive maneuvering is necessary, this override may cause unexpected skips in coverage. The aggressiveness factor uses the user defined look-ahead values to adjust AccuBoom response for these driving styles and/or field areas requiring aggressive maneuvering when crossing spray zones.

The AccuBoom aggressiveness factor adds a percentage of the current turn-on or turn-off look-ahead setting to the time which AccuBoom overrides subsequent zone boundaries.



AccuBoom Aggressiveness Factor

- ☐ Off
- ☐ Low
- ☐ Med
- ☐ High
- ☐ Very High
- ☒ Maximum

To set the AccuBoom aggressiveness:

1. Touch the Boom Area on the main screen.
2. From the AccuBoom Control Setup screen, touch **Next** until the AccuBoom Aggressiveness Factor screen is displayed.
3. Select the desired aggressiveness setting to match the operator driving style or requirements.
4. Touch **OK** to accept the aggressiveness factor setting and return to the main screen.

Enabling AccuBoom™ Override

The AccuBoom Override feature allows the operator to apply product to a previously covered area during an active job. This feature is useful when backing into corners during boundary spraying, to start product application from a complete stop, or to apply additional product on a heavily infested area of the field.

Note: Use the AccuBoom Override when accelerating from a complete stop to allow the valves to open and allow the application system to develop a proper spray or spread pattern and avoid gaps in coverage.

1. While in a job, touch the boom area on the main Viper screen. The AccuBoom Control Setup screen displays.
2. Using the screen keyboard, enter a value, in seconds, in the AccuBoom Override Sec field.

Note: The value previously entered for the AccuBoom Override Seconds field will be automatically re-entered when starting new jobs or resuming a previous job file.

3. Touch the **Activate** button to override all boom sections On.
4. The main screen will re-appear with the AccuBoom Override showing in the boom area.

Note: When the field computer is interfacing with a CANbus system controlling 6 products or more, the AccuBoom Override will not be displayed on the screen.


5. AccuBoom control of all boom sections will be overridden until the time set as the Override Seconds value expires. Once the set override time has run out, AccuBoom automatic section control will resume for all boom sections selected for AccuBoom control.

AccuBoom™ Spray/No-Spray Mapping

AccuBoom can be set up to operate based on a variety of different map features that define spray and no-spray zones. The AccuBoom Setup screen allows the operator to select the desired method of operation for AccuBoom.

The following methods are available for setting up or creating an AccuBoom map:

- Standard AccuBoom
- Create AccuBoom No-Spray Map
- Load AccuBoom No-Spray Map
- Create Map from Field Boundary



Standard AccuBoom™ Method

The standard method automatically controls sections based upon previously applied or covered areas of a job. An Rx map may be used to further control the AccuBoom operation in this mode. If an Rx map is used, the extents of the Rx map define the field boundaries while zero rate zones define areas where AccuBoom automatically turns the booms off.

Note: Be sure that the 'Enable Zero Rate Shut-Off' is selected. If zero rate zones are used in multiple Rx maps, they must coincide and be the same in all maps used in the job.

Create AccuBoom™ No-Spray Map Method

This method allows the operator to define spray and no-spray zones. The spray/no-spray zones may be created while in the scouting operation or during product application. When this method is selected, a new screen prompts the operator to name the map to be created. The operator also has the option to create a boundary no-spray zone. Selecting the Create No-Spray Boundary option causes the Viper to automatically create a no-spray zone for three boom widths outside the extents of all the spray zones created.

Once the job has been started, AccuBoom will function the same as in the standard AccuBoom mode until all the zones have been defined and the spray/no-spray map is created. After the map has been created, all of the no-spray zones will be masked off. Creating Spray/No Spray maps will be explained later in this section.


Note: *If the Viper is set for 'Manual' control mode or a job is not in progress, standard AccuBoom functionality will not be available and only the scouting or AccuBoom mapping features will be available.*

Load AccuBoom™ No-Spray Map Method

This method allows the operator to load a map that has already been created. If this method is selected, touching the Next button will display a screen showing the AccuBoom maps contained in memory. The operator can then select the desired map to load. No further setup is required.

Create Map From Field Boundary Method

This method allows the operator to select an existing field boundary to use in creating a no-spray field boundary. When the Next button is selected, a new screen is displayed showing the names of the fields stored on the Viper internal memory.



The operator selects the desired field boundary to create a no-spray boundary for the field. A no-spray zone for three booms widths around the extents of the largest zone will be created based on the field boundary file.

Note: The file selected must have a completed boundary. If the file selected does not have a completed boundary, a prompt will be displayed indicating that the boundary is not complete. Select another option or another field that contains a completed boundary.

Changing Spray/No-Spray Default Colors

A set of default colors is provided for the spray and no-spray zones. The operator may change the colors used to identify spray and no-spray zones.

1. Select **Menu**.
2. Select **Setup, Maps, and Scout Maps**.

Note: The spray and no-spray labels will be grayed out and cannot be changed, but the color can be changed by the operator.

3. Touch **Color** next to the spray or no-spray feature name. The Feature Colors screen displays.
4. Touch the desired color to assign to the spray or no-spray zone and touch **OK**. Viper assigns the color to the zone and returns to the Enter Features Name and Color screen.
5. For other zones, repeat step 3 through 4.
6. Touch **OK** when to finish modifying the colors for the spray and no-spray zones. Viper saves the information and returns to the Main Screen.

Note: Select colors for the spray and no-spray zones that are different from the coverage map colors, as the coverage map will be painted over the AccuBoom map in the AccuBoom tab display.

AccuBoom™ Spray/No-Spray Maps

An AccuBoom spray/no-spray map may be created on the Viper Pro before an actual job or product application using the scouting function or the map may be created during the application. The first step in creating an AccuBoom spray/no-spray map is to define the spray and no-spray zones within a field. These zones are created in the same method as boundary fields.

Note: The spray and no-spray selections will only be available while creating a map.

How to Create a Spray/No-Spray Map

1. Start a new job.
2. Touch the **Scout** tab.
3. Select **Record**, then **Zone**. The Record Field Feature screen displays.
4. Select **Spray** or **No-Spray**.

Note: Only one zone type may be created at a time.

5. Enter the offset distance in feet [meters] from the center of the implement or boom.
6. Select the direction (left or right) to offset the zone boundary while driving the perimeter of the field feature.

Note: To record the boundary at the center of the swath width or implement, enter an offset of zero and select either left or right.

7. Touch **OK**. Viper draws the boundary line on the Scout map as the machine travels along the zone boundary.
8. To close the boundary, touch **Finish**.


Note: Spray/no-spray zones do not have the auto close feature. Touch the Finish button and select the Zone to finish at the end of the boundary.

9. To define additional spray/no-spray zones, repeat step 3 through 8 for each spray or no-spray boundary. Once a zone is created, it can be viewed on the Scout tab and on the AccuBoom tab. The AccuBoom tab will show all finished zones as well as allow the operator to create the finished AccuBoom spray/no-spray map when all zones have been defined.


Note: Any area not defined will default to a spray zone. However, if the create boundary selection has been checked, it is important to create the outer boundary of the field as a spray zone.

If an existing field boundary has been selected for use in an AccuBoom enabled job, the selected boundary will be displayed in the Map area. The operator may still define additional zones if necessary for the job.

Once all spray and no spray zones are created, select the AccuBoom tab and touch the **Create Map** button.



The spray and no-spray zones previously created will be converted to an AccuBoom spray/no-spray zone map. The previously created spray and no-spray zones will be removed from the Scout tab and will appear as an AccuBoom spray/no-spray map. This map is now available by selecting the AccuBoom tab. The zones will be colored according to their type and the default colors previously selected for spray and no-spray zones.



Note: The Create Map button will only appear when at least one zone has been defined and when there are no zones in the process of being defined.

CHAPTER

9

Using AutoBoom™

The AutoBoom feature, used in conjunction with Viper Pro, adjusts the height of booms automatically. Using the machine hydraulics, the AutoBoom parallel hydraulic system always keeps the hydraulic valves open, gently balancing the hydraulic cylinders and allowing the booms to descend or elevate effortlessly.


There are two AutoBoom systems that can be controlled by Viper Pro:

PowerGlide Plus AutoBoom utilizes gauge wheels to maintain optimum boom height while state-of-the-art hydraulics are used to maintain constant hydraulic pressure in the lift cylinders. PowerGlide Plus systems are typically used in pre-emergent applications.

UltraGlide AutoBoom uses state-of-the-art ultrasonic sensors, instead of the gauge wheels, to gauge the distance to the ground. UltraGlide systems can be used in both pre and post emergent applications.








Note: *Terrain conditions and the machine's hydraulic system will dictate the actual speeds that can be achieved. Typically, rougher and more varied field terrain require slower AutoBoom application speeds.*

'Calibration Required' will display in the AutoBoom area of the main screen when AutoBoom is initially installed.



AutoBoom™ Status Display

The current status of AutoBoom can be determined by viewing the AutoBoom area on the Viper main screen.

	AutoBoom is detected but is not calibrated. The AutoBoom system must be calibrated before operation
	AutoBoom is detected and calibrated, but currently turned off. Turn on AutoBoom to use.
	AutoBoom was detected but communication has been lost. Troubleshoot AutoBoom
	AutoBoom is detected and on, but is not enabled. Press the two A's to enable AutoBoom.
	AutoBoom is detected and in operation. No errors are detected in the operation.
	AutoBoom is detected and on but is not enabled. Alarm conditions have occurred on both booms. Troubleshoot.
	AutoBoom is detected and on and is enabled. Alarm conditions have occurred on both booms. Troubleshoot.

Note: *If a center ultrasonic sensor is installed, Ctr Ht is displayed in the AutoBoom area in place of the set height.*

Refer to the *CAN AutoBoom Calibration and Operation Manual* for detailed instructions on calibrating and operating either the UltraGlide or PowerGlide Plus AutoBoom systems with the Viper Pro field computer.

CHAPTER 10

File Maintenance and Editing Reports

Overview

File Maintenance can be defined as the process of archiving specific files from the Viper Pro and deleting files that are no longer needed. It is recommended that the user perform this maintenance at the end of each day. If this is not possible, maintenance should be performed at least once a week.

To view existing jobs, or add to field applications at a later date, all files associated with those jobs must be transferred back to the Viper Pro field computer. Be sure to backup or save files for any jobs that may need to be resumed at a later date. All files associated with the job file to be resumed must be transferred back to the field computer to resume the job.

File maintenance ensures that the Viper Pro system can perform at optimal efficiency by removing files that are no longer needed. Maintenance also safeguards valuable information from being lost in the event that a file is damaged or corrupted, since files will be archived on a personal computer or laptop for future reference.

File Maintenance

All Viper Pro job files are stored in memory located inside the Viper Pro. The storage location for these files is of a fixed size and will hold a large, but limited, number of files. Do not allow the storage memory to become too full. If the storage memory becomes too full, a Storage Memory warning displays. File maintenance should be conducted on a regular basis to ensure sufficient storage space is available for future jobs and to back up completed job information. Once the report files are saved on a home or office computer, delete the covMaps, jobs, and vnav files from the Viper Pro internal memory by using the Automatic File Maintenance or USB File Transfer features.

Files can be loaded onto the Viper Pro or downloaded from the Viper Pro using an external USB flash drive. Insert the USB flash drive into the USB connector located in the lower left hand corner of the Viper Pro.

Note: *Do not leave the USB flash drive in the front USB connector while operating the machine. Insert the USB flash drive into the front USB connector only to perform file maintenance.*

If a Slingshot Field Hub is connected to the Viper Pro, files may also be transferred wirelessly to the Slingshot web site. A user account will be required to access files transferred to the Slingshot web site on a home or office PC. Refer to Appendix H, *Wireless Communications and Remote Service*, for more information on using the wireless file transfer features.


Note: *Do not use the Automatic File Maintenance feature to create reports for a Slingshot account.*

The Automatic File Maintenance feature does not export the types to a USB flash drive necessary for creating Slingshot reports and will remove job data from the Viper Pro. Job data transferred using the Automatic File Maintenance feature cannot be reinstalled onto the field computer for export to Slingshot. Refer to the USB File Transfer and Advanced File Maintenance section on page 185 for instructions on outputting the necessary file types.


Preparing a USB Flash Drive for File Maintenance

The USB flash drive must be prepared with the necessary file folders to simplify file maintenance. To populate the thumb drive with the necessary file folders, do the following:


1. Start Viper Pro.
2. Insert a clean formatted USB flash drive into the front USB port and touch **Menu** then **File Maint.**



The following screen will display.



3. Select **Initialize External Storage**. The following screen will display.




4. Touch **OK**. The necessary file folders will be loaded onto the thumb drive.
5. Touch **OK** to return to the File Maintenance main menu.

The USB flash drive will now be populated with the necessary file folders needed by the Viper Pro.

Flash Drive File Structure

The USB flash drive will be populated with the following file folder structure.



Note: *If the USB flash drive was initialized with an older version of software, an Rbin folder may also be available. This folder would contain any Rbin files from the Viper Pro. This file is not used with newer software versions and may be deleted if desired. Verify that the Rbin folder is empty before deleting the folder.*

RDE Folder

The RDE Inbox folder contains AgX job and recommendation files for transfer between the Viper Pro and a home or office PC.

Note: *Do not remove, rename or overwrite any job files stored in the RDE folder or sub-folders. Modifying these files will cause errors with the AgX job features on the Viper Pro field computer.*

The RDE Outbox folder will contain any .jdp (job data package) files for upload to the Slingshot web service.

Viper Folder

The viper folder contains the job and miscellaneous folders which contain files used by the Viper Pro.

Jobs Folder

The jobs folder will initially be empty. This folder will contain job related information downloaded from the Viper Pro. These files contain all information associated with a specific job and may be archived on a home or office PC for future use.

Misc Folder Sub-folders

The misc folder contains job reports and files which are not job specific. Several sub-folders are contained in the misc folder to help organize this information. The following information is contained in the sub-folders.

AccuBoom Sub-folder. The AccuBoom sub-folder can be used to upload or download no-spray zone templates that have been set up for specific fields. Once these templates are transferred to the Viper Pro, they can be used when starting a new job in the selected field.

AutoBoom Alarms Sub-folder: The AutoBoom Alarms sub-folder can be used to download AutoBoom alarm information. This information will only be available on the Viper Pro if the alarm recording function is enabled in AutoBoom.

BoundaryShp. The boundaryShp folder contains any shapefiles for field boundaries created using GIS software and transferred to the Viper Pro field computer.

Note: *Field Boundaries created using the Viper Pro are saved as a part of the job file.*

Clone. The clone sub-folder will only appear on the USB drive if a clone of the Viper Pro has been created. Clones may be used as “restore points” to quickly and easily reset the Viper Pro field computer to a previous set up. A clone will contain the following files contained within the Viper Pro file structure:

- Coverage Maps
- Prescription Maps
- Streetmaps
- Scout Maps
- A-B Lines
- RAD folder containing as-applied RAD files or .jdf files
- Job files
- Report files
- Boom Configuration
- AccuBoom Configuration
- Comm Port settings

Refer to *Clone or Restore Settings* section on page 189 for instructions on creating or restoring clone files.

GuideArchive Sub-folder. The guide Archive sub-folder can be used to transfer A-B guidance lines from one machine to another.

Profiles Sub-folder. The profiles sub-folder stores previously configured machine profiles for different machine configurations.

Reports Sub-folder. The reports sub-folder contains specific job reports which the field computer generates during file maintenance. The Viper Pro creates application reports in both a shapfile format and bitmap (.bmp) files.

Shapefile reports for a job will have a .shp, .shx, .prj and .dbf file for each product applied in the job and may require specialized software to view the reports.

Bitmap reports are generated for each product applied during the job and may be viewed or printed on any computer without special software tools.


RxMaps Sub-folder. The ‘rxMaps’ sub-folder is used to transfer prescription maps to the Viper Pro. These prescription maps must be in the proper shapefile format used by the Viper Pro.

Streetmaps Sub-folder. The streetmaps sub-folder can be used to load streetmap shapefiles onto the Viper Pro. The streetmaps must be in the proper shapefile format used by the Viper Pro.

Note: *Once the streetmap files are loaded into the Viper, the streetmap must still be loaded into the Viper Pro system memory.*


Performing File Maintenance

Viper Pro provides flexible options for managing and maintaining files stored on the Viper Pro field computer.



To access the File Maintenance feature:

1. Touch **Menu** on the Viper Pro main screen.
2. Select **File Maint.** The following file maintenance options will be displayed.



Wireless File Transfer

The Wireless File Transfer button is displayed only if a Slingshot Field Hub is connected and communicating with the Viper Pro field computer. Select this option to setup the desired method for initiating file transfer via a wireless connection.

Note: *A wireless signal is required to transfer files from the Viper Pro field computer. If signal is weak or not available, files may not be transferred as expected.*

Files may also be transferred to a USB flash drive and then uploaded to the Slingshot web site from a home or office PC. Refer to the Uploading Reports to the Slingshot Web Site section on page 191 for more information.

Automatic

If the “Automatic File Upload at End of Job” option is selected, the Viper Pro will attempt to transfer application files automatically each time a job file is closed.

Prompt

If the “Prompt Before Upload at End of Job” option is enabled, the operator will be prompted to before the Viper Pro attempts to transfer files.

Disable

Select the “Disable Wireless File Transfer” to disable sending files from the Viper Pro.

Note: *If wireless file transfer is disabled, all of the job files will remain in the field computer internal memory. Periodic file maintenance will be required to remove these files to keep memory available for new job files.*

Do not use the Automatic File Maintenance feature to create reports for a Slingshot account. *The Automatic File Maintenance feature does not export the types to a USB flash drive necessary for creating Slingshot reports and will remove job data from the Viper Pro. Job data transferred using the Automatic File Maintenance feature cannot be reinstalled onto the field computer for export to Slingshot. Refer to the USB File Transfer and Advanced File Maintenance section on page 185 for instructions on outputting the necessary file types.*

Real Time Data Reporting

This feature is not supported at this time.

Job Notifications

If the field computer is registered with a Raven Slingshot account capable of receiving job notifications, the field computer may be enabled to send notifications of job events to a third party (e.g. office data management server) via the Slingshot server. These notifications may provide customized data management services or transfer between the Raven field computer and the office.

The following job events will trigger notifications to be sent from the field computer:

• Power Up	• Power Down
• Job Start	• Job End
• Pause Job	• Continue Job

Web Notifications

If the field computer is registered with a Raven Slingshot account capable of sending web notifications, the field computer may be enabled to receive web notifications from a third party (e.g. office data management server) via the Slingshot server.


Note: *Any web notification dialogues or prompts displayed by the field computer are managed by the third party. Contact the third party system administrator if any assistance is required.*

Uploading Prescription Maps from a USB Flash Drive

Prescription maps may be uploaded from the USB flash drive by selecting the USB RxMap Upload button on the File Maintenance screen.

To upload prescription maps:

1. Touch **Menu** on the main screen.
2. Select **File Maint.** from the list of menu options.
3. Select **USB RxMap Upload** from the list of file maintenance options. The following warning screen will display.



4. Touch **OK** to upload the prescription maps from the USB flash drive to the Viper Pro internal storage or **Cancel** to abort the upload process.

USB File Transfer and Advanced File Maintenance

The USB File Transfer feature allows the machine operator to select specific files to copy, move or delete from a connected USB drive or internal memory.

Note: Completed job files transferred to a USB flash drive may be uploaded to the Slingshot web site using a free user account. The web site may be used to edit and archive completed job files or to export a shapefile format of the job information for use in third party software systems. Refer to the *Uploading Reports to the Slingshot Web Site* section on page 191 for information on uploading files from a USB flash drive.

If a Slingshot Field Hub is connected to the Viper Pro field computer, files may be transferred to the Slingshot web site via the wireless connection. Refer to the Wireless File Transfer section on page 183 for details.

To perform advanced file maintenance:

1. Touch **Menu** on the main screen.
2. Select **File Maint.** from the list of menu options.
3. Select **USB File Transfer** from the list of file maintenance options. The Advanced File Maintenance screen will display.

Advanced File Maintenance		
Select file type to work with		
<input type="radio"/> Job	<input type="radio"/> Guidance	<input type="radio"/> Accuboom
<input type="radio"/> Report	<input type="radio"/> RxMap	<input type="radio"/> Profile
<input type="radio"/> Street Map	<input type="radio"/> Boundary	<input type="radio"/> All Types

Note: Touch the **Reset** button at the bottom of the Advanced File Maintenance screen to clear all selections and begin the advanced file maintenance setup again. Select the **Cancel** button to return to the File Maintenance screen.

Selecting a File Type to Work With

4. Select the type of file on which to perform file maintenance or transfer via a connected USB drive.

Advanced File Maintenance		
Select file type to work with		
<input checked="" type="radio"/> Job	<input type="radio"/> Guidance	<input type="radio"/> Accuboom
<input type="radio"/> Report	<input type="radio"/> RxMap	<input type="radio"/> Profile
<input type="radio"/> Street Map	<input type="radio"/> Boundary	<input type="radio"/> All Types

Note: To transfer a job file to another Viper Pro field computer, select the “Job” option and select “Copy” in the next step. To export files to a USB drive for use with the Slingshot web site, select the “Job” option and select “Export” in the next step.

To export a shapefile or bitmap report, select the “Report” option and then select “Copy” in the next step.

Selecting an Operation to Perform

5. Once the type of file is selected, the Select Operation to Perform selection displays. Select:
- Copy - Makes a copy of the selected file on the destination storage location. Copied file is retained on the source storage location.
 - Delete - Deletes the selected files from the source storage location.
 - Move - Move the file from the source storage location to the destination storage location. The selected file on the source storage location is deleted.
 - Export - Select the export option to transfer a job data package .zip file to the connected USB flash drive. The file will be transferred to the RDE Outbox folder and may then be transferred to the Slingshot web site via a home or office PC.

Advanced File Maintenance		
Select file type to work with		
<input checked="" type="radio"/> Job	<input type="radio"/> Guidance	<input type="radio"/> Accuboom
<input type="radio"/> Report	<input type="radio"/> RxMap	<input type="radio"/> Profile
<input type="radio"/> Street Map	<input type="radio"/> Boundary	<input type="radio"/> All Types
Select Operation to Perform		
<input type="radio"/> Copy	<input type="radio"/> Delete	<input type="radio"/> Move
<input type="radio"/> Export		

Note: The Export operation will only be available with job files.

Selecting Source/Destination

6. Select the source location of the files on which the selected operation will be performed. For the Copy and Move operations, the destination is also listed.

Advanced File Maintenance		
Select file type to work with		
<input checked="" type="radio"/> Job	<input type="radio"/> Guidance	<input type="radio"/> Accuboom
<input type="radio"/> Report	<input type="radio"/> RxMap	<input type="radio"/> Profile
<input type="radio"/> Street Map	<input type="radio"/> Boundary	<input type="radio"/> All Types
Select Operation to Perform		
<input checked="" type="radio"/> Copy	<input type="radio"/> Delete	<input type="radio"/> Move
<input type="radio"/> Export		
Select Source/Destination		
<input checked="" type="radio"/> Viper --> USB Drive	<input type="radio"/> USB Drive --> Viper	

Advanced File Maintenance		
Select file type to work with		
<input checked="" type="radio"/> Job	<input type="radio"/> Guidance	<input type="radio"/> Accuboom
<input type="radio"/> Report	<input type="radio"/> RxMap	<input type="radio"/> Profile
<input type="radio"/> Street Map	<input type="radio"/> Boundary	<input type="radio"/> All Types
Select Operation to Perform		
<input type="radio"/> Copy	<input checked="" type="radio"/> Delete	<input type="radio"/> Move
<input type="radio"/> Export		
Select Source/Destination		
<input checked="" type="radio"/> From Viper	<input type="radio"/> From USB Drive	

Selecting Associated File Actions

7. Some file types may be associated with a job file on the Viper Pro. If job files will be deleted, the operator must choose what action to perform on files associated with the job file being deleted.

Advanced File Maintenance		
Select file type to work with		
<input checked="" type="radio"/> Job	<input type="radio"/> Guidance	<input type="radio"/> Accuboom
<input type="radio"/> Report	<input type="radio"/> RxMap	<input type="radio"/> Profile
<input type="radio"/> Street Map	<input type="radio"/> Boundary	<input type="radio"/> All Types
Select Operation to Perform		
<input type="radio"/> Copy	<input checked="" type="radio"/> Delete	<input type="radio"/> Move
<input type="radio"/> Export		
Select Source/Destination		
<input checked="" type="radio"/> From Viper	<input type="radio"/> From USB Drive	
Select Associated File Actions		
<input type="radio"/> Delete Accuboom File	<input type="radio"/> Delete RxMap Files	
<input type="radio"/> Prompt	<input type="radio"/> Select All	

Note: Deleting job files is the only condition which associated file actions must be selected.

Selecting File Selection Method

8. Next, select the method to select specific files.

- By Age - Select the “by Age” option to set an age for files which the action will be performed upon. The operation will be automatically selected and copied, moved, or deleted.
- All - Select the “All” option to perform the selected operation on all files of the selected type.
- Selected - Set the “Selected” option to manually select the files to copy, move, or delete.

Advanced File Maintenance

Select file type to work with

☒ Job ☐ Guidance ☐ Accuboom
☐ Report ☐ RxMap ☐ Profile
☐ Street Map ☐ Boundary ☐ All Types

Select Operation to Perform

☐ Copy ☒ Delete ☐ Move ☐ Export

Select Source/Destination

☒ From Viper ☐ From USB Drive

Select Associated File Actions

☐ Delete Accuboom File ☐ Delete RxMap Files
☐ Prompt ☐ Select All

Selection Method

☐ Delete by Age ☐ Delete Selected
☐ Delete All

Next Reset Cancel

9. Finally, touch the **Next** button to begin the file maintenance operation.

If the “Selected” option is selected in step 8, a list of available files will be listed.

Select the Job to Delete

D:\viper\data\jobs\

JOB-09Oct01-1702.job	09Oct01 17:04
JOB-09Oct02-1620.job	09Oct02 16:59
JOB-09Oct06-0812.job	09Oct06 08:14
JOB-09Oct06-0814.job	09Oct06 09:43
JOB-09Oct09-1215.job	09Oct09 12:15

1275.10MB Available on Viper
735.53MB Available on Ext.

Delete Cancel

Operation Button

Select a file from the list and touch the operation button to perform the operation on the selected file. Touch the **Cancel** button to return to the Advanced File Maintenance screen.

Initialize External USB Flash Drive

Select the Initialize External USB Drive option and follow the on-screen instructions to setup the required file structure on a connected USB flash drive.

Automatic File Maintenance

Note: *Do not use the Automatic File Maintenance feature to create reports for a Slingshot account.*

The Automatic File Maintenance feature does not export the types to a USB flash drive necessary for creating Slingshot reports and will remove job data from the Viper Pro. Job data transferred using the Automatic File Maintenance feature cannot be reinstalled onto the field computer for export to Slingshot. Refer to the USB File Transfer and Advanced File Maintenance section on page 185 for instructions on outputting the necessary file types.


The automatic file maintenance feature will automatically perform the following steps:

1. Move all report files to the USB drive.
2. Delete all existing job files from Viper Pro internal storage.

Note: *All field boundaries, saved A-B lines, AccuBoom templates, street and prescription maps will be maintained on the internal storage.*

To perform automatic File Maintenance:

1. Touch **Menu** on the main screen.
2. Select **File Maint.** from the list of menu options.
3. Select **Automatic File Maintenance** from the list of file maintenance options. The following warning screen will display.



Touch **OK** to download the report files from the Viper Pro internal storage and delete associated job files from the Viper Pro or **Cancel** to abort the downloading of report files.

Clone or Restore Settings

The Clone or Restore Settings feature can be used to save all settings and files from the Viper Pro field computer to external memory. These clones can then be reloaded to restore settings to the same Viper Pro or transferred to another Viper Pro.

Touch the **Clone or Restore Settings** button to view the following display.

If a clone has previously been created, select the file name from the list and touch Restore Clone to restore the selected clone on the Viper Pro. To delete a clone, select the file name and touch Delete Clone to remove the selected clone.

Touch the Create Clone button to save the Viper Pro settings to the selected file. The following screen will be displayed.

Enter a name for the clone in the Clone Name field along the top of the screen. Select the "Include Job Files" option to include the current job files located on the Viper Pro internal memory with the clone. Once finished, touch the OK button to create the clone.

AgX File Maintenance

Note: The AgX File Maintenance button will not be displayed unless an AgX activation key has previously been entered on the Viper Pro. Contact a local Raven dealer for more information or to acquire an activation key.

Select the AgX File Maintenance option to transfer AgX recommendations to the Viper Pro from a connected USB flash drive or to delete recommendations currently stored on the Viper Pro field computer.

To perform AgX File Maintenance:

1. Touch **Menu** on the main screen.
2. Select **File Maint.** from the list of menu options.
3. Select **AgX File Maintenance** from the list of file maintenance options. The following warning screen will display.



4. Touch a recommendation name and the 'Delete' button to remove the selected recommendation from the Viper Pro field computer. To delete all recommendations from the Viper Pro, touch the 'Delete All' button.
5. To transfer recommendations from the USB flash drive connected to the Viper Pro, select the 'Upload Recommendations' button. The Viper Pro will look for AgX recommendations located in the RDE Inbox folder.

Note: Do not remove, rename or overwrite any files stored in the RDE Inbox folder on the USB flash drive prior to transferring files to the Viper Pro. Modifying these files will cause errors with the AgX job features on the Viper Pro field computer.

Once the files have been transferred to the field computer, the files may be deleted from the USB flash drive using a home or office PC.

Select External Drive

If more than one USB flash drive is connected to the Viper Pro at one time, the 'Select External Drive' button will be displayed on the File Maintenance screen. Touch this button to select an external drive.

Uploading Reports to the Slingshot Web Site

Completed job reports may be uploaded to the Raven Slingshot web site using a free Slingshot user account. The Slingshot web site offers tools for creating, editing and archiving job files from the Viper Pro and may also be used to export a job report in the shapefile format.

Note: *Do not use the Automatic File Maintenance feature to create reports for a Slingshot account.*

The Automatic File Maintenance feature does not export the types to a USB flash drive necessary for creating Slingshot reports and will remove job data from the Viper Pro. Job data transferred using the Automatic File Maintenance feature cannot be reinstalled onto the field computer for export to Slingshot. Refer to the USB File Transfer and Advanced File Maintenance section on page 185 for instructions on outputting the necessary file types.

File Transfer Methods

Files may be uploaded to the Slingshot web site using either of the following methods:

- Wirelessly using the Slingshot Field Hub.
- Via a computer connected to the Raven Slingshot web site.

Note: *Both transfer methods require a free user account to access the Slingshot web site.*

Job files transferred to the Raven Slingshot web site cannot be transferred back to the Viper Pro field computer to resume data logging or mapping as-applied information previously in progress. Do not delete job files from the field computer until the job has been completed.

Using the Slingshot Field Hub

If a Slingshot Field Hub is connected to the Viper Pro, completed job files may be transferred to the Raven Slingshot web site wirelessly. Refer to the *Wireless File Transfer* section on page 183 for details on setting up file transfer options.

Using a Computer

The USB File Transfer and Automatic File Maintenance features may be used to transfer completed job data packages to a USB flash drive connected to the Viper Pro field computer. Data packages may then be transferred to the Slingshot web site using a home or office computer with an internet connection to create a job report.

Refer to the *USB File Transfer and Advanced File Maintenance* section on page 185 or *Automatic File Maintenance* section on page 188 for details on transferring the information on performing these file maintenance procedures.

Note: *To create the required job data package (.jdp) file required for upload to the Raven Slingshot site, a job or report file must be exported to the USB flash drive. Refer to the USB File Transfer and Advanced File Maintenance section on page 185 for more information about using the Export action on Viper Pro job files.*

User Account Sign-up

To set up a free user account:

1. Access the Raven Slingshot web site:

www.ravenslingshot.com

Note: To request a form for multiple user accounts, send an email request to:

info@ravenslingshot.com

2. Select the desired language in the upper, left corner of the site.
3. Click on the 'Request Account' tab to the right side of the site.
4. Fill in the required information and be sure to select the 'New Slingshot User Acct.' option for the request type.
5. Select 'Submit Query' to submit the user account information. Login information will be sent to the user email address provided in the form within 24 hours of the request.

Uploading Job Reports from a USB to the Slingshot Web Site


Note: Do not use the Automatic File Maintenance feature to create reports for a Slingshot account.

The Automatic File Maintenance feature does not export the types to a USB flash drive necessary for creating Slingshot reports and will remove job data from the Viper Pro. Job data transferred using the Automatic File Maintenance feature cannot be reinstalled onto the field computer for export to Slingshot. Refer to the USB File Transfer and Advanced File Maintenance section on page 185 for instructions on outputting the necessary file types.

1. Insert the USB flash drive into a home or office PC and login to the Raven Slingshot web site at:

www.ravenslingshot.com

2. Select the desired language in the upper, left corner of the site.
3. Click on 'Log In' in the upper, right corner of the site.
4. Enter the account user name and password and select 'Sign On.'
5. Select the 'Manage' tab at the top of the screen and click 'Files.'



6. Select the “Import File” button along the top of the File Manager display and select “My Library” to browse the local computer for files to upload to the Slingshot web site.
7. Locate the job data package (.jdp.zip) file located on the connected flash drive. The Viper Pro automatically stores transfers the files to the “X:\RDE\Outbox” directory when performing USB file maintenance where “X” is the drive letter assigned by the computer to the connected flash drive.
8. Allow the Raven Slingshot site to process the file.

Note: *Review the help information on the Slingshot web site for information on performing available file operations as available.*

9. When finished working with job and report files, select the ‘logout’ option in the upper, right corner of the screen.

CHAPTER

11

Troubleshooting the Viper Pro System

This chapter contains information on troubleshooting the Viper Pro system. Please read through all sections in this chapter before contacting technical support, as many common questions are answered here.

Viper Pro Troubleshooting Information

This section contains information about possible issues and solutions for the Viper Pro system.

General Issues

Issue	Possible Cause	Solution
Viper does not power up.	<ul style="list-style-type: none">• No power to unit• Blown fuse• Poor ground	<ul style="list-style-type: none">• Check for +12VDC on pin 16 of the Viper power cable.• Check for continuity in 10 amp fuse in Viper power cable.• Make sure that pin 1 is connected to the battery ground.
CAN nodes not detected.	<ul style="list-style-type: none">• No power to CAN nodes• Weak or dirty power to the CAN nodes• Water in CAN nodes• Corrosion in CAN connections• Broken cable to node• Low power voltage	<ul style="list-style-type: none">• Verify that there is 12 volt power and ground to the CAN node's logic power• Verify that the 12 volt power to the CAN node is coming from the switch relay that is connected to the battery• Do not direct any pressure or wash stream directly at the CAN node(s) to prevent water and moisture from building up in the nodes.• Disconnect and clean the CAN connections.• Repair or replace cable.• Verify at least +10VDC at node.
Touch screen does not respond to touch	<ul style="list-style-type: none">• Area touched does not include a selectable function• System is busy processing a previous request	<ul style="list-style-type: none">• Touch an area of the screen that contains a selectable function.• Wait for system to finish processing previous requests.

Issue	Possible Cause	Solution
Red DGPS Status indicator on the Main Screen	<ul style="list-style-type: none"> • GPS cable disconnected • No power to the GPS receiver • Incorrect port setting 	<ul style="list-style-type: none"> • Check the cable between the GPS receiver and the Viper Pro. • Check power to the GPS receiver. • Make sure that the port settings on the Viper Pro and the GPS receiver are the same.
Red 'X' in product control area on the main screen	<ul style="list-style-type: none"> • Control console not turned on • No connection between the Control console and the Viper Pro • Wrong console selected • Incorrect port setting • Incorrect communications cable • Node connection issue on CAN system 	<ul style="list-style-type: none"> • Turn on the power switch on the control console. • Check the connections between the control console and the Viper Pro. • Verify the model of the console and select the correct console from the product control setup menu (Menu>Setup>Prod Control). • Make sure that the communication port settings are the same between the control console and the Viper Pro. • Use only the supplied communications cable. • See the <i>CAN Troubleshooting</i> section on page 202.
Viper does not completely power down	<ul style="list-style-type: none"> • The orange wire is connected directly to a 12V power source 	<ul style="list-style-type: none"> • Do not connect the orange wire to a source of +12VDC.
Vehicle battery discharges overnight	<ul style="list-style-type: none"> • CAN nodes are wired directly to the battery 	<ul style="list-style-type: none"> • Wire the CAN nodes through a relay or switched power source.

Setup Issues

Issue	Possible Cause	Solution
Previous settings have been lost	<ul style="list-style-type: none"> • Settings data deleted from memory • Poor CAN connections 	<ul style="list-style-type: none"> • Review Chapter 10, <i>File Maintenance and Editing Reports</i>, and Appendix B, <i>Understanding Viper Pro Files</i>, for data information. • See the <i>CAN Troubleshooting</i> section on page 202.
Profile displays as default	<ul style="list-style-type: none"> • No profile loaded into Viper 	<ul style="list-style-type: none"> • Create a profile and load it into Viper. Refer to the <i>Profiles</i> section on page 49 for additional assistance with creating profiles.

Issue	Possible Cause	Solution
Streetmaps will not load	<ul style="list-style-type: none"> • The streetmaps files are not located in the streetmaps folder • Streetmaps are located in a sub-folder in the Streetmaps folder • Streetmaps are not in the correct format • Too many streetmaps files in the Streetmaps folder 	<ul style="list-style-type: none"> • Move the streetmaps files to the Streetmaps folder on the disk. • Move the streetmaps to the Streetmaps root folder. • Save the streetmap files in the shapefile format. • Limit the number of county streetmap files in the Streetmap folder.

Job Issues

Issue	Possible Cause	Solution
Boom numbers are gray	<ul style="list-style-type: none"> • Boom switches are turned off • AccuBoom enabled but machine not moving • CAN is disconnected 	<ul style="list-style-type: none"> • Turn boom and master switch on. • Move the machine out of the applied zone. • See the <i>CAN Troubleshooting</i> section on page 202.
Boom number does not turn green when turned on	<ul style="list-style-type: none"> • The boom is not set up properly • Nodes not completely programmed • The boom is disconnected 	<ul style="list-style-type: none"> • Check the boom setup from the Setup menu. • Check node calibration and ensure all calibration is completed. • Check the connection and wiring to the boom.
Serial Console AccuBoom controlled boom sections will not turn off	<ul style="list-style-type: none"> • Boom switches on console are in the 'On' position 	<ul style="list-style-type: none"> • Boom switches for parallel AccuBoom systems must be in the 'Off' position.
CAN System AccuBoom will not turn on	<ul style="list-style-type: none"> • Boom switches are in the 'Off' position 	<ul style="list-style-type: none"> • Boom switches for CAN AccuBoom must be in the 'On' position.
Product function keys do not work	<ul style="list-style-type: none"> • Not a CAN system • Product application is turned off 	<ul style="list-style-type: none"> • Product function keys work only in a CAN system. • Switch product application to either auto or manual mode.
Dates and time are incorrect	<ul style="list-style-type: none"> • No GPS • No GPS RMC or ZDA • Incorrect time zone selected 	<ul style="list-style-type: none"> • Make sure that the GPS receiver is operating properly and that there is a green 'thumbs-up' icon displayed in the GPS section of the main screen. • Check the GPS receiver to make sure the RMC or ZDA string is selected. • Verify the time zone selected in the Menu/Setup/Local/Time Zone section.

Issue	Possible Cause	Solution
Product spread in zero rate zones	<ul style="list-style-type: none"> • Bed creep • Wrong valve type on vehicle • Incorrect valve setting 	<ul style="list-style-type: none"> • Adjust hydraulic valve to stop the bed creep. • Must use either a Fast Close or PWM Close valve. • Check valve or PWM setting.
Rate sensor failure alarm activated when enabling a product in automatic control mode	<ul style="list-style-type: none"> • Min PW value too low 	<ul style="list-style-type: none"> • Refer to the <i>PWM Control Valve Tuning</i> section on page 226 for information on using the PWM calibration assistance or automatic calibration features and properly adjust the Min PW value for the control system.

Rx Map Issues

Issue	Possible Cause	Solution
Only one prescription map loads	<ul style="list-style-type: none"> • A multi-product VRA registration is not available 	<ul style="list-style-type: none"> • Purchase a multi-product registration from a local Raven dealer.
The prescription map does not display properly	<ul style="list-style-type: none"> • Wrong datum type 	<ul style="list-style-type: none"> • Use WGS-84 decimal degrees when creating an Rx map.

Coverage Map Issues

Issue	Possible Cause	Solution
Gaps displayed in coverage map	<ul style="list-style-type: none"> • Section widths not set correctly • Guidance and total section width not the same 	<ul style="list-style-type: none"> • Check section widths and center values. • Set guidance width and total section width to the same value.
Product coverage displayed in zero rate zones	<ul style="list-style-type: none"> • Vibration chatter in encoder • Valve or motor is not set to close completely 	<ul style="list-style-type: none"> • Make sure that the encoder is firmly mounted. Increase value in "Zero Rate Tolerance." • Adjust valve or motor to close or stop completely with no rate applied.
Cannot achieve target rate	<ul style="list-style-type: none"> • Driving too fast for vehicle • Calibration numbers incorrect • Speed calibration incorrect 	<ul style="list-style-type: none"> • Speed may exceed capabilities of vehicle to deliver product. Slow down the vehicle or configure the vehicle to supply a higher amount of product. • Check and adjust meter calibration, density, and other calibration numbers. • Check and adjust speed calibration setting.

Error Messages

The following table provides issues and solutions about error messages displayed on the Viper system.

General Error Messages

Issue	Possible Cause	Solution
The Activation key is not valid	<ul style="list-style-type: none"> Incorrect Activation key entered 	<ul style="list-style-type: none"> Re-enter the Activation key. If this still does not work, contact a local Raven representative.
Scout file error	<ul style="list-style-type: none"> Scout file for one of the jobs is missing File is an older version and not compatible with the current software release 	<ul style="list-style-type: none"> Touch OK to bypass. Touch OK to bypass.
JobMap error	<ul style="list-style-type: none"> Scout file for job is missing 	<ul style="list-style-type: none"> Touch OK to bypass and create a scout file for the current job.

Setup Error Messages

Issue	Possible Cause	Solution
Sections must be specified in left-to-right order	<ul style="list-style-type: none"> Sections are not configured sequentially in a left-to-right order 	<ul style="list-style-type: none"> Configure the sections in a left-to-right order. See the <i>Boom and Implement Setup</i> section on page 160 for more information on configuring sections.
There is a gap or overlap between sections	<ul style="list-style-type: none"> Improper values entered into either section widths and/or the left/right values for individual sections. 	<ul style="list-style-type: none"> Check the section setup values entered for Left/Right, and check the sections set up for this product. Set up sections sequentially from left-to-right. Left/Right value is measured from center of section.
	<ul style="list-style-type: none"> Section select functions not properly configured. 	<ul style="list-style-type: none"> Section select must specify individual sections for individual products if a gap or overlap is detected.
Missing Scout File	<ul style="list-style-type: none"> Scout files have been deleted from the scout folder but other folders contain files associated with the job. 	<ul style="list-style-type: none"> Delete all files with the same name from all the other folders on the flash drive if the specified job name is not necessary for the job in progress. Use the File Maintenance function to delete the remaining files. Make sure to keep a backup on a home or office PC if the job will be needed at a later date.
Rx Colors error. "You must enter a name for this template"	<ul style="list-style-type: none"> The custom RxMap Colors was selected but no name was given to the template 	<ul style="list-style-type: none"> Enter a name for the custom Rx Color template.
RxColor error. "You must pick a color for entry Minimum"	<ul style="list-style-type: none"> There is no color selected for the range 	<ul style="list-style-type: none"> Touch Select and select a color for the minimum level.
Could not grow buffer	<ul style="list-style-type: none"> Streetmaps that are being installed are too large for the Viper system memory 	<ul style="list-style-type: none"> Limit streetmaps to four counties or less, depending upon the file size. More densely populated counties have a larger file size than sparsely populated counties.



Job Error Messages

Issue	Possible Cause	Solution
Open New Job error	<ul style="list-style-type: none"> For non-VRC (Variable Rate Control) jobs, DGPS coverage must be available before starting the job 	<ul style="list-style-type: none"> Check for GPS signal.
No GPS Coverage Warning: You must have GPS coverage if you start a non-VRC job.	<ul style="list-style-type: none"> Displays when starting a job without a GPS signal 	<ul style="list-style-type: none"> Check for GPS Signal.
Missing Product Information: No Product Name Entered	<ul style="list-style-type: none"> No product name entered 	<ul style="list-style-type: none"> Enter a least one character for a product name.
Job is opened in View mode only.	<ul style="list-style-type: none"> Existing job was started in View mode only. No changes can be saved. 	<ul style="list-style-type: none"> Close the job and restart in 'Add to Job' mode.
You must set up the section information in the Setup menu	<ul style="list-style-type: none"> When starting a job, this message displays if the sections have not been setup 	<ul style="list-style-type: none"> Configure the section information in the Setup menu.
You have not set up all of the products for this job	<ul style="list-style-type: none"> Information for all of the products has not been entered during the job setup process. 	<ul style="list-style-type: none"> Make sure that all products have an assigned product name.
You must select at least 1 section for this product	<ul style="list-style-type: none"> Every product in the system must have at least one section assigned to it. 	<ul style="list-style-type: none"> Using the Boom Select option, check at least one section for the product.
The Section Settings for this job do not match your current section setup. Cannot add to this job.	<ul style="list-style-type: none"> When adding to an existing job, all section settings must match exactly the section configuration when the job was originally started. 	<ul style="list-style-type: none"> Re-configure the section setup to match the configuration when the job was originally started.

Variable Rate Control (VRC) Error Messages

Issue	Possible Cause	Solution
Browse Rx Files	<ul style="list-style-type: none"> VRC must be selected in order to enter prescription information 	<ul style="list-style-type: none"> Select VRC in the Product Setup screen.
VRC must be selected in order to enter prescription information	<ul style="list-style-type: none"> VRC was not selected during the product setup 	<ul style="list-style-type: none"> Select VRC in the Product Setup screen.
No VRC Products	<ul style="list-style-type: none"> There are no more selections to make 	<ul style="list-style-type: none"> Touch OK to start the job.

Issue	Possible Cause	Solution
No Rx file chosen for this product	<ul style="list-style-type: none"> • VRC was selected for the product during the product setup, but no Rx map was loaded 	<ul style="list-style-type: none"> • Un-select the VRC selection or load an Rx map for the product.
No Rx rate field chosen for product	<ul style="list-style-type: none"> • VRC was selected and an Rx map was loaded, but a selection was not made in the Rate field 	<ul style="list-style-type: none"> • Select the appropriate item from the Rate field.
When VRC is checked, a Prescription File and Rate Field must be supplied	<ul style="list-style-type: none"> • VRC was selected during the product setup, but a prescription map and rate field have not been selected 	<ul style="list-style-type: none"> • Touch Browse to select the appropriate prescription file. Select the appropriate rate item in the Rate field.
Color templates are available only when VRC is selected	<ul style="list-style-type: none"> • Color template selected without selecting VRC 	<ul style="list-style-type: none"> • A color template must be selected after VRC is selected and the prescription map is loaded.

GPS Error Messages

Issue	Possible Cause	Solution
No GPS Coverage warning	<ul style="list-style-type: none"> • DGPS must be available to start a VRC (Variable Rate Control) or guidance job 	<ul style="list-style-type: none"> • Make sure that the GPS data is being received by the Viper system.
Warning: You do not have optimum GPS coverage. Some features may be disabled.	<ul style="list-style-type: none"> • GPS reception does not have differential correction. Therefore, some features, such as guidance, will not be available when starting a job in this condition 	<ul style="list-style-type: none"> • Enable the differential correction function in the GPS receiver. Contact the receiver manufacturer for additional information.
No Differential	<ul style="list-style-type: none"> • Differential GPS has not been detected by Viper 	<ul style="list-style-type: none"> • Check the GPS receiver to make sure that it has the differential correction function. Contact the manufacturer for additional information.
No GPS	<ul style="list-style-type: none"> • Viper does not detect a GPS signal 	<ul style="list-style-type: none"> • Make sure that the GPS receiver is turned on and receiving a signal. • Make sure that the port setting for Viper and the GPS receiver match. • Make sure that the required NMEA messages are turned on in the GPS receiver.

CAN Troubleshooting

Although the control algorithm is located within the CAN node, all of the same troubleshooting techniques used in a traditional hard-wired system still apply to a CAN system. CAN allows for modularization of the control system, but the behavior of the system remains the same. Flow and speed sensors, as well as the control valve and section valves, are used in the same fashion.

Below are some common causes for communication failures:

Issue	Possible Cause	Solution
CANbus cannot read the product node	<ul style="list-style-type: none"> The node is not connected to the CANbus 	<ul style="list-style-type: none"> Connect the node and re-initialize the Viper Pro to read the product node.
Node is not properly powered	<ul style="list-style-type: none"> Check and reconnect the power 	<ul style="list-style-type: none"> Connect the Clean Power - 16 gauge red wire and High Current Power - 12 gauge red wire from the product node to a 12VDC power source that is capable of supplying power to all nodes connected to the CANbus system
Node is not properly grounded	<ul style="list-style-type: none"> Check and ground the node 	<ul style="list-style-type: none"> Connect the Clean Ground - 16 gauge white wire and the High Current Ground - 12 gauge white wire to a good, quality ground source. Raven recommends grounding the wires to the negative terminal of the battery.
The Boom/Speed node share power and ground connections	<ul style="list-style-type: none"> Distribute power and ground 	<ul style="list-style-type: none"> Make sure that each node has a separate power and ground connection.
CANbus ends not terminated	<ul style="list-style-type: none"> Terminate CANbus ends 	<ul style="list-style-type: none"> Make sure that both ends of the CANbus system are properly terminated. See Chapter 3, <i>Installation, Start Up and Registration</i>, for more information.

APPENDIX

A

System Diagrams

The following diagrams may be helpful for installing or troubleshooting the Viper Pro field computer or product control system. The following diagrams may show optional features or components not required for operation and will not apply to all systems if the required hardware has not been installed.

Contact a local Raven dealer for purchasing or more information on components shown in the following diagrams.

Additional system diagrams are available (free of charge) from the Raven Industries web site:


www.ravenhelp.com

Note: *Refer to the Generation 2 Cable Connections section on page 19 for an example of a generation 2 cabled system.*

Viper Pro Serial Console Connection (Optional)

1. Connect one end of the Raven RS-232 cable to the connector labeled “Console” on the end of the Viper interface cable.
2. Connect the other end to the serial port connector on the back of the Raven SCS console.

FIGURE 1. Serial Control Console Connection to Viper Pro with Phoenix 200 Example



Note: Use only a Raven RS-232 communication cable between the Viper system and the SCS console. This cable is available as listed below. Contact a local Raven dealer for purchasing and more information.

Part	Part Number
RS-232 cable - 3 ft. [0.9 m]	115-0171-040
RS-232 cable - 10 ft. [3 m]	115-0159-822

Viper Pro with External Light Bar

Connect the light bar to the COM3 port on the Viper Pro Auxiliary Interface cable. Refer to the following figure and follow the light bar installation instructions.

FIGURE 2. RGL 600/600ic External Light Bar Connection Options




FIGURE 3. Viper Pro with Phoenix 200, RGL 600, SmarTrax™ and TM-1 Tilt Sensor




FIGURE 4. Phoenix 300 DGPS Receiver and Antenna with Viper Pro System Example






FIGURE 5. Phoenix 200 DGPS Smart Antenna with Viper Pro System Example




Viper Pro with SmarTrax

FIGURE 6. Viper Pro with CAN SmarTrax (3D) and Phoenix 300



Viper Pro CANbus Diagrams

FIGURE 7. Viper Pro Single Product (Liquid) CAN Control System



Manual No. 016-0171-152 Rev. G



FIGURE 9. Viper Pro with Dual Product (Granular) and Spinner Control and Phoenix 200




FIGURE 10. Viper Pro CAN Single Product (Granular) Product Control





FIGURE 11. Viper Pro with CAN Product (Liquid) Control and AccuBoom



APPENDIX

B

Calculating the Calibration Values

Speed Cal

Raven Industries recommends the following values for the initial speed cal:

Sensor Type	Used with	English	Metric
Radar/GPS	External Raven GPS Receiver	785	199
	GPS Speed over CANbus	1000	254
	Raven Radar	598	152
Wheel	Wheel Magnets	1000	254
	Speedometer Drive Speed Sensor	612	155

These values are usually a good starting point and will generally yield adequate results; however, the speed cal should still be refined for each vehicle.

Note: *The GPS speed over CANbus feature is only available with specific Raven speed sense nodes. This feature utilizes NMEA speed over ground data transmitted over the CAN network which eliminates the need for a separate, external speed sensor.*



NOTICE

When using the GPS speed over CANbus feature, no refining or adjustment is necessary or recommended to the speed cal value. Losing GPS signal for more than a second will also result in loss of the CAN speed signal which may affect product application in progress.

Using the Calibration Assistance

1. Make sure any section switches are turned OFF before powering the field computer on.
2. Touch within the **Product Control** area on the main screen.
3. Touch within the **Miscellaneous Settings** area on the CAN Controller Status screen. The Miscellaneous Settings screen will display.

Miscellaneous Settings

Speed Sensor ☒ Radar ☐ Wheel

Speed Cal

Calibration Assistance

Self Test

AccuBm Node ☐ Combo ☒ AccuBm Only

Audible Alarm ☐ Off ☒ On

Enable Injection Flush ☒

Boom Capacity ☒ Off ☐ On

Max Capacity **Default**

4. Touch the **Calibration Assistance** button on the Miscellaneous Settings screen. The Speed Calibration screen will appear.

Speed Calibration

To begin the calibration procedure:

1. Mark off a known distance to drive.
2. Enter the marked off test distance.

Test Distance: Feet

3. Drive to the starting point.

Next

Cancel

5. Mark off the physical distance to be driven for the test.
6. Enter a measured test distance, in feet [meters], in the **Test Distance** box.

Note: A distance of at least 500 feet [152 meters] should be used for this test. A shorter distance may give less accurate results.

7. Touch **Next**.
8. Begin driving the machine toward the test distance starting point at normal speed. When the beginning of the test distance is reached, touch the **Begin Cal Run** button. ****Calibrating**** will begin flashing on-screen.

Speed Calibration

To calibrate the speed:

1. Press the Begin Cal Run button.

Begin Cal Run

2. Drive to the second marked point, increasing and decreasing speed gradually.

Prev

3. Press the End Cal Run button.

End Cal Run

Cancel

9. Drive the test distance.

Speed Calibration

To calibrate the speed:

1. Press the Begin Cal Run button.

Begin Cal Run

2. Drive to the second marked point, increasing and decreasing speed gradually.

Prev

3. Press the End Cal Run button.

End Cal Run

**** Calibrating ****

Cancel

10. At the end of the measured test distance, touch the **End Cal Run** button. The new speed cal value will be calculated automatically.

Speed Calibration

To calibrate the speed:

Speed Calibration Complete

The speed calibration procedure has ended:

Test Distance: 500
Actual Distance: 410

Current Speed Cal: 1000
New Speed Cal: 1216

Apply the new Speed Cal?

Yes **No**

11. Touch **Yes** and the new speed cal will be applied.

Note: Touch **No** to discard the calculated speed cal and continue using the existing value.

Verification of the Speed Cal Value

The following procedure may be used to verify the speed cal currently entered on the field computer.

1. Make sure any section switches are turned OFF before powering the field computer ON.
2. Touch the **Product Control** area at the bottom of the main screen to display the CAN Controller Status screen.
3. Touch the **Tally Registers** button at the bottom of the screen.

Rate +/- 2.0	Pump Cal 0	PVVM 0
Meter Cal 700.0	Min Pw 0	
	Max Pw 253	
Pressure 1 71	Application Liquid	
Pressure 2 61	AIM	
Tally Registers		OK

4. Touch the **Reset** button next to the Distance display on the Tally Registers screen.

Tally Registers

Node	Ttl Vol	Field Volume	Tnk Vol	Ttl Area	Fld Area
1	0.0	0.0	0.0	0.0	0.0
2	0.0	0.0	0.0	0.0	0.0
3	0.0	0.0	0.0	0.0	0.0
4	0.0	0.0	0.0	0.0	0.0
5	0.0	0.0	0.0	0.0	0.0

Distance 0 Miles
2250 Feet

5. Drive a known distance:
 - a. Re-run the same test distance driven during the **Calibration Assistance** procedure.
 - b. Drive a test distance of 1 mile [1 km].

Note: *Accelerate and decelerate slowly. To achieve the most accurate calibration, do **not** use the vehicle odometer or the field computer distance display to measure the actual distance driven.*

6. Record the distance from the field computer Tally Registers screen.
If the distance display on the Tally Registers screen matches the measured test distance, the calculated speed cal is correct. If the distance display does not match, repeat the *Using the Calibration Assistance* section on page 216 to recalculate the speed cal automatically or use the *Speed Cal Formulas* section on page 218 to manually calculate the speed cal value.

Note: *If a test distance of one mile [1 km] is used, the distance value displayed on the Tally Registers screen should be 5280 feet [1000]. If the value displayed in the Feet [Meters] field is between 5260 [980] and 5300 [1020], the current speed cal value is correct.*

Speed Cal Formulas

Perform the following calculation to determine the speed calibration

$$\frac{OSC \times 5280}{D} = CSC$$

where OSC = the Old Speed Cal value, D = the Viper Pro odometer reading, and CSC = the Corrected Speed Cal.

For Example:

Using the default Speed Cal of 598 [152], and a Viper Pro odometer reading of 5000 feet [980 meters]:
in English Units:

$$\frac{598 \times 5280}{5000} = 631$$

the Corrected Speed Cal is 631.

in Metric units:

$$\frac{152 \times 1000}{980} = 155$$


Therefore, the Corrected Speed Cal is 155.

7. Enter the corrected speed cal of 631 [155].
8. Confirm that the new Speed Cal is correct by repeating the procedure in the *Verification of the Speed Cal Value* section on page 217.

Wheel Drive Speed Sensor

1. Mark the tire on which the speed sensor is installed using chalk or a piece of tape as shown below.
2. Mark the corresponding spot on the ground.
3. Count 10 full revolutions of the wheel while traveling in a straight path. The mark must stop with the chalk or tape in the same orientation that it began at the starting point.

FIGURE 1. Calculating the Speed Cal with a Wheel Magnet Speed Sensor System



4. Mark the stopping point and measure the distance between the starting and stopping marks on the ground in inches [dm]. Round to the nearest whole number.

Note: This measurement is critical to the performance of the Viper Pro. **Measure Carefully.** Be sure tire is properly inflated before measuring. If possible, measurements should be made in the type of soil in which the vehicle will be operating. Tire circumference will vary when measured in soft or hard packed soil. For best results, measure several times and average the results.

5. Enter this measurement as the new speed cal.

Adjusting for Additional Magnets

Typically, four magnets are used with the wheel drive speed sensor. However, to ensure accurate speed readings for large tires and very low speed applications, additional wheel magnets may be necessary. Any even number of magnets may be used as long as they are of alternating color and equally spaced. After calculating the speed cal, this number must be adjusted according to the number of magnets installed using the following formula:

$$\frac{4}{NM} \times D = ADJ$$

where ADJ = Adjusted Speed Cal, NM = Number of Magnets used and D = the Distance Measured.

For Example:

The distance measured between starting and stopping marks is 1200 and six magnets are installed.

$$\frac{4}{6} \times 1200 = 800$$

The Adjusted Speed Cal is 800.

Boom Cal or Section Width Calibration

Use the following formulas to calculate the section width(s) of a boom or implement. The section width is used by application control systems to adjust product rates for active sections during application.

Calculate the boom section width with the formula:

$$T \times S = SW$$

where T = the number of Tips in each boom section, S = the spacing between tips, and SW = the Section Width.

For Example:

20 tips in a section with spacing of 40 inches [101.6 cm] would yield:

$$BSW = 20 \times 40[101.6] = 800[2032]$$

or a Section Width of 800 inches [2032 cm] (approximately 67 feet [20.32 m]). Enter 800 [2032] as the boom width for this section.

Band Spraying Adjustment

The standard application rate must be adjusted when utilizing a system set up to apply product in bands across the boom width. Refer to *Band Spraying Rate Adjustment* section on page 234 for assistance calculating the rate adjustment required for the sprayer configuration.

Boom or Section Mapping

The boom mapping feature allows the operator configure the field computer for the actual boom sense wire connections or customize the character representing each boom or implement section.

Map Booms To Wiring Setup

Viper Boom	Wired As	Display Character
1	<input type="text" value="1"/>	<input type="text" value="L"/>
2	<input type="text" value="2"/>	<input type="text" value="1"/>
3	<input type="text" value="3"/>	<input type="text" value="2"/>
4	<input type="text" value="4"/>	<input type="text" value="3"/>
5	<input type="text" value="5"/>	<input type="text" value="R"/>

Cancel

OK

Navigation icons: back, forward, search, etc.

Mapping the Booms

1. From the Viper Pro main screen, touch **Menu**, and **Setup, Boom**.
2. Touch **Next** until the Boom Setup Summary screen is displayed.
3. Select the **Map Booms** button. The Map Booms to Wiring Setup screen will display.

Viper Boom	Wired As	Display Character
1	1	L
2	2	1
3	3	2
4	4	3
5	5	R

The 'Viper Boom' column displays the number of the boom sense sections configured for the current configuration. These numbers correspond to the section values displayed from left-to-right on the Viper Pro main screen.

Note: Touch the **Next** button if necessary to display 'Wired As' and 'Display Character' settings for sections 6 through 10.

4. Use the 'Wired As' column to set the actual boom sense wired connection for each configured section.

Note: Raven boom sense wires are color coded as follows:

Section Number	Lead Wire Color	Section Number	Lead Wire Color
1.	Black	9.	White/Blue
2.	Brown	10.	Pink
3.	Blue	11.	Yellow/White
4.	Black/White	12.	Green/White
5.	Brown/White	13.	Red/White
6.	Blue/White	14.	White/Yellow
7.	White/Black	15.	White/Green
8.	White/Brown	16.	White/Red

*Viper will not allow 'Wired As' sections to be skipped. For example, if the value entered as the **Number of Boom Sections** setting is set to 3, 'Wired As' must be 1, 2, and 3 in any order. These three sections cannot be 'Wired As' 1, 2, and 4. To skip a boom section, a boom must be configured with '0' width.*

17. Use the 'Display Character' column to customize the "Booms" display on the Viper Pro main screen. For example, the display character for section 1 may be set to L to signify that section 1 is the left fence row.

Note: Use only the characters 0, 1, 2, 3, 4, 5, 6, 7, 8, 9, D, E, L, R, and * to label the booms. It is recommended to use * for skipped booms.

18. The following table is an example of a possible boom mapping configuration.

TABLE 1. Boom Mapping Example

Logical	Wired As	Display Character
1	1	L
2	2	1
3	3	2
4	4	3
5	5	4
6	6	5
7	9	R
8	8	*
9	7	*

19. Touch **OK** to return to the Boom Setup Summary screen. Touch **OK** to save the displayed section settings and return to the Viper Pro main screen or proceed to the

Advanced Section Setup

The standard boom setup covered in the *Boom or Section Cal* section on page 45 is sufficient for a standard boom configuration with the sections end-to-end with no overlap or skips.

The advanced section settings allow the operator to customize boom or implement sections individually to reflect specialized configurations with overlaps, skips or offset sections.

1. Select **Menu**, then **Setup**, and **Boom**.
2. Touch **Next** until the Boom Setup Summary screen is displayed.

Boom Setup Summary
Touch a Boom Section or Summary Entry for Advanced Settings

GPS Antenna

1 2 3 4 5

Boom System Center
Overall Width: 1060.0 Left/Right: 0.0 Fore/Aft: -120.0

Boom Section Summary

Boom	Width	Left Right	Fore Aft	Wired As	Display Character
1	140.0	-460.0	-120.0	1	1
2	240.0	-270.0	-120.0	2	2
3	320.0	10.0	-120.0	3	3
4	240.0	290.0	-120.0	4	4
5	120.0	470.0	-120.0	5	5

Prev
Map Booms
Cancel
OK

- Touch a boom section displayed in the section configuration overview or select the section summary entry at the bottom of the screen to access additional section settings. The Boom Section Settings screen for the selected section will display.

Boom Section 3 Settings

Section Width

Enter the location of the midpoint of this boom section with respect to the GPS antenna.

Left and Aft are indicated by negative values (use the minus sign).

Left/Right

Fore/Aft

Measurements Are Inches

- The **Section Width** for the section is displayed at the top of the screen. Touch the displayed value and use the on-screen keypad to enter a new section width value if necessary.
- Touch the **Left/Right** offset value and use the on-screen keypad to enter the distance of the section midpoint from the GPS antenna. If the section is offset to the left of the GPS antenna, enter a negative value for the Left/Right offset value.

Note: The left/right offset must be measured parallel to the boom or implement width. Select the **More Info** button to display an overview of the offset measurements and directions.

- Touch the **Fore/Aft** offset value and use the on-screen keypad to enter the distance of the section midpoint from the GPS antenna. If the section is behind the GPS antenna, enter a negative value for the Fore/Aft offset value.
- Touch **Next** to advance to the next boom or implement section to the right or **Prev** to go back to the previous section to the left.
- Once the width and offset values are entered correctly for each boom or implement section, touch the **OK** button to return to the Boom Setup Summary screen.

Boom Setup Summary

Touch a Boom Section or Summary Entry for Advanced Settings

GPS Antenna

1 2 3 4 5

Boom System Center

Overall Width: 1060.0 Left/Right: 0.0 Fore/Aft: -150.0

Boom Section Summary

Boom	Width	Left Right	Fore Aft	Wired As	Display Character
1	140.0	-460.0	-120.0	1	1
2	240.0	-270.0	-120.0	2	2
3	320.0	10.0	-180.0	3	3
4	240.0	290.0	-120.0	4	4
5	120.0	470.0	-120.0	5	5

- Verify that the section configuration overview represents the actual application equipment or implement configuration.
- Touch **OK** to save the section settings and return to the Viper Pro main screen.


Valve Cal

To ensure that the proper amount of product is being applied, the valve cal must be programmed for the type of control valve(s) connected to the control system. The field computer uses the valve calibration number to adjust the response time of the control valve motor to changes in the vehicle speed.

The following control valve calibration numbers are recommended for the valves listed:

Control Valve Type	Valve Cal
AIM Command	63
Fast (C-F) or Fast Close (C-FC)	743
PWM (C-P) or PWM Close (C-PC)	43

Each digit in the calibration number corresponds to a specific function of the valve. The following functions apply to the digits in the valve calibration number:



Valve Backlash Digit

This value controls the time of the first correction pulse after detecting a change in correction direction. The values range from 1 to 9, where 1 is for a short pulse and 9 is for a long pulse.

Note: The backlash digit is not used with a fast, fast close, PWM, PWM close or standard motor control valve.

Valve Speed Digit

This value controls the response time of the control valve motor. If the valve speed setting is too fast, the valve will over correct and the system can start to oscillate. The following valves have specific values:

- Standard Control Valve: This valve has a range of values from 1 to 9, with 1 being slow and 9 being fast.
- Fast and Fast Close Control Valve: These valves have a range of values from 0 to 9, with 0 for fast and 9 for slow.

Note: The speed digit is not used with a PWM or PWM close valve.

Brake Point Digit

The Brake Point digit sets the percent away from the target rate at which the control valve starts to turn at a slower rate so that it does not overshoot the target rate. The values range from 0 to 9, where 0 is a 5% rate, 1 is a 10% rate and 9 is a 90% rate.

Dead Band Digit

The Dead Band digit is the allowable difference between the target rate and the actual application rate. The values range from 1 to 9, where 1 equals 1% difference and 9 equals 9% of the difference.

Flow Cal (Dual Loop Control Mode)

The flow cal value has two components which may be used to adjust the response of the application system.



Note: *It is recommended to set the Sgain value prior to making any adjustments to the flow cal value.*

Flow System Gain. The first digit(s) of the flow cal correspond to a flow system gain between 1 and 99. The higher the flow system gain, the more aggressive the system will respond to changes in flow rate.

Note: *When entering a flow gain value from 1 to 9, it is not necessary to enter a zero in front of the value.*

If the system adjusts to rate control changes too slowly, increase the flow gain digit(s) to increase the system response rate. If the system overshoots or oscillates around the desired flow rate, decrease the flow gain digit(s) to help stabilize the system.

Dead Band Digit. The last, or right most, digit in the flow cal value is the dead band digit. The dead band digit is the allowable difference between the target rate and the actual application rate. The values range from 1 to 9, where 1 equals 1% difference and 9 equals 9% of the difference.

Sgain (Pressure System Gain - Dual Loop Control Mode)

The default setting for the Sgain value is 100. To adjust the system aggressiveness, enter a value between 1 and 999 as necessary.

Note: *It is recommended to increase or decrease the current value in increments of 10 or less when making adjustments to the Sgain setting. If the new value does not produce significant or notable changes in the system response, increments of 20 may be used.*

Increase the Sgain value if the observed product pressure increases too slowly or if the system takes a long time to reach a set standby pressure or rate input change. If the system is consistently over shooting a set standby pressure or oscillating around a target rate, decrease the Sgain value until the system stabilizes.

PWM Control Valve Tuning

The Viper Pro field computer provides three methods for fine tuning a PWM or PWM close valve used for controlling product application:

PWM Manual Calibration

The operator may enter the known values for the following PWM valve calibration settings within the Product Control Settings area:


• Min PW (Minimum Pulse Width)	• Standby Pressure	• PW Freq (Pulse Width Frequency)
• (Max PW) Maximum Pulse Width	• Pre Set PW (Preset Pulse Width)	

Note: *The PWM valve will not be operated during manual calibration. It is recommended to verify that any changes to these settings will have the desired affect before controlling product application.*

Refer to the Node Control Settings Screen (Page 2) section on page 130 for more information on the min pw, max pw values and the Node Control Settings Screen (Page 3) section on page 131 for details on the standby pressure, preset pw and pw freq values.

PWM Calibration Assistance

The calibration assistant allows the operator to manually increase or decrease the PWM output using on-screen controls and set the PWM minimum, maximum, frequency and preset values based upon observed operation.



WARNING

The PWM valve output will increase and decrease as the up and down arrows are selected. Keep any bystanders away from areas where product may be expelled and moving components when performing the calibration process.

Note: *It is recommended to perform the calibration process with water in liquid tanks or while performing a catch test with a dry or granular application system.*

To use the calibration assistant mode, toggle the vehicle master switch and at least one section to the on position. To stop the PWM output at any time during the calibration process, toggle the vehicle master switch to the off position.

Note: *Refer to the Node Control Settings Screen (Page 2) section on page 130 for more information on the min pw, max pw values and the Node Control Settings Screen (Page 3) section on page 131 for details on the standby pressure, preset pw and pw freq values configured using the calibration assistant.*

1. Touch within the Product Control Settings area on the CAN Controller Status screen. The first Node 1 Settings screen will display.

2. Touch **Next**.

Node 2 Settings

Valve Cal 43

Valve Cal 2 0

Valve Adv 5

Fan Cal 0

Min Pw 1

Max Pw 253

Prev

Next

Cancel

OK

PWM Manual Cal PWM Auto Cal

Note: The PWM Manual Cal and Auto Cal buttons will be displayed only if a PWM or PWM Close is the selected valve type. See the Application and Control Valve Type(s) section on page 40 for more information on the valve type selection.

3. Touch the **PWM Manual Cal** button. The Min PWM Calibration screen will be displayed.

Liquid

Min PWM Calibration

Setting the Minimum PWM:

1. Press the UP/DOWN arrows until the minimum desired pressure is reached.
2. Press the Set Min PWM button to set the minimum PWM setting.

Current Conditions: Node 1

Pressure 1 18

Pressure 2 ----

Vol/Min 0.0

Current Min PWM: 22

Set Min PWM

Next

Cancel

OK

Granular

Min PWM Calibration

Setting the Minimum PWM:

1. Turn the Spreader switch on.
2. Press the DOWN arrow until the belt stops, or press the UP arrow until the belt just begins to move.
3. Press the Set Min PWM button to set the minimum PWM setting.

Current Conditions: Node 1

Actual Rate 0.0

Vol/Min 0.0

Current Min PWM: 25

Set Min PWM

Next

Cancel

OK

The field computer will display the current monitored conditions at the node and the current minimum PWM value set on the field computer. The field computer will also display the following information based on the type of application system:

- For a liquid application system, the pressures at the transducer locations will be displayed.
 - For a dry or granular system, the field computer will display the product rate and volume per minute and the currently set minimum PWM value.
4. Use the up or down arrows at the bottom of the screen to adjust the displayed Current Min PWM value. Adjust the minimum value so that:
 - a. either the minimum desired boom pressure is achieved or the required pressure to achieve spray pattern is observed at the spray tips when controlling a liquid application.


Note: If an electronic pressure transducer is not installed, a manual gauge must be used to calibrate the Min and Max PW.

- b. either the belt just begins to move or just stops moving when controlling a granular application.

- Touch the **Set Min PWM** button to enter the minimum PWM setting.

Note: *It is recommended to reduce the PWM minimum value by 10 to allow a small dead band during actual field applications.*

- Touch the **Next** button. The Max PWM Calibration screen will display.




The Max PWM Calibration screen will display the current maximum PWM value as well as the current conditions monitored by the node as displayed on the previous screen.

- Use the up or down arrows at the bottom of the screen to adjust the displayed Current Max PWM value. Adjust the maximum value so that:
 - the maximum desired boom pressure is achieved at the spray tips when controlling a liquid application.

Note: *If an electronic pressure transducer is not installed, a manual gauge must be used to calibrate the Min and Max PW.*



- the maximum desired belt speed is achieved when controlling a granular application.
- Touch the **Set Max PWM** button to enter the maximum PWM setting.
 - Touch **OK** to complete the PWM calibration procedure. A screen will display showing the current PWM settings and the new PWM minimum and maximum values.
 - Touch **Yes** to use the new calibration settings or **No** to keep the previous settings.



PWM Automatic Calibration

Note: *Automatic PWM calibration must be used if the PWM Smart Control feature is enabled. Refer to Smart Control section on page 127 for additional information on the Smart Control feature.*

The automatic calibration mode will allow the field computer to automatically adjust the PWM output and attempt to determine the minimum, maximum and preset values.

	<div data-bbox="686 422 1237 495"> WARNING</div> <p data-bbox="686 495 1237 676">The PWM valve output will increase and decrease during the calibration process. Keep away from areas where product may be expelled and moving components and alert anyone around the equipment when performing the calibration process.</p>
---	--

To use the automatic assistant mode, toggle the vehicle master switch and at least one section to the on position. Touch the 'Stop Cal' button at any time during the calibration to stop PWM output.

Note: *If calibrating the PWM smart control feature, the product must be set as a granular application with a PWM type control valve.*



The automatic calibration process may take up to two minutes to complete. Maintain sufficient engine RPM and set the remote hydraulic flow to allow for at least 1 GPM [3.8 L/m] flow for each motor on the control system. The field computer will display a prompt when the calibration process is complete. If the system fails to calibrate properly, touch the 'OK' button and select 'Start Cal' again to restart the calibration process.

Meter Cal

For liquid applications, the meter cal value is typically found on the flow meter. Enter the value found on the flow meter to ensure the field computer is properly registering the product flow during product application.

Flow Meter Service and Maintenance

Periodic maintenance of the flow meter may help to extend the effective service life of the flow meter or internal components. If the flow meter does not register the applied product volume properly, the following steps will be necessary to service the flow meter:

	<div data-bbox="760 548 824 604"></div> <div data-bbox="841 554 1073 596">WARNING</div> <p data-bbox="634 617 1188 745">Exposure to agricultural chemicals may be harmful or fatal. Thoroughly bleed and flush the application system lines prior to disassembling fittings, hoses and the flow meter.</p> <p data-bbox="634 772 1188 905">If the flow meter is used for applying anhydrous ammonia, bleed the nurse tank hose and flush the system with water before maintaining the flow meter.</p>
---	---

The following procedure should be performed more frequently if the flow meter is used with harsh chemicals or in anhydrous ammonia.

1. Remove the flow meter from the application system and flush with clean water.
2. If necessary, dismantle the flow meter housing.
3. Remove the turbine hub and turbine from the flow meter.
4. Clean the turbine hub and turbine and remove any metal filings or other foreign materials such as wettable powders.
5. Check the turbine blades for wear or damage. Refer to the flow meter replacement parts sheet provided with the flow meter and replace the turbine as necessary.
6. While holding the turbine hub, spin the turbine. The turbine should spin freely with very little drag within the turbine hub. Refer to the flow meter replacement parts sheet provided with the flow meter and replace the turbine hub/turbine assembly as necessary.
7. Reassemble the flow meter.
8. Using a low pressure jet of air (5 PSI [34 kPa]), verify that the turbine still spins freely after reassembly. If the turbine drags or does not move, loosen the hex stud on the bottom of the turbine hub 1/16 turn until the turbine spins freely.
9. If the flow meter continues to provide inaccurate product volumes, refer to the *Flow Meter/Encoder Extension Cables* section on page 239.

Flow Meter Recalibration

The calibration value for the specific flow meter is printed on the tag attached to the flow meter and will typically provide accurate metering of product application. The following procedure may be used to check the meter calibration or recalibrate the flow meter.

Note: *Performing routine maintenance is recommended to help extend the service life and accuracy of the flow meter. Review the Flow Meter Service and Maintenance section on page 230 to service the flow meter as necessary.*

Before calibrating the flow meter:

1. It is recommended to perform the flow meter calibration with clean water only. Clean out the supply tank and flush the product lines with clean water. Refill the tank with clean water.
2. On the field computer, verify any active jobs are closed.
3. Toggle all boom section switches and the master section switch to the off position.
4. Disconnect one of the section product lines near the spray tips.
5. Set up a calibrated catch container (i.e. 5 gallon [19 L] bucket and place the disconnected end of the product line in the container.

To recalibrate the flow meter:

1. On the field computer Home screen, touch the Tools Menu icon.
2. Select the Product Control icon from the System menu.
3. On the Product Control Configuration screen, touch the Calibration Settings button.
4. Select the Meter Cal value and use the on-screen keypad to enter a value of 10 [38].
5. Touch the Accept icon until the Product Control Configuration screen is displayed.
6. Touch the Volume/Area Settings button.
7. Touch the Total Volume button and use the on-screen keypad to enter a value of 0.
8. Touch the Accept icon to return to the Volume/Area Settings screen.
9. While monitoring the Total Volume on the screen and the container, toggle the master switch and the appropriate section switch to the on position.
10. Dispense exactly 10 gallons [38 L] through the flow meter as measured by the calibrated catch container.

Important: *Do not rely on graduation markings/numbers molded into the applicator tank.*

11. Toggle the section or master switch off.
12. Read the value displayed on the field computer Total Volume button. This value should be within $\pm 3\%$ of the meter cal value printed on the flow meter tag.
13. To confirm accuracy, reset the Total Volume to 0 and repeat the above process several times. Always 'zero out' the Total Volume display before toggling the section switch on.

Note: *The above process is usually sufficient to check the flow meter calibration. For best results, set the Meter Cal value to 100 [378] and repeat the above procedure to dispense exactly 100 gallons [378 L] through the flow meter.*

To verify the flow meter calibration:

1. Fill the applicator tank with a predetermined volume of liquid (i.e. 250 gallons [946 L]).

Important: Do not rely on graduation markings/numbers molded into the applicator tank.

1. On the field computer Home screen, touch the Tools Menu icon.
2. Select the Product Control icon from the System menu.
3. On the Product Control Configuration screen, touch the Volume/Area Settings button.
4. Use the on-screen keypad to enter a value of 0 and touch the Accept icon.
5. Empty the applicator tank under normal operating conditions.
6. Return to the Total Volume displayed on the field computer and read the new value. The total volume value should match the known volume ($\pm 3\%$) used to fill the applicator tank.
7. If the total volume value displayed differs from the known volume by greater than 3%, use the following formula

$$\frac{MC \times V_m}{V_k} = CMC$$

Where MC = the Meter Cal value used during the test, V_m = the Volume measured by the field computer, V_k = the known Volume in the applicator tank and CMC = the Corrected Meter Cal.

For Example:

A set meter cal of 720 [190] is used to dispense 250 gallons [946 L] through the flow meter. At the end of the test, the field computer reads a measured volume of 260 gallons [984 L]:

$$\frac{720 \times 260}{250} = 749$$

or

$$\frac{[190] \times [984]}{[946]} = [198]$$

Therefore, the corrected meter cal is 749 [198].

8. Enter the corrected meter cal value before resuming application.

Rate Cal

The product rate cal value is entered in gallons per acre [L/ha] for liquid application systems or in pounds per acre [kg/ha] for granular applications.

Liquid Applications and Spray Nozzles

Enter the desired target volume per minute of liquid product for the application. Refer to *Unit of Measure Definitions* section on page viii or contact a local sprayer or chemical supply dealer for more assistance.

The spray nozzles may also need to be adjusted for the target application rate. The following information must be known in order to determine the correct spray nozzles to use with a liquid applicator.

- Nominal Application Pressure _____ PSI [kpa]
- Target Application Rate _____ GPA [lit/ha]
- Target Speed _____ MPH [km/h]
- Nozzle Spacing _____ inches [cm]

From this information, calculate the volume per minute per nozzle as follows:

$$NVPM = \frac{Rate \times Speed \times NS}{5,940[60,000]}$$

where NVPM = Nozzle Volume per Minute (in gallons/acre [L/ha]), Rate = Target Application Rate, Speed = Target Speed of Application and NS = Nozzle Spacing.

For Example:

Application Pressure = 30 PSI, Target Application Rate = 20 GPA, Target Speed = 5.2 MPH and Nozzle Spacing = 20 inches

$$NVPM = \frac{20 \times 5.2 \times 20}{5,940} = 0.35$$

Using the calculated Nozzle Volume per Minute of 0.35 at an Application Pressure of 30, select a tip that is capable of these application specifications. Contact a local sprayer supply dealer for available nozzles or spray tips.

Band Spraying Rate Adjustment

To calculate the adjusted applied rate for band spraying applications, use the following formula:

$$\frac{BR \times BW}{S} = AR$$

where BR = the Broadcast Rate, BW = the bandwidth, S = the spacing between the tips, and AR = the Adjusted Rate for band spraying.

For Example:

If the Broadcast Rate is 20 GPA [187 L/ha], the band width is 14 inches [35 cm], and the tip spacing is 40 inches [101 cm]:

$$AR = \frac{20[187] \times 14[35]}{40[101]} = 7[65]$$

Therefore, the adjusted rate is 7 GPA [65 L/ha].

Verifying Flow Rate Limits

The target rate for an application must be within the range of that specified for the Raven flow meter installed.

Flow Meter Model	Flow Range	Average Meter Cal Value
RFM 5	0.05 - 5 GPM [0.2 - 18.9 lit/min]	5500
RFM 15	0.3 - 15 GPM [1.1 - 56.8 lit/min]	1750
RFM 60P	1 - 60 GPM [3.8 - 210 lit/min]	720
RFM 100	3 - 100 GPM [11.4 - 380 lit/min]	700
RFM 200/ 200 Poly	15 - 200 GPM [56.8 - 760 lit/min]	164
RFM 400	25 - 400 GPM [94.6 - 1515 lit/min]	80

Pressure Transducer

Note: The Viper Pro will shutdown the liquid product pump if the boom pressure (P1) remains at zero for more than 20 seconds and the Valve Type is set to PWM.

Calibrating the Pressure Transducer

1. Read the pressure on an analog gauge connected in line with the pressure transducer.

Note: If no pressure gauge is installed in line with the pressure transducer, bleed or relieve any pressure applied to the transducer and enter a value of '0' for the pressure value in the procedure below.

2. Touch the Pressure area on the CAN Controller Status screen.

Rate Cal	15.0	Valve Adv	3	Valve Delay	0.0
Rate +/-	2.0	Pump Cal	0	PWM	0
Meter Cal	700.0	Min Pw	0		
		Max Pw	253		
Pressure 1	71	Application	Liquid		
Pressure 2	61		AIM		
Tally Registers				OK	

Note: Each product node or control channel has two pressure settings. Use the **Next** or **Prev** buttons to display the correct pressure transducer to calibrate before proceeding.

3. Touch the **Pressure** value and use the on-screen keyboard to enter the pressure gauge reading
4. Touch **Set** to calibrate the pressure transducer.
5. Touch **OK** to return to the CAN Controller Status screen.

APPENDIX


C

Testing Extension Cables

Speed Sensor Extension Cable

Verify that the system is in the Wheel Speed Sensor mode while testing the cable. Disconnect the extension cable from the speed sensor assembly cable. Hold the extension cable connector so that the keyway is pointing in the 12 o'clock position as shown below.

FIGURE 1. Speed Sensor Extension Cable Pin Diagram




Note: If a radar type speed sensor is used, the voltage between the 10 o'clock and 2 o'clock positions may read 12 VDC.


If a +5V DC voltage reading is not present, disconnect the flow meter cable and re-test the speed sensor cable. If the voltage reads +5V DC when the flow meter cable is disconnected, test the flow meter cable per Flow Meter/Encoder Extension Cables section on page 239.

Testing the Speed Sensor Cable


1. Touch **Product Control**.



2. Touch the **Miscellaneous** box. Enter 1000 as the Speed Cal and touch **OK**.



3. Touch **OK** to return to the CAN Controller Status screen.
4. Touch **Tally Registers**.
5. Touch the **Reset** button next to the **Distance** box.




6. With a small jumper wire (or paper clip), short between the 10 o'clock and 6 o'clock sockets with a 'short-no-short' motion. Each time contact is made, the Distance total should increase by increments of 1 or more.
7. If the Distance total does not increase, remove the section of cable and repeat the test at the connector that is the next closest to the node. If the distance total now increments during the short-no-short test, replace the defective cable as required.
8. If no pulses are registered, perform the above voltage checks.
9. If all of the cables test 'good', replace the Speed Sensor.

Note: After testing is complete, re-enter the correct Speed Cal and Speed Sensor type before starting application.

Flow Meter/Encoder Extension Cables

Before starting this test, disconnect the flow meter cable from the flow meter. Hold the flow meter cable so that the keyway is pointing in the 12 o'clock position as shown below.


FIGURE 2. Flow Meter Extension Cable Pin Diagram



Note: In a non-CAN system if a +5 voltage reading is not present, disconnect the Speed Sensor cable. If the voltage reading is restored, test the Speed Sensor cable as described in Appendix G, Testing the Speed Sensor Extension Cable.

Testing the Flow Meter/Encoder Cable

1. Touch **Product Control**.



2. Touch the **Product Control Settings** area.

The CAN Controller Status screen will be displayed.

CAN Controller Status			
Boom Cals		Miscellaneous	
L 5	5 180	Speed Sensor	Wheel
1 180	* 0	Speed Cal	1000
2 300	* 0	Self Test	0.00
3 120	R 5	Pump RPM	0
4 300		Speed	10.2
		Units	US
Product 1 ▼			
Dual Flow %	50	Flow/Shaft Alarm	Off Smoothing On
Off Rate %	30	Vac/Bin Alarm	Off Agitator Off
Low Tank	0.0	Decimal Shift	Off Ratio Rate Off
Low Limit	0.0	Zero Shutoff	On
Tank Vol	832.0	Spreader	0 Pre Set Pw 0
Area/Hour	0.0	Valve Cal	2123 Pw Freq 122
Vol/Min	0.0	Valve Cal	20 Ratio Rate 0.00
Rate Cal	15.0	Valve Adv	3 Valve Delay 0.0
Rate +/-	2.0	Pump Cal	0 PWM 0
Meter Cal	700.0	Min Pw	0
		Max Pw	253
Pressure 1	71	Application Liquid	
Pressure 2	61	AIM	
Tally Registers		OK	

3. Touch within the Product Control Settings area to display the node settings screen for the selected control channel.

4. Enter the number '1' in the **Meter Cal** or **Density** field. In granular modes, enter a value of '0' for the Spreader value and touch **OK** to return to the CAN Controller Status screen.

Node 1 Settings

Tank Volume	832.00
Rate Cal	15.00
Rate +/-	2.00
Density	700.00
Spreader	0

Calibration Assistance

Next
Cancel
OK

5. Touch the **Tally Registers** button at the bottom of the screen.
6. Note the 'Ttl Vol' (total volume) column and the registered values for each control channel.

Tally Registers

Node	Ttl Vol	Field Volume	Tnk Vol	Ttl Area	Fld Area
1	0.0	0.0	0.0	0.0	0.0
2	0.0	0.0	0.0	0.0	0.0
3	0.0	0.0	0.0	0.0	0.0
4	0.0	0.0	0.0	0.0	0.0
5	0.0	0.0	0.0	0.0	0.0
6	0.0	0.0	0.0	0.0	0.0
7	0.0	0.0	0.0	0.0	0.0
8	0.0	0.0	0.0	0.0	0.0
9	0.0	0.0	0.0	0.0	0.0
10	0.0	0.0	0.0	0.0	0.0

7. Toggle the section switches and the master switch on.
8. With a small jumper wire (or paper clip), short between the 2 o'clock and 6 o'clock sockets with a 'short-no-short' motion. Each time contact is made, the total volume should increase by increments of 1 or more.
9. If the total volume does not increase, remove the section of cable and repeat the test at the connector that is the next closest to the node. Replace the defective cable as required.
10. Verify the pin connection and voltage from the previous chart.
11. If all of the cables test 'good', replace the flow meter.

Note: After testing is complete, re-enter the correct meter cal or density and spreader constant values before starting application.

APPENDIX

D

Updating CAN Nodes via the Viper Pro

Viper Pro field computers with software version 3.0 or higher and CAN firmware version 16 or higher are capable of programming nodes on the CANbus directly through the Viper Pro using a USB flash drive with the CAN Update program.

Note: *Before trying to update a CAN Node, make sure the node is communicating properly over the CANbus. If the node is not communicating properly, the Viper Pro will be unable to update the node. It is recommended to keep the machine engine running during the update process to ensure proper voltage is supplied to the CANbus nodes.*



NOTICE

Updating a CAN node erases the current settings in the node. To retain settings and calibration data, be sure to write down all settings stored by the node(s) being updated.

The CAN Update program and node updates are available on the Raven web site:


www.ravenhelp.com

To Update CAN Nodes


1. Start the Viper Pro and access the Program Selection Menu screen.

Note: If the field computer is already powered up, touch the **Menu** button and select **Exit**. Select the **Exit to Menu** option on the Exit Viper screen.


2. Insert the USB flash drive with the CAN Update program and required .hex files into an available USB port on the Viper Pro field computer.
3. On the Program Selection Menu screen, select the option labeled “Update CAN Nodes” to begin the CAN Update Program.



4. The Update CAN Nodes screen displays a list of available node updates. This screen also displays the firmware version to which each node will be updated if the update is applied.



5. Touch the node update to apply.



Up to five single product nodes may be used in some applications. If more than one node is on the system, the node selection buttons will be displayed below the update list.

6. To start the node update:
 - a. If a non-product node (i.e. Boom Sense/Speed, AccuBoom, AutoBoom Node) is selected, Touch the **Start** button in the lower right corner of the screen to begin the update.
 - b. For single product control nodes, select the **Node** button corresponding to the product node to update.
 - c. For product controller nodes, select the first available node channel to which the controller node is assigned.

Note: If the Viper Pro cannot communicate with the selected node, the CAN Update Program will display an error. Troubleshoot the node and retry the update.

7. The Viper Pro begins communicating with the selected update. If communication is successful, the Viper Pro will begin the update by erasing the node's memory.

Note: The Viper Pro may take several minutes to prepare and apply the software update to the node.

8. When the update is completed, Viper Pro will display a Programming Complete prompt. Touch the **OK** button to continue.

Note: If errors are encountered during the node update re-apply the node update.

9. To update other nodes via the Viper Pro CANbus repeat step 5 through 8.

Node Recovery Mode

Note: The node program number will be required to properly recover the node. If the program number is unknown, contact a local Raven dealer or the Raven Technical Support Center for additional assistance with appropriate program numbers for recovering a CANbus node.

To attempt to recover a CANbus node on which a failed update has occurred:

1. From CAN Update screen, touch the Recov. button in the lower, left corner of the display.
2. Disconnect the rectangular connectors on the node for approximately 5 seconds to cycle power to the node. Ensure any status LEDs are off or stop flashing before reconnecting the node.

Appendix D

3. On the field computer, touch the versions field and use the scrolling list to select the appropriate node program to reset the node. The node program and version numbers will be displayed in the following format:

P144V111

Program Number Version Number

4. Touch the Start button to attempt to recover the node. If the node recovery fails, or for additional support, contact a local Raven dealer.

APPENDIX

E


Using the Front Panel Program with the Viper Pro System

The Front Panel Program may be used to configure Raven DGPS receivers only (e.g. Invicta 110, 115, or Phoenix 200).


Initializing the Front Panel Program

Note: *The Front Panel program cannot be used if a SmarTrax or TM-1 Tilt Module is installed between the field computer and DGPS receiver.*

1. Touch **Front Panel** from the Program Selection Menu.



2. After communication with receiver is established, the field computer may be used to navigate through the receiver menus by utilizing the buttons provided on the Viper Pro touch screen.



Note: Refer to the Operation Manual or Quick Start Guide for the specific Raven receiver used with the Viper Pro field computer. These documents may also be found on the Raven Applied Technology Division web site:

www.ravenhelp.com

APPENDIX

F

External Serial Rate Control

The Viper Pro is capable of receiving serial rate information from an external source to control product application. One source of external serial rate information is the GreenSeeker® RT200 by NTech Industries, Inc. The Viper can be set up to receive serial rate information from the GreenSeeker® RT200 on the Viper auxiliary comm port. The rate information fed to the Viper is stored in the application report and can be obtained by exporting the shapefile or bitmap using the file maintenance feature on the Viper Pro field computer.

The Viper Pro can be configured either as a CANbus system or the Viper Pro can be connected to a Raven serial console. Set up for either configuration with the Viper product control system is the same as without external serial rate control. Ensure that the Viper product control is configured properly before using an external serial rate source.

Setting up the Auxiliary Port for External Serial Rate Control

1. Select **Menu**, then **Startup**, and **Comm Ports**. The GPS Comm Port Setup screen displays.
2. Touch **Next**. The Auxiliary Comm Port screen displays.

Auxiliary CommPort Setup

Baud	Data Bits	Parity
<input type="radio"/> 1200	<input checked="" type="radio"/> 8	<input type="radio"/> Odd
<input type="radio"/> 4800	<input type="radio"/> 7	<input type="radio"/> Even
<input checked="" type="radio"/> 9600	Stop Bits	<input checked="" type="radio"/> None
<input type="radio"/> 19200	<input type="radio"/> 1	
<input type="radio"/> 38400	<input checked="" type="radio"/> 2	

☒ Serial Rate

View Data

Prev Cancel OK

Note: If a serial console is connected to the Viper Pro, the Console Comm Port screen displays. Touch **Next** to display the Auxiliary Comm Port screen.

3. Set the Auxiliary Comm Port settings to:
 - Baud = 9600
 - Data Bits = 8
 - Parity = None
 - Stop Bits = 2
4. Select the **Serial Rate** radio button.
5. Touch **OK** to return to the main Viper screen.


Connecting the GreenSeeker® RT200 to the Viper Pro

1. Connect the GreenSeeker® Interface Module to PDA Cable to the GreenSeeker® RT200.
2. Connect the DB-9 connector on the GreenSeeker® Interface Module to the Auxiliary Comm Port connector on the Viper harness.

Starting a Job with External Rate Control

Note: *External Serial Rate control is only available for Product #1. Make sure the system is configured to apply the desired product from the first product.*

1. Select **Menu**, then **Start Job**.
2. Select **New Job**.
3. Using the screen keyboard, enter a name for the job in the Job Name field. If no name is entered, the date and time are used for the job name.
4. Select the desired options from the list.
5. Touch **Next**. If AccuBoom has been selected from the options list, select AccuBoom option desired and touch **Next**.
6. If Swath Guidance has been selected from the option list, select the desired Swath Guidance pattern and touch **Next**.
7. In the Product Selection screen, enter the number of products for the current application.
8. Touch **Next**. The Product #1 Setup screen displays.



9. Using the screen keyboard, enter a product name in the Product Name field.
10. For External Serial Rate Control, select **Serial Rate**.

Note: *The Serial Rate selection will only appear if the Auxiliary Comm Port has been configured for Serial Rate. If the Serial Rate selection does not appear in the Product #1 setup screen, go back and set up the Auxiliary Comm Port for Serial Rate.*

11. Touch **OK**.

APPENDIX

Weather Station

G

The Viper Pro is capable of reading information from an external weather station and recording this information into the application report files. The information being recorded to the report includes:

- Temperature
- Relative Humidity
- Dew Point
- Barometric Pressure
- Wind Speed
- Wind Direction
- Wind Gust

The Viper Pro can only read information from one specific model of weather station. This unit is the WatchDog Sprayer Station Model 3349SS (P/N 117-0171-138) manufactured by Spectrum Technologies, Inc. This system may be ordered through any Raven dealer.

For more information on this system contact Spectrum Technologies at (800) 248-8873.

Weather Station Activation Key

In order to use the weather station with the Viper Pro system, the weather module activation key (P/N 077-0180-030) must be purchased from a Raven dealer. Once the key has been purchased and registered on-line, the activation key must be entered into the Viper Pro. See Chapter 3, *Installation, Start Up and Registration*, for help with registering and entering this information.

Connecting the Weather Station

If the Viper Pro is connected to a CAN control system, the weather station must be connected to the 'COM 2/ Console' connector on the Viper Pro main interface or chassis interface cable.


If the Viper Pro is connected to an external Raven serial controller, the weather station must be connected to 'COM 3/Light bar' on the Viper Pro auxiliary interface or chassis interface cable.

If the Viper Pro is using the Viper Pro combination cable (P/N 115-0171-744), connect the weather station to the 'Console' connector if using a CAN control system, or to the AUX connector if using an external Raven serial controller.

Comm Port Configuration

Once the system is properly powered and cabled, and the activation key has been entered into the Viper Pro, the Viper communications port must be configured for the weather station.

1. Touch **Menu / Setup / Comm Ports**.
2. Touch the **Next** button until the Weather Module Setup page is displayed.




3. Select which comm port the station is connected to.

Note: To record weather information into the report file, ensure the **Enable Logging** is checked. If weather data is not needed, leave this option un-checked to help conserve memory on the field computer.

4. **Initialize Station** must be selected one time to configure the weather station for use with the Viper Pro.
5. Touch **OK** to complete the set-up.

To view weather information, touch the **Display Data** button on the lower right hand side of the Viper, and then touch in the data area to toggle to the weather information.



Note: If the Wind Direction heading displayed in the Weather Information does not appear as expected, re-initialize the Weather Station as described in the Comm Port Configuration section on page 250.

Touch the **Record** button to log the current weather conditions into the application report. The record button will only display when in a job. The record button may be selected as many times as desired during the job, but only the information from the last button selection before the job is closed will be recorded into the application report.

APPENDIX

H

Wireless Communications and Remote Service


The Viper Pro field computer, with a Slingshot Field Hub, allows the operator to wirelessly transfer application data back to the home or office and transfer prescription data from the office to the field without the hassle of driving back and forth between locations. This feature also adds the ability to allow service technicians and support specialists to remotely control the Viper Pro field computer, help is now just a touch away.

Via the Field Hub wireless router, the Viper Pro can also be used to keep up-to-date with the latest weather forecasts or crop prices from internet web sites while still managing product application.

Note: For instructions on installing and setting up the Slingshot Field Hub, refer to the Field Hub Quick Reference Guide provided with the wireless device.





Wireless Communication Status

The status of wireless communications is displayed on the Viper Pro main screen in the tool bar below the map.







Wireless
Communication
Status Icon

The following icons may be displayed in the wireless status area:

	No Device Connected - No supported wireless device is connected to the ethernet port on the Viper Pro. This icon is also displayed if wireless communication is unavailable or has been lost.
	Communication OK - The status of wireless communication is good and no errors or alarms are present.
	Communication Error - An error has occurred with wireless communication or during a file transfer.
	Communication Lost or Unavailable - This icon will be displayed if the registration process has not been successfully completed.


The wireless status symbols also display the file transfer status for any files to or from the Viper Pro field computer.

	Sync In Progress - The blue arrow symbol is displayed on the wireless status icon while the Viper Pro and the Slingshot™ site are synchronizing.
	Files Received - The envelope symbol is displayed on the wireless status icon when files have been received by the field computer. When this symbol is displayed, touch the icon to display the File Manager tab.

Note: When the  or  symbols are displayed, touching the Communication Status icon will display the Connection Status tab on the Wireless Status screen. Touching the status icon at any other time will display the Site Information tab.

Wireless Status Screen

Touch the wireless status symbol displayed on the Viper Pro main screen to display the Wireless Status screen.



The Wireless Status screen displays information based on the tab selected on the right side of the screen. For details on the information displayed on each tab, refer to the following sections.

Site Information Tab

Displays information from the Slingshot™ site.

Remote Service Tab

The Remote Service feature allows a service technician to view and control a Viper Pro field computer in the field from his or her service location and assist the machine operator diagnose or troubleshoot the system.

Note: *The service technician will be able to determine whether a remote service session is necessary to assist with any issues encountered with the Viper Pro field computer. Contact a local Raven dealer or technical service provider before starting the remote service feature.*

To begin a remote service session:

Note: *The remote service feature must be enabled when the field computer is registered for Slingshot services. Contact a local Slingshot dealer for additional assistance.*

1. Touch the Wireless Status icon on the Viper Pro main screen and select the Remote Service tab.
2. Touch the "Enable Remote Service" button. Have the code displayed on the screen available when contacting a local Raven dealer for support.
3. Read the code to the technician to allow them to view and control the Viper Pro system.

Comm. Status Tab

The connection status tab displays the following information:


The screenshot shows a 'Wireless Status' window. On the left, there are four status indicators: 'Signal Strength' with four green bars, 'Ethernet Status' with a thumbs-up icon, 'Internet Status' with a thumbs-up icon, and 'Secure Server Connection' with a thumbs-up icon. Below these is a 'Communication Status' section with a text box containing the word 'Good'. Underneath is a 'Solution' section with a large empty text box. On the right side, there is a vertical menu with buttons for 'Site Information', 'Remote Service', 'Comm Status', 'File Manager', and 'Registration'. At the bottom right of the window is an 'OK' button.

- **Current Alarms** - Any current communication errors or alerts are displayed in this area.
- **Signal Strength** - Displays bars to represent the current strength of wireless signal. Four bars represent a strong signal.
- **Ethernet Status** - Displays the status of the connection via the ethernet port on the back of the Viper Pro.
- **Internet Status** - View the status of communication with the world wide web in this area.
- **Secure Server Connection** - The connection status with the secure server is displayed in this area.

Note: *If any error conditions are encountered, the Communication Status screen will display possible solutions.*

File Manager Tab

Access the File Manager tab to view a history of files recently transferred to or from the Viper Pro field computer.



Use the up or down arrows to scroll through the history of files sent from, or received by, the Viper Pro.

Touch a file from one of the lists to view file information such as the file type and size as well as the date and time the file was sent or received.


Note: *Do not use the Automatic File Maintenance feature to create reports for a Slingshot account.*

The Automatic File Maintenance feature does not export the types to a USB flash drive necessary for creating Slingshot reports and will remove job data from the Viper Pro. Job data transferred using the Automatic File Maintenance feature cannot be reinstalled onto the field computer for export to Slingshot. Refer to the USB File Transfer and Advanced File Maintenance section on page 185 for instructions on outputting the necessary file types.

Registration Tab



The Registration tab is used to register the Field Hub with the Slingshot™ and activate the various features of wireless communication on the Viper Pro field computer.

Note: If the Field Hub has been registered previously, the Viper Pro will display the registration status above the “Registration Code” button. Touching the “Registration Code” button will display the Re-Registration Warning prompt below. To re-register the Field Hub, touch the “Yes” button and proceed with the registration instructions to re-register the Field Hub.




To register:

1. Touch the Wireless Status icon on the Viper Pro main screen and select the Registration tab.



2. Touch the "Register" button.



3. A numeric code will be displayed. Allow a few minutes for the field computer to communicate with the Slingshot web service. Once communication is established, a green check mark will be displayed on the wireless status indicator.
4. Registration is complete.

To test wireless access:

1. Wait for the Viper Pro to automatically search for available files for transfer. This process may take up to five minutes.
2. If the Remote Service feature was enabled during registration, select the Remote Service tab and touch the "Enable Remote Service" button.
3. If a remote service session is enabled successfully, touch the button now labeled "Disable Remote Service."
4. Exit the Wireless Status screen by touching the **OK** button in the lower, right corner of the screen.
5. If the Web Access feature was enabled during registration, touch **Menu > Web** to open the Viper Pro internet browser and test the web access feature.

A**A-B Lines** 114**About Button** 138**AccuBoom™**

- Aggressiveness Factor 167
- Boom Disable 166
- Changing Spray/No-Spray Default Colors 171
- Configuring AccuBoom™ Control 165
- Control 166, 167
- Control Setup 163
- Create No-Spray Map Method 170
- Enabling Override 168
- Load No-Spray Map Method 170
- Override 165
- Spray/No-Spray Maps 171
- Spray/No-Spray Zones 169
- Standard Method 169
- Tab 88
- Using 161
- Zero Rate Shut Off 166

Active Matrix Transflective Touch Screen 6**Advanced Settings** 222**Advanced Settings and Features** 119**Agitator** 127**Alarms** 96**Alternate Swath Pattern Button** 112**Alternate View Button** 112**Application**

- Area 134

Application Reports

- Applicator Information 101
- Customer Information 99
- Field Information 99
- Ingredient Information 102
- Report Notes Information 103
- Vehicle Information 101
- Weather Information 100

Area/Hour 128**AutoBoom™**

- Status Indicator 137
- Using 175

Automatic File Maintenance 188**Auxiliary Comm Port Setup** 158**B****Boom**

- Boom and Implement Setup 160
- Mapping 220

Boom or Section Cals 45**C****Calculating**

- Speed Calibration 215

Calibrating the Pressure Transducer Using an Analog Gauge 235**Calibration Values**

- Rate Cal 233
- Section Widths 220
- Valve Cal 224

CAN (Controller Area Network)

- CAN System Connections 22
- Detecting Nodes 33

- Initialization Results 34

- Node Off-line Errors 34

- Troubleshooting 202

Care and Use 10**Clone or Restore Settings** 189**Comm Port Setup**

- Console 157
- GPS 154

Connecting the GreenSeeker® RT200 to the Viper Pro 248**Console Comm Port Setup** 157**Cov Tab** 86**Coverage Maps** 146

- Accessing Information 86
- Issues 198
- Setting Percentages and Colors 147
- Zero Rate Tolerance 147

Create Map From Field Boundary Method 171**Creating Application**

- Reports 98

D**Decimal Shift** 126**Density** 130**DGPS Receiver Connection** 21**Display Smoothing** 127**Download Street Maps** 144**Dual Flow %** 125**E****Electrical**

- Safety 2

Error Messages 199**Exit Button** 138**External Serial Rate Control** 247**F****Fan/Pump Cal** 131**Fan/Pump RPM** 121**Feature Settings Area** 124

- Agitator 127
- Decimal Shift 126
- Display Smoothing 127
- Dual Flow % 125
- Flow/Shaft Alarm 126
- Low Limit 125
- Off Rate % 125
- Ratio Rate 127
- Vacuum/Bin Alarm 126
- Zero Speed Shutoff 126

Field Conditions 100**File Maintenance** 141, 177

- USB File Transfer 185

Flash Drive File Structure 180**Flow/Shaft Alarm** 126**Front Panel** 7**Front Panel Program** 245

G

General Error Messages 199

General Issues 195

GPS

Comm Port Setup 154

DGPS Receiver Connection 21

Error Messages 201

Generic (Non-Raven) GPS Setup 155

Raven GPS Setup 156

Status Display 58

Guidance

Guidance Menu Icon 112

Guide Tab 83

Swath Guidance Patterns 106

Using the Guide Tab 111

Views 105

H

Hydraulic

Safety 2

I

Important Safety Information

Electrical 2

Hydraulics 2

Importing a Field Boundary

Initial Set Up and Navigation

Installation, Start Up & Registration

Introduction

Unit Definitions and Conversions viii

Unit of Measure Conversions viii

Unit of Measure Definitions viii

J

Jobs

Adding to an Existing Job 78

Error Messages 200

Existing 78

Issues 197

Pausing 80

Restarting a Paused Job 80

Starting a New AgX Job 68

Starting a New Standard Job 73

Starting with External Rate Control 248

Viewing an Existing Job 78

L

Light Bar

Bright Button 112

Dim Button 112

Guidance 159

Loading

A-B Lines 115

Profiles 49

Local Settings

Low Limit

Low Tank

M

Main Tab 83

Mapping the Booms 221

Maps 143

Marking a Field Boundary 88

Max PSI 132

Max PW 131

Menu 138

Meter Cal 130

Min PW 131

Misc Folder Sub-folders 181

Mounting the Field Computer 14

Multi-Product VRA 27

N

Node

Off-line Errors 34

Nodes

Detecting CANbus Nodes 33

Nudge Feature 116

O

Off Rate % 125

Off-Swath Direction 111

Off-Swath Distance 111

On-Screen Lightbar, Configuring 160

Override

Zero-Speed 165

Override Sec 165

Overview 177

P

Performing File Maintenance 182

Pre Set PW 131

Preparing a USB Thumb Drive for File Maintenance 178

Prescription (Rx) Maps 148

Colors 150

Deleting a Color Template 152

Editing a Color Template 152

Error Messages 200

Look-Ahead 149

Map Issues 198

Rx Tab 84

Uploading via USB 184

Pressure Area 133

Pressure Transducer 235

Product Application 67

Product Control Settings Area 128

Area/Hour 128

Fan/Pump Cal 131

Max PSI 132

Max PW 131

Meter Cal or Product Density 130

Min PW 131

Pre Set PW 131

PW Freq 132

PWM 128

Rate Bump (+/-) 129

Rate Cal 129

Ratio Rate 132
 Spreader 130
 Tank Volume 129
 Valve Advance 131
 Valve Cal 130
 Valve Delay 132
 Volume/Minute 128
Product Control Status Display 59
Product Information 102
Program Selection Menu 24
PW Freq 132
PWM 128

R
Rate Bump (+/-) 129
Rate Cal 129
Ratio Rate 127, 132
Re-Addressing Product Nodes 34
Rear Panel 9
ReCal A-B Button 113
Registration Keys and Feature Activation 142
Reset A-B Button 113
Rx
 See Prescription (Rx) Maps
Rx+Cov+Scout Tab 84

S
Save A-B Button 112
Saving an A-B Line 114
Saving Profile Information 49
Scout Maps 145
Scout Tab 87
Screen Icons 113
Serial Communication Port Setup 154
Setting or Resetting Distance and Individual Nodes 95
Setting the Fixed Contour Pattern 109
Setting the Last Pass Pattern 109
Setting the Max PSI 132
Setting the Pivot Pattern 110
Setting the Straight AB Line Pattern 106
Setting up the Auxiliary Port for External Serial Rate Control 247
Settings Area
 Feature 124
 Product Control 128
Setup
 Button 141
 Error Messages 199
 Issues 196
Single Product VRA 27
SmarTrax Status Indicator 59
Speed
 Display 121
Spreader 130
Starting a Job with External Rate Control 248
Street Maps 143
 Delete 145
 Download 144
 Load to Viper Pro 144

Swath
 Guidance Patterns 106
 Number 112
Swath Guidance 67
System Diagrams 203
 CAN AccuBoom™ with Serial Control Console and Viper Pro System Example 163
 CAN AccuBoom™ with Viper Pro System Example 162
 RGL 600/600ic External Lightbar Connection Options 205
 Sample CANbus System Diagram 22
 Serial Control Console Connection to Viper Pro with Phoenix 200 Example 204
 Viper Pro Dual Product (Liquid/Granular) CAN Control System 211
 Viper Pro Single Product (Liquid) CAN Control System 210
 Viper Pro with External Lightbar 205
 Viper Pro/Phoenix 200/RGL 600 Universal/SmarTrax Package 206

T
Tabs 83
Tally Registers 93
 Resetting 94
Tank Volume 129
Testing the Flow Meter Cables 239
Testing the Speed Sensor Extension Cable 237
Time Zone Configuration 37
To Configure the Scout Map 145
To Record Field Features 146
Touch Screen Calibration 26
Troubleshooting the Viper Pro System 195
Turn-Off % Coverage 164
Turn-On/Turn-Off Look-Ahead 164

U
Updating 241
USB File Maintenance 185
 Selecting a File Type to Work With 185
 Selecting An Operation To Perform 186
 Selecting Associated File Actions 186
 Selecting File Selection Method 187
 Selecting Source/Destination 186
USB File Transfer 185

V
Vacuum/Bin Alarm 126
Valve
 Cal 2 43
 Delay 132
Valve Advance 131
Valve Cal 130
Valve Cal 2 130
Variable Rate Control (VRC)
 See Prescription (Rx) Maps
Vehicle Indicator 112
Verifying Flow Rate Limits 234
Viper Pro
 Care and Use 10

Index

Features 27
Guidance 105
Mounting the Field Computer 14
Serial Console Connection 204
Troubleshooting Information 195
User Interface 6
Using 65
Using Front Panel 245

Vol/Min 128

W

Weather Station 249

Z

Zero Boom Pressure 134

Zero Speed Shutoff 126

Zoom Level 112



Limited Warranty

What Does this Warranty Cover?

This warranty covers all defects in workmanship or materials in your Raven Applied Technology Division product under normal use, maintenance, and service when used for intended purpose.

How Long is the Coverage Period?

Raven Applied Technology products are covered by this warranty for 12 months from the date of retail sale. In no case will the Limited Warranty period exceed 24 months from the date the product was issued by Raven Industries Applied Technology Division. This warranty coverage applies only to the original owner and is non-transferable.

How Can I Get Service?

Bring the defective part and proof of purchase to your Raven dealer. If the dealer approves the warranty claim, the dealer will process the claim and send it to Raven Industries for final approval. The freight cost to Raven Industries will be the customer's responsibility. The Return Materials Authorization (RMA) number must appear on the box and all documentation (including proof of purchase) must be included inside the box to be sent to Raven Industries.

What Will Raven Industries Do?

Upon confirmation of the warranty claim, Raven Industries will (at our discretion) repair or replace the defective product and pay for the standard return freight, regardless of the inbound shipping method. Expedited freight is available at the customer's expense.

What is not Covered by this Warranty?

Raven Industries will not assume any expense or liability for repairs made outside our facilities without written consent. Raven Industries is not responsible for damage to any associated equipment or products and will not be liable for loss of profit, labor, or other damages. The obligation of this warranty is in lieu of all other warranties, expressed or implied, and no person or organization is authorized to assume any liability for Raven Industries.

Damages caused by normal wear and tear, misuse, abuse, neglect, accident, or improper installation and maintenance are not covered by this warranty.



Extended Warranty

What Does this Warranty Cover?

This warranty covers all defects in workmanship or materials in your Raven Applied Technology Division product under normal use, maintenance, and service when used for intended purpose.

Do I Need to Register My Product to Qualify for the Extended Warranty?

Yes. Products/systems must be registered within 30 days of retail sale to receive coverage under the Extended Warranty. If the component does not have a serial tag, the kit it came in must be registered instead.

Where Can I Register My Product for the Extended Warranty?

To register, go online to www.ravenhelp.com and select Product Registration.

How Long is the Extended Warranty Coverage Period?

Raven Applied Technology products that have been registered online are covered for an additional 12 months beyond the Limited Warranty for a total coverage period of 24 months from the date of retail sale. In no case will the Extended Warranty period exceed 36 months from the date the product was issued by Raven Industries Applied Technology Division. This Extended Warranty coverage applies only to the original owner and is non-transferable.

How Can I Get Service?

Bring the defective part and proof of purchase to your Raven dealer. If the dealer approves the warranty claim, the dealer will process the claim and send it to Raven Industries for final approval. The freight cost to Raven Industries will be the customer's responsibility. The Return Materials Authorization (RMA) number must appear on the box and all documentation (including proof of purchase) must be included inside the box to be sent to Raven Industries. In addition, the words "Extended Warranty" must appear on the box and all documentation if the failure is between 12 and 24 months from the retail sale.

What Will Raven Industries Do?

Upon confirmation of the product's registration for the Extended Warranty and the claim itself, Raven Industries will (at our discretion) repair or replace the defective product and pay for the standard return freight, regardless of the inbound shipping method. Expedited freight is available at the customer's expense.

What is Not Covered by the Extended Warranty?

Raven Industries will not assume any expense or liability for repairs made outside our facilities without written consent. Raven Industries is not responsible for damage to any associated equipment or products and will not be liable for loss of profit, labor, or other damages. Cables, hoses, software enhancements, and remanufactured items are not covered by this Extended Warranty. The obligation of this warranty is in lieu of all other warranties, expressed or implied, and no person or organization is authorized to assume any liability for Raven Industries.

Damages caused by normal wear and tear, misuse, abuse, neglect, accident, or improper installation and maintenance are not covered by this warranty.