

R A V E N

SmarTrax™ Installation Manual



John Deere 8X60/8X70 Series

Disclaimer

While every effort has been made to ensure the accuracy of this document, Raven Industries assumes no responsibility for omissions and errors. Nor is any liability assumed for damages resulting from the use of information contained herein.

Raven Industries shall not be responsible or liable for incidental or consequential damages or a loss of anticipated benefits or profits, work stoppage or loss, or impairment of data arising out of the use, or inability to use, this system or any of its components. Raven Industries shall not be held responsible for any modifications or repairs made outside our facilities, nor damages resulting from inadequate maintenance of this system.

As with all wireless and satellite signals, several factors may affect the availability and accuracy of wireless and satellite navigation and correction services (e.g. GPS, GNSS, SBAS, etc.). Therefore, Raven Industries cannot guarantee the accuracy, integrity, continuity, or availability of these services and cannot guarantee the ability to use Raven systems, or products used as components of systems, which rely upon the reception of these signals or availability of these services. Raven Industries accepts no responsibility for the use of any of these signals or services for other than the stated purpose.

| | | |
|------------------|---|-----------|
| Chapter 1 | <i>Important Safety Information</i> | 1 |
| | Hydraulic Safety | 2 |
| | Electrical Safety | 2 |
| Chapter 2 | <i>Introduction</i> | 3 |
| | Preparing for Installation | 3 |
| | Recommendations | 4 |
| | Point of Reference | 4 |
| | Updates | 4 |
| | Kit Contents | 5 |
| Chapter 3 | <i>Hydraulic System Installation</i> | 11 |
| | Install Fittings in the SmarTrax Valve | 12 |
| | Install Fittings in the Flow Switch | 13 |
| | Install Fittings in the Hydraulic Float Valve | 13 |
| | Mount the SmarTrax Valve | 14 |
| | Mount the Hydraulic Float Valve | 15 |
| | Mount the Flow Switch | 16 |
| | Install the Steering Control Hoses | 17 |
| | Install the Pressure Hose | 20 |
| | Install the Tank Hose | 21 |
| | Install the Left and Right Steering Hoses | 22 |
| | Hydraulic Diagram | 24 |
| Chapter 4 | <i>Cab Component Installation</i> | 25 |
| | Install the SmarTrax Node | 25 |
| | Mount the SmarTrax Node | 25 |
| | Node Mounting Locations | 26 |
| | Install the Foot Switch | 27 |
| | Install the Node Harness | 27 |
| | Install the Valve Harness | 28 |
| | Install the Chassis Cable - SmarTrax-Only Systems (If Applicable) | 31 |
| | Connect SmarTrax to an Existing Chassis Cable (If Applicable) | 31 |
| | System Diagrams | 32 |
| Chapter 5 | <i>Startup Procedures</i> | 37 |
| | Verify the SmarTrax System Installation | 37 |
| | Calibrate the SmarTrax System | 38 |

CHAPTER

1

*Important Safety
Information*

NOTICE

Read this manual and the operation and safety instructions included with your implement and/or controller carefully before installing the SmarTrax™ system.

- Follow all safety information presented within this manual.
- If you require assistance with any portion of the installation or service of your Raven equipment, contact your local Raven dealer for support.
- Follow all safety labels affixed to the SmarTrax system components. Be sure to keep safety labels in good condition and replace any missing or damaged labels. To obtain replacements for missing or damaged safety labels, contact your local Raven dealer.

When operating the machine after installing SmarTrax, observe the following safety measures:

- Be alert and aware of surroundings.
- Do not operate SmarTrax or any agricultural equipment while under the influence of alcohol or an illegal substance.
- Remain in the operator's position in the machine at all times when SmarTrax is engaged.
- Disable SmarTrax when exiting the operator's seat and machine.
- Do not drive the machine with SmarTrax enabled on any public road.
- Determine and remain a safe working distance from other individuals. The operator is responsible for disabling SmarTrax when the safe working distance has diminished.
- Ensure SmarTrax is disabled prior to starting any maintenance work on SmarTrax or the machine.

 **WARNING**

- When starting the machine for the first time after installing SmarTrax, be sure that all persons stand clear in case a hose has not been properly tightened.
- The machine must remain stationary and switched off during SmarTrax installation or maintenance.

 **CAUTION**

Hydraulic Safety

- Raven Industries recommends that appropriate protective equipment be worn at all times when working on the hydraulic system.
- Never attempt to open or work on a hydraulic system with the equipment running. Care should always be taken when opening a system that has been previously pressurized.
- When disconnecting the hydraulic hoses or purging is required, be aware that the hydraulic fluid may be extremely hot and under high pressure. Caution must be exercised.
- Any work performed on the hydraulic system must be done in accordance with the machine manufacturer's approved maintenance instructions.
- When installing SmarTrax hydraulics or performing diagnostics, maintenance, or routine service, ensure that precautions are taken to prevent any foreign material or contaminants from being introduced into the machine's hydraulic system. Objects or materials that are able to bypass the machine's hydraulic filtration system will reduce performance and possibly damage the SmarTrax valve.

Electrical Safety

- Always verify that the power leads are connected to the correct polarity as marked. Reversing the power leads could cause severe damage to the equipment.
- Ensure that the power cable is the last cable to be connected.

Congratulations on your purchase of the Steering Ready system! This system is designed to provide cutting-edge, hands-free steering of the machine via Global Positioning System (GPS) coordinates.

This manual applies to the following machines:

MAKE: John Deere

MODEL: 8X60/8X70

FIGURE 1. John Deere 8770



Preparing for Installation

Before installing the SmarTrax system, park the machine where the ground is level, clean, and dry. Turn off the machine and leave it turned off for the duration of the installation process. Bleed pressure from the hydraulic system by loosening the hydraulic fittings slowly, where applicable.

During the installation process, follow good safety practices. Be sure to carefully read the instructions in this manual as you complete the installation process.

Recommendations

Raven Industries recommends the following best practices when installing or operating the SmarTrax system for the first time, at the start of the season, or when moving the SmarTrax system to another machine:

- Install the GPS antenna in the recommended location. Refer to the following table for the machine-specific antenna mounting location.

Note: *If your machine is not listed, install the antenna on the front-center of the cab.*

| Machine Preset | Antenna X Position (left to right) | Antenna Y Position (from the rear wheel axle to the antenna position on the cab) | Antenna Z Position (ground to top of antenna) |
|----------------------|---------------------------------------|---|---|
| John Deere 8x60/8x70 | Centered | 8 ft. 6 in./2.59 m | 10 ft. 6 in./3.20 m |

- Ensure the machine's hydraulic filters have been recently changed and there are no issues with the machine's hydraulic system (e.g., pump issues, faulty hydraulic motors, fine metal deposits in the hydraulic hoses, etc.).
- Ensure the machine's hydraulic system is using fresh oil and debris is flushed from the hydraulic hoses, valves, and filters.

Raven Industries recommends the following best practices when installing the SmarTrax system:

- Use part numbers to identify the parts.
- Do not remove the plastic wrap from a part until it is necessary for installation.
- Do not remove plastic caps from a part until it is necessary for installation.

Point of Reference

The instructions in this manual assume that you are standing behind the machine, looking toward the cab.

Updates

Software and manual updates are available on the Raven Applied Technology website:

<http://www.ravenhelp.com>

At Raven Industries, we strive to make your experience with our products as rewarding as possible. One way to improve this experience is to provide us with feedback on this manual.

Your feedback will help shape the future of our product documentation and the overall service we provide. We appreciate the opportunity to see ourselves as our customers see us and are eager to gather ideas on how we have been helping or how we can do better.

To serve you best, please send an email with the following information to

techwriting@ravenind.com

- John Deere 8X60/8X70 Series SmarTrax™ Installation Manual
- Manual No. 016-5034-020 Rev. B
- Any comments or feedback (include chapter or page numbers if applicable).
- Let us know how long have you been using this or other Raven products.

We will not share your email or any information you provide with anyone else. Your feedback is valued and extremely important to us.

Thank you for your time.

2

Kit Contents

This section contains a list of the components that are included in the SmarTrax kit. Before beginning the SmarTrax installation, compare the items in the kit with the components on this list. If you have questions about the kit, contact your Raven dealer.

Note: The SmarTrax node (P/N 063-0173-228) is sold separately. Contact your local Raven dealer for ordering information.

TABLE 1. SmarTrax Installation Kit (P/N 117-5034-020)

| Picture | Item Description | Part Number | Qty. |
|---|--|--------------|------|
| Not Pictured | Manual - SmarTrax and SmartSteer Calibration & Operation | 016-0171-277 | 1 |
| Not Pictured | Manual - John Deere 8X60/8X70 SmarTrax Installation Manual | 016-5034-020 | 1 |
|  | Valve - Hydraulic Float | 063-0131-136 | 1 |

TABLE 1. SmarTrax Installation Kit (P/N 117-5034-020)

| Picture | Item Description | Part Number | Qty. |
|---|---|--------------|------|
|  | Valve - SmarTrax Hydraulic | 334-0003-089 | 1 |
|  | Switch - Flow | 334-0003-085 | 1 |
|  | Bracket - SmarTrax Hydraulic Valve Mounting | 107-0171-705 | 1 |
|  | Bracket - Hydraulic Float Valve Mounting | 107-0171-935 | 1 |
|  | Bracket - Node Mounting | 107-0171-947 | 1 |
|  | Bracket - Flow Switch Mounting | 107-0171-980 | 1 |
|  | Cable - Valve Harness | 115-4001-204 | 1 |
|  | Cable - Node Harness | 115-4001-205 | 1 |
|  | Assembly - SmarTrax Foot Switch | 063-0172-470 | 1 |
|  | Screw - #10-16 x 3/4" Zinc Self-Tapping | 310-1002-073 | 4 |
|  | Bolt - 5/16"-18 x 7/8" Hex | 311-0052-104 | 6 |

TABLE 1. SmarTrax Installation Kit (P/N 117-5034-020)

| Picture | Item Description | Part Number | Qty. |
|---|----------------------------------|--------------|------|
|  | Bolt - 5/16"-18 x 2-1/2" Hex | 311-0052-111 | 2 |
|  | Bolt - 5/16"-18 x 3-1/2" Hex | 311-0052-115 | 2 |
|  | Bolt - 3/8"-16 UNC x 1" Hex | 311-0054-105 | 2 |
|  | Nut - 3/8"-16 Zinc Flanged Lock | 312-1001-164 | 5 |
|  | Nut - 5/16"-18 Nylon Insert Lock | 312-4000-059 | 6 |
|  | Washer - 5/16" Split Lock | 313-1000-019 | 6 |
|  | Washer - 3/8" Flat | 313-2300-013 | 4 |

TABLE 2. Hydraulic Installation Kit (P/N 117-0199-134)

| Picture | Item Description | Part Number | Qty. |
|---|---|--------------|------|
|  | Fitting - -12 ORFS M/M/F Swivel Run Tee Adapter | 333-0012-029 | 1 |
|  | Fitting - -12 ORFS (F) to -8 ORFS (M) Reducer | 333-0012-030 | 1 |
|  | Fitting - -10 ORFS M/M/F Swivel Run Tee Adapter | 333-0012-031 | 3 |

TABLE 2. Hydraulic Installation Kit (P/N 117-0199-134)

| Picture | Item Description | Part Number | Qty. |
|---|--|--------------|------|
|  | Fitting - -4 SAE O-Ring (M) Internal Hex Plug | 333-0012-051 | 1 |
|  | Fitting - -8 ORFS M/F 90° Swivel Elbow | 333-0012-067 | 6 |
|  | Fitting - -8 ORFS (M) to -6 SAE O-Ring (M) Straight Adapter | 333-0012-082 | 6 |
|  | Fitting - -10 ORFS M/F 90° Swivel Elbow | 333-0012-096 | 2 |
|  | Fitting - -6 SAE O-Ring (M) Internal Hex Plug | 333-0012-104 | 2 |
|  | Fitting - -8 ORFS (M) to -8 SAE O-Ring (M) Straight Adapter | 333-0012-168 | 2 |
|  | Fitting - -8 ORFS (M) to -10 SAE O-Ring (M) Straight Adapter | 333-0012-304 | 2 |
|  | Fitting - -16 ORFS M/M/F Swivel Run Tee Adapter | 333-0012-321 | 1 |
|  | Fitting - -16 ORFS (F) to -8 ORFS (M) Reducer | 333-0012-322 | 1 |
|  | Hydraulic Hose - -10 ORFS (F) 90° to -8 ORFS (F) - 32" | 214-1000-746 | 1 |
|  | Hydraulic Hose - -10 ORFS (M) to -8 ORFS (F) - 35" | 214-1000-751 | 1 |

TABLE 2. Hydraulic Installation Kit (P/N 117-0199-134)

| Picture | Item Description | Part Number | Qty. |
|---|---|--------------|------|
|  | Hydraulic Hose - -8 ORFS (F) to -8 ORFS (F) - 72" | 214-1000-752 | 1 |
|  | Hydraulic Hose - -10 ORFS (F) to -8 ORFS (F) - 122" | 214-1000-753 | 1 |
|  | Hydraulic Hose - -10 ORFS (F) to -8 ORFS (F) - 106" | 214-1000-754 | 1 |
|  | Hydraulic Hose - -10 ORFS (F) to -8 ORFS (F) - 24" | 214-1000-755 | 1 |
|  | Hydraulic Hose - -8 ORFS (M) 90° to -6 ORFS (F) - 18" | 214-1001-015 | 1 |
|  | Hydraulic Hose - -8 ORFS (F) 90° to -6 ORFS (M) - 18" | 214-1001-016 | 1 |
|  | Hydraulic Hose - -8 ORFS (M) 90° to -6 ORFS (F) - 22" | 214-1001-017 | 1 |
|  | Hydraulic Hose - -8 ORFS (F) 90° to -6 ORFS (M) - 22" | 214-1001-018 | 1 |

CHAPTER

3

Hydraulic System Installation



WARNING

Hydraulics are under pressure. Care should always be taken with a system that has been pressurized.

Before beginning the SmarTrax hydraulic installation, turn off the machine and relieve pressure by turning the steering wheel left and right.

Never work on a hot machine. Always allow it to cool before performing diagnostics, maintenance, or routine service.

When disconnecting or purging hydraulic hoses, be aware that the hydraulic fluid within the machine's system may be extremely hot and under high pressure.

Tampering with hydraulic valves may cause serious injury or death, and will void the warranty.



CAUTION

When installing SmarTrax hydraulics or performing diagnostics, maintenance, or routine service, ensure precautions are taken to prevent any foreign material from being introduced into the machine's hydraulic system.

Objects or materials that are able to bypass the machine's hydraulic filtration system will reduce performance and possibly damage the SmarTrax hydraulic valve.

| | |
|---|---------------|
|  | NOTICE |
| <p>The appearance of the SmarTrax hydraulic valve may vary slightly from the images contained in this manual. However, the fittings, hose connections, and cable connections remain the same.</p> | |

Install Fittings in the SmarTrax Valve

Before mounting the SmarTrax valve (P/N 334-0003-089) on the machine, install the proper fittings in the valve. This prepares the valve for installation and simplifies the hose connection process later in the procedure.

FIGURE 1. Fittings Installed in SmarTrax Valve



| Fitting | Part Number | Port |
|--|--------------|-------------------|
| Fitting - -8 ORFS (M) to -10 SAE O-Ring (M) Straight Adapter | 333-0012-304 | A, B |
| Fitting - -8 ORFS (M) to -8 SAE O-Ring (M) Straight Adapter | 333-0012-168 | P, T |
| Fitting - -6 SAE O-Ring (M) Internal Hex Plug | 333-0012-104 | LSPV, LS STEER |
| Fitting - -4 SAE O-Ring (M) Internal Hex Plug | 333-0012-051 | PS |

Install Fittings in the Flow Switch

FIGURE 2. Fittings Installed in Flow Switch



1. Remove the existing hydraulic fittings from Ports A1 and B3 of the flow switch (P/N 334-0003-085).

Note: The existing hydraulic fittings are not used in the SmarTrax system.

2. Remove the pressure transducer from Port B1.
3. Remove the plugs from Ports A2 and B2 and install them in Ports A1 and B1.
4. Install the pressure transducer in Port B3.
5. Install -8 ORFS (M) to -6 SAE O-ring (M) straight adapter fittings (P/N 333-0012-082) in Ports A2 and B2 of the flow switch.

Install Fittings in the Hydraulic Float Valve

FIGURE 3. Fittings Installed in Hydraulic Float Valve



1. Remove the hydraulic port plugs from the Ports A1, A2, B1 and B2 of the hydraulic float valve (P/N 063-0131-136).
2. Install -8 ORFS (M) to -6 SAE O-ring (M) straight adapter fittings (P/N 333-0012-082) in the open ports.

Mount the SmarTrax Valve

FIGURE 4. SmarTrax Valve Mounting Location



1. Identify the valve mounting location on the left side of the machine.
2. Remove the side panels covering the engine.

FIGURE 5. SmarTrax Valve Installed



3. Mount the SmarTrax valve (P/N 334-0003-089) on the valve mounting bracket using four 5/16"-18 x 7/8" hex bolts (P/N 311-0052-104) and four 5/16" lock washers (P/N 313-1000-019).
4. Secure the hydraulic valve mounting bracket (P/N 107-0171-705) to the machine's frame using two 3/8"-16 UNC x 1" hex bolts (P/N 311-0054-105), four 3/8" flat washers (P/N 313-2300-013), and two 3/8"-16 zinc flanged lock nuts (P/N 312-1001-164).


Mount the Hydraulic Float Valve

FIGURE 6. Machine's Steering Control Valve Location



1. Locate the machine's steering control valve on the right side of the machine, in front of the cab and below the exhaust.

FIGURE 7. Steering Control Valve Bolts to be Removed



2. Remove the existing bolts installed on the machine's steering control valve.

FIGURE 8. Float Valve Installed



3. Position the hydraulic float valve (P/N 063-0131-136) on the end of the float valve mounting bracket (P/N 107-0171-935) with Ports A2 and B1 facing up.
4. Secure the float valve to the mounting bracket using 5/16"-18 x 3-1/2" hex bolts (P/N 311-0052-115) and two 5/16" lock nuts (P/N 312-4000-059).
5. Install the float valve mounting bracket on the machine's steering control valve using the machine's existing bolts that were removed in step 2.

Mount the Flow Switch

FIGURE 9. Flow Switch Installed




1. Using the flow switch valve mounting bracket (P/N 107-0171-980) as a template, drill 3/8" holes in the frame channel to the right of the float valve (P/N 063-0131-136) mounting location.
2. Secure the flow switch (P/N 334-0003-085) to the flow switch mounting bracket using two 5/16"-18 x 2-1/2" hex bolts (P/N 311-0052-111), two 5/16" lock washers (P/N 313-1000-019), and two 5/16" lock nuts (P/N 312-4000-059).

Note: The flow switch should be positioned so that the pressure transducers installed in Ports A3 and B3 point down.

3. Mount the flow switch mounting bracket to the frame channel using two 5/16"-18 x 7/8" hex bolts (P/N 311-0052-104) and two 5/16"-18 nylon insert lock nuts (P/N 312-4000-059).

Install the Steering Control Hoses

FIGURE 10. Machine's Steering Valve Configuration



1. Disconnect the hose from the front left feed back port of the machine's steering valve.
2. Install the male end of the supplied hydraulic hose (P/N 214-1001-016) on the machine's hose.

FIGURE 11. Hydraulic Hose Connected to Hydraulic Float Valve



3. Connect the 90° end of the installed hydraulic hose to the fitting installed in Port A2 of the hydraulic float valve (P/N 063-0131-136).
4. Install the straight end of the supplied hydraulic hose (P/N 214-1001-015) on the open front left feed port of the machine's steering valve.
5. Connect the 90° end of the installed hydraulic hose to the fitting installed in Port A1 of the hydraulic float valve.
6. Disconnect the hose from the front right feed back port of the machine's steering valve.
7. Install the male end of the supplied hydraulic hose (P/N 214-1001-018) on the machine's hose.

FIGURE 12. Hydraulic Hose Connected to Hydraulic Float Valve



8. Connect the 90° end of the installed hydraulic hose to the fitting installed in Port B2 of the hydraulic float valve.
9. Install the straight end of the supplied hydraulic hose (P/N 214-1001-017) on the open front right feed port of the machine's steering valve.

FIGURE 13. Hydraulic Hose Connected to Hydraulic Float Valve



10. Connect the 90° end of the installed hydraulic hose to the fitting installed in Port B1 of the hydraulic float valve.

FIGURE 14. Left Steering Port on Machine's Steering Valve



11. Disconnect the steering hose from the rear left port of the machine's steering valve.
12. Install the male end of the supplied hydraulic hose (P/N 214-1000-751) on the machine's hose.

FIGURE 15. Steering Hose Installed on Flow Switch



13. Connect the other end of the installed hydraulic hose to the fitting installed in Port A2 of the flow switch (P/N 334-0003-085).

FIGURE 16. Steering Port on Machine's Steering Valve



14. Install the 90° end of the supplied hydraulic hose (P/N 214-1000-746) in the open port of the steering valve.
15. Connect the straight end of the installed hydraulic hose to the fitting installed in Port B2 of the flow switch.

Install the Pressure Hose

FIGURE 17. Pressure Hose on Steering Valve



1. Disconnect the machine's pressure hose from the steering valve.

FIGURE 18. Pressure Hose Installed on Steering Valve



2. Install a -10 ORFS M/M/F swivel run tee adapter fitting (P/N 333-0012-031) in the open pressure port.
3. Connect the machine's pressure hose to the opposite end of the installed tee fitting.
4. Install the -10 ORFS end of the supplied hydraulic hose (P/N 214-1000-755) on the opposite end of the installed tee fitting.
5. Connect the -8 ORFS end of the installed hydraulic hose to the fitting installed in Port P of the SmarTrax valve (P/N 334-0003-089).


Install the Tank Hose

FIGURE 19. Machine's Tank Connection



1. Locate hydraulic return filter on the inside of the frame rail, below the engine.
2. Disconnect the tank hose from the filter.

FIGURE 20. Tank Hose Installed




3. Install the appropriate fittings in the open filter port.
 - **Model 8870 Only** - Install a -16 ORFS M/M/F swivel run tee adapter fitting (P/N 333-0012-321) in the open port, then install a -16 ORFS (M) to -8 ORFS (M) reducer fitting (P/N 333-0012-322) on the 90° end of the tee fitting.
 - **All Other Models** - Install a -12 ORFS M/M/F swivel run tee adapter fitting (P/N 333-0012-029) in the open port, then install a -12 ORFS (M) TO -8 ORFS (M) reducer fitting (P/N 333-0012-030) on the 90° end of the tee fitting.
4. Connect the machine's tank hose to the end of the installed tee.
5. Install one end of the supplied hydraulic hose (P/N 214-1000-752) on the reducer fitting installed on the 90° end of the installed tee fitting.

6. Connect the other end of the installed hydraulic hose to the fitting installed in Port T of the SmarTrax valve (P/N 334-0003-089).

Install the Left and Right Steering Hoses


1. Locate the steering cylinder on the right side of the machine.

FIGURE 21. Left Steering Hoses Installed on Steering Cylinder



2. Disconnect the left steering hose from the tee fitting in the rod-end of the steering cylinder.
3. Install a -10 ORFS M/M/F swivel run tee adapter fitting (P/N 333-0012-031) on the machine's tee fitting.
4. Connect the machine's left steering hose to the opposite end of the installed tee fitting.
5. Install the -10 ORFS end of the supplied hydraulic hose (P/N 214-1000-753) on the 90° end of the installed tee fitting.
6. Connect the -8 ORFS end of the installed hydraulic hose to the fitting installed in Port A of the SmarTrax valve (P/N 334-0003-089).


FIGURE 22. Right Hoses Installed on Steering Cylinder



7. Disconnect the right steering hose from the base-end of the steering cylinder.


8. Install a -10 ORFS M/M/F swivel run tee adapter fitting (P/N 333-0012-031) in the open port of the steering cylinder.
9. Connect the machine's right steering hose to the opposite end of the installed tee fitting.
10. Install the -10 ORFS end of the supplied hydraulic hose (P/N 214-1000-754) on the 90° end of the installed tee fitting.
11. Connect the -8 ORFS end of the installed hydraulic hose to the fitting installed in Port B of the SmarTrax valve.

Hydraulic Diagram



BEFORE

AFTER



Install the SmarTrax Node

Note: The SmarTrax node (P/N 063-0173-228) is sold separately. Contact your local Raven dealer for ordering information.

Mount the SmarTrax Node

1. Identify the SmarTrax node mounting location next to the operator's seat in the right side of the cab.

FIGURE 1. Node Installed on Mounting Bracket



2. Install the node on the node mounting bracket (P/N 107-0171-947) using three 3/8"-16 flanged lock nuts (P/N 312-1001-167).

FIGURE 2. SmarTrax MD Node Installed




Note: The forward vehicle direction is 3 in the pictured node orientation.

- Secure the node mounting bracket to the cab floor using four #10-16 x 3/4" self-tapping screws (P/N 310-1002-073), positioning the bracket so that the node connectors point toward the front of the machine.

Node Mounting Locations

FIGURE 3. Node Mounting



When choosing the location for the SmarTrax node, consider the following points:

- Mount the SmarTrax node inside the machine's cab on a flat, level surface for proper performance and cable connection.
- One of the six numbered direction arrows on the node must be oriented in the direction of forward vehicle travel, one arrow pointing straight up, and two of the arrows parallel to the ground.

Note: Make a note of the number of the arrow that is oriented in the direction of forward vehicle travel. This number will be needed during the SmarTrax calibration process.

- The node mounting location must not create tripping hazards.
- Mount the node in a location where it will not be kicked or jarred during normal equipment operation.
- The location must allow cable routing to avoid crimping or damaging the cables or the node connections.

- Securely fasten the node using bolts or screws through at least two of the three mounting holes. When mounted properly, the node should not become loose or rotate.

Install the Foot Switch

FIGURE 4. Foot Switch Installed



1. Select a suitable location for the foot switch (P/N 063-0172-470) to be installed.

Note: *The foot switch should be installed in a location where the operator has easy access to it and is able to fully press the pedal.*

2. Using the holes in the foot switch as a template, drill holes in the floor of the cab.
3. Secure the foot switch connector to the floor by installing the supplied screws in each of the mounting holes.
4. Route the foot switch cable connector toward the node mounting location.

Install the Node Harness

FIGURE 5. Node Harness Connected to Node



1. Insert the two large, rectangular connectors of the node harness (P/N 115-4001-205) into the correct ports of the node.
2. Tighten the bolts on the harness connectors to secure the connections.
3. Locate the ENABLE connector on the node harness and connect it to the foot switch cable connector.

Install the Valve Harness

FIGURE 6. Valve Harness Connected to Node Harness



1. Connect the 12-pin Deutsch connector on the valve harness (P/N 115-4001-204) to the mating 12-pin connector on the node harness (P/N 115-4001-205)

FIGURE 7. Valve Harness Connected to Flow Switch



2. Plug the 3-pin PSI 1 and PSI 2 connectors from the valve harness into the pressure transducers installed on the flow switch.

Note: *These connections can be plugged into either transducer.*

FIGURE 8. PVES Connection



3. Plug the PVES connector from the valve harness into the open 4-pin port of the SmarTrax valve (P/N 334-0003-089).


FIGURE 9. AUX VALVE Connections



4. Connect the AUX VALVE 1 connector to the coil connector above the B ports of the hydraulic float valve (P/N 063-0131-136).
5. Connect the AUX VALVE 2 connector to the coil connector above the A ports of the hydraulic float valve.



FIGURE 10. Harness Wiring Diagram



Install the Chassis Cable - SmarTrax-Only Systems (If Applicable)

If the machine does not contain an existing chassis power system (such as AutoBoom, product control, et.), it is necessary to install the chassis power cable to operate the SmarTrax system. If a CAN system already exists on the machine, refer to *Connect SmarTrax to an Existing Chassis Cable (If Applicable)* below to connect power to the SmarTrax system.

Note: *The chassis cable is sold separately. Contact your local Raven dealer for ordering information.*

1. Locate the SmarTrax chassis cable (P/N 115-4001-085).
2. Connect the TO SMARTRAX NODE connector from the chassis cable to the round 16-pin connector on the node harness (P/N 115-4001-205).
3. Connect the TO CONSOLE CABLE connector to the Raven console cable.
4. Install a terminator (P/N 063-0172-369) on the CAN cable connector.
5. Loop and tie-off the REMOTE SWITCH cable connection, securing it with plastic cable ties as necessary.

Note: *The REMOTE SWITCH connector is not used in the SmarTrax system. Ensure the cable is secured away from moving parts and heat sources.*

6. Connect the ring terminals to the battery.

Note: *The positive connectors are fused.*

Connect SmarTrax to an Existing Chassis Cable (If Applicable)

Note: *The SmarTrax interface tee is sold separately. Contact your local Raven dealer for ordering information.*

1. Locate and disconnect the connection between the Raven console cable and chassis cable on the machine's existing CAN system.
2. Install the SmarTrax interface tee cable (P/N 115-4001-070 or 115-4001-071) between the chassis and Raven console harness.
3. Connect the SmarTrax node harness (P/N 115-4001-205) to the remaining SmarTrax interface tee.

**WARNING**

When starting the machine for the first time after installing SmarTrax, be sure that all persons stand clear in case a hose has not been properly tightened.

**WARNING**

Do not use hands to check for leaks. Hydraulic fluid under pressure can penetrate the skin and cause serious injury or death.

Verify the SmarTrax System Installation

1. Turn on the machine.
2. Double-check all fittings and hose connections to ensure that:
 - Hoses are not rubbing on or interfering with moving parts.
 - Hydraulic fluid is not leaking from the system.
3. Turn the machine's wheels fully from side to side repeatedly to remove air from the hydraulic system.

Note: *During the SmarTrax system installation, whenever the hydraulic system is purged for maintenance, or when fittings are loosened or disconnected, air is introduced into the lines of the hydraulic system. If air pockets are present, the wheels may not move consistently when the steering wheel is turned.*

4. Continue turning the wheels until they move steadily and smoothly when the steering wheel is turned.

5. Access the System Diagnostic screen by selecting the MACHINE TEST option on the Machine Type screen and turn the wheels using the Raven console.

Note: *If there are issues with the SmarTrax system, turn off the machine and correct them immediately. For additional assistance, refer to the SmarTrax and SmartSteer Calibration & Operation Manual (P/N 016-0171-277) or contact your local Raven dealer.*

Calibrate the SmarTrax System

Refer to the SmarTrax and SmartSteer Calibration & Operation Manual (P/N 016-0171-277) for instructions on calibrating the SmarTrax system, adjusting system settings, and system operation.

C

Cab Component Installation 25

- Connecting SmarTrax to an Existing Chassis Cable 31
- Installing the Chassis Cable - SmarTrax-Only Systems 31
- Installing the Foot Switch 27
- Installing the Node Harness 27
- Installing the SmarTrax Node 25
 - Mounting the SmarTrax Node 25
 - Node Mounting Locations 26
- Installing the Valve Harness 28
- System Diagrams 32

H

Hydraulic System Installation 11

- Hydraulic Diagram 23
- Installing Fittings in the Flow Switch 13
- Installing Fittings in the Hydraulic Float Valve 13
- Installing Fittings in the SmarTrax Valve 12
- Installing the Left and Right Steering Hoses 22
- Installing the Pressure Hose 20
- Installing the Steering Control Hoses 17
- Installing the Tank Hose 21
- Mounting the Flow Switch 16
- Mounting the Hydraulic Float Valve 15
- Mounting the SmarTrax Valve 14

I

Important Safety Information

- Electrical Safety 2
- Hydraulic Safety 2

Introduction

- Kit Contents 5
- Preparing for Installation 3
 - Point of Reference 4
 - Recommendations 4

K

Kit Contents 5

S

Startup Procedures

- Calibrating the SmarTrax System 34
- Verifying the SmarTrax System Installation 33

RAVEN

Limited Warranty

What Does this Warranty Cover?

This warranty covers all defects in workmanship or materials in your Raven Applied Technology Division product under normal use, maintenance, and service when used for intended purpose.

How Long is the Coverage Period?

Raven Applied Technology products are covered by this warranty for 12 months from the date of retail sale. In no case will the Limited Warranty period exceed 24 months from the date the product was issued by Raven Industries Applied Technology Division. This warranty coverage applies only to the original owner and is non-transferable.

How Can I Get Service?

Bring the defective part and proof of purchase to your Raven dealer. If the dealer approves the warranty claim, the dealer will process the claim and send it to Raven Industries for final approval. The freight cost to Raven Industries will be the customer's responsibility. The Return Materials Authorization (RMA) number must appear on the box and all documentation (including proof of purchase) must be included inside the box to be sent to Raven Industries.

What Will Raven Industries Do?

Upon confirmation of the warranty claim, Raven Industries will (at our discretion) repair or replace the defective product and pay for the standard return freight, regardless of the inbound shipping method. Expedited freight is available at the customer's expense.

What is not Covered by this Warranty?

Raven Industries will not assume any expense or liability for repairs made outside our facilities without written consent. Raven Industries is not responsible for damage to any associated equipment or products and will not be liable for loss of profit, labor, or other damages. The obligation of this warranty is in lieu of all other warranties, expressed or implied, and no person or organization is authorized to assume any liability for Raven Industries.

Damages caused by normal wear and tear, misuse, abuse, neglect, accident, or improper installation and maintenance are not covered by this warranty.



Extended Warranty

What Does this Warranty Cover?

This warranty covers all defects in workmanship or materials in your Raven Applied Technology Division product under normal use, maintenance, and service when used for intended purpose.

Do I Need to Register My Product to Qualify for the Extended Warranty?

Yes. Products/systems must be registered within 30 days of retail sale to receive coverage under the Extended Warranty. If the component does not have a serial tag, the kit it came in must be registered instead.

Where Can I Register My Product for the Extended Warranty?

To register, go online to www.ravenhelp.com and select Product Registration.

How Long is the Extended Warranty Coverage Period?

Raven Applied Technology products that have been registered online are covered for an additional 12 months beyond the Limited Warranty for a total coverage period of 24 months from the date of retail sale. In no case will the Extended Warranty period exceed 36 months from the date the product was issued by Raven Industries Applied Technology Division. This Extended Warranty coverage applies only to the original owner and is non-transferable.

How Can I Get Service?

Bring the defective part and proof of purchase to your Raven dealer. If the dealer approves the warranty claim, the dealer will process the claim and send it to Raven Industries for final approval. The freight cost to Raven Industries will be the customer's responsibility. The Return Materials Authorization (RMA) number must appear on the box and all documentation (including proof of purchase) must be included inside the box to be sent to Raven Industries. In addition, the words "Extended Warranty" must appear on the box and all documentation if the failure is between 12 and 24 months from the retail sale.

What Will Raven Industries Do?

Upon confirmation of the product's registration for the Extended Warranty and the claim itself, Raven Industries will (at our discretion) repair or replace the defective product and pay for the standard return freight, regardless of the inbound shipping method. Expedited freight is available at the customer's expense.

What is Not Covered by the Extended Warranty?

Raven Industries will not assume any expense or liability for repairs made outside our facilities without written consent. Raven Industries is not responsible for damage to any associated equipment or products and will not be liable for loss of profit, labor, or other damages. Cables, hoses, software enhancements, and remanufactured items are not covered by this Extended Warranty. The obligation of this warranty is in lieu of all other warranties, expressed or implied, and no person or organization is authorized to assume any liability for Raven Industries.

Damages caused by normal wear and tear, misuse, abuse, neglect, accident, or improper installation and maintenance are not covered by this warranty.

RAVEN

John Deere 8X60/8X70 Series
SmarTrax™ Installation Manual
(P/N 016-5034-020 Rev B 03/14 E22972)



Raven Industries

Applied Technology Division
P.O. Box 5107
Sioux Falls, SD 57117-5107
www.ravenprecision.com

Toll Free (U.S. and Canada): (800)-243-5435
or Outside the U.S. :1 605-575-0722
Fax: 605-331-0426
www.ravenhelp.com

Notice: This document and the information provided are the property of Raven Industries, Inc. and may only be used as authorized by Raven Industries, Inc. All rights reserved under copyright laws.

©Raven Industries, Inc. 2013, 2014