

System Tuning


Use this screen to adjust the performance when acquiring the line. Can be adjusted between 1 and 50. The higher the number, the more aggressive it will be.



These are the only 2 screens you will use to tune the SmarTrax system.



Use this screen to adjust the on-line performance. Can be adjusted between 1 and 50. The higher the number, the more sensitive it will be.




Line Acquire Tuning

If the machine is constantly overshooting the line as in Case 1, decrease your Aggressiveness Line Acquire number.

If the machine takes too long to acquire the line as in Case 2, increase your Aggressiveness Line Acquire number.

Important: DO NOT adjust any other calibration number to tune the machine. If you cannot tune the machine with the 2 screens above, go back and verify that all of the calibration numbers you entered are correct.



OnLine Tuning

If the machine constantly weaves around the line as in Case 1, decrease your Sensitivity OnLine number.

If the machine has a very slow weave as in Case 2, increase your Sensitivity OnLine number.

Troubleshooting

This screen is located under the Status Menu



The foot switch is activated when "FOOT SWITCH" appears in capital letters.



The pressure switch is activated when "STEER SWITCH" appears in capital letters.



You can manually steer using the left or right arrow button.

This is the current reading from the steering sensor

SmarTrax

Straight shot to easy steering

Initial System Start-Up

- Upon initial start-up, the SmarTrax controller will prompt you to answer "Yes" or "No" to having read and understand the Operation Manual. To continue with start-up, you must answer "Yes" by pressing the Right arrow button.
- Press the Left or Right arrow to select the Sensor Type you are using (SPS or Yaw). Once the correct type is displayed, press the Down arrow.
Yaw: If "Yaw" is selected as the Sensor Type, refer to the instructions in blue to help set up your SmarTrax controller.
- Press the Left or Right arrow to select the machine type you are using (Articulated, Front Steered, Rear Steered, Track, or a specific Tune Set). Once the correct type is selected, press the Down arrow.
Yaw: A machine specific tune set must be selected as the Machine Type.
- Press the Left or Right arrow to select the Driving Device (Hydraulic or QuickTrax). Once the correct device is selected, press the Down arrow.
Yaw: If a QuickTrax tune set is available, you may select either "QuickTrax" or "Hydraulic". Otherwise, this setting will be locked to "Hydraulic" if "Yaw" was selected in Step 2.
- Turn the steering wheel to verify that the pressure switch is working properly. The words "steer switch" will display in capital letters and a new screen will display when the console detects a change from the steer switch.
- Press the foot switch to ensure that it is connected properly. The words, "foot switch" will display in capital letters and a new screen will display when the console detects a change from the foot switch.
- Yaw: Skip to Step 12.* Turn the wheels all the way to the left. Press the Right arrow to save the displayed value. The next screen will display.
Important: The number must be greater than 10, but less than 1000.
- Turn the wheels to the center. Press the Right arrow to save the displayed value. The next screen will display.
Important: The number must be at least 100 more than the right number.
- Turn the wheels all the way to the right. Press the Right arrow to save the displayed value. The next screen will display.
Important: The number must be greater than 10, but less than 1000 and must be at least 100 more than the center number.
- Hold the Left arrow button. The console will verify that the wheels turn in that direction. The next screen will display.
- Hold the Right arrow button. The console will verify that the wheels turn in that direction. The next screen will display.
- If SPS was selected as the Sensor Type in Step 2, skip this step. **Make sure the vehicle is at a complete stop before pressing the Right arrow button to Zero the Yaw Rate. Press the Down arrow to proceed to the next step.**
- Press the Left or Right arrow to select the distance units (Feet, Decimal, Feet-Inches, or Metric). Press the Down arrow to lock in your selection.
Yaw: Skip to Step 16.

Quick Start Guide

P/N 016-0159-982 Rev F

- Measure and enter the correct wheel base for your machine. Use the Left or Right arrow to enter the value. Press the Down arrow to lock in your measurement.
Note: If a Tune Set was selected in Step 3, Skip to Step 16.
Note: Entering an inaccurate number will cause the system to operate incorrectly. See the SmarTrax manual for information on measuring the wheel base correctly.
- Measure and enter the correct minimum turn radius for your machine. Use the Left or Right arrow to enter the value. Press the Down arrow to lock in your measurement.
Note: Entering an inaccurate number will cause the system to operate incorrectly. See the SmarTrax manual to measure the minimum turn radius correctly.
- Measure the distance between the rear axle and the GPS antenna. Use the Left or Right arrow to enter the number. Press the Down arrow to lock in your measurement.
Note: Entering an inaccurate number will cause the system to operate incorrectly.
Yaw: If no Tilt Sensor or GPS Enhancer is installed, initial setup is complete.
- Measure and enter the height of the GPS antenna above ground. Use the Left or Right arrow to enter the value. Press the Down arrow to lock in your measurement.
- Turn the machine up to the working RPM. Move to an open space. Drive ahead slowly and press the foot switch to begin calibration.
- The "Calibrating" screen will display and the wheels should be turning. If the pressure switch is triggered, calibration will stop and will need to be re-started. The Home screen will display when calibration is complete.

Raven Industries
Flow Controls Division
P.O. Box 5107
Sioux Falls, SD 57117-5107

RAVEN

PRECISION Solutions

Toll Free 800-243-5435
Fax 605-331-0426
www.ravenprecision.com
fcdinfo@ravenind.com

SmarTrax Controller Menu Structure

Below you will find the menu structure for the SmarTrax controller. When you power up and after the initial start-up and calibration, the Home screen will display after pressing the right arrow.

Home Screen


Press and hold the Up and Down arrows simultaneously to return to the Home screen at any time.



Press and hold the Left and Right arrows simultaneously to go to the Zero Yaw Rate screen if 'Yaw' was selected as the Sensor Type.



1 - 50 See the System Tuning section for more information.



1 - 50 See the System Tuning section for more information.



press and hold to enter Advanced Menu

Vehicle Setup



Displays the selected Machine Type (Front steered, Rear steered, Articulated, Track, or a specific machine Tune Set).



Displays the Driving Device selection (Hydraulic or QuickTrax).



Displays the selected Sensor Type (SPS or Yaw).



follow the menu structure for the selected Sensor Type



While the machine is at a complete stop, press the Right arrow button to re-zero the Yaw Rate



Current SPS Count Turn the wheel to the left. Press the Right arrow to calibrate.



Current SPS Count Turn the wheel to the center. Press the Right arrow to calibrate.



Current SPS Count Turn the wheel to the right. Press the Right arrow to calibrate.



Refer to the machine's owners manual or the SmarTrax Operation Manual for information on measuring the Wheel Base.



Refer to the machine's owners manual or the SmarTrax Operation Manual for information on measuring the Minimum Turning Radius.



Refer to the SmarTrax Operation Manual for help with programming the antenna position.




Sets the length of pulse from the pressure switch needed to disengage the system. Press the Left or Right arrow to set this value.



GPS Enhancer *



Sets the height from the ground to the GPS Antenna



Roll Heading GPS Enhancer Heading



This is the correct setting for this screen




Displays the enhancer software version



Press the Right arrow to reset the enhancer



Press the Right arrow to switch select Active or Bypassed mode for the enhancer



* This advanced menu screen is only available if you are using a GPS enhancer.

** Holding the Left and Right arrows while at the Home screen will send a forward command to the enhancer.

TM-1 Tilt Sensor *



Angle of sensor Temperature of the tilt sensor



Press the Right arrow to reset the sensor to zero. Be sure the machine is on level ground before pressing the Right arrow.



Sets the height from the ground to the GPS Antenna.



Refers to the tilt compensation speed. Press the Right arrow to select from the available settings (Off, Slow, Normal, or Fast).



* This advanced menu screen is only available if you have a tilt sensor installed.

Advanced Menu

Console Configuration



Press the Right arrow to turn the back light On or Off.



Press the Left or Right arrow to adjust the LCD Contrast.



Sets the displayed units. Press the Right arrow to select from Feet-Decimal, Feet-Inches, or Metric.




Sets the speed units. Press the Right arrow to select from Mph or Km/h.



Sets the GPS output on the programming port. Press the Right arrow to choose On or Off.



Toggles the sound when a key is pressed. Press the right arrow to select from On or Off.



Displays the serial number of the controller.



This screen locks the calibration values that are entered for the machine. Press the Right arrow to select On and lock the settings or Off to allow settings to be modified.



Status Menu Configuration



Calculated receiver speed. Cannot be adjusted. Displays the actual receiver speed. .2 = 5 Hz .1 = 10 Hz



Displays error logs 1-10. Press the Right arrow to view errors.



Displays the GPS date and time.




If 'Yaw' is selected as the Sensor Type, the current Yaw Rate of the sensor.



Displays the percentage of time verses inches for the last hour that the system has been engaged.



Average speed and error over the last 5 minutes that the system has been engaged.



Return to Home screen