

Envizio™ Software Update Details

Version: 2.0

Release Date: 12/01/06

Please note that it is recommended to use a USB storage device without U3 technology (also known as "U3 smart drives") as it could cause downloading or job storage issues.

Download and Installation Instructions

All the configuration settings in the Envizio will be set to default so please write down all settings prior to installing the update. These settings will need to be entered again after updating the software.

Jobs created on Envizio versions 1.01 or 1.02 are not compatible with this version of software. These jobs must be removed (download to USB memory stick if you wish to keep a copy of these jobs) from the Envizio prior to updating the software.

Your current Envizio system can be upgraded to the Envizio Plus system, which allows AutoBoom and AccuBoom capabilities. For more information, please contact your Raven Distributor.

This function allows you to update the software for the Envizio Plus system. This may be done whenever there is a new software version available. You must have the software update stored on a USB storage device prior to beginning the update. To do this, copy or download the update to the root directory of the USB storage device. NOTE: The file is in a zip format and needs to be uncompressed before loading it onto the USB drive.

For questions about storing the new software on your USB storage device, contact your Raven distributor or Raven Technical Service Representative.

Connect the USB storage device to one of the Envizio Plus USB ports, located on the right-hand side of your Envizio Plus console.

From the 'Configuration Page 1' screen, touch the 'Next' button. From the 'Configuration Page 2' screen, touch the 'Next' button. The 'Configuration Page 3' displays.

If the USB storage device is being detected, you will see 'Installer: \Hard Disk\installer.exe', beside the 'Install Program Update' button. Touch the 'Install Program Update' button if you would like to update the software.

Release Notes

Ability to change WAAS PRN selection on Raven receivers.

AccuBoom operational enhancements.

Fix for Accuboom Boom Selection.

Boom section width can now be set to zero.