

Planter & Seeder Controls

OmniRow®

Replacement Parts

Black Nylon Hex Rod, 7/8" x 14.5"	1-211-0002-001
Cable, Adapter, Bin/Air, Pressure/Vac	1-115-3001-123
Cable, OmniRow Level 1 CAN Node	1-115-3001-045
Cable, OmniRow Level 2 CAN Node	1-115-3001-065
Cable, Planter/Seeder Auxiliary Control Node	1-115-3001-109
Cable, Planter/Seeder Auxiliary Monitoring Node	1-115-3001-108
Kit, Remote Section Control	1-117-0171-224
Magnetic Mount Proximity Switch Kit	1-117-0171-298
OmniMotor Hydraulic Motor Side Cover	1-117-3001-089
OmniRow Hydraulic Motor	1-416-8000-001
OmniRow Hydraulic Motor Seal Kit	1-117-3001-019
OmniRow Hydraulic Motor Sensor Connector Kit	1-117-3001-020
OmniRow Hydraulic Motor Speed Sensor	1-422-0000-101
OmniRow Hydraulic PWM Valve/Body	1-063-0131-140
OmniRow Planter Node	1-063-3001-001
Planter and Seeder Auxiliary Control Node	1-063-3001-006
Planter and Seeder Auxiliary Monitoring Node	1-063-3001-005
Pressure Reducing Manifold, High Flow	1-063-0131-142
Pressure Reducing Manifold, Low Flow	1-063-0131-141
Seed Tube Sensor, High Rate	1-422-0000-100
Vacuum and Pressure Sensor (0-5 PSI)	1-063-0173-424

Planter Auxiliary Monitoring & Product Control

Key, Planter and Seeder Auxiliary Control Node	1-077-0180-071
Kit, Planter Auxiliary Control Node	1-117-3001-048
Kit, Planter Auxiliary Monitoring Node	1-117-3001-047
Node, CAN Single Product Control	1-063-0173-304
Single Product Node Mounting Kit	1-117-0171-299

Planter Auxiliary Sensors

Air Pressure Transducer (0-150PSI)	1-422-0000-113
Bin Level Sensor	1-412-6000-008
Hydraulic Pressure Transducer (0-3000 PSI)	1-422-0000-093
Liquid Pressure Transducer (0 – 250 PSI)	1-422-0000-090
Vacuum and Pressure Sensor Kit (0-5 PSI)	1-117-3001-045