

# DCS 300 REPLACEMENT PARTS

ITEM	DESCRIPTION	RAVEN PART #
1	Faceplate Assembly (French) Faceplate Assembly (English)	063-0171-274 063-0171-414
2	P.C. Assembly Display	064-0159-535
3	Threaded Spacer	305-2540-625
4	P.C. Assembly Processor	064-0159-577
5	Connector Plate Assembly	063-0171-267
6	Screw, 6-32 UNC x 5/16 in.	311-0004-008
7	Enclosure w/ Inserts	063-0171-135
8	Screw, 6-32 UNC	321-0000-085
9	Mounting Bracket	107-0159-007
10	Knob	309-1000-006
11	Washer, Lock Internal	313-3000-007
12	Hex Nut	312-1001-014
13	Power Switch	412-2011-037
14	Alarm Light	019-0159-132
15	DCS 300 Console (French) DCS 300 Console (English)	063-0171-273 063-0171-413
16	Key Switch	412-8000-003
17	Key	412-8000-004
18	Cable, Console Control	115-0159-706

