

DCS 400 REPLACEMENT PARTS

ITEM	DESCRIPTION	RAVEN PART #
1	Master Switch	412-2011-046
2	Boom Switch	412-2011-047
3	Rate 1-6/Master Switch	412-1001-004
4	Adj. Switch	412-2011-049
5	Power Switch	412-2011-048
6	Blast Button	412-2011-072
7	Mounting Bracket	106-0159-437
8	Mounting Knob	106-0159-438
9	Fuse Holder	510-2001-018
10	Fuse, 15 Amp.	510-1003-003
11	Console Control Cable	115-0159-418
	Console Control Cable (Turf)	115-0159-509
12	Flow Control Cable (6 ft.)	115-0159-404
	Flow Control Cable (12 ft.)	115-0159-405
13	Flow Meter Cable Ext.(6 ft.)	115-0159-016
	Flow Meter Cable Ext.(12 ft.)	115-0159-017
14	Flow Ext. Cable (12 ft.)	115-0159-409
	Flow Ext. Cable (24 ft.)	115-0159-414
15	Switch Cover	063-0171-246
16	1-Set Filler Spacers	117-0159-421
17	Face Plate Assembly	063-0171-284
18	Display Board Spacer	107-0159-478
19	LCD Display Board	064-0159-428
20	Processor Board	064-0159-583
21	Connector Plate Assembly	063-0171-282
22	Back Assembly	063-0159-530
23	DSC 400 Console	063-0171-272

