

# DCS 410 REPLACEMENT PARTS

ITEM	DESCRIPTION	RAVEN PART #
1	POWER Switch	412-2011-048
2	MASTER Switch	412-2011-046
3	Blast Button	412-2011-072
4	MANUAL INC/DEC Switch	412-2011-049
5	RATE Knob Assembly	063-0171-802
6	Knob Cap	309-1000-018
7	Mounting Knob	106-0159-438
8	Mounting Bracket	106-0159-437
9	Key Switch	412-8000-005
	Key	412-8000-006
10	DCS 410 Console	063-0172-008
11	Fuse Holder	510-2001-018
12	Fuse, 15 Amp	510-1003-003
13	World Allison Interface or Speed Sensor Assembly	115-0159-953 063-0171-340
14	Adapter Plug	115-0171-017
15	Dust Cap	063-0171-043
16	Console Cable (31 ft)	115-0159-957
17	Anti-Ice Cable (10 ft)	115-0159-955
18	Switch Cover	063-0171-851
19	1-Set Filler Spacers	117-0159-421
20	Face Plate Assembly	063-0171-852
21	Display Board Spacer	107-0159-478
22	LCD Display Board	064-0159-454
23	Processor Board	064-0159-719
24	Connector Plate Assembly	063-0171-853
25	Back Assembly	063-0159-530
	Tier 2 Relay Box (not shown)	063-0171-860
	Temperature Interface Cable (not shown)	115-0171-062

