

DCS 710 REPLACEMENT PARTS

ITEM	DESCRIPTION	RAVEN PART #
1	MASTER Switch/POWER Switch	412-2011-073
2	Blast Button	412-2011-072
3	MANUAL INC/DEC Switch	412-2011-049
4	RATE/SPINNER Knob Assembly Knob Cap	063-0171-802 309-1000-018
5	ALARM light	019-0159-132
6	Mounting Knob	106-0159-438
7	Mounting Bracket	106-0159-437
8	Key Switch	412-8000-005
9	Key	412-8000-006
10	DCS 710 Console	063-0171-736
11	Fuse Holder	510-2001-018
12	Fuse, 15 Amp	510-1003-003
13	World Allison Interface Cable Speed Sensor Assembly	115-0159-953 063-0171-340
14	Lane Switch Box Kit	117-0159-718
15	Console Cable (31 ft)	115-0159-957
16	Y-Cable (2 ft)	115-0171-024
17	Anti-ice Cable (10 ft)	115-0159-955
18	Granular Cable (9 ft)	115-0159-956
19	Pre-wet Cable (2ft)	115-0171-011
20	Temperature Interface Cable	115-0171-062
21	Switch Cover	063-0171-743
22	1-Set Filler Spacers	117-0159-421
23	Face Plate Assembly	063-0171-744
24	Display Board Spacer	107-0159-478
25	LCD Display Board	063-0171-961
26	Processor Board	064-0159-687
27	Connector Plate Assembly	063-0171-777
28	Back Assembly	063-0159-530
	Pre-wet Booster (not shown)	063-0171-719

