







RGL 600 Smartbar Quick Start Guide

PART # 016-0159-856
09/03 REV B



Simply improving your position.



Headlands Off





Headlands Combined




Combined

Shaded Area - Headland areas
Solid Line - Path of antenna within headland Areas


Pivot Swathing








Separate

Shaded Area - Headland areas
 Solid Line - Path of antenna within Headland Areas




Contour Swathing Diagram



press and hold MENU Button
TO...CFG

Configuration Mode Navigation Diagram



press and hold MENU Button from any Configuration Mode screen
TO...OPR
returns to Operational Mode Home Screen