



HAWKEYE GENERIC CABLING FOR SELF PROPELLED SPRAYER (PAIRED WITH EXISTING RAVEN CAN SYSTEM)




HAWKEYE GENERIC CABLING FOR PULL-TYPE SPRAYER (PAIRED WITH EXISTING RAVEN CAN SYSTEM)




RELEASED DATE	ECO #	REV.	DRAWING NO.
1/15/16	27069	B	054-1005-005
10/26/17	30314	C	054-1005-005

HAWKEYE GENERIC CABLING FOR PULL-TYPE SPRAYER (TRACTOR WITH EXISTING IBBC CONNECTION)




RELEASED DATE	ECO #	REV.	DRAWING NO.
1/15/16	27069	B	054-1005-005
10/26/17	30314	C	054-1005-005

HAWKEYE GENERIC CABLING FOR PULL TYPE SPRAYER (OPTION #1)



RELEASED DATE	ECO #	REV.	DRAWING NO.
1/15/16	27069	B	054-1005-005
10/26/17	30314	C	054-1005-005

HAWKEYE GENERIC CABLING FOR PULL TYPE SPRAYER (OPTION #2)



NOTE: ONE OF THE SWITCHING *OPTIONS* (ISO SWITCHBOX, ISO BOOM/SPEED ECU OR FOOTSWITCH) IS NECESSARY FOR THE PROPER FUNCTION OF THIS SYSTEM. CHOOSE THE OPTION BEST SUITED FOR THE SYSTEM BEING DESIGNED.

RELEASED DATE	ECO #	REV.	DRAWING NO.
1/15/16	27069	B	054-1005-005
10/26/17	30314	C	054-1005-005

HAWKEYE GENERIC CABLING FOR SELF PROPELLED SPRAYER

4

3

2

1

D

D

C


C

B

B

A

A



4

3

2


1

RELEASED DATE	ECO #	REV.	DRAWING NO.
1/15/16	27069	B	054-1005-005
10/26/17	30314	C	054-1005-005

HAWKEYE 20" SPACING GENERIC CABLING

** 3, 6, AND 9 NOZZLE CABLES AVAILABLE **
 ** 4', 6', AND 12' EXTENSION CABLES AVAILABLE **
 ** FENCE ROW TEE USED WHEN FENCE ROW VALVE IS NOT AT THE END OF THE BOOM **
 ** FENCE ROW/TERMINATOR ADAPTER USED WHEN FENCE ROW VALVE IS AT THE END OF THE BOOM **
 ** IF NO FENCE ROW VALVE, STANDARD TERMINATOR ADAPTER NEEDED **

USE COMBINATIONS OF THE 3, 6, AND 9 NOZZLE CABLES AS NEEDED TO ADEQUATELY COVER THE BOOM BEING FITTED UP. ANY NON-USED NOZZLE CONNECTIONS MUST HAVE A JUMPER PLUG INSTALLED.




(CABLING SHOWN IS BASED ON A 90' SPRAYER)

115-7305-*** AND 115-7303-*** CABLES ARE INTERCHANGABLE

HAWKEYE 15" SPACING GENERIC CABLING

** 4, 6, 10, AND 12 NOZZLE CABLES AVAILABLE **
 ** 4', 6', AND 12' EXTENSION CABLES AVAILABLE **
 ** FENCE ROW TEE USED WHEN FENCE ROW VALVE IS NOT AT THE END OF THE BOOM **
 ** FENCE ROW/TERMINATOR ADAPTER USED WHEN FENCE ROW VALVE IS AT THE END OF THE BOOM **
 ** IF NO FENCE ROW VALVE, STANDARD TERMINATOR ADAPTER NEEDED **

USE COMBINATIONS OF THE 4, 6, 10 AND 12 NOZZLE CABLES AS NEEDED TO ADEQUATELY COVER THE BOOM BEING FITTED UP. ANY NON-USED NOZZLE CONNECTIONS MUST HAVE A JUMPER PLUG INSTALLED.



(CABLING SHOWN IS BASED ON A 90' SPRAYER)

115-7305-*** AND 115-7303-*** CABLES ARE INTERCHANGABLE

RELEASED DATE	ECO #	REV.	DRAWING NO.
1/15/16	27069	B	054-1005-005
10/26/17	30314	C	054-1005-005