

Remote Section Control Operator's Guide

016-0171-230 Rev. D (03/18) E31083

Press the number corresponding to the section followed by the ON button to turn the section on. The section will automatically turn off after 30 seconds.

Press to turn the section off.
or
Press and hold for 5 seconds to turn the remote off.

Press the left arrow to cycle through sections from right to left.

Specifications:
Input Voltage - 2 AA Batteries
Range - 200 feet [60 m]
Transmit Frequency - 418 MHz

Press to turn the remote on. The remote will automatically turn off after 60 seconds of inactivity.

Press the right arrow to cycle through sections from left to right.



⚠ DANGER

Use extreme caution when working with hazardous chemicals. Exposure to hazardous chemical could result in death or serious injury. To avoid injury or death, always wear proper protective equipment.

* Note: Any remote may be used with any AccuBoom or Planter Control node capable of Remote Section Control. Refer to the *OmniRow Calibration and Operation Manual* for detailed operation of the Remote Section Control with a planter control system.

When using the Remote to control AccuBoom systems with fewer than ten sections, the left and right arrows will still cycle through all ten available section inputs. For example, if the vehicle has six sections, the operator must press the right arrow key five additional times from the sixth section before the system returns to the first section in the cycle.

Use Lithium batteries for optimal performance.

FCC Statement:

This device complies with Part 15 of the FCC Rules.

Operation of this device is subject to the following two conditions:

- (1) This device may not cause harmful interference
- (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio or television technician for help

This equipment has been certified to comply with the limits for a Class B computing device, pursuant to FCC Rules. In order to maintain compliance with FCC regulations, shielded cables must be used with this equipment. Operation with non-approved equipment or unshielded cables is likely to result in interference to radio reception. The user is cautioned that changes and modifications made to the equipment without the approval of manufacturer could void the user's authority to operate this equipment.

Radio Frequency Interference Requirement - Canada

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

L'utilisation de ce dispositif est autorisée seulement aux deux conditions suivantes: (1) il ne doit pas produire de brouillage, et (2) l'utilisateur du dispositif doit être prêt à accepter tout brouillage radioélectrique reçu, même si ce brouillage est susceptible de compromettre le fonctionnement du dispositif.